



Allen-Bradley 1395 345A Contactor Replacement

Instructions

General

The contactor supplied as a replacement item for 345A (100HP–230V and 200HP–460V) 1395 drives has changed suppliers. The mounting holes and terminal positions are changed on the new contactor. As a result this new contactor is supplied mounted on an adapter plate that allows it to be mounted using the same hardware as the old contactor. These instructions will provide you with the information necessary to correctly mount and wire the replacement contactor.

Safety Precaution



ATTENTION: To avoid a shock hazard, verify that all power to the drive has been disconnected and locked out before servicing or removing the Contactor assembly.

Tools & Equipment

The following tools & equipment must be available before starting a contactor assembly replacement:

1. Torque Wrench calibrated in Foot Pounds or Newton Meters.
2. Socket Wrench, short extension and a 1/2 in. socket.
3. Flat screw driver with 1/4" blade.
4. Plastic cable ties to match the ones removed from the wires.

Contactor Removal


1. Before removing any connections or wires from the old contactor unit, check to make certain that the wiring harness is marked as shown in Table 1A. If wires are not marked, they should be marked using the old contactor terminal identification in the table as a guide.
2. Remove all cables and wires to the old contactor. If your unit is equipped with dynamic braking the dynamic brake connections to the contactor must also be removed.
3. While supporting the old contactor from below, remove the hardware holding it to the drive and remove it from the drive.

Contactor Installation

1. Position the new Contactor/Adapter Plate unit in the drive and secure with the three fasteners at 1A, 2A, 3A (Figure 1–1) and torque to 75 in. lbs (8.5 Newton Meter²).
2. Install the ground wire between the new contactor unit and the ground stud as shown in Figure 1–1.

3. Install the M1 connections at terminals 83 & 84 (Figure 1-1).

Figure 1-1.
345A Contactor Connections



4. Install the four coil connections (K1, K2 & SP1-1&2) at A1 & A2.
5. Install the Power Pole connections at A1 & A2. If your unit includes dynamic braking, install the dynamic braking connections at A3.



Allen-Bradley has been helping its customers improve productivity and quality for 90 years. A-B designs, manufactures and supports a broad range of control and automation products worldwide. They include logic processors, power and motion control devices, man-machine interfaces and sensors. Allen-Bradley is a subsidiary of Rockwell International, one of the world's leading technology companies.



With major offices worldwide.

Algeria • Argentina • Australia • Austria • Bahrain • Belgium • Brazil • Bulgaria • Canada • Chile • China, PRC • Colombia • Costa Rica • Croatia • Cyprus • Czech Republic • Denmark • Ecuador • Egypt • El Salvador • Finland • France • Germany • Greece • Guatemala • Honduras • Hong Kong • Hungary • Iceland • India • Indonesia • Israel • Italy • Jamaica • Japan • Jordan • Korea • Kuwait • Lebanon • Malaysia • Mexico • New Zealand • Norway • Oman • Pakistan • Peru • Philippines • Poland • Portugal • Puerto Rico • Qatar • Romania • Russia-CIS • Saudi Arabia • Singapore • Slovakia • Slovenia • South Africa, Republic • Spain • Switzerland • Taiwan • Thailand • The Netherlands • Turkey • United Arab Emirates • United Kingdom • United States • Uruguay • Venezuela • Yugoslavia

World Headquarters, Allen-Bradley, 1201 South Second Street, Milwaukee, WI 53204 USA, Tel: (1) 414 382-2000 Fax: (1) 414 382-4444