

**RELIANCE  
ELECTRIC** 

# **AUTOMAX Pocket Reference**



**Rockwell  
Automation**

**Bringing Together Leading Brands in Industrial Automation**

The information in this user's manual is subject to change without notice.

**DANGER**

**THIS MATERIAL IS NOT INTENDED TO PROVIDE OPERATIONAL INSTRUCTIONS. QUALIFIED ELECTRICAL PERSONNEL MUST READ AND UNDERSTAND THE APPLICABLE INSTRUCTION MANUALS IN THEIR ENTIRETY PRIOR TO INSTALLING, ADJUSTING, OPERATING, AND SERVICING THIS EQUIPMENT. FAILURE TO OBSERVE THIS PRECAUTION COULD RESULT IN SEVERE BODILY INJURY OR LOSS OF LIFE.**

Motorola is a trademark of Motorola, Inc.

The Norton Editor is a trademark of Peter Norton Computing.

Kermit is a trademark of the trustees of Columbia University.

Windows is a trademark of Microsoft Corporation.

Multibus is a trademark of Intel Corporation.

Ethernet is a trademark of Xerox.

Modbus is a trademark of Gould, Inc.

Toledo Scale is a trademark of Toledo Scale.

Reliance®, AutoMax®, MaxPak®, AutoMate®, ReSource™ and R-NET™ are trademarks of Reliance Electric or its subsidiaries.

# Table of Contents

Introduction . . . . .	iii
Organization of This Reference Manual . . . . .	iv
Section I: Status and Error Codes . . . . .	1-0
Status and Error Codes . . . . .	1-1
General Troubleshooting Procedures . . . . .	1-3
Error Code Listing (by Location of Code Display) . . . . .	1-5
57C430, 57C431, or 57C435 . . . . .	1-5
57C404, and 57C416 . . . . .	1-12
57406 . . . . .	1-13
57C417, 57C414, 57C418, 57C428. . . . .	1-13
45C33, 57C330 . . . . .	1-14
57C424 . . . . .	1-15
57C429 . . . . .	1-15
.LOG Files and Screen Display . . . . .	1-16
Section II: Hardware Module Reference. . . . .	2-0
45C33, 57C330 Remote I/O Head . . . . .	2-1
57401 Drive Digital I/O . . . . .	2-3
57C400 115 VAC Input. . . . .	2-4
57C402 24-115 VAC/DC Output . . . . .	2-5
57C403, 61C503 115 VAC Output . . . . .	2-5
57C404 Network Communications . . . . .	2-6
57406, 57405 Drive Control and Analog I/O . . . . .	2-10
57C409 2-Channel Analog Input . . . . .	2-11
57C410 Analog Output. . . . .	2-13
57C411 Resolver Input. . . . .	2-15
57412 Field Controller . . . . .	2-16
57C414 Modbus Interface . . . . .	2-16
57C415 24 VAC/DC Input . . . . .	2-19
57C416 Remote I/O . . . . .	2-20
57C417 AutoMate Interface . . . . .	2-21
57C418 Allen-Bradley Interface. . . . .	2-23
57C419 5-24 VDC Input . . . . .	2-26
57C420 5-24 VDC Output . . . . .	2-27
57C421 Pulsetach Input . . . . .	2-28
57C422 2-Axis Servo. . . . .	2-32
57C424 MaxPak III High Speed Link . . . . .	2-35
57C428 Toledo Scale Interface. . . . .	2-37
57C429 AutoMax R-Net Processor . . . . .	2-38
57C430, 57C431, 57C435 AutoMax Processor . . . . .	2-40
57C491, 57C493 Power Supply. . . . .	2-41
61C22, 61C23 Local I/O Head . . . . .	2-42
61C345 4-Input Analog Rail (4-20 mA) . . . . .	2-43
61C346 4-Input Analog Rail (0-10V) . . . . .	2-43
61C350 2-In/2-Out Analog Rail (0-10V) . . . . .	2-44
61C351 2-In/2-Out Analog Rail (4-20mA) . . . . .	2-45
61C365 4-Output Analog Rail (4-20mA) . . . . .	2-46
61C366 4-Output Analog Rail (0-10V) . . . . .	2-47
61C500 115 VAC Input. . . . .	2-48
61C515 24 VAC/DC Input . . . . .	2-49
61C540 Current Input . . . . .	2-50

61C542 Voltage Input . . . . .	2-52
61C544 RTD Input . . . . .	2-54
61C605 8-Channel Thermocouple . . . . .	2-56
61C613 16-Channel Analog Input . . . . .	2-58
<b>Section III: Programming Reference . . . . .</b>	<b>3-0</b>
BASIC Language Quick Reference . . . . .	3-1
BASIC Language Listing . . . . .	3-2
Control Block Language Quick Reference . . . . .	3-24
Control Block Execution Time Estimates . . . . .	3-42
AutoMax Off-Line PC Editor Quick Reference . . . . .	3-43
PC/Ladder Language Format . . . . .	3-44
PC/Ladder Logic Execution Time and Memory Usage Estimates. . . . .	3-46
Norton Editor Command Summary . . . . .	3-47
<b>Section IV: Appendices . . . . .</b>	<b>4-0</b>
Appendix A: ASCII Conversion Chart . . . . .	4-1
Appendix B: Decoding Bus Errors . . . . .	4-2
Appendix C: Summary of Common DOS Commands . . . . .	4-5
Appendix D: Windows Command Summary . . . . .	4-6

# Introduction

The equipment described in this document is manufactured by Reliance Electric Industrial Company.

This document is designed to serve as a quick reference for AutoMax systems. It includes information about programming, hardware module port and register descriptions, and a list of status and error codes. This document does not take the place of instruction manuals that describe the individual hardware modules, the programming languages, and the AutoMax Executive software. For specific information, you must refer to the following instruction manuals:

- J-3675 AutoMax ENHANCED BASIC LANGUAGE INSTRUCTION MANUAL
- J-3676 AutoMax CONTROL BLOCK LANGUAGE INSTRUCTION MANUAL
- J-3677 AutoMax LADDER LOGIC LANGUAGE INSTRUCTION MANUAL
- J-3616 KERMIT COMMUNICATIONS SOFTWARE INSTRUCTION MANUAL
- J-3618 NORTON EDITOR INSTRUCTION MANUAL
- J-3630 ReSource AutoMax PROGRAMMING EXECUTIVE INSTRUCTION MANUAL VERSION 1.0
- J-3684 ReSOURCE AutoMax PROGRAMMING EXECUTIVE INSTRUCTION MANUAL VERSION 2.0
- J-3636 COMMON MEMORY MODULE INSTRUCTION MANUAL
- J-3649 AutoMax CONFIGURATION TASK INSTRUCTION MANUAL
- J-3650 AutoMax PROCESSOR MODULE INSTRUCTION MANUAL
- J-3661 ReSource AutoMax SOFTWARE LOADING INSTRUCTIONS
- J-3750 ReSource AutoMax PROGRAMMING EXECUTIVE MANUAL VERSION 3.0
- S-3006 DISTRIBUTED POWER DC DRIVE CONFIGURATION AND PROGRAMMING
- IEEE 518 GUIDE FOR THE INSTALLATION OF ELECTRICAL EQUIPMENT TO MINIMIZE ELECTRICAL NOISE INPUTS TO CONTROLLERS
- Your personal computer and DOS operating system manual(s)
- Other instruction manuals applicable to your hardware configuration

# **Organization of this Reference Manual**

This reference manual is divided into four sections as follows:

1. Status and error codes organized by where they appear.
2. Hardware module reference.
3. Programming reference (BASIC, Control Block, PC/Ladder Logic, and Norton Editor).
4. Appendices:
  - A — ASCII conversion chart
  - B — Decoding hexadecimal addresses of bus errors
  - C — Summary of common DOS commands
  - D — Summary of Windows commands

# **Section I Status and Error Codes**





# Status and Error Codes

Status and error codes can be used to diagnose the state of the system. These codes indicate conditions or symptoms only, not necessarily the root cause of any problem. Status codes are those that indicate a condition that does not necessarily signify an error. For example, code "LO" means that the runbase, or operating system, needs to be loaded onto the rack. Error codes indicate a hardware or software problem in the system. Error code 7.2. displayed on the Processor module, for example, means that the system received a spurious interrupt during runbase booting. Depending upon its severity, an error can have three different effects on the system when it is running:

a) "ERROR" is listed in the task status field on the ON LINE menu of the AutoMax Programming Executive software. The task that caused the error, as well as any other tasks that are running, continue to run. In most cases, the error log for the task will show an error code and a line number indicating where the error occurred.

Example: Error code 759 in the error log; 0 is being used as a divisor in an application task.

b) All tasks in the rack are stopped. The Processor(s) can still respond to commands from the personal computer.

Example: Error code 17 on Processor LEDs; a task has attempted to read or write to an invalid address.

c) All tasks in the rack are stopped and all Processors in the rack are shut down. The Processor(s) cannot respond to commands from the personal computer.

Example: Error code F9 on Processor LEDs; the Processor runbase, or operating system, is not functioning correctly.

## Location of Status and Error Codes

Status and error codes can appear in three places. Hardware status and error codes are usually displayed on the seven-segment LEDs on faceplates. Codes found on module faceplates are read top to bottom. Note carefully that some of the codes include decimal points, which are easy to overlook. Codes "3.0." and "30", for example, are not the same.

Application software errors that occur while tasks are running are displayed in the error log maintained for each task by the AutoMax Executive software. The error log is accessed through the INFO LOG option from the ON LINE menu. Where applicable, the error log will display the line number of the statement that caused the error, or the hexadecimal bus address where the error occurred. To decode the bus error address, see Appendix B.

Errors that occur when tasks are compiled, loaded to the Processor, or saved from the Processor are written to .LOG files if the LOG option is selected. They are also displayed on the screen during these operations unless the NOSCREEN option is selected.

Another status indicator is the single green LED labeled "OK" found on some modules, such as the AutoMax Processor and the Common Memory module. This LED is either on or off and signifies whether the module is functioning properly when power is applied to the system. Note that in the case of the Common Memory module, this LED will also be off if the module is not in slot zero of the rack.

### **Organization of Status and Error Codes**

In this reference manual, status and error codes are listed together, organized in numerical and, where applicable, alphabetical order according to where they appear. Codes have been assigned in logical categories, e.g., BASIC Run Time Errors, and are so labeled. Specific troubleshooting procedures are usually included at the end of each section. A description of general troubleshooting procedures precedes the list of status and error codes.

# General Troubleshooting Procedures

## DANGER

**ONLY QUALIFIED ELECTRICAL PERSONNEL WHO ARE FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE EQUIPMENT AND HAZARDS INVOLVED SHOULD INSTALL, ADJUST, OPERATE, AND/OR SERVICE THE EQUIPMENT. FAILURE TO OBSERVE THIS PRECAUTION COULD RESULT IN SEVERE BODILY INJURY OR LOSS OF LIFE.**

## WARNING

**INSERTING OR REMOVING HARDWARE OR ITS CONNECTING CABLES MAY RESULT IN UNEXPECTED MACHINE MOTION. POWER TO THE MACHINE SHOULD BE TURNED OFF BEFORE INSERTING OR REMOVING HARDWARE OR ITS CONNECTING CABLES. FAILURE TO OBSERVE THIS PRECAUTION COULD RESULT IN BODILY INJURY.**

The following are intended to be general guidelines on troubleshooting. For specific information, turn to the individual instruction manuals for AutoMax hardware and software.

1. Check for error codes on hardware module faceplates and the error log for all tasks. If the information given is specific enough, e.g., the error log lists the line number where the error occurred, correct the problem indicated.
2. With power off, try removing and then re-inserting any suspect module.
3. With power off, confirm that each module with cable connections has the proper connector attached and that the connections are tight.
4. Check the voltage coming into the power supply through the rack connections labeled "188" and "189". It should be 115VAC.
5. Check the LEDs on I/O modules. Make certain their state (off or on) corresponds to the state of the device to which they are connected for input modules. For output modules, make certain the state of the LED corresponds to the state of the variable used to reference the point.

# General Troubleshooting (continued)

6. Check the voltage on each terminal strip for wiring problems.
7. Try to read inputs or write to outputs on suspect modules through the I/O Monitor in the AutoMax Executive software. If the problem is in a remote rack, try to read/write to the Remote I/O Communications module, M/N 57C416. If you can communicate with the Remote I/O Communications module, try accessing other modules in the remote rack.
8. Systematically replace modules, always replacing the most recently removed module before going on to the next. The last module removed before the problem was corrected is the one that caused the problem.

Basic order of replacement for local racks:

- suspect module
- Processor(s)
- power supply
- backplane

Basic order of replacement for remote racks:

- suspect module in remote rack
- Remote I/O Communications module in remote rack
- Remote I/O Communications module in local rack
- Processor(s) in local rack

9. Verify that the physical configuration of the system is reflected correctly in the configuration for the rack. Verify that application tasks reference the correct I/O points.

Note that one condition always signifies that a module is malfunctioning and should be replaced. If power to the rack is on and both the single green LED labeled "OK" and the seven-segment LEDs are off on any of the following modules, the module is malfunctioning and should be replaced:

- AutoMax Processor module
- DCS 5000 Processor module (M/N 57C407)
- Network module (M/N 57C404)
- Remote I/O module (M/N 57C416)
- Modbus Interface module (M/N 57C414)
- AutoMate Interface module (M/N 57C417)
- Allen-Bradley Interface module (M/N 57C418)
- Toledo Scale Interface module (M/N 57C428)

# **Error Codes Displayed on AutoMax Processor Module (M/N 57C430, M/N 57C431 or M/N 57C435)**

## **Processor Overload**

00 CPU Overload

Corrective action: move one or more application tasks to other Processor modules in the rack.

## **Power-Up Diagnostics**

The following error codes are displayed while the Processor module performs power-up diagnostics.

0.0.	EPROM failed
0.1.-0.3.	Bad CPU
0.4.	Internal bus error test failure
0.5.	Parity test failure
0.6.	External bus error test failure
0.7.	Processor in the wrong slot
1.0.-1.6.	RAM failure
2.0.	I/O protection failure
2.1.	PIO failed
2.2.	PC accelerator failed
2.3.	8253 timer/counter failed
2.4.	SIO failure
2.5.	Communications interrupt failed
2.6.	SIO interrupt failed
2.7.	8253 timer/counter interrupt failed
2.8.	Local watchdog failed
3.0.	Bad backplane
3.1.	Multibus parity test failure
4.0.-4.5.	Common memory RAM failure
4.6.	Common memory system watchdog failure
5.0.	Processors with incompatible EPROMs in rack

Corrective action: replace the Processor, or replace the Common Memory module if error codes 4.0.-4.6. remain on.

## **Runtime Errors**

02 Invalid task or configuration checksum

Corrective action: replace the Processor module.

# AutoMax Processor

## Error Codes (continued)

### Runbase Booting

The following status/error codes may be displayed while you load the runbase, i.e., operating system, onto the Processor module(s). All of the following codes except 6.5. apply to the top port of the Processor module, labeled "Programmer/Port B".

- 5.1. Incompatible runbase downloaded
- 6.0. Unexpected interrupt on upper port of Processor
- 6.1. Parity error
- 6.2. Receiver overrun
- 6.3. Framing error
- 6.4. Serial port fatal error
- 6.5. Illegal interrupt on lower port of Processor
- 6.6. Transmit interrupt error
- 6.7. Runbase integrity lost
- 6.8. Bad runbase checksum
- 6.9. Transmit buffer error
- 7.0. Multi-Processor runbase download in progress
- 7.1. Disconnect time-out during download
- 7.2. Spurious interrupt received

Corrective action: 6.3. may be caused by attempting AutoMax ON-LINE functions before the runbase is loaded onto the Processor module(s) in the rack. In this case, exit the ON-LINE menu and download the runbase. 7.0. is a status message only. For all other error codes, cycle power and try to load the runbase again.

### Loading the Runbase Over the Network

- 8.0. Bad message length specified for network message
- 8.1. Bad destination drop
- 8.2. Transmitting drop inactive
- 8.3. Destination port unallocated
- 8.4. Destination port busy
- 8.5. Did not receive expected response
- 8.6. Spurious network interrupt received
- 8.7. Network message is being transmitted

Corrective action: 8.0. and 8.1. are caused by a failed Processor in the left most slot. For 8.2., check the coax cable; then try replacing the Network module. For 8.3. – 8.5., check the destination Network module, then the leftmost Processor in the destination rack. For 8.6. and 8.7., cycle power and try to load the runbase again.

### Miscellaneous Processor Errors

- 8.8. Processor failure

Corrective action: replace Processor module.

# AutoMax Processor Error Codes (continued)

## STOP ALL Error Codes

The following hardware and software error codes cause all tasks running in the rack to stop.

- 10 Event count underflow
  - too many WAITs (max. 32768)
  - not enough SETs (BASIC tasks)
- 11 Event count overflow
  - too many SETs (max. 32767)
  - not enough WAITs (BASIC tasks)
- 12 Hardware event time-out
  - interrupt time exceeded programmed time-out limit in a Control Block task
- 13 Runbase boot error
  - a check on the runbase failed
- 14 Processor overlap limit exceeded
  - ran out of processing capacity (time)
- 15 External watchdog time-out detected
  - green LED out on another Processor
- 17 Address error detected
  - caused by a read/write to an invalid address
- 18 Spurious interrupt or hardware failure
- 19 Power failure detected
- 1A Watchdog on this Processor failed
- 1b Hardware event count limit exceeded
  - too many interrupts set without being acknowledged
  - program too long
  - collective scans too fast
- 1C Illegal instruction detected
  - runbase software fault
  - bad Processor module
  - bad EPROMs
- 1d Privilege violation detected
  - runbase software fault
  - bad Processor module
- 1E Un-implemented instruction detected
  - runbase software fault
  - bad Processor module
- 1F Illegal interrupt detected
  - runbase software fault
  - bad Processor module
- 31 Bus error
  - attempt to access invalid address
- 32 Define channel error
  - problem in application software
- 33 Define scan error
  - hardware fault

# AutoMax Processor

## Error Codes (continued)

- 34 Memory integrity lost  
– hardware fault
- 35 D-C drive CML block initialization error
- 36 Communication between drive Processor and I/O controller lost
- 37 D-C drive I/O controller run-time board error  
– hardware fault
- 38 UDC module generated a STOP ALL
- 39 UDC module interrupt allocation failed

Corrective action: correct the problem in application software. Try to reset by cycling power and re-loading configuration and application tasks. Replace the Processor module. For error codes 31 and 37, see Appendix B in this manual. For 38, examine the error logs for all UDC tasks in the rack. For 39, cycle power to the rack and re-load configuration and application tasks.

### BASIC STOP ALL Error Codes

The following error codes are caused by problems in BASIC tasks and cause all tasks running in the rack to stop.

- 40 Too many RETURNS from GOSUBs (or RETURN without GOSUB)
- 41 Illegal jump into a FOR loop
- 42 NEXT statement does not match current FOR
- 43 Invalid START EVERY statement
- 44 Invalid EVENT statement
- 45 STOP statement executed in application software (causes a STOP ALL and clears all I/O)
- 46 SET or WAIT attempted with no event definition
- 47 Task stack overflow
- 48 GOSUBs not balanced at END statement
- 49 Insufficient space for channel buffer
- 4A Attempted to execute undefined opcode
- 4B Attempted to execute non-executable opcode
- 4C Attempted to execute illegal opcode
- 4D RESTORE to non-DATA statement line number
- 4E Attempted to take square root of a negative number
- 4F Attempted RESUME without being in an ON ERROR handler

Corrective action: correct the problem in application software; for 47, check for PUT on a closed part; for 4A, check use of Ethernet functions in standard operating system.



# AutoMax Processor Error Codes (continued)

## Multibus™ and Processor Bus STOP ALL Error Codes

50	On-board parity error
51–54	On-board bus error or access violation
55	Multibus parity error during read access
56–58	Multibus access violation or bus error
60	Network interrupt allocation failed
61	Network receive queue overflow
62	Network transmit queue underflow

Corrective action: reset by cycling power and re-loading configuration and application tasks. If the small green LED labeled “OK” on the Processor module faceplate is off, replace the Processor module. For error 58, check for incorrect IOWRITE statement. Correct any incorrect accesses in application software. Systematically replace hardware modules. For error codes 50-57, if none of the above correct the problem, try replacing the Rack/Backplane assembly. Also see Appendix B in this manual.

## AutoMax Drive-Related Error Codes

The following error codes indicate a power circuit or external drive system fault. After correcting the problem, reset the Processor module by cycling power and re-loading the configuration task and application tasks to clear the error code. Note that these error codes also appear in the Error Log for the Processor.

80	Instantaneous overcurrent fault – armature current exceeded IOC_THRESH value in CML task
81	Line sync loss fault
82	Tach loss fault – 40% armature phase angle with less than 5% tach feedback
83	Overspeed/overvoltage fault – CML task OSV_FDBK exceeded OSV_THRESH number
84	Hardware overspeed fault – Drive Analog module potentiometer setting exceeded by input voltage
85	External IET fault – external fault input triggered
86	Phase rotation fault – incorrect phasing
87	Shorted SCR detected in power module

Corrective action: troubleshoot power circuit and external drive system.

# **AutoMax Processor Error Codes (continued)**

## **Configuration Error Codes**

The following error codes usually indicate a discrepancy between the actual hardware configuration and the I/O definitions in the configuration for the rack.

- |           |   |
|-----------|---|
| <b>E0</b> | TASK specified in configuration uninstalled, at wrong priority, of wrong type, on wrong Processor module; wrong spelling of TASK  |
| <b>E1</b> | Invalid configuration, configuration not successfully downloaded  |
| <b>E2</b> | I/O referenced in configuration is missing.   |
| <b>E3</b> | I/O referenced in configuration is missing. Invalid configuration, configuration not successfully downloaded.   |
| <b>E4</b> | Error building task, insufficient memory in Processor module. Invalid configuration, configuration not successfully downloaded.   |
| <b>E5</b> | Error building task, insufficient memory in Processor module. Invalid configuration, configuration not successfully downloaded.   |
| <b>E6</b> | I/O referenced in configuration is missing. Error building task, insufficient memory in Processor module.   |
| <b>E7</b> | Invalid configuration, configuration not successfully downloaded. I/O referenced in configuration is missing. Invalid configuration, configuration not successfully downloaded.   |
| <b>E8</b> | Error installing application task, common symbol could not be resolved, insufficient memory in Processor module.  |
| <b>E9</b> | Error installing application task, common symbol could not be resolved, insufficient memory in Processor module. Invalid configuration, configuration not successfully downloaded.  |
| <b>EA</b> | Error installing application task, common symbol could not be resolved, insufficient memory in Processor module. I/O referenced in configuration is missing.  |
| <b>Eb</b> | Error installing application task, common symbol could not be resolved, insufficient memory in Processor module. I/O referenced in configuration is missing. Invalid configuration, configuration not successfully downloaded |

# AutoMax Processor Error Codes (continued)

EC	Error building task; error installing application task, common symbol could not be resolved, insufficient memory in Processor module.
Ed	Error building task; error installing application task, common symbol could not be resolved, insufficient memory in Processor module. Invalid configuration not successfully downloaded.
EE	Error building task; error installing application task, common symbol could not be resolved, insufficient memory in Processor module. I/O referenced in configuration is missing.
EF	Common variable forced by another Processor module

Corrective action: verify that the configuration correctly describes the physical configuration of the system and the tasks installed on the Processor module(s). Reset by cycling power and re-loading the configuration and application tasks. For error code EF, un-force the variable and do a STOP ALL CLEAR from the AutoMax ON-LINE menu.

## Fatal Errors

The following error codes usually indicate that the runbase is not functioning correctly. If any of these error codes appear, the configuration task and all application tasks are deleted from the Processor module.

F0-F9	Fatal error
FA-FF	Fatal error

Corrective action: cycle power. Re-load the configuration task and all application tasks. Replace the Processor module.

## Informational Messages

The following codes signify a particular condition, not necessarily an error.

dd	This Processor module has successfully completed power-up diagnostics and is waiting for other Processor modules to complete their diagnostics
LO	The runbase needs to be loaded onto the rack
b0	Rack configuration is being validated
d0	Application task installation in progress

# **AutoMax Processor Error Codes (continued)**

- d1            Waiting on synchronizing event (in a rack with multiple Processors)
- d2            Waiting on mutual exclusion lock (in a rack with multiple Processors)

Corrective action for b0 and d0 that do not change or disappear: re-load configuration and application tasks.

## **Error Codes Displayed on Network (M/N 57C404) and Remote I/O (M/N 57C416) Communication Modules**

- 0 CPU failed power-up diagnostic
- 1 EPROM failed power-up diagnostic
- 2 RAM failed power-up diagnostic
- 3 CTC failed power-up diagnostic
- 4 SIO failed power-up diagnostic
- 5 DMA runtime failure; message transmit timeout
- 6 Dual Port memory failed power-up diagnostic
- 7 Memory management unit failed power-up diagnostic
- 8 or .8 Bad EPROMs
- 9 PIO port failed power-up diagnostic
- A Invalid drop number. This only occurs if the drop number on the thumbwheel switches is greater than 55 on a Network Module or greater than 7 on a Remote I/O Module.
- b Watchdog failed power-up diagnostic
- C Board not communicating. If board is a Master drop, no other drops are functional on the Network. If board is a Slave drop, it is not receiving any messages from the Master. This fault code is reset whenever the line goes active.
- d System (backplane) watchdog failure; Processor module(s) went down; module is operational but will not transmit or receive data until the watchdog is reset.
- E Power failure. This code is normally present from the time that a low voltage is detected until power is completely lost.

Corrective action (0 through 9, b): replace Network or Remote I/O Module.

## **Error Codes Displayed on AutoMax Drive Controller Module (B/M 57406)**

- 0 CPU diagnostic
- 1 EPROM diagnostic
- 2 RAM diagnostic
- 3 PIO (8255) diagnostic
- 4 Counter (8253) diagnostic
- 5 Watchdog timer diagnostic
- 6 Interrupt structure diagnostic
- 7 Analog board diagnostic
- 8 or .8 Bad EPROMs
- C Communication not active with processor  
(normal code when CML task stopped)
- d Spurious interrupt received — fatal
- E Power fail interrupt received — fatal
- F Watchdog timeout detected — fatal

Corrective action: replace Drive Controller module.  
Replace Drive Analog module. For code 7, check  
power supply voltage. For E, check power supply or  
backplane. For C, start the CML task.

## **Error Codes Displayed on AutoMate® (M/N 57C417) Modbus™ (M/N 57C414), Allen-Bradley™ (M/N 57C418), and Toledo Scale™ (M/N 57C428) Interface Modules**

- 0 CPU failed power-up diagnostic
- 1 EPROM failed power-up diagnostic
- 2 RAM failed power-up diagnostic
- 3 CTC failed power-up diagnostic
- 4 SIO failed power-up diagnostic
- 5 DMA failed
- 6 Dual Port memory failed power-up diagnostic
- 7 Memory management unit failed power-up  
diagnostic
- 8 or .8 Bad EPROMs
- 9 PIO port failed power-up diagnostic
- A Invalid device number. This only occurs if the de-  
vice number on the thumbwheel switches is 00.
- b Watchdog failed power-up diagnostic

- C Communication line status. Displayed only if the link has not been configured by the application program.
- d System (backplane) watchdog failed; a Processor module(s) went down. Module is operational but will not transmit or receive data until the watchdog is reset.
- E Power failure. This code is normally present from the time that a low voltage is detected until power is completely lost.

Corrective action (0 through 9, b): replace the module. For M/N 57C417, C may indicate that the R-NET Gateway is not responding.

## **Error Codes Displayed on Remote I/O Head (M/N 45C33 or 57C330)**

- 0 CPU failed power-up diagnostic
- 1 EPROM failed power-up diagnostic
- 2 RAM failed power-up diagnostic
- 3 CTC failed power-up diagnostic
- 3. CTC runtime failure
- 4 SIO failed power-up diagnostic
- 5 DMA failed
- 6 I/O device interface failed
- 8 or .8 Bad EPROMs
- 9 PIO port failed power-up diagnostic
- A Invalid device number. This only occurs if the device number on the thumbwheel switches is not between 1 and 7 inclusive.
- b Watchdog failed power-up diagnostic
- C Communication line status. This means that the Head is not receiving message from the Master. This fault is reset whenever the line goes active.
- E Power failure. This code is normally present from the time that a low voltage is detected until power is lost.

Corrective action (0 through 9, b): replace the Remote I/O Head.

## **Error Codes Displayed on MaxPak III High Speed Link (M/N 57C424)**

- 0 CPU failed power-up diagnostic
- 1 EPROM failed power-up diagnostic
- 2 RAM failed power-up diagnostic
- 3 CTC failed power-up diagnostic
- 5 DMA failed
- 6 Dual Port memory failed power-up diagnostic
- 7 Memory management unit failed power-up diagnostic
- 9 Parallel I/O port failed power-up diagnostic
- b Watchdog failed power-up diagnostic
- C Communication line status. Displayed only when no messages are received from the MaxPak III.
- d System (backplane) watchdog failed. Board is operational but will not transmit or receive data until the watchdog is reset.
- E Power failure. This code is normally present from the time that a power failure is detected until power is lost.
- .3 CTC run time failure.
- .4 SIO run time failure.
- .r Incompatible software revisions (MaxPak III - 57C424)

Corrective action (0 through 9, b): replace the MaxPak III High Speed Link.

## **Error Codes Displayed on R-Net Processor Module (M/N 57C429)**

(Code listed below is the "COM ER" LED pattern read top to bottom)

- 0001 EPROM checksum error
- 0010 Scratch pad RAM failure
- 0011 Dual port memory failure
- 0100 Node number witch setting > 250
- 0101 Communication circuit failure
- 0111 Local watchdog interrupt
- 1010 Software test (negative buffer length detected)
- 1011 Software test (Message Length = 0 detected)
- 1100 Unused interrupt detected
- 1101 Attempted word access on odd byte
- 1110 System watchdog interrupt
- 1111 Bus error

Corrective action: for errors 1-3, and 5, replace the R-Net Processor module; for error 4, correct switch setting on module; for errors 9-15, cycle power to attempt to clear the error.

# Compile, Load and Save Error Codes Displayed in .LOG Files and on the Screen

The error codes in this section are generated when tasks are compiled, saved from the Processor, or loaded onto the Processor with the LOG option selected. They are displayed in the corresponding .LOG files and on the screen unless the NOSCREEN option is selected.

## Control Block Error Codes

- 257 Bad Control Block statement format
- 258 Unrecognized name for Control Block
- 259 Missing END statement in Control Block task
- 261 Variable used in Control Block not defined
- 262 Bad literal value for KI, KP, or KD
- 263 Bad WLD \* KP / C value
- 264 Bad literal value for DEAD\_BAND, MAX\_CHANGE, or LOOP\_TIME
- 265 Invalid data type for literal in Control Block
- 266 Incomplete input pairs or input/output pairs in a Control Block
- 267 Bad SCALE, REQUIRED\_SAMPLES, or MAX\_COLUMNS value
- 268 Bad specification for array in Control Block
- 269 Control Block not the only statement for that line number
- 270 CML specified literal field out of range
- 271 SCAN\_LOOP block not allowed with CML block
- 272 Integer literal field too large
- 273 Invalid parameter keyword in Control Block
- 274 Calculated K value out of range
- 275 Literal symbol too long
- 276 Required Control Block field missing
- 277 Required Control Block literal missing
- 278 Control Block field must be literal
- 279 Control Block field must be variable
- 280 Non-contiguous inputs, input pairs or input/output pairs in Control Block
- 281 Missing SCAN\_LOOP block in Control Block task
- 282 Signed boolean or numeric literal not allowed
- 283 WLD value out of range
- 284 Invalid value for Lead Lag W
- 285 Invalid value for WM
- 286 Invalid value for WLD
- 287 Word size out of range
- 288 Array specified has too many subscripts
- 289 Integer literal > 24 bits (can't be accurately converted to real)
- 290 Invalid value for MAX\_INPUT



- 291 More than 1 CALL SCAN\_\_LOOP in a Control Block task
- 292 Fast floating point overflow
- 293 Fast floating point underflow
- 294 Fast floating point divided by 0
- 295 Meaningless tangent argument
- 296 Minimum number of inputs or outputs not programmed
- 297 Invalid data type for variable in Control Block
- 298 Parameter keyword previously defined in Control Block
- 299 Data structure symbol name too long
- 300 Data Structure requires more than maximum storage
- 301 Number of inputs/outputs greater than data structure definition
- 302 Duplicate definition or incorrect data structure type
- 303 Invalid Control Block Mode specified

**IODEF, RIODEF, NETDEF, RNETDEF, MODDEF  
Error Codes (Configuration Errors)**

- 306 Bad IODEF statement format
- 307 IODEF address must not be odd
- 308 Bad IODEF variable type
- 309 IODEF hex address too large
- 310 Invalid bit number specification in RIO/NET DEF
- 311 Invalid literal in RIO/NET DEF
- 312 Missing master slot specification in RIODEF
- 313 Bad literal in IODEF
- 314 Missing bit field specification
- 315 Missing slot specification
- 316 Bad RIO/NET DEF statement format
- 317 Missing drop specification
- 318 Bad MODDEF statement format
- 319 Bad GATEWAY register specification
- 320 Bad RNETDEF statement format
- 321 Bad RNETDEF register specification
- 322 Invalid variable data type in GATEWAY definition
- 323 Bad ABDEF statement format
- 324 Bad file specification in ABDEF statement
- 325 Bad boolean literal specification

**Function Call Error Codes**

- 336 Invalid function call format
- 337 Incorrect number of parameters in function call
- 338 Bad parameter data type in function call or bad array subscript
- 339 Parameter symbol not defined
- 340 Variable must be simple (not array variable)
- 341 Invalid function parameter
- 342 Invalid function expression
- 343 Bad function variable
- 344 Bad array; must be 1 dimension (integer)
- 345 Bad BLOCK\_\_MOVE variable
- 346 Variable in function call not defined as COMMON

### **Insufficient Memory Error Codes**

- 356 Insufficient memory to compile array
- 357 Insufficient memory to compile FOR statement
- 358 Insufficient memory to build symbol table
- 359 Insufficient symbol table memory
- 360 Object code buffer overflow
- 361 Opcode position overflow; statement too long
- 362 No more user stack
- 363 No more program stack
- 364 No more type stack; expression too long
- 365 No more operator stack; expression too long
- 366 No more memory to link object code buffer

### **FOR-NEXT Error Codes**

- 376 FOR control variable cannot be a tunable variable
- 377 NEXT control variable does not match FOR control variable
- 378 Control variable must be simple (not array) variable
- 379 Invalid data type on control variable in FOR statement
- 380 Bad FOR statement format
- 381 Invalid statement type following THEN in IF statement
- 382 Missing expected THEN
- 383 Invalid data type for expression in FOR statement
- 384 Missing corresponding FOR statement
- 385 FOR loops nested too deep

### **OPEN, CLOSE, INPUT, PRINT Error Codes**

- 396 Bad device name — PORTA or PORTB only
- 397 Bad logical file number specification
- 398 Bad device name for OPEN statement
- 399 Bad baud rate in OPEN SETUP parameter
- 400 Invalid device specification
- 401 Bad OPEN statement format
- 402 Duplicate logical file number
- 403 Invalid CLOSE statement format
- 404 Invalid device name
- 405 Missing expected print field
- 406 Specified file has not been defined (no OPEN)
- 407 Device must be accessed by OPEN first
- 408 Invalid data type for PRINT USING format
- 409 Bad PRINT USING format
- 410 Specified format field width too wide
- 411 Cannot have PRINT USING with channel
- 412 Bad GET statement format
- 413 Bad PUT statement format
- 414 Bad INPUT statement format
- 415 Cannot close a channel
- 416 Cannot GET from a channel
- 417 Cannot PUT to a channel
- 418 Bad SETUP specification in OPEN device
- 419 Open device attempted on a channel

## **START, WAIT, DELAY, EVENT Error Codes**

- 426 Invalid time units specification
- 427 Missing DELAY expression
- 428 Bad START EVERY statement
- 429 Bad WAIT statement format
- 430 Invalid event name
- 431 Bad EVENT statement format
- 432 Bad time units in START statement
- 433 Delay time units must be integer
- 434 Duplicate event name
- 435 Missing start interval
- 436 Missing event definition

## **Channel I/O Error Codes**

- 446 Missing DEPTH parameter on OPEN CHANNEL FOR INPUT
- 447 Bad OPEN CHANNEL format
- 448 Bad channel template in OPEN statement
- 449 Invalid DEPTH specification for OPEN CHANNEL
- 450 INPUT/PRINT reference does not match channel template
- 451 Not assigned
- 452 Channel template too large
- 453 Channel packet too large
- 454 Channel was opened for input but output was attempted
- 455 Channel was opened for output but input was attempted

## **Array Error Codes**

- 466 Array requires more than maximum storage
- 467 Bad array subscript
- 468 Number of subscripts does not match definition
- 469 Not assigned
- 470 Missing array dimension
- 471 Too many array subscripts

## **Miscellaneous Compiler Error Codes**

- 486 Missing delimiter
- 487 Missing equal sign "="
- 488 Missing left parenthesis "("
- 489 Missing right parenthesis ")"
- 490 Missing expected comma "," or semicolon ";"
- 491 Missing line number
- 492 Invalid line number
- 493 Line number out of range (must be 1 to 32767)
- 494 Invalid data type mixing in expression
- 495 Invalid variable type
- 496 Variable name same as reserved symbol
- 497 Variable name too long
- 498 Missing variable name
- 499 Variable name too long
- 500 Invalid subscripted variable
- 501 Invalid variable specified in READ statement
- 502 Missing variable definition

- 503 Invalid statement terminator; expecting EOS
- 504 Task must be a CONFIGURATION task
- 505 Missing operand (symbol or literal)
- 506 Missing arithmetic/relational operator
- 507 Not a valid statement for this task type
- 508 Invalid integer expression for ON GOTO
- 509 Invalid ON GOTO statement format
- 510 Missing expected TO
- 511 Expected expression not found
- 512 Missing expected line number
- 513 Invalid boolean expression
- 514 Invalid tunable statement definition
- 515 Symbol already defined; duplicate definition
- 516 Invalid data type for a tunable variable
- 517 Tunable variable ranges are inconsistent
- 518 Undefined variable or statement not permitted in this type of task
- 519 Invalid tunable variable definition format
- 520 Tunable cannot be array or left side of equal
- 521 Missing expected variable
- 522 DATA statement not first statement for this line number
- 523 Not assigned
- 524 Overflow in ASCII to binary integer conversion
- 525 Numeric literal too large
- 526 Real literal too large
- 527 Null buffer overflow; statement too large
- 528 Object buffer overflow; statement too large
- 529 Expression evaluator; stack integrity lost; expression too long and/or too complex
- 530 Compiler integrity lost
- 531 Illegal symbol in REM statement
- 532 CALL statement not first statement for this line number
- 533 Task not of type BASIC, Control or Configuration
- 534 Invalid task statement format
- 535 Invalid task priority
- 536 Invalid task name
- 537 Invalid slot specification
- 538 Missing string variable in GET statement
- 539 Illegal on board I/O address specified
- 540 Bad IOWRITE format
- 541 Bad IOWRITE option expression
- 542 Bad IOWRITE value expression
- 543 Bad IOWRITE address expression
- 544 REM statement not the first statement on the line
- 545 Bad ON ERROR statement format
- 546 Fatal expression evaluation error; no opcode match
- 547 String literal too large
- 548 Too many total elements for an array
- 549 Array variable was referenced as a simple variable
- 550 Illegal state in expression evaluation; integrity lost
- 551 Bad expression in SET\_\_MAGNITUDE statement

- 552 Bad SET\_\_MAGNITUDE statement format
- 553 Bad variable type in SET\_\_MAGNITUDE statement
- 554 Invalid TIMEOUT expression in EVENT statement
- 555 Symbol > 255 characters long; statement too long
- 556 Bad IF statement transfer line number
- 557 Invalid characters after the ampersand continuator
- 558 Remark statement too long
- 559 Line number out of range
- 560 Must be 1st statement on the line
- 561 Symbol is not a variable name
- 562 Loss of precision in converting real number

### **Resolution Error Codes**

- 656 Line used in RESTORE is not a DATA statement
- 657 FOR and NEXT variables do not match
- 658 Insufficient memory to compress object code
- 659 Object code larger than 32K
- 660 Stack requirements too large
- 661 Data structures too large
- 662 Symbol table integrity lost
- 663 Insufficient memory for post-compile resolution
- 664 Line number not resolved
- 665 Too many symbols
- 666 No TASK statement in configuration task
- 667 No symbols in configuration task
- 668 Duplicate data pointers with same data type; assigned two different variables of the same type to the same register or bit
- 669 Symbol table too large (too many symbols)
- 670 Invalid condition; integer literal in BASIC task symbol table
- 671 Unable to allocate enough space for symbol table
- 672 Symbol table integrity lost
- 673 Too many COMMON integers, double integers, booleans used
- 674 Unable to allocate space for the BASIC runtime structure header
- 675 Too many LOCAL integers, double integers, booleans used
- 676 Too many LOCAL integers, double integers, booleans literals used
- 677 Too many COMMON reals, strings, arrays used
- 678 Too many LOCAL reals, strings, arrays used
- 679 Too many OPEN CHANNEL statements
- 680 Too many arrays used
- 681 Too many FOR loops used
- 682 Too many real literals used
- 683 Too many real tunable variables defined
- 684 Invalid condition; literal in Configuration task
- 685 Invalid condition; string literal type in symbol table

- 686 Offset to real literal in Control Block task > 16 bits
- 687 Invalid condition; LOCAL variable in CONFIGURATION task
- 688 Invalid condition; relative symbol number not resolvable
- 689 Task too large
- 690 Error opening the object output file
- 691 Error writing to object output file
- 692 Task with READ statements but no DATA statements
- 693 Too many LOCAL integers, double integers, boolean variables used
- 694 Unable to allocate enough space for object code
- 695 Undefined Control Block data structure found
- 696 Error closing source file (disk may be full)
- 697 Error closing log file (disk may be full)
- 699 Error attempting to load time/date into object file
- 700 Object size > 32767 in Control Block task
- 701 Symbol & data size > 32767 in Control Block task

Corrective action: correct problem in the application software.

## **Run Time Error Codes Displayed in the Processor or UDC Error Log**

The following error codes are displayed in the error log maintained for each Processor and UDC module by the AutoMax Executive software.

- 756 Arithmetic integer overflow code
- 757 Arithmetic real overflow code
- 758 String concatenate overflow
- 759 Divide by zero
- 760 Integer multiply overflow
- 761 Integer assign overflow
- 762 Single integer conversion overflow in real to single integer
- 763 Double integer conversion overflow in real to double integer
- 764 Real to double conversion yields number > 24 bits
- 765 String overflow
- 766 Precision lost in real to integer array element conversion
- 767 Precision lost in real to double integer array element conversion
- 768 Precision lost in real to single integer conversion

- 769 Array subscript out of bounds
- 770 Requested substring > string
- 771 DATA type in READ statement does not match DATA statement
- 772 No more DATA statements
- 773 Bad line number for RESTORE
- 774 Overflow in conversion of real to integer of FOR loop control variable
- 775 Overflow in conversion of real to integer of FOR statement TO value
- 776 Overflow in conversion of real to integer of FOR statement STEP value
- 777 Integer > 24 bits in STEP value integer to real conversion
- 778 Bad IOWRITE
- 779 Integer control variable overflow in FOR statement
- 780 Double integer control variable overflow in FOR statement
- 781 Real control variable overflow in FOR statement
- 782 Negative delay
- 783 Delay value too large (0 to 32767)
- 784 Negative start interval
- 785 Delay value too large (0 to 32767)
- 786 Not assigned
- 787 Hardware event # ticks < 0
- 788 Hardware event ticks overflow
- 789 Print buffer overflow; print field too long
- 790 Device not open properly
- 791 OPEN with bad device address
- 792 Device not open for write
- 793 No stack space for print
- 794 Device not allocated
- 795 No buffer for print operation; insufficient memory
- 796 Fatal print error
- 797 Device already open
- 798 Device OPENed different from intended
- 799 Bad allocate
- 800 Bad default OPEN
- 801 Device already closed
- 802 Device opened as a channel
- 803 Bad device close; no address
- 804 Default device not allocated
- 805 Channel not open
- 806 Print integer channel overflow
- 807 Message overflow
- 808 Unsuccessful channel open
- 809 Integer > 24 bits in real conversion
- 810 Real to integer overflow
- 811 No buffer for GET operation
- 812 No print buffer
- 813 Device closed on GET
- 814 GET attempted to un-opened device; GET not open for read
- 815 Bad GET operation
- 816 No buffer for PUT operation
- 817 No print buffer
- 818 Device closed on PUT statement

- 819 PUT attempted on un-opened device; PUT not open for write
- 820 Unsuccessful PUT operation
- 821 Device should be open
- 822 Invalid baud rate
- 823 Bad SETUP re-configuration
- 824 Precision out of range
- 825 Print width too long; printing integer field in PRINT
- 826 Print width too long; printing integer field in PRINT USING with L/R/C/Z format
- 827 Negative decimal places
- 828 Number of decimal points > max precision
- 829 Width less than zero
- 830 Field width overflow
- 831 Requested substring width < zero
- 832 Requested substring width > maximum
- 833 No space for requested PRINT USING field
- 834 String > field width
- 835 Bad channel depth
- 836 Device not open
- 837 Attempted negative square root
- 838 First substring position specification > string length
- 839 Not assigned
- 840 Not assigned
- 841 Wrong data type input for boolean
- 842 Another error occurred during execution of ON ERROR routine
- 843 Could not allocate for write
- 844 Wrong data type input for string
- 845 Last substring position < first substring position
- 846 First substring position specification <= 0
- 847 Last substring position specification <= 0
- 848 Rotate count > 31
- 849 Overflow on absolute value function
- 850 Not assigned
- 851 Device open at END
- 852 Channel not open on input
- 853 Wrong type for integer
- 854 Next character after field not legal
- 855 Bad next character
- 856 No input channel I/O buffer
- 857 Not allocated for re-configuration
- 858 Bad BCD digit
- 859 Channel already open
- 860 Wrong token for comma
- 861 Not open for read
- 862 No comma between fields
- 863 Wrong data type input for real
- 864 No buffer space can be allocated for I/O
- 865 Not assigned
- 866 Invalid re-configuration
- 867 Missing line number
- 868 Bad device on input
- 869 Wrong type for double integer
- 870 No device address
- 871 Number > 24 bits



- 872 Not open for write
- 873 No device address
- 874 Attempt to execute a null opcode
- 875 Unbalanced GOSUB-RETURN
- 876 NEXT does not match loop variable in FOR statement
- 877 NEXT does not match FOR
- 878 Bad START statement format
- 879 Bad hardware event call
- 880 Undefined opcode
- 881 Stack overflow
- 882 No channel buffer space
- 883 STOP executed
- 884 Opcode not assigned
- 885 No event address defined
- 886 GOSUBs not balanced
- 887 Bad VAL function conversion
- 888 BCD output number > 9999
- 889 Bad bit number in function call
- 890 Bad option number in function call
- 891 Invalid GATEWAY transfer call
- 892 BLOCK\_MOVE invalid source parameter
- 893 BLOCK\_MOVE invalid destination parameter
- 894 BLOCK\_MOVE invalid transfer size parameter
- 895 RESUME without executing ON ERROR statement
- 956 UDC task tick rates do not match

Corrective action: correct problem in application software. For error code 891, check returned status variable of GATEWAY\_CMD\_OK@; decode status as follows:

Decimal	
01	Illegal function code
02	Illegal starting register
03	Illegal data
04	PC aborted
05	Not assigned
06	PC busy
07	Not assigned
08	Illegal data in response message
09	Response timeout error
20	Dual port address error
21	Gateway card not found or not accessible
22	No available Gateway channel
23	Illegal register number
24	Illegal number of registers
25	Illegal command number
26	Illegal command number/register set
27	Illegal register number/number of registers
28	Illegal device address

## UDC Drive Fault Register Error Codes

- 1000 SCR fault
- 1001 M-Contactor fault
- 1002 Not used
- 1003 Sync loss (A-C line voltage)
- 1004 Instantaneous overcurrent fault
- 1005 Conduction time out
- 1006 Field loss fault
- 1007 Tach loss fault
- 1008 Broken wire in resolver
- 1009 Not used
- 1010 Over-speed trip
- 1011 Power technology module fault
- 1012 Not used
- 1013 Not used
- 1014 Not used
- 1015 Fiber optic link com. fault

Corrective action: these errors reflect the status of the drive fault register (A=202, B=1202) on the UDC module. See S-3006 for more information.

## Serial I/O Error Codes

- 1064 EIA control (Carrier Detect lost)
- 1065 Parity error (when enabled)
- 1066 Overrun error
- 1067 Framing error

Corrective action: check for noise on the RS-232 cable, problems with the device connected to the Processor, and problems with the Processor itself.

## AutoMax DC Drive (DC\_DRIVE\_CML INIT) Errors

- |      |   |             |
|------|---|-------------|
|      |   | legal range |
| 2000 | IO_CNTL_SLOT error  | 0 to 15     |
| 2001 | DIG_IO_SLOT error   | 0 to 15     |
| 2002 | REF_LAG input out of range  | 1 to 500    |
| 2003 | PI_W_LEAD input out of range  | 10 to 500   |
| 2004 | AG_FACTOR input out of range  | 1 to 300    |
| 2005 | OSV_THRESH input out of range   | 0 to 32767  |
| 2006 | LIM_BAR input out of range  | 100 to 400  |
| 2007 | IOC_THRESH out of range   | 100 to 400  |
| 2008 | IOC calculation error<br>(IOC_THRESH > 1.8 LIM_BAR)   |             |
| 2009 | MAX_M_DROPOUT input out<br>of range   | .1 to 1.0   |
| 2010 | "Allocate Vector for Regulator" error. (Possible if using 4 Processor Modules and all 4 were using hardware interrupts. All 4 of the bus interrupt lines would be in use, leaving none for the CML task.) |             |

## **AutoMax DC Drive Run Time Errors**

- 2020 REF\_RATE input out of range 0 <= 32767
- 2021 KP input out of range 0 to 4
- 2022 TEST\_ALPHA input out of range 0 to 180
- 2023 CC\_THRESH input out of range 0 to 32767
- 2030 M-status would not go TRUE during start
- 2031 Current would not go to zero within  
MAX\_M\_DROPOUT during stop
- 2032 M-status would not go FALSE during stop
- 2050 Internal value > 32 bits; input numbers too  
large
- 2051 Computed OUTPUT value > 16 bits; input  
numbers too large, divide by zero
- 2054 WLG input value out of range
- 2055 WLD and/or WLG input value out of range
- 2056 KI input value out of range
- 2057 KP and/or WLD input value out of range
- 2058 COLUMN number out of range
- 2059 COLUMN can not currently be accessed

Corrective action: correct problem in application software.



# **Section II Hardware Module Reference**




Note the following conventions in register and bit descriptions:

- R = read only; must NEVER be written to by the application program
- R/W = read/write; can be read or written to by the application program
- X = not used

## Remote I/O Head M/N 45C33/57C330

The communications port on the 45C33/57C330 can connect to a single rail or to a Local Head, which can then connect to 1, 2, 3 or 4 rails. Note that input cards and output cards cannot be mixed on the same I/O rail; electronic input cards cannot be used.

### Sample Connection



# M/N 45C33/57C330

## (continued)

### LEDs

Color	LED	Description
yellow	RUN	Remote Head CPU in run
green	POWER	Power Supply OK
yellow	CPU READY	Remote Head CPU ready to run
		If Rail Fault Indicator is lit:
yellow	FAULT MSB	-->00 = Rail 0    01 = Rail 1
yellow	FAULT LSB	-----^ 10 = Rail 2    11 = Rail 3
red	RAIL FAULT	Rail Fault Indicator

### Programming terminal interrogation:

Command "R" can be entered to read the rails at a communication port with the coax connected and the module operating.


Command "S" for status can be entered with the coax connected and the module operating. The "Last Line Failure" codes displayed are as follows:

'LE'	restart due to excessive LINE ERRORS of any kind (RECEIVE TIMEOUT, CRC, OVERRUN, or ABORT).
'UI'	restart due to UNEXPECTED INIT request message.
'PF'	restart due to a POWER FAIL interrupt which occurs while the line is active. Input power has to remain valid for this code to be stored and displayed.
'Rn'	restart due to a port (rail) fault detected during the most recent port I/O update cycle.
n	port number (0-3) which experienced the fault.




# Drive Digital I/O Module B/M 57401

## Register 0 (READ Only)



## Register 1 (WRITE Bit 0 Only)



## LEDs

Color	LED	Description
yellow	IET	Reg 0, Bit 0 – 12 V IET input
yellow		Not used
yellow	AUX1	Reg 0, Bit 1 – Aux.1 Input
yellow	AUX2	Reg 0, Bit 2 – Aux.2 Input
yellow	MFBK	Reg 0, Bit 3 – “M” Cont. Input
yellow	DRIVE RUN	Reg 0, Bit 4 – Aux.3 Input
yellow	RPI	Reg 0, Bit 5 – Run Perm. Input not used
yellow	DFR	Reg 1, Bit 0 – Drive Fault Out
yellow	FMCR	Reg 1, Bit 1 – For. MCR
yellow	RMCR	Reg 1, Bit 2 – Rev. MCR
yellow	MCR	Reg 1, Bit 3 – Main Cntrl Relay (light only)

# B/M 57401 (continued)

Term	Signal	Description	Reg.
1	0 V (Common)	IET Common	
2	0 to 12 V DC	IET Input	Reg 0, Bit 0
3	0 V (Neutral)	Aux1 Neutral	
4	0 to 115 V AC	Aux1 Input	Reg 0, Bit 1
5	0 V (Neutral)	Aux2 Neutral	
6	0 to 115 V AC	Aux2 Input	Reg 0, Bit 2
7	0 V (Neutral)	M Fdbk Neu- tral	
8	0 to 115 V AC	M Fdbk Input	Reg 0, Bit 3
9	0 V (Neutral)	Aux3 Neutral	
10	0 to 115 V AC	Aux3 Input	Reg 0, Bit 4
11	0 V (Neutral)	RPI Neutral	
12	0 to 115 V AC	RPI Input	Reg 0, Bit 5
13	N.O.	DFR Contact	Reg 1, Bit 0
14	Wiper	DFR Contact	
15	N.C.	FMCR Con- tact	Reg 1, Bit 1
16	N.O.	FMCR Con- tact	
17	Wiper	FMCR Con- tact	
18	N.C.	RMCR Con- tact	Reg 1, Bit 2
19	N.O.	RMCR Con- tact	
20	Wiper	RMCR Con- tact	

## 115 V AC/DC Input Module M/N 57C400

### Register 0

MSB															LSB
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R

# M/N 57C400 (continued)

Term.	Signal	Description	Reg.
1	0 to 115 V AC	Signal Input	Reg 0, Bit 0
2	0 to 115 V AC	Signal Input	Reg 0, Bit 1
3	0 to 115 V AC	Signal Input	Reg 0, Bit 2
4	0 to 115 V AC	Signal Input	Reg 0, Bit 3
5	0 V AC	Isolated Common for bits 0 through 3	
6	0 to 115 V AC	Signal Input	Reg 0, Bit 4
7	0 to 115 V AC	Signal Input	Reg 0, Bit 5
8	0 to 115 V AC	Signal Input	Reg 0, Bit 6
9	0 to 115 V AC	Signal Input	Reg 0, Bit 7
10	0 V AC	Isolated Common for bits 4 through 7	
11	0 to 115 V AC	Signal Input	Reg 0, Bit 8
12	0 to 115 V AC	Signal Input	Reg 0, Bit 9
13	0 to 115 V AC	Signal Input	Reg 0, Bit 10
14	0 to 115 V AC	Signal Input	Reg 0, Bit 11
15	0 V AC	Isolated Common for bits 8 through 11	
16	0 to 115 V AC	Signal Input	Reg 0, Bit 12
17	0 to 115 V AC	Signal Input	Reg 0, Bit 13
18	0 to 115 V AC	Signal Input	Reg 0, Bit 14
19	0 to 115 V AC	Signal Input	Reg 0, Bit 15
20	0 V AC	Isolated Common for bits 12 through 15	

Output data is contained in register 0.

## 24-115 V AC/DC Output Module (M/N 57C402) and 115 V AC Output Module (M/N 57C403 and 61C503)

### Register 0

MSB														LSB	
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW

# M/N 57C402, 57C403 and 61C503 (continued)

<b>Term.</b>	<b>Signal</b>	<b>Description</b>	<b>Register</b>
1	0 to MAX	Signal Output	Reg 0, Bit 0
2	0 to MAX	Signal Output	Reg 0, Bit 1
3	0 to MAX	Signal Output	Reg 0, Bit 2
4	0 to MAX	Signal Output	Reg 0, Bit 3
5	MAX V AC	Isolated Common for bits 0 through 3	
6	0 to MAX	Signal Output	Reg 0, Bit 4
7	0 to MAX	Signal Output	Reg 0, Bit 5
8	0 to MAX	Signal Output	Reg 0, Bit 6
9	0 to MAX	Signal Output	Reg 0, Bit 7
10	MAX V AC	Isolated Common for bits 4 through 7	
11	0 to MAX	Signal Output	Reg 0, Bit 8
12	0 to MAX	Signal Output	Reg 0, Bit 9
13	0 to MAX	Signal Output	Reg 0, Bit 10
14	0 to MAX	Signal Output	Reg 0, Bit 11
15	MAX V AC	Isolated Common for bits 8 through 11	
16	0 to MAX	Signal Output	Reg 0, Bit 12
17	0 to MAX	Signal Output	Reg 0, Bit 13
18	0 to MAX	Signal Output	Reg 0, Bit 14
19	0 to MAX	Signal Output	Reg 0, Bit 15
20	0 V AC	Isolated Common for bits 12 through 15	

MAX = 24 V AC for 57C402 and 115 V AC for 57C403

## Network Communications Module M/N 57C404

The Network module must have the DROP DEPTH set in the application software before data can be read or written.

REGISTER 20=DROP DEPTH (decimal) must be greater than 0 (56 minus the thumbwheel setting).

# M/N 57C404 (continued)

register 20, bit 14 = error bit, set to ON by the Network module if existing DROP DEPTH is invalid.

register 20, bit 15 = processing complete bit, set to ON when the Network module has finished processing the DROP DEPTH register.

## DROP register formats:

DROP 0      register 4-7 = status for drops 1-55  
              registers 32-39 = broadcast registers

DROP 1-55    registers 0-31 = OUTPUTS (from  
                                    SLAVE) (read/write)  
              registers 32-63 = INPUTS (to SLAVE)  
                                    (read only)

**Programming terminal interrogation:** Command "s" for status can be entered with the coax connected and the module operating.

## Drop 0 (Area) Status and Control Registers

Registers 0-3	System use only; do not use
Register 4	Drop 0 through Drop 15 Status in bits 0 to 15
Register 5	Drop 16 through Drop 31 Status in bits 0 to 15
Register 6	Drop 32 through Drop 47 Status in bits 0 to 15
Register 7	Drop 48 through Drop 55 Status in bits 0 to 7
Registers 8-11	System use only; do not use
Register 12	Drop Number
Register 13	Keyswitch Mode (1 = protect, 2 = set-up, 3 = program)
Register 14	Messages Received
Register 15	Receive Timeouts
Register 16	CRC/Parity Errors
Register 17	Overrun Errors
Register 18	Abort Errors
Register 19	Messages Transmitted
Register 20	Drop Depth
Registers 21-31	System use only; do not use
Register 32	Broadcast Data — transmitted every 2.6 msec
Register 33	Broadcast Data — transmitted every 2.6 msec
Register 34	Broadcast Data — transmitted every 2.6 msec

## **M/N 57C404 (continued)**

Register 35	Broadcast Data — transmitted every 2.6 msec
Register 36	Broadcast Data — transmitted every 2.6 msec
Register 37	Broadcast Data — transmitted every 2.6 msec
Register 38	Broadcast Data — transmitted every 2.6 msec
Register 39	Broadcast Data — transmitted every 2.6 msec
Registers 40-63	System use only; do not use

In the master module, all registers are read only, with the exception of 32-39. Register assignments on slave modules are the same except that register 20 is read/write and all other registers are read only.

# M/N 57C404 (continued)

## Memory Map

To find the sequential register number for a particular drop, use the following:

$$\text{Sequential Register Number} = \text{Drop Number} * 64 + \text{Register Offset (0-63) in Desired Drop}$$

Sequential Register Number	Dual Port Memory Image	Drop Addressing (for use with NETDEF statements)
0	0	DROP 0 Registers 4-7 (comm. status bits)
63	63	Registers 32-39 (BROADCAST)
64	0 outputs 31	DROP 1 Registers 0-63
127	32 inputs 63	
128	0 outputs 31	DROP 2 Registers 0-63
191	32 inputs 63	
192	•	DROP 3 • • •
•	•	
•	•	
3519	•	DROP 54
3520	0 outputs 31	DROP 55 Registers 0-63
3583	32 inputs 63	

# Drive Controller Module (B/M 57406) Inputs and Drive Analog I/O Module (B/M 57405) Outputs

The Drive Analog I/O Module has three outputs: one non-changeable output for current minor loop feedback and two D/A outputs, which are "steerable" from the programming terminal. Drive Controller module inputs are READ only and must not be written to by the application program.

Function	Terminal	Nominal Scaling	57C406 Register #
Steerable D/A #1	1(-), 2(+)	$\pm 4095 = \pm 10 \text{ V DC}$ ( $\times 1$ Gain)	Not Available
Steerable D/A #2	3(-), 4(+)	$\pm 4095 = \pm 10 \text{ V DC}$ ( $\times 1$ Gain)	Not Available
Minor Loop	5(-), 6(+)	$\pm 4095 = \pm 3.3 \text{ V DC}$	Not Available
Analog Ref.	7, 8	$\pm 4095 = \pm 10 \text{ V DC}$	4096
Analog Tach Feedback	9, 10	$\pm 3072 = \pm 5 \text{ V DC}$	4097
Armature Voltage Feedback	*PMI (Scaling Circuit) through Drive Analog	$\pm 8192 = \pm 10 \text{ V DC}$	4098
Current Major Loop Feedback (filtered current feedback) MAJOR_I_FDBK%	PMI (Burden Resistor) through Drive Analog	$\pm 4095 = \pm 10 \text{ V DC}$	4099
AC Line Voltage	PMI (Line Sync Transformer) through Drive Analog	0-8130 = 0-10 V DC 4866 = 460 or 230 V AC	4100
Current Minor Loop Feedback (unfiltered current feedback) MINOR_I_FDBK%	PMI (Burden Resistor) through Drive Analog	$\pm 4095 = \pm 10 \text{ V DC}$	4101

\*Available for use when 57408-1 is installed for fast bridge change.



# B/M 57406 and 57405 (continued)


Function	Units	Default Value	57C406 Register #
Tach Loss Threshold	deg.α	109	4136
PLL Max Phase Change	μsec	2	4137
PLL Max Period Change	μsec	4	4138
Bit 0 Enables Fast Bridge Change	N/A	0 (disabled)	4146

## 2-Channel Analog Input Module M/N 57C409

### Register Assignments

Register Number	Description	Channel	Access
0	Data	0	R
1	Data	1	R
2	Current Count	0	R
3	Current Count	1	R
4	Status Register		R
5	Interrupt Status and Control	0	R/W
6	Interrupt Status and Control	1	R/W
7	Period Count	0	R/W
8	Period Count	1	R/W
9	Low Pass Filter Selection	0	R/W
10	Low Pass Filter Selection	1	R/W

### Status Register (READ Only) 4



# M/N 57C409 (continued)

## Register 5 (ISCR for Channel 0)

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
R	x	x	x	x	x	x	x	R	RW	R	R	R	R	R	R

## Register 6 (ISCR for Channel 1)

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
R	x	x	x	x	x	x	x	R	RW	R	R	R	R	R	R

Bit 15: Interrupt Flag  
 Bit 14: Interrupt Line ID  
 Bit 13: Interrupt Line ID  
 Bit 12: Interrupt Line ID  
 Bit 11: Interrupt Line ID  
 Bit 10: Interrupt Line ID  
 Bit 9: Interrupt Line ID  
 Bit 8: Interrupt Line ID  
 Bit 7: Interrupt Line ID  
 Bit 6: Interrupt Line ID  
 Bit 5: Enable Common Clock  
 Bit 4: Interrupt Enabled  
 Bit 3: Interrupt Line ID  
 Bit 2: Interrupt Line ID  
 Bit 1: Interrupt Line ID  
 Bit 0: Interrupt Line ID

## Low Pass Filter Selection

For register 9 (channel 0) and register 10 (channel 1) bits 0 and 1:

Data	Filter Corner Frequency $\pm 11\%$
00	300 rad/sec
01	145 rad/sec
10	79 rad/sec
11	21 rad/sec

## LEDs

Color	LED	Description
yellow	CCLK ON	CCLK running on backplane
yellow	CCLK Enable	This card driving CCLK
yellow	CSD	N/A
yellow	IOCK	N/A


Term.	Signal	Description	Reg.
1	$\pm 10\text{ V} = \pm 4095$	Channel 0 Input	0
2	$\pm 1\text{ V} = \pm 4095$	Channel 0 Input	0
3		Channel 0 Common	
4	$\pm 10\text{ V} = \pm 4095$	Channel 1 Input	1
5	$\pm 1\text{ V} = \pm 4095$	Channel 1 Input	1
6		Channel 1 Common	
7		N/C	
8	+15 V	+25 ma power supply (for external use)	
9	0 V	Common	
10	-15 V	-25 ma power supply	

# Analog Output Module M/N 57C410

## Register Assignments

Register Number	Description	Access
0	Channel 0	RW
1	Channel 1	RW
2	Channel 2	RW
3	Channel 3	RW

## Register Bit Arrangement



## LEDs

Color	LED	Description
green	ISOL Power 0	Ch. 0 Isolated Power Supply OK
green	ISOL Power 1	Ch. 1 Isolated Power Supply OK
green	ISOL Power 2	Ch. 2 Isolated Power Supply OK
green	ISOL Power 3	Ch. 3 Isolated Power Supply OK

# M/N 57C410 (continued)

Term.	Signal	Voltage		Reg.
1		$\pm 5$ V	Ch. 0 Jumper	0
2	$\pm 4095$	$\pm 10$ V	Ch. 0 Volt. Output	
3		$\pm 8$ V	Ch. 0 Jumper	
4	$\pm 4095$	4-20 ma	Ch. 0 Curr. Output	
5		0 V	Ch. 0 Common	
6		$\pm 5$ V	Ch. 1 Jumper	1
7	$\pm 4095$	$\pm 10$ V	Ch. 1 Volt. Output	
8		$\pm 8$ V	Ch. 1 Jumper	
9	$\pm 4095$	4-20 ma	Ch. 1 Curr. Output	
10		0 V	Ch. 1 Common	
11		$\pm 5$ V	Ch. 2 Jumper	2
12	$\pm 4095$	$\pm 10$ V	Ch. 2 Volt. Output	
13		$\pm 8$ V	Ch. 2 Jumper	
14	$\pm 4095$	4-20 ma	Ch. 2 Curr. Output	
15		0 V	Ch. 2 Common	
16		$\pm 5$ V	Ch. 3 Jumper	3
17	$\pm 4095$	$\pm 10$ V	Ch. 3 Volt. Output	
18		$\pm 8$ V	Ch. 3 Jumper	
19	$\pm 4095$	4-20 ma	Ch. 3 Curr. Output	
20		0 V	Ch. 3 Common	

Note: Install jumpers for indicated voltage range ( $\pm 10$  V DC without jumpers).


# Resolver Input Module

## M/N 57C411

### Register Assignments

Register Number	Description	Access
0	Resolver Data	R
1	External Latch Data	R
2	Interrupt Status	R
3	Interrupt Status and Control	R/W
4	Update Period	R/W

### Interrupt Status and Control Registers Registers 2 and 3



### LEDs

Color	LED	Description
yellow	DIRECTION	Forward or Reverse Rotation
yellow	FDBK OK	Resolver Electrically Connected
yellow	CCLK OK	CCLK running on backplane
yellow	IPS OK	Isolated Power Supply OK
green	OK	Board OK

Term.	Approx. Signal Level	Description
1	26 V AC	Reference Output
2	16 V AC	Reference Output
3	11.8 V AC	Reference Input
4	11.8 V AC	Reference Input
5	11.8 V AC	Sine Input
6	11.8 V AC	Sine Input
7	11.8 V AC	Cosine Input
8	11.8 V AC	Cosine Input
9		Input for Strobe (Contact Closure Req'd)
10		Input for Strobe (Contact Closure Req'd)

# Field Controller Module B/M 57412

## Register Assignments

Register Number	Description	Range	Access
0	Field ON (bit 0)	1 or 0	R/W
1	Voltage Stability	1 to 255	R/W
2	Current Stability	1 to 255	R/W
3	Voltage Reference	0 to 255	R/W
4	Current Reference	$\pm 255$	R/W
5	Current Feedback	$\pm 127$	R

# Modbus Interface Module M/N 57C414

## Status and Control Registers

Register 0	Status and Control Register 1
Register 1	Status and Control Register 2
Register 2	Status and Control Register 3
Register 3	Status and Control Register 4
Register 4	Device Status (bit 0)
Registers 5-11	Not used
Register 12	Device Number
Register 13	Keyswitch Mode (1 = protect), 2 = set-up, 3 = program)
Register 14	Messages Received
Register 15	Receive Timeouts
Register 16	CRC/Parity Errors
Register 17	Overrun Errors
Register 18	Framing Errors
Register 19	Messages Transmitted
Register 20	Configuration/Update Request
Register 21	Baud Rate (1200, 2400, 4800, 9600, 19200)
Register 22	Response Timeout (seconds)
Register 23	Number of Retries
Register 24	Response Turn-around Delay (milliseconds)
Registers 25-49	Not used
Registers 50-54	Used for Debug Mode
Registers 55-61	Not used
Register 62	Module identification
Register 63	(ASCII 'GTW')

# M/N 57C414 (continued)

## Memory Map

This address map shows the relationship of the Modbus address to the decimal register number and the hex bus address number.

Multibus Access	Modbus Register Number	Modbus Access
R	00001 – 04096 single bits	R/W
R/W	10001 – 14096 single bits	R
R/W	30001 – 31024 16-bit registers	R
R/W	40001 – 41024 16-bit registers	R/W

Modbus Register Number	Decimal Register Number	Hex Bus Address	Modbus Register Designations
00001 bit addressable	64	2s0080	COIL REGISTERS
04096	319	2s027E	
10001 bit addressable	320	2s0280	INPUT REGISTERS
14096	575	2s047E	
30001 word addressable	576	2s0480	INPUT REGISTERS
31024	1599	2s0C7E	
40001 word addressable	1600	2s0C80	HOLDING REGISTERS
41024	2623	2s147E	


S = slot

# M/N 57C414 (continued)

Register 21 must be set up before register 20.


REGISTER 21 = baud rate  
(1200,2400,4800,9600,19200)

REGISTER 20 = configuration (see below)



## Register 4

## Link Status





# M/N 57C414

## (continued)

To convert Modbus Interface registers to hexadecimal addresses which can then be monitored using the DCS 5000 or AutoMax Executive software, perform the following calculations.

X = the register you want to monitor

- For registers 00001 – 04096:  
 $X = ((\{\text{Modbus register \#} - 1\} / 16) + 64)$   
For registers 10001 – 14096:  
 $X = ((\{\text{Modbus register \#} - 1\} / 16) + 320)$   
For registers 30001 – 31024:  
 $X = (\text{Modbus register \#} - 29425)$   
For registers 40001 – 41024:  
 $X = (\text{Modbus register} - 38401)$
- First, drop off any remainder from your result (X). Then multiply that result by 2.
- Convert the result of #2 above to hexadecimal format.
- To the result from #3 above add the following:  
2s0000H  
where s = slot number of the Interface module in hexadecimal.
- The result is the DCS 5000 and AutoMax equivalent of the Modbus register.

Note: Registers 00001 to 14096 actually refer to bits within a Multibus word.

## 24V AC/DC Input Module

### M/N 57C415

#### Register 0

MSB														LSB	
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R

## M/N 57C415 (continued)

Term.	Signal	Description	Register
1	0 to 24 V AC	Signal Input	Reg 0, Bit 0
2	0 to 24 V AC	Signal Input	Reg 0, Bit 1
3	0 to 24 V AC	Signal Input	Reg 0, Bit 2
4	0 to 24 V AC	Signal Input	Reg 0, Bit 3
5	0 V AC	Isolated Common for bits 0 through 3	
6	0 to 24 V AC	Signal Input	Reg 0, Bit 4
7	0 to 24 V AC	Signal Input	Reg 0, Bit 5
8	0 to 24 V AC	Signal Input	Reg 0, Bit 6
9	0 to 24 V AC	Signal Input	Reg 0, Bit 7
10	0 V AC	Isolated Common for bits 4 through 7	
11	0 to 24 V AC	Signal Input	Reg 0, Bit 8
12	0 to 24 V AC	Signal Input	Reg 0, Bit 9
13	0 to 24 V AC	Signal Input	Reg 0, Bit 10
14	0 to 24 V AC	Signal Input	Reg 0, Bit 11
15	0 V AC	Isolated Common for bits 8 through 11	
16	0 to 24 V AC	Signal Input	Reg 0, Bit 12
17	0 to 24 V AC	Signal Input	Reg 0, Bit 13
18	0 to 24 V AC	Signal Input	Reg 0, Bit 14
19	0 to 24 V AC	Signal Input	Reg 0, Bit 15
20	0 V AC	Isolated Common for bits 12 through 15	

Input data is contained in register 0.

## Remote I/O Communications Module M/N 57C416

### Drop 0 (Master) Status and Control Registers

Registers 0-3	Not used
Register 4	Drop 1 through Drop 7 Status in bits 1 to 7
Registers 5-11	Not used
Register 12	Drop Number
Register 13	Keyswitch Mode (1 = protect, 2 = set-up, 3 = program)
Register 14	Messages Received
Register 15	Receive Timeouts
Register 16	CRC/Parity Errors
Register 17	Overrun Errors
Register 18	Abort Errors
Register 19	Messages Transmitted
Registers 20-511	Not used

All registers are read only.

### Programming terminal interrogation:

Command "R" can be used to read the registers in a module in the slave drop with the coax connected and the module operating. Command "S" can be used to read the status of the module.

# AutoMate Interface Module M/N 57C417

## Status and Control Registers

Register 0	Status and Control Register 1
Register 1	Status and Control Register 2
Register 2	Status and Control Register 3
Register 3	Status and Control Register 4
Register 4	Device Status (bit 0-3)
Registers 5-11	Not used
Register 12	Drop Number
Register 13	Keyswitch Mode (1 = protect, 2 = set-up, 3 = program)
Register 14	Messages Received
Register 15	Receive Timeouts
Register 16	Checksum/Parity Errors
Register 17	Overrun Errors
Register 18	Framing Errors
Register 19	Messages Transmitted
Register 20	Link Configuration/Update Request
Register 21	Link Baud Rate (1200, 2400, 4800, 9600, 19200)
Register 22	Response Timeout (seconds)
Register 23	Number of Nodes
Registers 24-49	Not used
Registers 50-59	Used for Debug Mode
Registers 60, 61	Not used
Register 62	Module Identification
Register 63	(ASCII 'GTWY')

## Memory Map

This address map shows the relationship of the AutoMate address to the decimal register number and the hex bus address number.

Multibus Access	AutoMate Register Number	AutoMate Access
R	0000.00 - 0377.17 single bits	R/W
R/W	0400.00 - 0777.17 single bits	R
R/W	2000 - 3777 16-bit registers	R
R/W	4000 - 5777 16-bit registers	R/W

# M/N 57C417 (continued)


AutoMate Register Number (Octal)	Decimal Register Number	Hex Bus Address	AutoMate Register Designations
0000.00 bit addressable	64	2s0080	DISCRETE OUTPUTS (from AUTOMATE)
0377.17	319	2s027E	
0400.00 bit addressable	320	2s0280	DISCRETE INPUTS (to AUTOMATE)
0777.17	575	2s047E	
2000 word addressable	576	2s0480	INPUT REGISTERS (to AUTOMATE)
3777	1599	2s0C7E	
4000 word addressable	1600	2s0C80	OUTPUT REGISTERS (from AUTOMATE)
5777	2623	2s147E	

"s" is the slot number where the module is located.

Register 21 must be set up before register 20.

REGISTER 21 = Link baud rate  
(1200,2400,4800,9600,19200)

REGISTER 20 = Link configuration, update re-  
quest (see below)



# M/N 57C417

## (continued)

To convert AutoMate Interface registers to decimal register numbers which can then be monitored using the DCS 5000 or AutoMax Executive software, perform the following calculations.

X = the register you want to monitor

1. For octal registers 0000.00 – 0377.17 and 0400.00 – 0777.17:  
 $X = (\text{AutoMate register \#} + 64)$   
For registers 2000 – 3777 and 4000 – 5777:  
 $X = (\text{AutoMate register \#} - 448)$
2. The result is the DCS 5000 and AutoMax equivalent of the register.

## Allen-Bradley Interface Module M/N 57C418

### Status and Control Registers

Register 0	Status and Control Register 1
Register 1	Status and Control Register 2
Register 2	Status and Control Register 3
Register 3	Status and Control Register 4
Register 4	Device Status (bit 0)
Registers 5-11	Not used
Register 12	Station Number
Register 13	Keyswitch Mode (1 = protect, 2 = set-up, 3 = program)
Register 14	Messages Received
Register 15	Receive Timeouts
Register 16	Checksum/Parity Errors
Register 17	Overrun Errors
Register 18	Framing Errors
Register 19	Messages Transmitted
Register 20	Link Configuration
Register 21	Baud Rate (1200, 2400, 4800, 9600, 19200)
Register 22	Response Timeout (seconds)
Register 23	Number of Retries
Register 24	ACK/NAK Timeout (25 ms. increments)
Registers 25-49	Not used
Registers 50-59	Used for Debug Mode



# M/N 57C418 (continued)

A-B Interface File Register Number	Decimal Register Number	Hex Bus Address	A-B Interface File Designations
0	64	2s0080	
bit addressable			B0
255	319	2s027E	
0	320	2s0280	
bit addressable			B1
255	575	2s047E	
0	576	2s0480	
word addressable			N0
1023	1599	2s0C7E	
0	1600	2s0C80	
word addressable			N1
1023	2623	2s147E	

To convert Allen-Bradley Interface registers to decimal register numbers which can then be monitored using the DCS 5000 or AutoMax Executive software, perform the following calculations.

X = the register you want to monitor

- For file N0 registers:  

$$X = (\text{file N0 register \#} + 576)$$
 For file N1 registers:  

$$X = (\text{file N1 register \#} + 1600)$$
 For file B0 registers:  

$$X = (\text{file B0 register \#} + 64)$$
 For file B1 registers:  


$$X = (\text{file B1 register \#} + 320)$$
- The result is the DCS 5000 and AutoMax equivalent of the register.

# 5-24 V DC Input Module M/N 57C419

## Registers 0 and 1

	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R
1	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R


## Register 2



\*1 These bits are controlled by the operating system and must not be set by the user.

B17-B20 refer to field connections.

## Register 3



\* A Latch must be acknowledged by writing a 0 to the proper bit after the latch has occurred.

B17-B20 refer to field connections.



# M/N 57C419 (continued)

Term.	Signal	Description
1	5 or 24 V DC	Isolated Voltage for bits 0 to 3
2	0 to V supply	Signal input for bit 0
3	0 to V supply	Signal input for bit 1
4	0 to V supply	Signal input for bit 2
5	0 to V supply	Signal input for bit 3
6	5 or 24 V DC	Isolated Voltage for bits 4 to 7
7	0 to V supply	Signal input for bit 4
8	0 to V supply	Signal input for bit 5
9	0 to V supply	Signal input for bit 6
10	0 to V supply	Signal input for bit 7
11	5 or 24 V DC	Isolated Voltage for bits 8 to 11
12	0 to V supply	Signal input for bit 8
13	0 to V supply	Signal input for bit 9
14	0 to V supply	Signal input for bit 10
15	0 to V supply	Signal input for bit 11
16	5 or 24 V DC	Isolated Voltage for bits 12 to 15
17	0 to V supply	Signal input for bit 12*
18	0 to V supply	Signal input for bit 13*
19	0 to V supply	Signal input for bit 14*
20	0 to V supply	Signal input for bit 15*

\*Reg. 1 only, these 4 inputs are also the latch inputs.

Terminal strips A (Reg. 0) and B (Reg. 1) share the same layout.

## 5-24 V DC Output Module M/N 57C420

### Registers 0 and 1


MSB														LSB			
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0		
RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW		

# Pulsetach Input Module M/N 57C421B

## Register and Bit Assignments


Register Number	Bit Assignment						Access
	15	...	8	7	...	0	
0	extended sign			MSB			R
1	24-bit counter					LSB	R
2	MSB	16-bit timer			LSB		R/W
3	11111111			MSB			R/W
4	24-bit comparator					LSB	R/W
5	Interrupt status and control register					LSB	R/W
6	MSB	Control register			LSB		R/W
7	MSB	Control register			LSB		R/W

## Register 5 (ISCR)





# M/N 57C421B (continued)

## Register 6



# M/N 57C421B (continued)

## Register 7



- 15 EXT ORIGIN/CLEAR STATUS RESET; 0 = Reset
- 14 TIMER EXTERNAL COUNT STOP STATUS RESET; 0 = Reset
- 13 EXTERNAL LATCH STATUS RESET
- 12 COUNTER = COMPARATOR STATUS RESET; 0 = Reset
- 11 BORROW STATUS RESET; 0 = Reset
- 10 CARRY STATUS RESET; 0 = Reset

### LEDs

Color	LED	Description
yellow	COUNT STOP	External Count Stop Input
yellow	LATCH	External Latch Input
yellow	CLEAR	External Clear Input
yellow	FORWARD	Forward rotation sensed
yellow	REVERSE	Reverse rotation sensed
green	CCLK OK	CCLK running on backplane

# M/N 57C421B (continued)

Term.	Signal	Description
1		N/C
2	0 to +12 V DC	Channel +A 12 V Input
3	0 to +12 V DC	Channel +B 12 V Input
4	0 to +12 V DC	Channel +Z 12 V Input
5		N/C
6	0 to +5 V DC	Origin Clear 5 V Input
7	0 V	Origin Clear Common
8	0 to +5 V DC	External Latch 5 V Input
9	0 V	External Latch Common
10	0 to +5 V DC	External Count Stop 5 V Input
11	0 V	External Count Stop Common
12	0 to +5 V DC	Channel +A 5 V Input
13		N/C
14	0 to +5 or +12	Channel A Common or -A
15	0 to +5 V DC	Channel +B 5 V Input
16		N/C
17	0 to +5 or +12	Channel B Common or -B
18	0 to +5 V DC	Channel +Z 5 V Input
19		N/C
20	0 to +5 or +12	Channel Z Common or -Z

N/C=no connection.

# 2-Axis Servo Module

## M/N 57C422B

### Register Assignments

Register 0	Encoder set-up
Register 1	Drive set-up
Register 2	Switch set-up
Register 3	Proportional gain
Register 4	Integral gain
Register 5	Velocity loop gain
Register 6	Feedforward gain
Register 7	Deadband compensation
Register 8	Maximum position error
Register 9	Maximum velocity error
Register 10	In-position tolerance
Registers 11, 12	Positive overtravel limit
Registers 13, 14	Negative overtravel limit
Registers 15, 16	Low speed homing reference
Registers 17, 18	Command position
Registers 19, 20	Command velocity
Registers 21, 22	Command acceleration
Registers 23, 24	Command deceleration
Registers 25, 26	Gear ratio
Register 27	User LEDs register
Register 28	Direct drive reference command
Registers 29, 30	Sync position
Register 31	Maximum voltage reference
Register 32	Positive linearization constant
Register 33	Negative linearization constant
Registers 34, 35	Feedback unwind constant
Registers 36, 37	Gearing unwind constant
Register 38	Gearing modes
Registers 39, 40	Backlash Compensation
Register 64	Interrupt Reset (for both X and Y)
Register 65	Mode
Register 66	Command
Register 67	Command
Registers 68, 69	Interrupt enable
Register 72	Status
Register 73	Fault
Registers 74, 75	Current feedback position
Registers 76, 77	Current gearing position
Registers 78, 79	Current velocity
Register 80	Following error
Register 81	Velocity error
Register 82	Digital input status
Register 83	Current velocity status update period
Registers 84, 85	Feedback registration position
Registers 86, 87	Gearing registration position
Registers 99-103	Software version number
Registers 104, 105	Interrupt status
Registers 124, 125	Master axis position increment
Registers 126, 127	Master Reference position

# M/N 57C422B

## (continued)

Register 128	Number of points in CAM table
Register 129	Time between points in CAM table
Register 130	CAM Mode
Register 131	Loop back point in Time CAM table
Registers 132-2046	CAM data table
Register 4095	Interrupt status and control (for both X and Y)

Register assignments for X axis. For Y axis, add 2048 to the X axis register numbers (except registers 64 and 4095).

### LEDs

Color	LED	Description
yellow	XHOME	↑ Home Limit Input
yellow	X+OTRAV	X Positive Overtravel Input
yellow	X-OTRAV	I Negative Overtravel Input
yellow	XFAULT	A Fault Input
yellow	XF.REG	x Feedback Registration Input
yellow	XG.REG	i Gearing Registration Input
yellow	XENABLE	s Enable Input
yellow	XSP	↓ Spare
yellow	STAT3	CPU Status LEDs
yellow	STAT2	CPU Status LEDs
yellow	STAT1	CPU Status LEDs
yellow	DIAG	CPU Status LEDs
green	OK	Board OK
yellow	YHOME	↑ Home Limit Input
yellow	Y+OTRAV	Y Positive Overtravel Input
yellow	Y-OTRAV	I Negative Overtravel Input
yellow	YFAULT	A Fault Input
yellow	YF.REG	x Feedback Registration Input
yellow	YG.REG	i Gearing Registration Input
yellow	YENABLE	s Enable Input
yellow	YSP	↓ Spare

# M/N 57C422B (continued)

Term.	Signal	Description
1	0 V (Common)	from Encoder Power Supply
2	+5 V	from Encoder Power Supply
3	0 V	to Feedback Encoder
4	+5	to Feedback Encoder
5	0 to +5	+A from Feedback Encoder
6	0 to +5	-A from Feedback Encoder
7	0 to +5	+B from Feedback Encoder
8	0 to +5	-B from Feedback Encoder
9	0 to +5	+Z from Feedback Encoder
10	0 to +5	-Z from Feedback Encoder
11	0 V	to Gearing Encoder
12	+5	to Gearing Encoder
13	0 to +5	+A from Gearing Encoder
14	0 to +5	-A from Gearing Encoder
15	0 to +5	+B from Gearing Encoder
16	0 to +5	-B from Gearing Encoder
17	0 to +5	+Z from Gearing Encoder
18	0 to +5	-Z from Gearing Encoder
19		N/C
20		N/C
21	+12/15 V DC	from Drive Reference Power Supply
22	-12/15 V DC	from Drive Reference Power Supply
23	0 V (Common)	to Drive Reference & From Power Supply
24	$\pm 12/15$ V DC	to Drive Reference
25		Watchdog Contact Output
26		Watchdog Contact Output
27	0 to 24 V DC/AC	Home Limit Switch Input
28	0 V (Common)	Home Limit Switch Common
29	0 to 24 V DC/AC	Positive Overtravel Limit Switch Input
30	0 V (Common)	Positive Overtravel Limit Switch Common
31	0 to 24 V DC/AC	Negative Overtravel Limit Switch Input
32	0 V (Common)	Negative Overtravel Limit Switch Common
33	0 to 24 V DC/AC	Drive Fault Input
34	0 V (Common)	Drive Fault Input
35	0 to 24 V DC	Feedback Registration Input
36	0 V (Common)	Feedback Registration Common
37	0 to 24 V DC	Gearing Registration Input
38	0 V (Common)	Gearing Registration Common
39		N/C
40		N/C

Note: Both the X and Y axis have the same terminal layout. The uppermost connector on the module is for the X axis.



# MaxPak III

## High Speed Link

### Module M/N 57C424

#### Dual Port Register Assignments

Register 0	Status and control
Register 4	Link active
Register 12	Device number
Register 13	Keyswitch state
Register 14	Messages received
Register 15	Receive timeouts
Register 16	Checksum errors
Register 17	Overrun errors
Register 18	Framing errors
Register 19	Messages transmitted
Register 20	Parity errors
Register 26	Comm. error flags
Register 27	Configuration error flags
Register 28	MaxPak III status byte
Register 29	Transmit active
Register 30	Command/status change
Register 31	Comm. error reset
Register 40	Total input on-line registers
Register 41	Total input off-line registers
Register 42	Total input on-line bits
Register 43	Total input off-line bits
Register 44	Total output registers
Register 45	Total output bits
Register 60	Fatal error #
Register 62	Module ASCII ID "HS"
Register 63	Module ASCII ID "L"
Register 64	Module version number
Register 70	# of registers to send to MaxPak III
Register 71	# of bits to send to MaxPak III
Register 75	# of registers to receive from MaxPak III
Register 76	# of bits to receive from MaxPak III
Register 80	Max. receive timeout (in msec.)
Register 81	Speed loop time period (in ticks)
Register 100	Data receive register 0
Register 101	Data receive register 1
Register 102	Data receive register 0
Register :	
Register 354	Data receive register 254
Register 355	Data receive register 255
Register 400	Data receive packed bits reg. 0
Register 401	Data receive packedbits reg. 1
Register :	


Register 415	Data receive packed bits reg. 15
Register 1100	Data transmit register 0
Register 1101	Data transmit register 1
Register 1102	Data transmit register 2
Register :	
Register 1354	Data transmit register 254
Register 1355	Data transmit register 255
Register 1400	Data transmit packed bits reg. 0
Register 1401	Data transmit register 1
Register :	
Register 1415	Data transmit packed bits reg. 15

# Toledo Scale Interface Module M/N 57C428

Register 21 must be set up before register 20.

REGISTER 21 = baud rate  
(1200,2400,4800,9600,19200)

REGISTER 20 = Update request  
(non-zero for update request)



## Register Assignments

Register 4	Link status
Register 14	Number of good messages received
Register 15	X
Register 16	Number of checksum or parity errors
Register 17	Number of overrun errors
Register 18	Number of framing errors
Register 20	Configuration/update request
Register 21	Baud rate
Register 22	Link timeout
Register 64	Request status
Register 65	Message counter
Register 66	Status byte "A"
Register 67	Status byte "B"
Register 68	Status byte "C"
Registers 69, 70	Indicated weight
Registers 71, 72	Tare weight

## LEDs

Color	LED	Description
green	OK	Module is operational

# AutoMax R-Net Processor Module M/N 57C429

## Register Organization

Register	Description	R/W
Register 0-63	Status and Control	R/W
Register 64-2623	AutoMate Image	R/W
Register 2624-3583	Not used	X
Register 3584-4095	Command Buffer	R

## Status and Control Registers

Register 0	System use only
Register 1	System use only
Register 2	System use only
Register 3	System use only
Register 4	Drops on line status (15-0)
Register 5	Drops on line status (31-16)
Register 6	Drops on line status (47-32)
Register 7	Drops on line status (63-48)
Register 8	System use only
Register 9	System use only
Register 10	System use only
Register 11	System use only
Register 12	Node number
Register 13	Slot number
Register 14	Messages received count
Register 15	Receive timeouts count
Register 16	CRC error count
Register 17	Overrun error count
Register 18	Illegal message count
Register 19	Messages transmitted count
Register 20	Lost token count
Register 21	Max. node number
Register 22	Response timeout (in seconds)
Register 23	Current token time
Register 24	Max. token time
Register 25	Reserved for system use
Register :	
Register 49	Reserved for system use
Register 50	Transmit global data enabling reg. for AutoMate image reg. 71
Register 51	Transmit global data enabling reg. for AutoMate image reg. 72
Register 52	Transmit global data enabling reg. for AutoMate image reg. 73
Register 53	Transmit global data enabling reg. for AutoMate image reg. 74
Register 54	Reserved for system use
Register :	
Register 59	Reserved for system use
Register 60	LED error code
Register 61	Reserved for system use
Register 62	Reserved for system use
Register 63	Reserved for system use

## **AutoMate Image Registers**

Registers 64-575	AutoMate Registers 0000.00-0777.17 (octal)
Registers 576-2623	AutoMate Registers 2000-5777 (octal)

# **AutoMax Processor Module M/N 57C430, M/N 57C431 and M/N 57C435**

## **Connection Information**

All Processor module ports except for the port labeled "PROGRAMMER/PORT B" on the leftmost Processor in the rack are available to the user to connect to an external device which will be controlled by application tasks running on the Processor. Refer to the Enhanced BASIC Language Instruction Manual (J-3675) for more information. Note that with AutoMax Processor modules, you can use the statements OPEN "PORTA" or OPEN "PORTB".

Note: If you do not enable bit 15 (hardware handshaking) in the SETUP parameter of the OPEN statement, only pins 2, 3 and 7 of the port you OPEN will be meaningful.

<b>Pin #</b>	<b>I/O</b>	<b>Function</b>
2	O	This signal contains transmitted data.
3	I	This signal contains received data.
4	O	Transmit status. This signal is true whenever the transmitter is sending characters. It is used to "bracket" a character transmission. It can be used to enable/disable any type of external equipment, such as a tri-state transmit modem, which requires an enable signal to output characters. This signal is meaningful only if hardware handshaking has been enabled.
5	I	This signal enables the transmitter. It must be true for the transmitter to send a character. This signal is typically used for hardware flow control. It is meaningful only if hardware handshaking has been enabled.
6	I	This signal enables the receiver. It must be true in order for the receiver to accept characters. If the signal becomes false while a message is being received, any characters being received will be deleted and an error will be reported to the application software. This signal is meaningful only if hardware handshaking has been enabled.
7		Signal common.

# M/N 57C430, 57C431, and 57C435 (continued)

Pin #	I/O	Function
10	O	This signal is an isolated +12 Volt which can be used as an enable or equipment ready indicator. The signal is always on whenever power is applied to the Processor.
20	O	This signal indicates receiver status. The signal is true whenever the receiver can accept characters, i.e., when the receive buffer is not full. When the receive buffer fills to within a specified limit, the signal is turned off. The signal can be used to disable another transmitter. It is meaningful only when hardware handshaking has been enabled.

## LEDs

Color	LED	Description
green	BAT.OK	On-board battery status
green	OK	Module is operational

# Power Supply Module M/N 57C491 and M/N 57C493

## 57C491

Color	LED	Description
green	POWER	Power applied indicator
yellow	P/S READY	All voltages present
yellow	SYSTEM READY	All AutoMax Processors OK
red	BLOWN FUSE	Line fuse indicator (ON = open)


## 57C493

Color	LED	Description
green	POWER	Power applied indicator
red	FAULT	AutoMax Processor watch-dog is not present or output voltage is out of range

# Local I/O Head

## M/N 61C22 and 61C23

The ports on the 61C22 can connect to four Digital Rails. Note that input cards and output cards cannot be mixed on the same Rail. Electronic input cards cannot be used with the 61C22.




### LEDs

Color	LED	Description
green	POWER	Power ON indicator
green	COMM	Comm. w/host OK
red	RAIL FAULT 0	Rail 0 fault
red	RAIL FAULT 1	Rail 1 fault
red	RAIL FAULT 2	Rail 2 fault
red	RAIL FAULT 3	Rail 3 fault



# 4-Input 4-20 mA Analog Rail Module M/N 61C345

**Registers 0, 1, 2 and 3 (READ only)**



## LEDs


Color	LED	Description
green	POWER OK	All req'd power present
green	COMM OK	Communication w/host OK

Note that the MODE switch must always select local head mode for operation with the DCS/AutoMax Remote Head.

Term.	Signal	Description	Reg.
1	0 to 20 mA	Input Channel 0	0
2	0	Common Channel 0	
3		N/C	
4	0 to 20 mA	Input Channel 1	1
5	0	Common Channel 1	
6		N/C	
7	0 to 20 mA	Input Channel 2	2
8	0	Common Channel 2	
9		N/C	
10	0 to 20 mA	Input Channel 3	3
11	0	Common Channel 3	
12		N/C	

# 4-Input 0-10 V Analog Rail Module M/N 61C346

**Registers 0, 1, 2 and 3 (READ only)**



# M/N 61C346 (continued)

## LEDs


Color	LED	Description
green	POWER OK	All req'd power present
green	COMM OK	Communication w/host OK

Note that the MODE switch must always select local head mode for operation with the DCS/AutoMax Remote Head.


Term.	Signal	Description	Reg.
1	0 to 10 V	Input Channel 0	0
2	0	Common Channel 0	
3		N/C	
4	0 to 10 V	Input Channel 1	1
5	0	Common Channel 1	
6		N/C	
7	0 to 10 V	Input Channel 2	2
8	0	Common Channel 2	
9		N/C	
10	0 to 10 V	Input Channel 3	3
11	0	Common Channel 3	
12		N/C	

## 2-In/2-Out 0-10 V Analog Rail Module M/N 61C350

### Registers 0 and 1



### Registers 2 and 3 (READ only)



# M/N 61C350 (continued)

## LEDs


Color	LED	Description
green	POWER OK	All req'd power present
green	COMM OK	Communication w/host OK

Note that the MODE switch must always select local head mode for operation with the DCS/AutoMax Remote Head.


Term.	Signal	Description	Reg.
1	0 to 10 V	Output Channel 0	0
2	0	Common Channel 0	
3		N/C	
4	0 to 10 V	Output Channel 1	1
5	0	Common Channel 1	
6		N/C	
7	0 to 10 V	Output Channel 2	2
8	0	Common Channel 2	
9		N/C	
10	0 to 10 V	Output Channel 3	3
11	0	Common Channel 3	
12		N/C	

## 2-In/2-Out 4-20 mA Analog Rail Module M/N 61C351

### Registers 0 and 1



### Registers 2 and 3 (READ only)



# M/N 61C351 (continued)

## LEDs


Color	LED	Description
green	POWER OK	All req'd power present
green	COMM OK	Communication w/host OK

Note that the MODE switch must always select local head mode for operation with the DCS/AutoMax Remote Head.

Term.	Signal	Description	Reg.
1	4 to 20 mA	Output Channel 0	0
2	0	Common Channel 0	
3		N/C	
4	4 to 20 mA	Output Channel 1	1
5	0	Common Channel 1	
6		N/C	
7	4 to 20 mA	Output Channel 2	2
8	0	Common Channel 2	
9		N/C	
10	4 to 20 mA	Output Channel 3	3
11	0	Common Channel 3	
12		N/C	

## 4 Output 4-20 mA Analog Rail Module M/N 61C365

### Registers 0, 1, 2 and 3 (READ only)



## LEDs

Color	LED	Description
green	POWER OK	All req'd power present
green	COMM OK	Communication w/host OK


Note that the MODE switch must always select local head mode for operation with the DCS/AutoMax Remote Head.

# M/N 61C365 (continued)

Term.	Signal	Description	Reg.
1	4 to 20 mA	Output Channel 0	0
2	0	Common Channel 0	
3		N/C	
4	4 to 20 mA	Output Channel 1	1
5	0	Common Channel 1	
6		N/C	
7	4 to 20 mA	Output Channel 2	2
8	0	Common Channel 2	
9		N/C	
10	4 to 20 mA	Output Channel 3	3
11	0	Common Channel 3	
12		N/C	

## 4 Output 0-10 V Analog Rail Module M/N 61C366

### Registers 0, 1, 2 and 3 (READ only)



### LEDs

Color	LED	Description
green	POWER OK	All req'd power present
green	COMM OK	Communication w/host OK

Note that the MODE switch must always select local head mode for operation with the DCS/AutoMax Remote Head.

# M/N 61C366 (continued)

Term.	Signal	Description	Reg.
1	0 to 10 V	Output Channel 0	0
2	0	Common Channel 0	
3		N/C	
4	0 to 10 V	Output Channel 1	1
5	0	Common Channel 1	
6		N/C	
7	0 to 10 V	Output Channel 2	2
8	0	Common Channel 2	
9		N/C	
10	0 to 10 V	Output Channel 3	3
11	0	Common Channel 3	
12		N/C	

## 115 V AC Input Module M/N 61C500

### Register 0 (READ only)

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R

Term.	Signal	Description	Reg.
1	0 to 115 V AC	Signal Input	Reg 0, Bit 0
2	0 to 115 V AC	Signal Input	Reg 0, Bit 1
3	0 to 115 V AC	Signal Input	Reg 0, Bit 2
4	0 to 115 V AC	Signal Input	Reg 0, Bit 3
5	0 V AC	Isolated Common for bits 0 through 3	
6	0 to 115 V AC	Signal Input	Reg 0, Bit 4
7	0 to 115 V AC	Signal Input	Reg 0, Bit 5
8	0 to 115 V AC	Signal Input	Reg 0, Bit 6
9	0 to 115 V AC	Signal Input	Reg 0, Bit 7
10	0 V AC	Isolated Common for bits 4 through 7	
11	0 to 115 V AC	Signal Input	Reg 0, Bit 8
12	0 to 115 V AC	Signal Input	Reg 0, Bit 9
13	0 to 115 V AC	Signal Input	Reg 0, Bit 10
14	0 to 115 V AC	Signal Input	Reg 0, Bit 11
15	0 V AC	Isolated Common for bits 8 through 11	
16	0 to 115 V AC	Signal Input	Reg 0, Bit 12
17	0 to 115 V AC	Signal Input	Reg 0, Bit 13
18	0 to 115 V AC	Signal Input	Reg 0, Bit 14
19	0 to 115 V AC	Signal Input	Reg 0, Bit 15
20	0 V AC	Isolated Common for bits 12 through 15	

Input data is contained in Register 0.

# 24 V AC/DC Input Module

## M/N 61C515

### Register 0 (READ only)

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R

Term.	Signal	Description	Reg.
1	0 to 24 V AC/DC	Signal Input	Reg 0, Bit 0
2	0 to 24 V AC/DC	Signal Input	Reg 0, Bit 1
3	0 to 24 V AC/DC	Signal Input	Reg 0, Bit 2
4	0 to 24 V AC/DC	Signal Input	Reg 0, Bit 3
5	0 V AC	Isolated Common for bits 0 through 3	
6	0 to 24 V AC/DC	Signal Input	Reg 0, Bit 4
7	0 to 24 V AC/DC	Signal Input	Reg 0, Bit 5
8	0 to 24 V AC/DC	Signal Input	Reg 0, Bit 6
9	0 to 24 V AC/DC	Signal Input	Reg 0, Bit 7
10	0 V AC	Isolated Common for bits 4 through 7	
11	0 to 24 V AC/DC	Signal Input	Reg 0, Bit 8
12	0 to 24 V AC/DC	Signal Input	Reg 0, Bit 9
13	0 to 24 V AC/DC	Signal Input	Reg 0, Bit 10
14	0 to 24 V AC/DC	Signal Input	Reg 0, Bit 11
15	0 V AC	Isolated Common for bits 8 through 11	
16	0 to 24 V AC/DC	Signal Input	Reg 0, Bit 12
17	0 to 24 V AC/DC	Signal Input	Reg 0, Bit 13
18	0 to 24 V AC/DC	Signal Input	Reg 0, Bit 14
19	0 to 24 V AC/DC	Signal Input	Reg 0, Bit 15
20	0 V AC	Isolated Common for bits 12 through 15	

Input data is contained in Register 0.

# Current Input Module

## M/N 61C540

Register Number	Description	Access
0	Channel 0 A/D Data	R
1	Channel 1 A/D Data	R
2	Channel 2 A/D Data	R
3	Channel 3 A/D Data	R
4	Channel 4 A/D Data	R
5	Channel 5 A/D Data	R
6	Channel 6 A/D Data	R
7	Channel 7 A/D Data	R
8	Channel 8 A/D Data	R
9	Channel 9 A/D Data	R
10	Channel 10 A/D Data	R
11	Channel 11 A/D Data	R
12	Channel 12 A/D Data	R
13	Channel 13 A/D Data	R
14	Channel 14 A/D Data	R
15	Channel 15 A/D Data	R
16	High High Alarm Status	R
17	High Alarm Status	R
18	Low Alarm Status	R
19	Low Low Alarm Status	R
20	Out of Range Status	R
21	Channel Configuration Status	R
22	Configuration Status	R
23	Channel Number	R/W
24	Maximum Scaling Value	R/W
25	Minimum Scaling Value	R/W
26	Number of Samples	R/W
27	High High Alarm	R/W
28	High Alarm	R/W
29	Low Alarm	R/W
30	Low Low Alarm	R/W
31	Configuration Command	R/W



# Current Input Module

## M/N 61C540 (continued)

Terminal Block Label	Current Input Function
V1	Primary Power Source for Current Loops
G1	Primary Power Source Return
0A	Current Loop 0: Power
0B	Current Loop 0: 4-20 mA Input
S	Current Loop 0: Cable Shield
S	Current Loop 1: Cable Shield
1A	Current Loop 1: Power
1B	Current Loop 1: 4-20 mA Input
2A	Current Loop 2: Power
2B	Current Loop 2: 4-20 mA Input
S	Current Loop 2: Cable Shield
S	Current Loop 3: Cable Shield
3A	Current Loop 3: Power
3B	Current Loop 3: 4-20 mA Input
4A	Current Loop 4: Power
4B	Current Loop 4: 4-20 mA Input
S	Current Loop 4: Cable Shield
S	Current Loop 5: Cable Shield
5A	Current Loop 5: Power
5B	Current Loop 5: 4-20 mA Input
6A	Current Loop 6: Power
6B	Current Loop 6: 4-20 mA Input
S	Current Loop 6: Cable Shield
S	Current Loop 7: Cable Shield
7A	Current Loop 7: Power
7B	Current Loop 7: 4-20 mA Input
8A	Current Loop 8: Power
8B	Current Loop 8: 4-20 mA Input
S	Current Loop 8: Cable Shield
S	Current Loop 9: Cable Shield
9A	Current Loop 9: Power
9B	Current Loop 9: 4-20 mA Input
10A	Current Loop 10: Power
10B	Current Loop 10: 4-20 mA Input
S	Current Loop 10: Cable Shield
S	Current Loop 11: Cable Shield
11A	Current Loop 11: Power
11B	Current Loop 11: 4-20 mA Input
12A	Current Loop 12: Power
12B	Current Loop 12: 4-20 mA Input
S	Current Loop 12: Cable Shield
S	Current Loop 13: Cable Shield
13A	Current Loop 13: Power
13B	Current Loop 13: 4-20 mA Input
14A	Current Loop 14: Power
14B	Current Loop 14: 4-20 mA Input
S	Current Loop 14: Cable Shield
S	Current Loop 15: Cable Shield
15A	Current Loop 15: Power
15B	Current Loop 15: 4-20 mA Input
V2	Back-up Power Source for Current Loops
G2	Back-up Power Source Return

# Voltage Input Module

## M/N 61C542

Register Number	Description	Access
0	Channel 0 A/D Data	R
1	Channel 1 A/D Data	R
2	Channel 2 A/D Data	R
3	Channel 3 A/D Data	R
4	Channel 4 A/D Data	R
5	Channel 5 A/D Data	R
6	Channel 6 A/D Data	R
7	Channel 7 A/D Data	R
8	Channel 8 A/D Data	R
9	Channel 9 A/D Data	R
10	Channel 10 A/D Data	R
11	Channel 11 A/D Data	R
12	Channel 12 A/D Data	R
13	Channel 13 A/D Data	R
14	Channel 14 A/D Data	R
15	Channel 15 A/D Data	R
16	High High Alarm Status	R
17	High Alarm Status	R
18	Low Alarm Status	R
19	Low Low Alarm Status	R
20	Out of Range Status	R
21	Channel Configuration Status	R
22	Configuration Status	R
23	Channel Number	R/W
24	Maximum Scaling Value	R/W
25	Minimum Scaling Value	R/W
26	Number of Samples	R/W
27	High High Alarm	R/W
28	High Alarm	R/W
29	Low Alarm	R/W
30	Low Low Alarm	R/W
31	Configuration Command	R/W

# Voltage Input Module

## M/N 61C542 (continued)

Terminal Block Label	Voltage Input Function
0A	Voltage Circuit 0: Analog Common
0B	Voltage Circuit 0: $\pm 10V$ Input
S	Voltage Circuit 0: Cable Shield
S	Voltage Circuit 1: Cable Shield
1A	Voltage Circuit 1: Analog Common
1B	Voltage Circuit 1: $\pm 10V$ Input
2A	Voltage Circuit 2: Analog Common
2B	Voltage Circuit 2: $\pm 10V$ Input
S	Voltage Circuit 2: Cable Shield
S	Voltage Circuit 3: Cable Shield
3A	Voltage Circuit 3: Analog Common
3B	Voltage Circuit 3: $\pm 10V$ Input
4A	Voltage Circuit 4: Analog Common
4B	Voltage Circuit 4: $\pm 10V$ Input
S	Voltage Circuit 4: Cable Shield
S	Voltage Circuit 5: Cable Shield
5A	Voltage Circuit 5: Analog Common
5B	Voltage Circuit 5: $\pm 10V$ Input
6A	Voltage Circuit 6: Analog Common
6B	Voltage Circuit 6: $\pm 10V$ Input
S	Voltage Circuit 6: Cable Shield
S	Voltage Circuit 7: Cable Shield
7A	Voltage Circuit 7: Analog Common
7B	Voltage Circuit 7: $\pm 10V$ Input
8A	Voltage Circuit 8: Analog Common
8B	Voltage Circuit 8: $\pm 10V$ Input
S	Voltage Circuit 8: Cable Shield
S	Voltage Circuit 9: Cable Shield
9A	Voltage Circuit 9: Analog Common
9B	Voltage Circuit 9: $\pm 10V$ Input
10A	Voltage Circuit 10: Analog Common
10B	Voltage Circuit 10: $\pm 10V$ Input
S	Voltage Circuit 10: Cable Shield
S	Voltage Circuit 11: Cable Shield
11A	Voltage Circuit 11: Analog Common
11B	Voltage Circuit 11: $\pm 10V$ Input
12A	Voltage Circuit 12: Analog Common
12B	Voltage Circuit 12: $\pm 10V$ Input
S	Voltage Circuit 12: Cable Shield
S	Voltage Circuit 13: Cable Shield
13A	Voltage Circuit 13: Analog Common
13B	Voltage Circuit 13: $\pm 10V$ Input
14A	Voltage Circuit 14: Analog Common
14B	Voltage Circuit 14: $\pm 10V$ Input
S	Voltage Circuit 14: Cable Shield
S	Voltage Circuit 15: Cable Shield
15A	Voltage Circuit 15: Analog Common
15B	Voltage Circuit 15: $\pm 10V$ Input

# RTD Module M/N 61C544

Register Number	Description	Access
0	Channel 0 A/D Data	R
1	Channel 1 A/D Data	R
2	Channel 2 A/D Data	R
3	Channel 3 A/D Data	R
4	Channel 4 A/D Data	R
5	Channel 5 A/D Data	R
6	Channel 6 A/D Data	R
7	Channel 7 A/D Data	R
8	Channel 8 A/D Data	R
9	Channel 9 A/D Data	R
10	Channel 10 A/D Data	R
11	Channel 11 A/D Data	R
12	Channel 12 A/D Data	R
13	Channel 13 A/D Data	R
14	Channel 14 A/D Data	R
15	Channel 15 A/D Data	R
16	High High Alarm Status	R
17	High Alarm Status	R
18	Low Alarm Status	R
19	Low Low Alarm Status	R
20	Out of Range Status	R
21	Channel Configuration Status	R
22	Configuration Status	R
23	Channel Number	R/W
24	Reserved	
25	Reserved	
26	Number of Samples	R/W
27	High High Alarm	R/W
28	High Alarm	R/W
29	Low Alarm	R/W
30	Low Low Alarm	R/W
31	Configuration Command	R/W

# RTD Module

## M/N 61C544 (continued)

Term. Block	RTD Function	RTD Function
Pin Number	Ch. 0-7 D-Shell	Ch. 8-15 D-Shell
1	Current Out Ch. 0	Current Out Ch. 8
2	Current Return Ch. 0	Current Return Ch. 8
3	RTD Voltage (+) Ch. 0	RTD Voltage (+) Ch. 8
4	RTD Voltage (-) Ch. 0	RTD Voltage (-) Ch. 8
5	Shield	Shield
6	Shield	Shield
7	Current Out Ch. 1	Current Out Ch. 9
8	Current Return Ch. 1	Current Return Ch. 9
9	RTD Voltage (+) Ch. 1	RTD Voltage (+) Ch. 9
10	RTD Voltage (-) Ch. 1	RTD Voltage (-) Ch. 9
11	Current Out Ch. 2	Current Out Ch. 10
12	Current Return Ch. 2	Current Return Ch. 10
13	RTD Voltage (+) Ch. 2	RTD Voltage (+) Ch. 10
14	RTD Voltage (-) Ch. 2	RTD Voltage (-) Ch. 10
15	Shield	Shield
16	Shield	Shield
17	Current Out Ch. 3	Current Out Ch. 11
18	Current Return Ch. 3	Current Return Ch. 11
19	RTD Voltage (+) Ch. 3	RTD Voltage (+) Ch. 11
20	RTD Voltage (-) Ch. 3	RTD Voltage (-) Ch. 11
21	Current Out Ch. 4	Current Out Ch. 12
22	Current Return Ch. 4	Current Return Ch. 12
23	RTD Voltage (+) Ch. 4	RTD Voltage (+) Ch. 12
24	RTD Voltage (-) Ch. 4	RTD Voltage (-) Ch. 12
25	Shield	Shield
26	Shield	Shield
27	Current Out Ch. 5	Current Out Ch. 13
28	Current Return Ch. 5	Current Return Ch. 13
29	RTD Voltage (+) Ch. 5	RTD Voltage (+) Ch. 13
30	RTD Voltage (-) Ch. 5	RTD Voltage (-) Ch. 13
31	Current Out Ch. 6	Current Out Ch. 14
32	Current Return Ch. 6	Current Return Ch. 14
33	RTD Voltage (+) Ch. 6	RTD Voltage (+) Ch. 14
34	RTD Voltage (-) Ch. 6	RTD Voltage (-) Ch. 14
35	Shield	Shield
36	Shield	Shield
37	Current Out Ch. 7	Current Out Ch. 15
38	Current Return Ch. 7	Current Return Ch. 15
39	RTD Voltage (+) Ch. 7	RTD Voltage (+) Ch. 15
40	RTD Voltage (-) Ch. 7	RTD Voltage (-) Ch. 15

# 8-Channel Isolated Thermocouple and Low Level Input Module M/N 61C605


## Memory Map

Hex Bus Address	Function	Register Name	Description
2S0000 2S0000	Write Read	Data ready	Interrupt enable Read data ready status
2S0001	Write	Command	Write analog data command
2S0001	Read	Status	Read analog data status
2S0002	Read	A/D data (low)	Read analog data low byte
2S0003	Read	A/D data (high)	Read analog data high byte

Note: The 61C605 is programmed using BASIC IOWRITE statements and IOREAD% functions.


## Data Ready Register

LOCATION: BASE + 0



## Command Register


LOCATION: BASE + 1



# M/N 61C605 (continued)

## Status Register

LOCATION: BASE + 1



Term.	Description
1	N/C
2	N/C
3	N/C
4	Channel 0 High
5	Channel 0 Low
6	- 12 V DC
7	Channel 1 High
8	Channel 1 Low
9	- 12 V DC
10	Channel 2 High
11	Channel 2 Low
12	- 12 V DC
13	Channel 3 High
14	Channel 3 Low
15	- 12 V DC
16	N/C
17	N/C
18	N/C
19	N/C
20	Ground
21	Ground
22	N/C
23	Channel 4 High
24	Channel 4 Low
25	- 12 V DC
26	Channel 5 High
27	Channel 5 Low
28	- 12 V DC
29	Channel 6 High
30	Channel 6 Low
31	- 12 V DC
32	Channel 7 High
33	Channel 7 Low
34	- 12 V DC
35	N/C
36	N/C

N/C = no connection.

# 16-Channel Analog Input Module M/N 61C613

## Register Assignments

- Location (M+0) Status/error from module;  
command from software
- Location (M+1) Command from software
- Location (M+2) Return value from module or  
software
- Location (M+3) Not ready/ready from module

M = base address in Multibus (byte) format.

Note that these registers cannot be monitored.

Term.	Signal	Description
1		N/C
2	+ Signal	Channel 0
3	- Signal	Channel 0
4		N/C
5		N/C
6		N/C
7		N/C
8	+ Signal	Channel 1
9	- Signal	Channel 1
10		N/C
11		N/C
12		N/C
13		N/C
14	+ Signal	Channel 2
15	- Signal	Channel 2
16		N/C
17		N/C
18		N/C
19		N/C
20	+ Signal	Channel 3
21	- Signal	Channel 3
22		N/C
23		N/C
24		N/C
25		N/C
26	+ Signal	Channel 4
27	- Signal	Channel 4
28		N/C
29		N/C
30		N/C
31		N/C
32	+ Signal	Channel 5
33	- Signal	Channel 5
34		N/C
35		N/C
36		N/C



# M/N 61C613 (continued)

<b>Term.</b>	<b>Signal</b>	<b>Description</b>
37		N/C
38	+ Signal	Channel 6
39	- Signal	Channel 6
40		N/C
41		N/C
42		N/C
43		N/C
44	+ Signal	Channel 7
45	- Signal	Channel 7
46		N/C
47		N/C
48		N/C
49	+ Signal	Temp Sensor
50	- Signal	Temp Sensor

Terminal layout is shown for second connector; third connector has same layout (add 8 to Channel designation numbers above). Note that the first connector is not used.



# **Section III Programming Reference**



# BASIC

## Language Quick Reference

This section is an alphabetical listing of statements and functions in Reliance® Enhanced BASIC Language. The format of each listing is organized as follows. Each listing begins with the keyword. The line following the keyword begins with a letter designation indicating the type of instruction:

- (s) = BASIC statement (may be allowed in CONTROL BLOCK also)
- (f) = BASIC function (may be allowed in CONTROL BLOCK also)
- (c) = BASIC configuration task statement (for AutoMax versions up to and including 2.1)

After the letter designation comes a description of the listing and the format of the listing. Fields in capital letters must be entered as shown. This includes any special characters attached to fields, e.g., "%". Fields shown in lower-case represent specific information the programmer must enter in upper-case. Note that the underscore character "\_" is a valid alphanumeric character used for clarification purposes only, i.e., to divide words at logical points.

Example:

The function

```
BLOCK__MOVE@(source%, dest%, size)
```

could be implemented in an IF-THEN-ELSE statement in the following manner:

```
1000 IF BLOCK__MOVE@(NETW__1__32%, NETW__2__32%, 32) THEN
    STOP
    ELSE
        11000
    END_IF
```

Following the listing format is a description of the fields the programmer must enter and the variable types permitted. At the very end of each listing is an example.

For detailed information about the BASIC language, refer to J-3675.

### Variable Types

Five types of variables are used in BASIC:

1. Single integer (16-bit) variables (value range -32768 — +32767)  
Terminating character: %
2. Double integer (32-bit) variables (value range -2147483648 — +2147483648)  
Terminating character: !

3. Real variables (value range  $9.2233717 \times 10^{18}$  to  $5.4210107 \times 10^{-20}$  and  $-9.2233717 \times 10^{18}$  to  $-2.7105054 \times 10^{-20}$ )  
Terminating character: none
4. Boolean (1 bit) variables [value range TRUE (ON) or FALSE (OFF)]  
Terminating character: @
5. String variables (value range 1 — 255 characters, must begin with letter or underscore)  
Terminating character: \$

BASIC also permits array variables of up to four dimensions. Array subscripts must be positive integer variables or expressions in the range of 0 — 32767.

## BASIC Language Listing

### ABDEF

(c) Defines a variable for the Allen-Bradley® Interface module (M/N 57C418).

```
ABDEF var _name[SLOT=slot_number, FILE=file,           &
          REGISTER=register_number, BIT=bit_number]
var _name = integer, real or boolean variable name for register or bit; integers
and reals limited to integer files; booleans limited to binary
files
slot_number = slot number of the interface module
file = file designation for the dual port interface area; must be enclosed in single
or double quotes:
```

File	Register Number Range
B0=Binary file 0	0 <= 255
B1=Binary file 1	0 <= 255
N0=Integer file 0	0 <= 1023
N1=Integer file 1	0 <= 1023

```
register_number = register number within the file
bit_number = bit number (0 — 15) within the register; specified for booleans
only
```

### Example:

```
1000 ABDEF RETURN%(SLOT=8, FILE=N1, REGISTER=975)
```

### ABS

(f) Returns absolute value of an expression in real or integer format, depending upon input format.

```
ABS(expression)
expression = numeric (integer or real)
```

### Example:

```
1000 VALUE1=ABS(VALUE%*2)
```

### ASC%

(f) Returns decimal ASCII value of single character string.

```
ASC%(string)
string = string variable or expression
```

### Example:

```
1000 NUMBER%=ASC%(STRING1$)
```

## ATN

(f) Returns value (in real format) equal to arctangent of the input.

ATN(expression)

expression = numeric (integer or real) representing radians

Example:

```
1000 RADIANS=ATN(ANGLE)
```

## BCD\_IN%

(f) Returns decimal value of BCD input.

BCD\_IN%(expression)

expression = single or double variable or expression; value range ≤9999 hex

Example:

```
1000 SWITCH_VALUE%=BCD_IN%(INPUT_CARD%)
```

## BCD\_OUT%

(f) Returns BCD value of a decimal number.

BCD\_OUT%(expression)

expression = single or double variable or expression; value range ≤9999 hex

Example:

```
1000 IN_VALS=BCD_OUT%(SWITCH_VALS%)
```

## BINARY\$

(f) Returns the binary form of the input as a string of 1s and 0s.

BINARY\$(expression)

expression = integer or integer expression

Example:

```
1000 BIT$ = BINARY$(NUMBER_1%)
```

## BIT\_CLR@

(f) Tests if bit is OFF (FALSE) at specified bit position.

BIT\_CLR@(variable, bit\_number)

variable = single or double integer

bit\_number = bit within the variable to test; 0 — 15 for single integer, 0 — 31 for double integer

Example (in IF-THEN-ELSE statement):

```
1000 IF BIT_CLR@(BIT_VALS%,2) THEN
    2500
    ELSE
    3000
    END_IF
```

## BIT\_\_MODIFY@

(f) Sets or clears the specified bit in the specified variable based on the selected option. Function is TRUE if bit change operation is completed. Function is FALSE if bit change operation is not completed. FALSE can occur if the specified variable is forced or if the bit is already in the correct state.

BIT\_\_MODIFY@(variable, bit\_\_number, option)

variable = single or double integer variable

bit\_\_number = bit within the variable to test; 0 — 15 for single integer, 0 — 31 for double integer

option = defines the change to be made to the bit; integer or boolean expression

Option 0 = unconditionally set bit to 0

1 = unconditionally set bit to 1

2 = if bit is 0, then set to 1

3 = if bit is 1, then set to 0

Example (in IF-THEN-ELSE statement):

```
1000 IF BIT__MODIFY@(BIT__VALS%,2,SYSTEM__RUNNING@) THEN
    3000
    ELSE
    4000
END__IF
```

## BIT\_\_SET@

(f) Tests if specified bit is ON (TRUE).

BIT\_\_SET@(variable,bit\_\_number)

variable = single or double integer variable

bit\_\_number = bit within the variable to test; range 0 — 15 for single integer, 0 — 31 for double integer

Example (in IF-THEN-ELSE statement):

```
1000 IF BIT__SET@(BIT__VALS%,1) THEN
    2000
    ELSE
    3000
END__IF
```

## BLOCK\_\_MOVE@

(f) Moves a block of registers to and from the network.

BLOCK\_\_MOVE@(source, dest, size)

source = boolean, integer, double integer, or real variable or one-dimensional integer array specifying starting point of registers to move

dest = integer variable or one-dimensional array specifying starting point of area to which registers are to be moved

size = number of registers (16-bit words) to move

Example (in IF-THEN-ELSE statement):

```
1000 IF BLOCK__MOVE@(NETW__1__32%, NETW__2__32%, 32) THEN
    STOP
    ELSE
    11000
END__IF
```



## CHR\$

(f) Returns a string character equal to decimal ASCII value of the input expression.

CHR\$(expression)

expression = integer (hexadecimal equivalent permitted; must be terminated with H)

Example:

```
1000 A$=CHR$(41H)
```

## CLOSE

(s) De-allocates a channel or port.

CLOSE #device\_number

device\_number = logically assigned (through OPEN statement) device number; range 1 — 255

Example:

```
1000 CLOSE #1
```

## CLR\_ERRLOG

(f) Clears the entire error log for the task, regardless of the number of logged errors.

CLR\_ERRLOG

Example:

```
1000 CLR_ERRLOG
```

## COMMON

(s) Defines a common variable accessible to all tasks in the system.

COMMON variable

variable = simple or subscripted variable of any type; more than one variable is permitted in the statement if separated by commas; string variable length can be specified by adding the following immediately after the variable, or directly between the variable and the array specification:

:n

where n is the maximum string length (range 1 — 255); if not specified, default maximum is 31.

Example:

```
1000 COMMON COIL@, STRING5:15(100), NUM2!
```

## CONVERT%

(f) Converts data formats

CONVERT% (src\_variable, src\_subscript, dest\_variable, dest\_subscript, & num\_of\_words, mode)

src\_variable = the variable that selects where to get data from. This parameter may be a scalar or an array of any data type. If src\_variable is an array, it could be the base name and any data type character only.

src\_subscript = only used if the src\_variable is an array. It determines where in the array to begin reading. If not an array, the value should be 0.

dest\_variable = the variable that selects where to move the data. This parameter may be a scalar or an array of any data type. If dest\_variable is an array, it should only be the base name and any data type character.

dest\_subscript = only used if destination\_variable is an array. It determines where in the array to begin writing. If not an array, the value should be 0.

num\_of\_words = selects the number of words to move.  
mode = determines the mode of operation.

Value	Function
0	Move data with no change in format
1	Convert from Motorola Floating Point to IEEE format
2	Convert from IEEE Floating Point to Motorola format
4	Word swap (0102H to 0201H)
8	Long word swap (01020304H to 04030201H)
9	Motorola to IEEE followed by long word swap
10	Long word swap followed by IEEE to Motorola

#### Example:

```
STATUS@ = CONVERT%(SRC_ARRAY, 10, DST_ARRAY, 20, 60, 9)
```

## COS

(f) Returns value (in real format) equal to cosine of input.

```
COS(expression)
```

expression = numeric (integer or real) representing radians

#### Example:

```
1000 COS(ANGLE)
```

## DATA

(s) See READ-DATA.

## DELAY

(s) Delays program execution by specified time period.

```
DELAY n units
```

n = arithmetic expression or constant that is evaluated to an integer result  
units = type of unit to delay program execution; available units are HOURS, MINUTES, SECONDS, and TICKS (1 TICK = 5.5 milliseconds)

#### Example:

```
1000 DELAY 5 TICKS
```

## END

(s) (c) Denotes physical end of program; required in Control Block programs.

```
END
```

#### Example:

```
20000 END
```

## EVENT NAME (software)

(s) Defines a software event; used with SET and WAIT ON.

```
EVENT NAME = event_name
```

event\_name = symbolic name for an event

#### Example:

```
2000 EVENT_NAME = SW_EVENT_1
```

## EVENT NAME (hardware)

(s) Defines a hardware event; used with SET and WAIT.

```
EVENT NAME = event_name
INTERRUPT_STATUS = I/O_variable
TIMEOUT = timeout_count
```

event\_name = symbolic name given to particular event  
I/O\_variable = name of a common symbol that references the address of an interrupt register on a module that handles interrupts  
timeout\_count = specifies the maximum amount of time that can pass before a hardware event occurs; range 1 — 32767 ticks (1 tick = 5.5 milliseconds)

Example:

```
1000 EVENT NAME = MARKER_PULSE
      INTERRUPT_STATUS = RESOLVER_INTREG%
      TIMEOUT = 100
```

## EXP

(f) Returns a real value equal to (e \*\* expression), where e = 2.71828.

```
EXP(expression)
expression = numeric (integer or real) expression
```

Example:

```
1000 NUMBER = EXP(2*3)
```

## FINDVAR!

(f) Accepts a variable name as a string expression and returns a pointer to that variable.

```
FINDVAR!(varname$)
varname$ = a string expression for the name of the variable to find.
```

Example:

```
POINTER! = FINDVAR!(VARIABLE_NAMES)
```

## FIX

(f) Returns the whole part of a real number.

```
FIX(expression)
expression = a real variable or expression
```

Example:

```
1000 WHOLE_PART = FIX(REAL_VALUE)
```

## FOR-NEXT

(s) Performs repetitive program looping based on parameters specified.

```
FOR variable = expression_1 TO expression_2,           &
                STEP expression_3
```

```
...
...
NEXT variable
```

variable = simple numeric variable used as loop index  
expression\_1 = initial value of index; any numeric expression  
expression\_2 = terminating value of index; any numeric expression  
expression\_3 = optional; incremental value of index; any numeric expression; default is +1

Example:

```
1000 FOR M% = 1100 TO 1500 STEP 100
...
...
3000 NEXT M%
```

## GATEWAY\_CMD\_OK@

(f) Boolean function used for register transfers to interface modules. Used with VARPTR! function.

```
GATEWAY_CMD_OK@(status,cmd_code,slave_drop,
                 slave_reg,master_var,num_regs)
                                     &
status = integer variable name where gateway command is stored
cmd_code = variable name or expression representing command sent to interface module; must be type integer
slave_drop = variable name or expression of type integer; device address of the slave for which the command is intended
slave_reg = a string variable or expression describing the starting register in the slave that is to be read or written
master_var = variable name (using VARPTR! function) or expression representing the address of the first register in the master from or to which data is to be written; must be type double integer
num_regs = variable name or expression defining the number of registers to be transferred; must be of type integer
```

Example (including VARPTR! function, in IF-THEN-ELSE statement):

```
1500 MSTR_REG! = VARPTR!(MASTER)
2000 IF NOT GATEWAY_CMD_OK@(RET_STAT1%,MOD_REG%,
                             SLVDROP%,SLVREG$,MSTR_REG!,XFER_SIZE%) THEN
                                     &
                                     &
                                     &
                                     &
                                     &
                                     &
2500
ELSE
3000
END_IF
```

## GBLDEF

(c) Defines common variables accessed through the Network Communications module (M/N 57C404 or M/N 57C404A). Position information is stored in a separate file with the extension .NET.

```
GBLDEF variable {SLOT=s[, NETWORK="n"]
[, NET_NAME=name]}
```

variable = the name that will be used in this drop to reference the network variable; all variable types except string are supported; although reals and double integer variables can also be used, it is strongly recommended that they be avoided because of the possibility that all 32 bits will not transfer in one operation.

s = slot that contains the Network Communication module (M/N 57C404 or 57C404A) in this rack; range 0-15.

n = name of the .NET file from which to extract the rest of the definition for this variable; range is a single letter from A to Z in quotation marks; if not specified, default is A.

name = the name that will be used on the network to reference the network variable; this field is used only when you want the name of the network variable to be different on the network ("name" in the .NET file) than it is in this rack; the name must be unique within the network; if the field is not specified, the default is "variable".

Example:

```
60 GBLDEF REF_1% [SLOT=3, NETWORK="B", NET_NAME=SPEED%]
```

## GET

(s) Inputs a single character from a device into a string variable.

```
GET #n:EMPTY=m, string__variable
```

n = the logical number assigned to a device using an OPEN statement; if not entered, default is PORTA on the Processor module on which the task resides

m = :EMPTY=m is an optional parameter; m specifies line number to which to transfer control if the channel is empty

string\_\_variable = a string variable which will be loaded with one character from the device

Example:

```
1000 GET #2:EMPTY=1100, A$
```

## GOSUB-RETURN

(s) GOSUB unconditionally transfers program control to the specified line number until RETURN statement. RETURN returns program control to first numbered program line following the GOSUB or ON GOSUB statement that caused program control to be diverted to a particular error-handling routine.

```
GOSUB n
```

```
...
```

```
...
```

```
RETURN
```

n = integer or integer expression representing line number

Example:

```
1000 GOSUB 2000
```

```
...
```

```
...
```

```
3000 RETURN
```

## GOTO

(s) Unconditionally transfers program control to specified line number.

```
GOTO n
```

n = integer or expression representing line number

Example:

```
1000 GOTO 2000
```

## HEX\$

(f) Returns the hexadecimal value of the input as a string.

```
HEX$(expression)
```

expression = integer or integer expression

Example:

```
1000 HEX__VAL$ = HEX$(X%)
```

## INCLUDE

(s) Inserts a DOS file containing statements into the task as it is compiling.

```
INCLUDE "filename.INC"
```

filename = name of the DOS file containing the statements to be included; drive and subdirectory specification cannot be included; the file itself must have only one statement per line and must not have line numbers as these will be generated by the compiler in increments of 1, beginning with the INCLUDE statement line number; no INCLUDE statements are permitted in the file itself; the extension .INC is required in the filename

Example:

```
1000 INCLUDE "IODEFS.INC"
```

## IF-THEN-ELSE

(s) Conditionally executes statements following THEN or transfers program control based on the results of the relational expression. If the expression is true, the statement following THEN is executed. If the expression is false, the statement following ELSE is executed.

```
IF boolean_exp THEN
    statement
ELSE
    statement
END_IF
```

boolean\_exp = boolean variable or relational expression; if this parameter must be extended to the second line [and the ampersand (&) added to the end of the line to indicate it continues], all of the following lines except the last must also include the & at the end

statement = either program line to be executed, or BASIC statement or series of statements separated by backslashes or colons

Example:

```
1000 IF (A > 3) THEN
    3000
ELSE
    A = 3
END_IF
```

## INPUT

(s) Reads data from a device or channel.

```
INPUT #n:EMPTY=m, input_list
```

n = optional; logical device number assigned using OPEN statement; range 1 — 255; default is Processor PORTA

m = parameter :EMPTY=m is optional and specified only for channels and not devices; specifies line number to which to transfer control if the channel is empty

input\_list = list of variables to be read, separated by commas; simple or subscripted variables

Example:

```
10000 INPUT #1:EMPTY=10200, A%,B%
```

## IODEF (standard addressing)

(c) Defines I/O in local rack using standard DCS5000/AutoMax addressing.

```
IODEF variable _name[SLOT=slot_number, REGISTER=reg_number, BIT=bit_number] &
```

variable\_name = integer, double integer or boolean variable  
slot\_number = slot number of the I/O module in the local chassis; range 0 — 15  
reg\_number = register number of the I/O module; range 0 — 32767 16-bit registers; default is 0 if not specified  
bit\_number = bit number in the register; specified for booleans only; range 0 — 15

### Example:

```
1000 IODEF DIGITAL_IN%[SLOT=3, REGISTER=1, BIT=4]
```

## IODEF (hexadecimal addressing)

(c) Defines I/O in a local rack using hexadecimal addressing.

```
IODEF variable _name[ADDRESS=hex_addressH, BIT=bit_number]
```

hex\_address = specific hexadecimal address of the I/O location; must be a word (16 bits) or even address with the lower order bit equal to zero; the address always starts with 2, followed by the hexadecimal slot number and the four-digit hexadecimal byte number  
variable\_name = integer, double integer or boolean variable  
bit\_number = bit number in the register; specified for booleans only; range 0 — 15

### Example:

```
1000 IODEF RELAY_1@[ADDRESS=260000H,BIT=1]
```

## IOREAD%

(f) Returns an integer value obtained by reading data from an I/O module.

```
IOREAD%(option,addressH)
```

option = integer variable or expression that defines the type of READ access to perform

- option 1 = byte read
- option 2 = double byte read:
  - address = LSB
  - address + 1 = MSB
  - (used for foreign I/O modules only)
- option 3 = double byte read:
  - address = MSB
  - address + 1 = LSB
- option 4 = 32-bit word read:
  - address = MSB
  - address + 1 = next byte
  - address + 2 = next byte
  - address + 3 = LSB

address = double integer variable or expression that contains the address data is to be read from; range  $\geq 220000H$

### Example:

```
1000 X%=IOREAD%(2, 220000H)
```

## IOWRITE

(s) Outputs data to an I/O module.

IOWRITE%(option, data, addressH)

option = integer variable or expression that defines the type of READ access to perform

option 1 = byte read

option 2 = double byte read:

address = LSB

address + 1 = MSB

(used for foreign I/O modules only)

option 3 = double byte read:

address = MSB

address + 1 = LSB

option 4 = 32-bit word read:

address = MSB

address + 1 = next byte

address + 2 = next byte

address + 3 = LSB

data = integer variable name or expression defining data to output

address = double integer variable or expression that contains the address data is to be read from; range  $\geq 220000H$

Example:

```
1000 IOWRITE(3, DATA_1,230000H)
```

## LEFT\$

(f) Returns a substring of specified length from the leftmost portion of a string.

LEFT\$(string, string\_length)

string = a string variable or expression; string variables must be surrounded by single or double quotes

string\_length = the number of characters to take from the left side of the string

Example:

```
1000 SUB_STRING = LEFT$('ABCDEFG',4)
```

## LEN%

(f) Returns a value equal to the character length of the specified string variable or expression.

LEN%(string)

string = a string variable or expression

Example:

```
1000 LENGTH% = LEN%('STRING1')
```

## LET

(s) Assigns a value to a variable.

LET variable = expression

variable = simple or subscripted variable of any type

expression = constant or expression

Example:

```
1000 LET SPEED% = 25
```

## LN

(f) Returns a real value (in real format) equal to the natural log of the input.

LN(expression)

expression = numeric (integer or real) expression

Example:

```
1000 NATURAL_LOG = LN(REFERENCE! + GAIN%)
```



## LOCAL (simple or subscripted variable)

(s) Defines a variable used in the local application task only; opposite of COMMON.

LOCAL variable

variable = simple or subscripted variable of any type; more than one variable is permitted in the statement if separated by commas; string variable length can be specified by adding the following immediately after the variable, or directly between the variable and the array specification:

:n

where n is the maximum string length (range 1 — 255); if not specified, default maximum is 31.

### Example:

```
1000 LOCAL ABC%, STRING1$:50, STRING2$:10(100)
```

## LOCAL (tunable variable)

(s) Defines a tunable variable used in the local application task only.

```
LOCAL simple_variable[CURRENT=value_1,HIGH=value_2,           &  
                      LOW=value_3, STEP=value_4]
```

simple\_variable = tunable variable of integer, double integer or real type

value\_1 = initial current value

value\_2 = the highest value the variable can achieve

value\_3 = the lowest value the variable can achieve

value\_4 = the amount that the operator can change the value by incrementing or decrementing it through the executive software

### Example:

```
1000 LOCAL TENSION_GAIN%(CURRENT=25,HIGH=50,LOW=10,           &  
                          STEP=5]
```

## MEMDEF

(c) Defines common variables which do not have physical I/O associated with them. These variables are cleared (set to 0, FALSE, or OFF) during a STOP ALL condition.

MEMDEF variable

variable = simple or subscripted variable of any type; multiple variables are permitted if separated by commas

### Example:

```
1000 MEMDEF ERROR_MESSAGE$, SHEET_COUNT!
```

## MID\$

(f) Returns a substring from a string, starting and ending with the specified character positions.

MID\$(string, start, end)

string = string variable or expression; string variables must be surrounded by single or double quotation marks

start = starting character position of substring

end = ending character position of the substring

### Example:

```
1000 SUBSTRING_1$ = MID$('ABCDEFG',2,3)
```

## MODDEF

(c) Defines I/O accessed through the Modbus Interface module (M/N 57C414).

```
MODDEF var __name[SLOT=slot, REGISTER=register]
```

var \_\_name = integer or boolean variable

slot = slot number of the I/O module

register = register number on the I/O module; register value range:

integer variables: 30001 — 41024

boolean variables: 1 — 14096

Example:

```
1000 MODDEF COILREF%(SLOT=7,REGISTER=30001)
```

## NETDEF

(c) Defines common variables accessed through the Network Communications module (M/N 57C404 or M/N 57C404A).

```
NETDEF var __name[SLOT=slot,DROP=drop,REGISTER=register, &  
                BIT=bit]
```

var \_\_name = name of register or bit; integer or boolean variable

slot = slot number of Network module in the rack on which the task will run;  
range 0 — 15

drop = drop number of the network drop where var \_\_name is stored; range 0  
— 43

register = register number on the Network module on which var \_\_name is  
stored; range 0 — 63

bit = bit number of the bit in the register number on the Network module;  
range 0 — 15

Example:

```
1000 NETDEF LINEREF%(SLOT=6,DROP=0,REGISTER=32,BIT=0)
```

## NEXT

See FOR-NEXT.

## NVMEMDEF

(c) Defines common variables not associated with physical I/O and that retain their values in the event of a power failure or STOP ALL condition.

NVMEMDEF variable

variable = simple or subscripted variable of any data type; multiple variables  
are permitted if separated by commas

Example:

```
1000 NVMEMDEF REV__COUNT!, GEAR__RATIOS%(10,10)
```

## ON ERROR GOTO

(s) Unconditionally transfers program control to specified statement line if a non-fatal error occurs.

```
ON ERROR GOTO line __number
```

line \_\_number = line number where control should be transferred in the event  
of an error; typically where an error-handling routine begins

Example:

```
1000 ON ERROR GOTO 2000
```

## ON GOSUB

(s) Conditionally transfers program control to a subroutine at any one of the specified line numbers based on the result of an integer expression.

ON expression GOSUB line \_\_number

expression = integer variable or arithmetic expression that results in an integer value

line \_\_number = line number to which control is transferred depending upon the evaluated expression; multiple line numbers are separated by commas; see RETURN

### Example:

```
1000 ON GAIN% GOSUB 2000,3000,4000
```

## ON GOTO

(s) Conditionally transfers program control to one of the specified line numbers based on the result of an integer expression.

ON expression GOTO line \_\_number

expression = integer variable or arithmetic expression that results in an integer value; result determines which line number control is transferred to; if result = 1, control is transferred to first line number, etc.

line \_\_number = line number to which control is transferred depending upon the evaluated expression; multiple line numbers are separated by commas

### Example:

```
1000 ON A% GOTO 1100,1200,1300,1400
```

## OPEN

(s) Allocates a Processor port for exclusive use and equates a logical name with the port; used with INPUT and PRINT statements.

```
OPEN "device__name" AS FILE #n,SETUP=specs,baud__rate,      &  
ACCESS=status
```

device\_\_name = pre-assigned character string that defines the name for the device; PORTA or PORTB


n = number assigned to the port; range 1 — 255

specs = a hexadecimal word constant or integer expression that describes a bit pattern defining various characteristics for the device; see below for more information on this parameter

baud\_\_rate = baud rate of device

status = optional parameter; specifies whether this task has EXCLUSIVE or NON\_EXCLUSIVE access to the device; if EXCLUSIVE, no other task can read or write to the device until this task closes it (with CLOSE); if this parameter is specified as EXCLUSIVE, specs and baud\_\_rate must be enclosed in parentheses. If this parameter is specified as NON\_EXCLUSIVE, specs and baud\_\_rate cannot be specified in this statement. If not specified, the default is EXCLUSIVE

## Specifying the "specs" Parameter in OPEN Statements



0000 = Default Setting

## OPEN CHANNEL

(s) Equates a logical name with a data channel in the system, creating a data path between tasks. Allows tasks to communicate using the INPUT and PRINT statements. The OPEN CHANNEL statements in the tasks that are communicating must be exactly the same except for the depth parameter, which is specified only in tasks which want to input data from the channel.

```
OPEN CHANNEL FOR input_or_output AS FILE #n, TYPE=(type), &
DEPTH=depth
```

input\_or\_output = specifies whether the task is reading data from the channel (INPUT), or sending data through the channel (OUTPUT)

n = a logical number for that channel; range 1 - 255

type = list of different variable types that are to be passed through the channel; multiple types must be separated by commas:

- I = single integer
- D = double integer
- R = real
- S = string
- B = boolean

depth = how many messages a channel or data path can hold before it is considered full; integer constant or expression; specified only if the task is reading data from the channel, not writing

Example:

See J-3675 for more information.

## PRINT

(s) Outputs data to a device or channel; used with the OPEN statement.

```
PRINT #n:FULL=m, print_list
```

n = logical number assigned to device or channel using OPEN statement;  
range 1 — 255; if not specified, default is PORTA

m = :FULL=m is applicable only if n is a channel and not a device and is optional; m specifies the line number to which control is to be transferred if the channel is full

print\_list = list of data items to be printed separated by commas or semi-colons

### Example:

```
1000 PRINT #2, SPEED%, B%
```

## PRINT USING

(s) Outputs data to a device using the specified format.

```
PRINT USING #n, type_width:expression
```

n = logical number assigned to device or channel using OPEN statement;  
range 1 — 255; if not specified, default is PORTA

type\_width = format type followed by field width with no spaces between;  
format types:

L = left justify

R = right justify

C = center

Z = load leading zeros in front

D = print in decimal format

field width: integer or integer expression in the range 1 — 132;  
D format field width =

integer1.integer2

integer1 = total field width; range 3 — 132

integer2 = number of characters after the decimal; range 0 — 26

expression = variable expression; multiple expressions must have the type\_width parameter specified individually and must be separated by commas

### Example:

```
1000 PRINT USING #1, L40:STRING1$, D3.1:SPEED
```

## PUT

(s) Outputs a single character to a device.

```
PUT #n, string_variable$
```

n = the logical number assigned to a device using an OPEN statement; if not specified, default is PORTA

string\_variable = string variable

### Example:

```
1000 PUT #2, A$
```

## READ-DATA

(s) Inputs data from a list of values, expressions, literals, or strings in the DATA statements; also used with RESTORE.

```
READ variable
```

```
DATA expression
```

variable = simple or subscripted variable of any type; multiple variables must be separated by commas

expression = expression loaded into the corresponding variable in the READ statement; the type must match the variable type in the READ statement; string constants must be enclosed in single or double quotes

### Example:

```
1000 READ A%, C1!, Z$  
...  
...  
2000 DATA 2, (83+19), "OVERSPEED"
```

## READVAR%

(f) Accepts a variable name as a string and returns the value in variable VALUE. Requires the Ethernet™ operating system in the rack.

```
READVAR%(vn$,value)
```

vn\$ = a string expression for the name of the variable to read. It can be a boolean, integer, double integer, real or string, or an array of these types.

Only one-dimensional arrays are allowed.

value = the variable where the value read is written.

### Example:

```
STATUS% = READVAR%(VARIABLE__NAME$,value)
```

## REM and !

(s) Either statement can be used to document the program with comments and explanations. ! statements are downloaded with the task onto the Processor module if the task was compiled with the /Reconstruct option; these statements require 50 μsec. to execute. The task can then be fully reconstructed and uploaded back to the personal computer at a later date. REM statements are stripped out when the task is compiled.

```
REM comment
```

or

```
! comment
```

```
comment = any text
```

### Example:

```
1000 REM This is a non-reconstructible comment  
2000 !This is a reconstructible comment
```

## RESTORE

(s) Restores internal data pointer to the first data item of the first DATA statement or to the first data item of the specified DATA statement line number.

```
RESTORE n
```

n = line number of DATA statement; integer or expression; if not specified, default is first DATA statement in the task

### Example:

```
1000 RESTORE 5000
```

## RESUME

(s) Returns program control to first numbered program line following the ON ERROR statement that caused program control to be diverted to an error handling routine.

RESUME

### Example:

1000 RESUME

## RETURN

(s) See GOSUB-RETURN.

## RIGHT\$

(f) Returns a substring of specified length from the rightmost portion of a string.

RIGHT\$(string, string\_length)

string = string variable or expression; strings must be enclosed in single or double quotation marks

string\_length = the number of characters to take from the right side of the string

### Example:

1000 STRING1\$ = RIGHT\$("ABCDEF",4)

## RIODEF

(c) Defines I/O located in a remote rack.

RIODEF variable[MASTER\_SLOT=master\_slot,DROP=drop, &  
SLOT=slot,REGISTER=register,BIT=bit]

variable = integer or boolean variable

master\_slot = slot number of the remote I/O master module in the main, or local, rack; range 0 — 15

drop = drop number of the remote I/O rack; range 0 — 7

slot = slot number of the I/O module in the remote rack; range 0 — 15

register = register number on the remote I/O module; range 0 — 31; default is 0 if not specified

bit = bit number of the I/O point on the register; specified for boolean variables only; range 0 — 15

### Example:

1000 RIODEF LEVEL%[MASTER\_SLOT=15,DROP=3,SLOT=4, &  
REGISTER=1]

## RNETDEF

(c) Defines I/O in the system connected via R-NET using the AutoMate Interface module (M/N 57C417).

RNETDEF variable[SLOT=slot,REGISTER=register]

variable = integer or boolean variable

slot = slot number of the 57C417 module; range 0 — 15

register = register number on the I/O module; format:

0000.BB

where 0000 is the register number in octal, and BB is the bit number in octal; bit number range 0 — 17

Registers reserved for integer variables:

Register Number	Multibus Access	R-NET Access
2000 — 3777	r/w	read only
4000 — 5777	r/w	r/w

Registers reserved for boolean variables:

Register Number	Multibus Access	R-NET Access
0000.00 — 0377.17	read only	r/w
400.00 — 777.17	r/w	read only

**Example:**

```
1000 RNETDEF GATEOK@[SLOT=6,REGISTER=400.00]
```

**ROTATEL%**

(f) Returns an integer value equal to the integer expression that was input rotated the specific number of binary places to the left.

```
ROTATEL%(variable,count)
```

variable = a single or double integer variable or expression

count = number of bit positions to rotate the integer expression; bit 15 (or 31 for double integers) wraps around to bit 0

**Example:**

```
1000 MOVE1% = ROTATEL%(INPUT_CARD%, 4)
```

**ROTATER%**

(f) Returns an integer value equal to the integer expression that was input rotated the specific number of binary places to the right.

```
ROTATER%(variable,count)
```

variable = a single or double integer variable or expression

count = number of bit positions to rotate the integer expression; bit 0 wraps around to bit 15 (or 31 for double integers)

**Example:**

```
1000 SWAP1% = ROTATER%(INPUT_CARD%, 3)
```

**SET\_MAGNITUDE**

(s) Assigns 16 or 32-bit hexadecimal values to variables.

```
SET_MAGNITUDE(variable,value)
```

variable = numeric simple variable of any type

value = numeric constant or expression

**Example:**

```
1000 SET_MAGNITUDE(A%,OFFFFH)
```

**SET-WAIT ON**

(s) SET and WAIT ON allow synchronization between tasks based on the setting of an event. WAIT ON suspends a task until an event occurs in another task. SET makes the suspended task eligible to run. The software EVENT NAME statement must be used in both tasks to define the event used to synchronize the tasks.

```
SET event_name  
WAIT ON event_name
```

event\_name = name of event; must be defined previously in each task using software EVENT NAME; the variable must be a common



Example:

### 1st Task

```
1000 EVENT NAME = GAIN_OVER
...
...
2000 IF GAIN > MAX_GAIN THEN SET GAIN_OVER
```

### 2nd Task

```
1000 EVENT NAME = GAIN_OVER
...
...
2000 WAIT ON GAIN_OVER
```

## SHIFTL%

(f) Returns an integer value equal to the integer expression that was input shifted the specified number of the binary places to the left. Binary places vacated by the shift are filled with 0s.

SHIFTL%(variable,count)

variable = single or double variable or expression

count = number of bit positions to shift the integer or integer expression (shift begins at bit 15 for single integer and 31 for double integer)

Example:

```
1000 LSBITS__0_4% = SHIFTL%(INPUT_CARD%,12)
```

## SHIFTR%

(f) Returns an integer value equal to the integer expression that was input shifted the specified number of binary places to the right.

SHIFTR%(variable,count)

variable = single or double variable or expression

count = number of bit positions to shift the integer or integer expression (shift begins at bit 0)

Example:

```
1000 SHIFT1% = SHIFTR%(INPUT_CARD,4)
```

## SIN

(f) Returns the sine (in real format) of the input.

SIN(expression)

expression = numeric (integer or real) representing radians

Example:

```
1000 RADIANS = SIN(ANGLE)
```

## SQRT

(f) Returns a real value equal to the square root of the input and the same data type as the input.

SQRT(expression)

expression = integer or real variable or expression

Example:

```
1000 SQUARE_ROOT = SQRT(INPUT1)
```

## STR\$

(f) Returns a string of characters from a numeric expression.

STR\$(expression)

expression = integer or real expression

Example:

STRING\$ = STR\$(NUM1%\*3)

## START EVERY

(s) Causes periodic re-start of the task.

START EVERY n units

n = any arithmetic expression or constant that evaluates to an integer result

units = units of time to delay re-start; units are SECONDS, MINUTES, HOURS and TICKS (1 TICK = 5.5 milliseconds); the plural form of the time unit must always be used, i.e., 1 TICKS, not 1 TICK

Example:

1000 START EVERY 20 TICKS

## STOP

(s) Stops program execution. Clears all I/O (sets to 0, FALSE or OFF) in the local and remote racks.

STOP

Example:

1000 STOP

## TAN

(f) Returns the tangent (in real format) of the input.

TAN(expression)

expression = numeric (integer or real) expression representing radians

Example:

1000 RADIANS = TAN(ANGLE)

## TASK

(c) Defines for each application task the task name, programming language, priority, Processor location, and whether the task is critical to the operation of the system.

TASK name[TYPE=language,PRIORITY=m,SLOT=n,CRITICAL=status]

name = name of the task, limited to 8 characters; first character must be a letter

language = programming language the task is written in; either BASIC, PC or CONTROL

m = priority of task execution on a scale of 4 (highest) to 11 (lowest)

n = slot number of the Processor on which the task will run; range 0 - 4

status = specifies whether the task is critical to the system, i.e., whether it can be stopped independently (FALSE) or only via a STOP ALL command from the executive software (TRUE)

Example:

1000 TASK SPD\_REG[TYPE=CONTROL,PRIORITY=5,SLOT=2, &  
CRITICAL=FALSE]

## THEN

(s) See IF-THEN.

## VAL%

(f) Returns the integer value of a string in an integer format.

VAL%(string)

string = string variable or expression

Example:

```
1000 NUMBER% = VAL%(FIRST_WORD$)
```

## TST\_ERRLOG@

(f) Tests the state of the error log and loads the number of errors into the specified variable.

TST\_ERRLOG@(variable%)

variable = integer variable that will be loaded with the number of logged errors (1 to 3)

Example (in IF-THEN-ELSE statement):

```
1000 IF TST_ERRLOG@(NUM_ERRORS%) THEN
    2000
    ELSE
    3000
    END_IF
```

## VAL

(f) Returns the real value of a string in a real format.

VAL(string)

string = string variable or expression

Example:

```
1000 NUMBER = VAL(FIRST_WORD$)
```

## VARPTR!

(f) Returns the address of the variable which is the first register on the Modbus Interface module to which or from which data is to be transferred. Used with the GATEWAY\_CMD\_OK@ function.

VARPTR!(variable)

variable = common variable representing the physical address of the first register on the Modbus Interface module to which or from which data is to be transferred

Example:

```
1000 MSTR_REG! = VARPTR!(MASTER)
```

## WRITEVAR%

(f) Writes a value to a variable entered as a string. Requires the Ethernet™ operating system in the rack.

WRITEVAR%(vn\$,value)

where

vn\$ = a string expression for the name of the variable to write to. It can be a boolean, integer, double integer, real, or string, or an array of these types. Only one-dimensional arrays are allowed.

value = the variable that has the value to write; cannot be a literal.

Example:

```
STATUS% = WRITEVAR%(VARIABLE_NAME$, VALUE)
```

## WAIT ON

(s) See SET-WAIT ON.


# Control Block Language Quick Reference

Note that all text must be entered in uppercase.

## ABSOLUTE\_VALUE

Function

$$\text{OUTPUT} = |\text{INPUT}|$$




CALL ABSOLUTE\_VALUE(INPUT=input%,  
OUTPUT=output%)

&

## ALARM

Function

If INPUT is equal to or exceeds any of the alarm limits, the proper ALARM output(s) are set TRUE.



CALL ALARM(INPUT=input%,  
HIGH\_LIMIT=high\_limit%,  
LOW\_LIMIT=low\_limit%,  
HIGH\_HIGH\_LIMIT=high\_high\_limit%,  
LOW\_LOW\_LIMIT=low\_low\_limit%,  
ALARM\_HIGH=alarm\_high@,  
ALARM\_LOW=alarm\_low@,  
ALARM\_HIGH\_HIGH=alarm\_high\_high@,  
ALARM\_LOW\_LOW=alarm\_low\_low@)


&  
&  
&  
&  
&  
&  
&

## AMPLIFIER

Function

$$\text{OUTPUT} = (\text{INPUT1} \cdot \text{GAIN1} + \dots + \text{INPUTn} \cdot \text{GAINn}) / \text{SCALE}$$

&




CALL AMPLIFIER(INPUT1=input1%,GAIN1=gain1%...  
INPUTn=inputn%,GAINn=gainn%,SCALE=scale%,  
OUTPUT=output%)

&  
&

## AND

Function

OUTPUT = INPUT1 and ... INPUTn



```
CALL AND(INPUT1=input1@,  
INPUTn=inputn@,  
OUTPUT=output@)
```

&  
&

## BIT SELECT

Function

If (INPUT - OFFSET)  $\geq$  0 and  
(INPUT - OFFSET)  $\leq$  15  
then OUTPUT(INPUT - OFFSET) is set TRUE

All other outputs(n) are set FALSE

else

All outputs(n) are set FALSE



```
CALL BIT_SELECT(INPUT=input%,OFFSET=offset%,  
OUTPUT0=output0@, ... OUTPUTn=outputn@)
```

&

## COMPARE


Function

Compares INPUT1 against INPUT2

OUTPUT\_GTR is set TRUE when INPUT1 is greater than INPUT2

OUTPUT\_EQU is set TRUE when INPUT1 is equal to INPUT2

OUTPUT\_LES is set TRUE when INPUT1 is less than INPUT2




```
CALL COMPARE(INPUT1=input1%,INPUT2=input2%,  
OUTPUT_GTR=greater_than@,  
OUTPUT_EQU=equal@,  
OUTPUT_LES=less_than@)
```

&  
&  
&

## COUNTER

Function

$$\text{OUTPUT} = \text{OUTPUT}(n-1) + \text{INPUT}(+) - \text{INPUT}(-)$$




```
CALL COUNTER(RESET = reset@,PRESET = preset!%),      &  
INPUT_PLUS = input_plus%,                          &  
INPUT_MINUS = input_minus%,                        &  
OUTPUT = output%
```

## DIFFERENCE

Function

$$\text{OUTPUT} = \text{INPUT1} - \text{INPUT2}$$




```
CALL DIFFERENCE(INPUT1 = input1%,INPUT2 = input2%,  &  
OUTPUT = output%)
```

## DIFF\_LAG

Function

$$\text{LAPLACE TRANSFER FUNCTION} = \frac{s/\omega LG}{1 + (s/\omega LG)}$$



```
CALL DIFF_LAG(INPUT = input%,omega LG = omega LG,WM = nnn.n,  &  
INITIAL_VALUE = initial_value%,RESET = reset@,            &  
OUTPUT = output%)
```

## FUNCTION BLOCK

### Function

$$\text{subscript\_remainder} = \frac{\text{INPUT} * (\text{table\_size} - 1)}{(\text{max\_input} + 1)}$$

$$\text{OUTPUT} = \text{tN} \% (\text{subs}) + \{ [\text{Tn} \% (\text{subs} + 1) - \text{Tn} \% (\text{subs})] * \text{REM} \}$$


where:

Tn = Table n

Subs = Subscript of above equation

REM = Remainder of above equation

(Note: OUTPUT is the result of linear interpolation between two points in the table.)




```
CALL FUNCTION(INPUT=input%,MAX_INPUT=max_input,
SELECT=select@,TABLE1=table1%,
TABLE2=table2%,OUTPUT=output%)
```

&  
&

## INTEGRATE

### Function

$$\text{LAPLACE TRANSFER FUNCTION} = \frac{KI}{S}$$



```
CALL INTEGRATE(INPUT=input%,KI=ki,WM=nnn.n,
INITIAL_VALUE=initial_value%,
LIMIT_PLUS=limit_plus%,
LIMIT_MINUS=limit_minus%,RESET=reset@,
HOLD_PLUS=hold_plus@,
HOLD_MINUS=hold_minus@,
SATURATED_PLUS=saturated_plus@,
SATURATED_MINUS=saturated_minus@,
OUTPUT=output%)
```

&  
&  
&  
&  
&  
&  
&

## INVERTER

### Function

If ENABLE = TRUE then OUTPUT = -INPUT

else

OUTPUT = INPUT




CALL INVERTER(ENABLE = enable@, INPUT = input%,  
OUTPUT = output%)

&

## LAG

Function

$$\text{LAPLACE TRANSFER FUNCTION} = \frac{1}{1 + (s/\omega g)}$$



CALL LAG(INPUT = input%, ωg = ωg, WM = nnn.n,  
INITIAL\_VALUE = initial value%,  
RESET = reset@, OUTPUT = output%)

&  
&

## LATCH

Function

If RESET is TRUE set OUTPUT FALSE

else

If RESET is FALSE and SET is TRUE set OUTPUT TRUE

else if

RESET and SET are FALSE and CLOCK is TRUE  
set OUTPUT to the state of INPUT

else

OUTPUT state is unchanged.



CALL LATCH(RESET = reset@, SET = set@,  
CLOCK = clock@, INPUT = input@,  
OUTPUT = output@)


&  
&

## LEAD\_LAG

Function

$$\text{LAPLACE TRANSFER FUNCTION} = \frac{1 + (s/\omega ld)}{1 + (s/\omega lg)}$$






```
CALL LEAD_LAG(INPUT=input%,omega_d=omega_d,           &
omega_g=omega_g,WM=rnn.n,                             &
INITIAL_VALUE=initial_value%,                         &
RESET=reset@,OUTPUT=output%)
```

## LIMIT

### Function

OUTPUT=INPUT within the range LIMIT(+) to LIMIT(-). If INPUT exceeds either limit, OUTPUT is held at that limit and the proper SATURATED output will be set.



```
CALL LIMIT(INPUT=input%,LIMIT_PLUS=limit_plus%,      &
LIMIT_MINUS=limit_minus%,                            &
SATURATED_PLUS=saturated_plus@,                     &
SATURATED_MINUS=saturated_minus@,                   &
OUTPUT=output%)
```


## MOVE

### Function

If ENABLE=TRUE then  
OUTPUT1=INPUT1

...

OUTPUTn=INPUTn




Maximum "n" = 8

```
CALL MOVE(ENABLE=enable@,                             &
INPUT1=input1%,OUTPUT1=output1%,...                 &
INPUTn=inputn%,OUTPUTn=outputn%)
```

## MULTIPLY AND DIVIDE

### Function

$$\text{OUTPUT} = \text{INPUT} * \text{INPUT2} / \text{INPUT3}$$




CALL MULTIPLY\_DIVIDE(INPUT1 = input1%,  
 INPUT2 = input2%, INPUT3 = input3%,  
 OUTPUT = output%)

&  
 &

## NOTCH FILTER

### Function

$$\text{LAPLACE TRANSFER FUNCTION} = \frac{S^2 + \omega_n^2}{S^2 + \omega_n S / Q + \omega_n^2}$$




CALL NOTCH(INPUT = input%,  
 Q\_FACTOR = q\_factor,  
 WN = \omega\_n,  
 RESET = reset@,  
 OUTPUT = output%)

&  
 &  
 &  
 &

## OR

### Function

$$\text{OUTPUT} = \text{INPUT1 or } \dots \text{ INPUTn}$$



Maximum "n" = 8


CALL OR(INPUT1 = input1@,  
 INPUTn = inputn@,  
 OUTPUT = output@)

&  
 &

## PACK BITS

### Function

BITn in OUTPUT is set to the state of INPUTn. If INPUTn is not programmed, then BITn in OUTPUT is set FALSE.



Maximum "n" = 15

CALL PACK\_BITS(INPUT0=input0@, ... INPUTn=inputn@,  
OUTPUT=output%)

&

## PID

### Function

If MANUAL is true then


```

ERROR=0
IOUT(n)=INITIAL_VALUE
If IOUT(n) > LIMIT_PLUS - FEED_FORWARD then
IOUT(n)=LIMIT_PLUS - FEED_FORWARD
SATURATED_PLUS=TRUE
If IOUT(n) < LIMIT_MINUS - FEED_FORWARD then
IOUT(n)=LIMIT_MINUS - FEED_FORWARD
SATURATED_MINUS=TRUE
OUTPUT=IOUT(n) + FEED_FORWARD
  
```

Else

```

ERROR=INPUT - FEEDBACK or FEEDBACK - INPUT
Incr(n)=Calculated delta change value for selected PID
algorithm (ISA or Independent)
If ABS(ERROR) < DEAD_BAND then incr(n)=0
If ABS(incr(n)) > MAX_CHANGE then
limit Incr(n) to MAX_CHANGE
IOUT(n)=Incr(n) + IOUT(n-1)
If HOLD_PLUS is TRUE and IOUT(n) > IOUT(n-1) then
IOUT(n)=IOUT(n-1)
If HOLD_MINUS is TRUE and IOUT(n) < IOUT(n-1) then
IOUT(n)=IOUT(n-1)
If IOUT(n) > LIMIT_PLUS - FEED_FORWARD then
IOUT(n)=LIMIT_PLUS - FEED_FORWARD
SATURATED_PLUS=TRUE
If IOUT(n) < LIMIT_MINUS - FEED_FORWARD then
IOUT(n)=LIMIT_MINUS - FEED_FORWARD
SATURATED_MINUS=TRUE
OUTPUT=IOUT(n) + FEED_FORWARD
  
```




```

CALL PID(ISA= < boolean literal > ,ACTION= < boolean literal > ,           &
  DERIVATIVE= < boolean literal > ,MANUAL=manual@,                       &
  KP=kp,KI=ki,KD=kd,LOOP_TIME=loop_time,                                &
  INITIAL_VALUE=initial_value%,FEED_FORWARD=feed_forward%,             &
  INPUT=input%,FEEDBACK=feedback,                                       &
  DEAD_BAND=dead_band%,MAX_CHANGE=max_change%,                         &
  LIMIT_PLUS=limit_plus%,LIMIT_MINUS=limit_minus%,                     &
  HOLD_PLUS=hold_plus@,HOLD_MINUS=hold_minus@,                          &
  SATURATED_PLUS=saturated_plus@,                                       &
  SATURATED_MINUS=saturated_minus@,                                     &
  ERROR=error%,OUTPUT=output%)

```

## PROP\_INT



```

CALL PROP_INT(INPUT=input%,KP= kp,ωld= ωld,                             &
  WM= nnn.n,INITIAL_VALUE=initial_value%,                               &
  LIMIT_PLUS=limit_plus%,                                               &
  LIMIT_MINUS=limit_minus%,RESET= reset@,                               &
  HOLD_PLUS=hold_plus@,                                                 &
  HOLD_MINUS=hold_minus@,                                               &
  SATURATED_PLUS=saturated_plus@,                                       &
  SATURATED_MINUS=saturated_minus@,                                     &
  OUTPUT=output%)

```

## PULSE\_MULTIPLIER

### Function

If WORD\_SIZE > 0 (Relative mode) then

If falling edge of RESET then

INPUT(n-1)=INITIAL\_VALUE


ERROR=INPUT - INPUT(n-1)

else

ERROR=INPUT

$$OUTPUT = \left( \frac{ERROR * MULTIPLIER}{32767} \right) +$$

OUTPUT = REM(n-1)



```


CALL PULSE_MULT(INPUT=input%,RESET= reset@,                             &
  WORD_SIZE= nnn,INITIAL_VALUE=initial_value%,                         &
  MULTIPLIER=multiplier%,OUTPUT=output%)

```

## RAMP

### Function

For a change in INPUT, OUTPUT will ramp toward the new INPUT value. During steady state operation, OUTPUT=INPUT. Two types of RAMP generators are provided: a normal (algebraic) ramp and an absolute value ramp. For a normal ramp, the accel condition is defined by an input that is becoming more positive, and a decel condition is defined by an input that is becoming more negative. For an absolute value ramp, the accel condition is defined by an input moving away from zero, and a decel condition is defined by an input moving towards or through zero.




```
CALL RAMP(INPUT=input%,ABS_RAMP=TRUE/FALSE,           &
  RESET=reset@,INITIAL_VALUE=initial_value%,         &
  HOLD=hold@,ACCEL_RATE=accel_rate%,                 &
  DECEL_RATE=decel_rate%,SCALE=nnnnn,               &
  OUTPUT=output%,RATE=rate%)
```

## READ BITS

### Function

This function reads data from a column in the specified BOOLEAN data structure.




```
CALL READ_BITS(STRUCTURE_NAME=structure_name@,       &
  COLUMN=column%,ENABLE=enable@,                    &
  ERROR=error@,                                     &
  OUTPUT1=output1%,... OUTPUTn=outputn%)
```

## READ WORDS

### Function

This function reads data from a column in the specified INTEGER data structure.




```
CALL READ_WORDS(STRUCTURE_NAME=structure_name%,           &
  COLUMN=column%,ENABLE=enable@,                         &
  ERROR=error@,                                          &
  OUTPUT1=output1%, . . . OUTPUTn=outputn%)
```

## RUNNING AVERAGE

### Function

$$OUTPUT = \frac{[INPUT(n) + \dots + INPUT(n+1)]}{(REQUIRED\_SAMPLES)}$$

The OUTPUT is updated each scan with the average of the samples read for INPUT over the last RS scans.




```
CALL RUNNING_AVERAGE(REQUIRED_SAMPLES=req_sam,          &
  RESET=reset@,                                         &
  INPUT=input%,                                         &
  DATA_VALID=data_valid@,                             &
  MAX_VALUE=max_value%,MIN_VALUE=min_value%,          &
  OUTPUT=output%)
```

## SAMPLED AVERAGE

### Function

$$OUTPUT = \frac{[INPUT(1) + \dots + INPUT(RS)]}{(REQUIRED\_SAMPLES)}$$

The OUTPUT is updated once every RS scans with the average of the samples read for INPUT during the last RS scans.




```
CALL SAMPLED_AVERAGE(REQUIRED_SAMPLES=req_sam,         &
  INPUT=input%,                                         &
  RESET=reset@,                                         &
  DATA_VALID=data_valid@,                             &
  MAX_VALUE=max_value%,MIN_VALUE=min_value%,          &
  OUTPUT=output%)
```

## SCALE

### Function

If CLAMP is TRUE and INPUT exceeds INPUT\_MAX or INPUT\_MIN, then the value of INPUT is clamped at the proper limit.

$$\text{OUTPUT} = \frac{(\text{INPUT} - \text{INPUT\_MIN}) * (\text{OUTPUT\_MAX} - \text{OUTPUT\_IMIN})}{\text{INPUT\_MAX} - \text{INPUT\_MIN}} + \text{OUTPUT\_IMIN}$$



```
CALL SCALE(INPUT=input%,CLAMP=clamp@,           &
            INPUT_MAX=input_max%,                &
            INPUT_MIN=input_min%,                &
            OUTPUT_IMAX=output_imax%,           &
            OUTPUT_IMIN=output_imin%,           &
            OUTPUT=output%)
```

## SCAN\_LOOP

Time scanned loop (no event)

```
CALL SCAN_LOOP(TICKS=ticks%)
```

Or hardware event

```
EVENT_NAME=START_TASK,                           &
INTERRUPT_STATUS=ISCR%,TIMEOUT=6                 &
CALL SCAN_LOOP(TICKS=4,                           &
EVENT=START_TASK)
```


Or software event

```
EVENT_NAME=BEGIN
CALL SCAN_LOOP(TICKS=4,EVENT=BEGIN)
```

## S\_CURVE

### Function

The S\_CURVE block performs the same basic function as the RAMP block with a jerk rate added. If the REVERSE bit=TRUE, then the input ACCEL rate will become the DECEL rate and the input DECEL rate will become the ACCEL rate. This is used to provide the function similar with the "motor" type RAMP block (ABS\_RAMP=TRUE). With the S\_CURVE block, however, this function can be dynamically controlled by the application.



```

CALL $ _CURVE(INPUT=input%,RESET=reset@,
HOLD=hold@,ACCEL_RATE=accel_rate%,
DECEL_RATE=decel_rate%,
JERK_RATE=jerk_rate%,
SCALE=nnnnn,REVERSE=reverse@,
INITIAL_VALUE=initial_value%,
OUTPUT=output%,RATE=rate%)


```

## SEARCH

### Function

Compare INPUT against selected TABLE elements.

Search the selected table for a match according to the comparison options selected by the three BOOLEAN inputs COMPARE\_GTR, COMPARE\_EQU and COMPARE\_LES. The search starts at the top of the table (array element 0) and tests INPUT against each element in the table until either a match is found or the end of the table is reached (last element in the array). If a match occurs, the search function is terminated and the index into the table where the match occurred is written to OUTPUT. FOUND is then set true. If no match occurred, the OUTPUT is set to a value of -1 and FOUND is set FALSE.



```


CALL SEARCH(COMPARE_GTR = < boolean literal >,
COMPARE_EQU = < boolean literal >,
COMPARE_LES = < boolean literal >,
INPUT = input%,
SELECT = select@,
TABLE1 = table1%,TABLE2 = table2%,
FOUND = found@,OUTPUT = output%)

```

## SELECT

### Function

OUTPUT will equal the sum of all selected inputs. If no SELECT is true, OUTPUT=0.



```

CALL SELECT(INPUT1 = input1%,SELECT1 = select1@,
... INPUTn = inputn%,SELECTn = selectn@,
OUTPUT = output%)


```



## SHIFT BITS

### Function

When RESET is FALSE and SHIFT is TRUE, shift the data in the specified BOOLEAN data structure towards the output(s), update the output(s) with the state(s) at column MCOL - 1 and if ENABLE is TRUE, shift the state(s) of the input(s) into column 0, else set the state(s) of column 0 FALSE.




```
CALL SHIFT_BITS(STRUCTURE_NAME=struct_name@,           &
  MAX_COLUMNS=max_columns%,                             &
  RESET=reset@,SHIFT=shift@,                            &
  INPUT1=input1@, . . . INPUTn=inputn@,                 &
  ENABLE=enable@,DATA_VALID=data_valid@,               &
  OUTPUT1=output1@, . . . OUTPUTn=outputn@)            &
```

## SHIFT WORDS

### Function

When RESET is FALSE and SHIFT is TRUE, shift the data in the specified INTEGER data structure towards the output(s), update the output(s) with the value(s) at column MCOL - 1, and if ENABLE is TRUE, shift the data at the input(s) into column 0, else shift zeros into column 0.




```
CALL SHIFT_WORD(STRUCTURE_NAME=struct_name%,          &
  MAX_COLUMNS=max_columns%,                           &
  RESET=reset@,SHIFT=shift@,                          &
  INPUT1=input1%, . . . INPUTn=inputn%,                &
  ENABLE=enable@,DATA_VALID=data_valid@,              &
  OUTPUT1=output1%, . . . OUTPUTn=outputn%)          &
```

## SUMMER

### Function

$$\text{OUTPUT} = \text{INPUT1} + \text{INPUT2}$$



CALL SUMMER(INPUT1 = input1%, INPUT2 = input2%,  
OUTPUT = output%)

&


## SWITCH

### Function

If SELECT = TRUE then  
OUTPUT = INPUT1

else

OUTPUT = INPUT2




CALL SWITCH(INPUT1 = input1%, INPUT2 = input2%,  
SELECT = select@, OUTPUT = output%)

&

## TRANSITION

### Function

OUTPUT = TRUE when INPUT goes from off to  
on




CALL TRANSITION(INPUT = input@,  
OUTPUT = output@)

&

## UNPACK BITS

### Function

OUTPUT<sub>n</sub> is set to the state of BIT<sub>n</sub> in INPUT




```
CALL UNPACK_BITS(INPUT=input%,  
OUTPUT0=output0@, ... OUTPUTn=outputn@)
```

&

## WRITE BITS

### Function

This function stores data into a column in the specified BOOLEAN data structure.




```
CALL WRITE_BITS(STRUCTURE_NAME=structure_name@,  
COLUMN=column%,ENABLE=enable@,  
INPUT1=input1@, ... INPUTn=inputn@,  
ERROR=error@)
```

&  
&  
&

## WRITE WORDS

### Function

This function stores data into a column in the specified INTEGER data structure.



```
CALL WRITE_WORD(STRUCTURE_NAME=struct_name%,  
COLUMN=column%,ENABLE=enable@,  
INPUT1=input1%, ... INPUTn=inputn%,  
ERROR=error@)
```


&  
&  
&

# Current Minor Loop

## DC\_DRIVE\_CML

### Function

Performs the current minor loop regulation for the S6R DC Motor drive.



```

CALL DC_DRIVE_CML(IO_CNTL_SLOT=io_cntl_slot%,           &
DIG_IO_SLOT=dig_io_slot%,                               &
AC_LINE_FREQ=ac_line_freq%,                             &
*REFERENCE=reference%,*REF_RATE=ref_rate,              &
REF_LAG=ref_lag,*KP=kp,PI_W_LEAD=pi_w_lead,           &
AG_FACTOR=ag_factor%,                                   &
*CC_THRESH=cc_thresh%,                                  &
*CML_RUN=cml_run@,                                     &
*CML_COAST_STOP=cml_coast_stop@,                       &
*MCR_SELECT=mcr_select@,                               &
MAX_M_DROPOUT=max_m_dropout,                           &
*CML_TEST=cml_test@,                                   &
*TEST_BRPOL=test_brpol@,                               &
*TEST_ALPHA=test_alpha%,                               &
IOC_THRESH=ioc_thresh%,                                &
LIM_BAR=lim_bar%,                                      &
DIGITAL_TACH=digital_tach@,                            &
*SPEED_FDBK=speed_fdbk%,                              &
TACH_LOSS_STOP=tach_loss_stop@,                       &
*OSV_FDBK=osv_fdbk%,                                  &
OSV_THRESH=osv_thresh%,                                &
*NONSTAND_PHROT=nonstand_phrot@,                      &
AUTO_PHROT=auto_phrot@,                               &
*FAULT_RESET=fault_reset%,                            &
DC_CML_STATE=dc_cml_state@,                           &
SYNC_LOCKED=sync_locked@,                             &
LINE_PERIOD=line_period%,                              &
INSWITCH_POSA=inswitch_posa@,                         &
INSWITCH_POSB=inswitch_posb@,                         &
INFAULT_RESET=infault_reset@,                        &
**DC_TIME=dc_time%,                                   &
**BRIDGE_POL=bridge_pol@,                             &
**REF_RATE_OUT=ref_rate_out%,                         &
**REF_LAG_OUT=ref_lag_out%,                           &
**FDBK_GAIN=fdbk_gain%,**I_FDBK=i_fdbk%,             &
**INTEGRAL_GAIN=integral_gain%,                      &
**DELTA=delta%,IOC_OUT=ioc_out@,                     &
SYNC_LOSS_OUT=sync_loss_out@,                        &
TACH_LOSS_OUT=tach_loss_out@,                        &
OSV_OUT=osv_out@,                                     &
EXT_IET_OUT=ext_iet_out@,                             &
PHROT_FLT_OUT=phrot_fit_out@,                        &
BAD_SCR_OUT=bad_scr_out@,                             &
BAD_SCR_NUM=bad_scr_num%,                             &
DIAG_DATA=diag_data%)

```

\* Dynamically adjustable

\*\* Latched on error

Note that the asterisks are not part of the CML statement.

# Control Block Execution Time Estimates

The execution time for a Control Block task can be determined by adding the execution time for each statement to the SCAN\_LOOP/END time. Dividing by the scan time (TICKS × tick rate in seconds) gives the estimated CPU usage for the task.

Block Name	7010 Processor Maximum Time (μsec)	6010/6011 Processor Maximum Time (μsec)
ABSOLUTE_VALUE	9.16	41
ALARM	11.16 + n(2.48)	44 + n(11)
AMPLIFIER	13.16 + k(3.12)	62 + k(13.8)
AND	10.80 + j(1.88)	41 + j(8.3)
BIT_SELECT	26.04 + n(1.20)	118 + n(6.5)
COMPARE	11.24 + n(1.16)	45 + n(5.5)
COUNTER	15.64	61
DIFFERENCE	10.80	44
DIFF_LAG	33.04	154
END	13.82 + t(2.0) + i(1.6) + b(2.2) + d(2.5)	60 + t(3.2) + i(2.8) + b(4.3) + d(4.9)
FUNCTION	23.56	93
INTEGRATE	39.14	193
INVERTER	10.84	48
LAG	26.52	118
LATCH	15.04	68
LEAD_LAG	68.60	284
LIMIT	18.20	69
MOVE	10.40 + p(2.32)	39 + p(11)
MULTIPLY_DIVIDE	13.76	71
NOTCH	85.16	393
OR	10.24 + j(1.88)	41 + j(8.3)
PACK_BITS	24.28 + j(1.44)	110 + j(5)
PID	124.00	515
PROP_INT	40.32	193
PULSE_MULT	18.32	86
RAMP	27.72	122
READ_BITS	24.32 + n(1.12)	106 + n(7.3)
READ_WORDS	25.76 + n(1.28)	111 + n(5.6)
RUNNING_AVERAGE	28.64	125
SAMPLED_AVERAGE	29.00	125
S_CURVE	47.00	282
SCALE	22.48	98
SCAN_LOOP	80.00 + t(1.6) + i(2.5) + b(3.8) + d(4.1)	326 + t(2.4) + i(4.4) + b(6.8) + d(7.2)
SEARCH	19.80 + m(0.68)	74 + m(3)
SELECT	11.36 + j(2.52)	44 + j(12.2)
SHIFT_BITS	18.28 + p(2.04)	92 + p(19.7)
SHIFT_WORDS	17.80 + p(1.72)	89 + p(13.3)
SUMMER	11.28	44
SWITCH	11.52	47
TRANSITION	11.36	48
UNPACK_BITS	23.40 + n(1.44)	106 + n(7.3)
WRITE_BITS	25.56 + j(1.36)	103 + j(6)
WRITE_WORDS	25.52 + j(0.36)	110 + j(1.9)
! < REM >	9.88	40

b = number of common boolean variables referenced by the task  
 d = number of common double integer variables referenced by the task  
 i = number of common integer variables referenced by the task  
 j = total number of inputs programmed  
 k = total number of input pairs programmed  
 m = number of elements searched  
 n = total number of outputs programmed  
 p = total number of input/output pairs programmed  
 t = total number of common integer, boolean, and double integer variables referenced by the task

# **AutoMax Off-Line PC Editor**

## **Quick Reference**

- F1 — Help**
  
- F2 — Initiate search for variable name/contact type**
- ALT-F2 — Next occurrence search variable**
  
- F3 — Commands**
  - E — Exit and update file**
  - Q — Quit**
  - R — Resequence**
  - S — Substitute**
  - P — Preset modify**
  - A — Add element description**
  - C — Change element description**
  - I — Program information**
  - M — Move sequence**
  - D — Delete multiple sequences**
  - N — Include sequences from file**
  - W — Wildcard substitution**
  - T — Text edit descriptions**
  - V — Variable scope change**
  
- F4 — Normally open contact**
- ALT-F4 — Up transition contact**
  
- F5 — Normally closed contact**
- ALT-F5 — Down transition contact**
  
- F6 — Horizontal line**
- ALT-F6 — Delete element**
  
- F7 — Vertical branch**
- ALT-F7 — Delete branch**
  
- F8 — Coil — ( )**
  
- F9 — Functions**
  - T — Timer (On-delay)**
  - O — Off-delay timer**
  - C — Counter**
  - S — Shift register**
  - R — Remarks**
  - E — Event coil**
  
- F10 — Find sequence number/coil name**
  
- Home — First sequence**
- End — Last sequence**
- PgUp — Previous sequence**
- PgDn — Next sequence**
- Del — Delete sequence**
- Ins — Insert sequence (after)**

# PC/Ladder Language Format

## Normally Open Contact

bitname



## Normally Closed Contact

bitname



## Up Transition Contact

bitname



## Down Transition Contact

bitname




## Coil


bitname



## On Delay Timer




## Off Delay Timer







### Counter



### Shift Register



### Event Coil



# PC/Ladder Logic Execution Time and Memory Usage Estimates

The execution time for a ladder logic task can be estimated using the following timing estimates. After the total execution time is computed, divide by the scan time to obtain an estimate of the CPU usage for the task. A maximum of 2047 different symbols may be used in a single task. Ladder logic tasks are limited to a maximum of 90K bytes for ladder sequences plus 45K for symbols.

Ladder Logic Operation	7010 Execution Time In $\mu$ sec	6010 Execution Time In $\mu$ sec	Memory Usage in bytes
Normally Open Contact	.5	1.5	6
Normally Closed Contact	.5	1.5	6
Transition Contacts			
AND	1.0	3.0	10
OR	1.2	3.5	12
Coils	7.1	26.0	8
Timers	14.7	50.0	24
Counters	14.0	50.0	24
Shift Registers	11.9	41.0	24
Events			
Event Set	152.0	272.0	
Event Not Set	9.6	18.0	24
Remark	3.5	11.0	24
Variables			8+ # of characters in name
System Overhead - Fixed	100	314	3000
System Overhead - Variable	$6c+3f$	$18c+9f$	$c/n * 10 + 10/\text{sequence}$
<b>Key:</b> c = number of common variables f = number of forced variables n = packing density, a function of how the common booleans are stored in memory. The value can range from 1 (worst case) to 16 (ideal case). Use a value of 8 as an estimate.			

# Norton™ Editor

## Command Summary

**F1 — Help**

**F2 — Status**

**F3 — File commands**

- E — *Exit*, save the data and end the edit session
- Q — *Quit*, discard the data and end the edit session
- S — *Save*, write the data to disk and continue editing
- X — *eXchange* windows, switch to other window
- N — *New*, edit a new file
- A — *Append* another file to end of edit data
- W — *Write* part of the data to disk
- L — *Load* more data from a large file
- C — *Close* the output file, open new output

**F4 — Block commands**

- S — *Set* a block marker
- R — *Remove* block markers
- D — *Delete* a block
- C — *Copy* a block
- W — *Window-to-window* block copy
- M — *Move* a block
- L — *Line*, mark an entire line as a block
- E — *End-of-line*, mark to end-of-line as a block
- F — *Find* block marker

**F5 — Screen format commands**

- L — *Line length*, set line length
- W — *Word-wrap*, toggle on and off
- F — *Format* a paragraph
- T — *Tab*, set tab spacing
- I — *Indent*, toggle auto indent on and off
- C — *Cursor*, set cursor type
- D — *Display*, set display color
- S — *Save* editor with new defaults set
- K — *Key define*, change operation of *Tab* and *Ins* keys

**F6 — Miscellaneous commands**

- G — *Goto* a line number
- M — *Matching* punctuation, finds matching symbol
- C — *Condensed* display mode
- Ins* — *Insert* mode cancel, switch to *replace* mode
- T — *Test* windows for differences

## **F7 — Printer commands**

- P** — *Print* entire edit buffer
- B** — *Block*, print marked block
- E** — *Eject* paper (form-feed)
- S** — *Size* in lines per page
- M** — *Margin*, set left margin for printing

## **F9 — DOS Command Processor**

### **Other commands:**

- Ins* — *Insert*, switch to insert mode
- ^U** — *Undelete*
- ^F** — *Find* or *find-and-replace*
- ^C** — *Continue* find operation
- ^P** — *Insert* control character
- ^V** — *Vice versa*, flip upper- and lowercase

### **Cursor Movement**

- |                              |                                     |
|------------------------------|-------------------------------------|
| <i>Right Arrow</i>           | right one character                 |
| <i>Left Arrow</i>            | left one character                  |
| <i>Up Arrow</i>              | up one line                         |
| <i>Down Arrow</i>            | down one line                       |
| <b>^Right Arrow</b>          | right one word                      |
| <b>^Left Arrow</b>           | left one word                       |
| <i>Home</i>                  | beginning of line                   |
| <i>End</i>                   | end of line                         |
| <i>PgUp</i>                  | top of page <i>or</i> previous page |
| <i>PgDn</i>                  | bottom of page <i>or</i> next page  |
| <b>^Home</b> or <b>^PgUp</b> | beginning of the edit data          |
| <b>^End</b> or <b>^PgDn</b>  | end of the edit data                |

### **Delete Commands**

<b>Key</b>	<b>Deletes</b>
<i>Backspace</i>	one character to the left, when in Insert mode
<i>Del</i>	the character under cursor
<b>^W</b>	the word to the left of the cursor
<i>Alt-W</i>	the word to the right of the cursor
<b>^L</b>	from the cursor to beginning of line
<i>Alt-L</i>	from cursor to end of line
<i>Alt-K</i>	the entire current line
<i>F4 D</i>	the marked block
<b>^U</b> or <i>Alt-U</i>	undeletes any but a deleted block (until the cursor is moved)

### **Search Commands**

- |              |                              |
|--------------|------------------------------|
| <b>Alt F</b> | Find string forward          |
| <b>^F</b>    | Find string reverse          |
| <b>Alt C</b> | Continue find string forward |
| <b>^C</b>    | Continue find string reverse |
| <b>F4 F</b>  | Find block marker forward    |

To make the search case-insensitive, terminate the string with ESC rather than RETURN.

To search for a new line character, enter control RETURN in the search string.

### **Search and Replace Commands**

Forward search and replace:

ALT F  
enter search string  
ALT F  
enter replacement string

Reverse search and replace:

^F  
enter search string  
^F  
enter replacement string

Responses to search and replace:

Y	— Replace
N	— Doesn't replace
*	— Replace all
SPACE	— Quits search and replace
ALT C	— Continue search forward
^C	— Continue search reverse



## **Section IV Appendices**





# Appendix A

## ASCII

### Conversion Chart

Hex	Dec	*	Char	Hex	Dec	Char	Hex	Dec	Char
00	0	@	NUL	2B	43	+	55	85	U
01	1	A	SOH	2C	44	,	56	86	V
02	2	B	STX	2D	45	-	57	87	W
03	3	C	ETX	2E	46	.	58	88	X
04	4	D	EOT	2F	47	/	59	89	Y
05	5	E	ENQ	30	48	0	5A	90	Z
06	6	F	ACK	31	49	1	5B	91	[
07	7	G	BEL	32	50	2	5C	92	\
08	8	H	BS	33	51	3	5D	93	]
09	9	I	HT	34	52	4	5E	94	^
0A	10	J	LF	35	53	5	5F	95	_
0B	11	K	VT	36	54	6	60	96	`
0C	12	L	FF	37	55	7	61	97	a
0D	13	M	CR	38	56	8	62	98	b
0E	14	N	SO	39	57	9	63	99	c
0F	15	O	SI	3A	58	:	64	100	d
10	16	P	DLE	3B	59	;	65	101	e
11	17	Q	DC1	3C	60	<	66	102	f
12	18	R	DC2	3D	61	=	67	103	g
13	19	S	DC3	3E	62	>	68	104	h
14	20	T	DC4	3F	63	?	69	105	i
15	21	U	NAK	40	64	@	6A	106	j
16	22	V	SYN	41	65	A	6B	107	k
17	23	W	ETB	42	66	B	6C	108	l
18	24	X	CAN	43	67	C	6D	109	m
19	25	Y	EM	44	68	D	6E	110	n
1A	26	Z	SUB	45	69	E	6F	111	o
1B	27	[	ESC	46	70	F	70	112	p
1C	28	\	FS	47	71	G	71	113	q
1D	29	]	GS	48	72	H	72	114	r
1E	30	^	RS	49	73	I	73	115	s
1F	31	-	US	4A	74	J	74	116	t
20	32		SP	4B	75	K	75	117	u
21	33	!		4C	76	L	76	118	v
22	34	"		4D	77	M	77	119	w
23	35	#		4E	78	N	78	120	x
24	36	\$		4F	79	O	79	121	y
25	37	%		50	80	P	7A	122	z
26	38	&		51	81	Q	7B	123	{
27	39	'		52	82	R	7C	124	
28	40	(		53	83	S	7D	125	}
29	41	)		54	84	T	7E	126	~
2A	42	*					7F	127	DEL

\* Press < CTRL > at the same time as the indicated character

# Appendix B

## Decoding Bus Errors

Some bus errors that occur in the rack can be easily traced using the procedure described below. These errors result in a hexadecimal entry in the "Error Specific" field in the programming executive software error log.

The procedure consists of converting the hexadecimal number given in the error log into a binary number, and then interpreting the most significant and least significant 16 bits as described below.

1. Convert the hexadecimal number found in the "Error Specific" field into a binary number. If the hexadecimal number consists of fewer than eight digits, pad the number with zeroes. For example, hexadecimal 3250184 would be padded with a zero first to become 03250184. The conversion to binary would look like this:

0    3    2    5    0    1    8    4  
 0000 0011 0010 0101 0000 0001 1000 0100

2. Interpret the resulting binary pattern in two stages. First, examine the most significant 16 bits using the pattern below. This step uses the sample value in step 1 above.

BIT																	
31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16		
0		Always Fixed				Byte Bit #				Always Fixed				Slot # in this rack			
0	0	0	0	0	0	1	1	0	0	1	0	0	1	0	1		
										2						5	

The first line under the figure above describes the meaning of the pattern. The second line shows the equivalent hexadecimal value. The third line shows the decimal value corresponding to the hexadecimal value in the second line. It is the decimal values that are used to decode the bus error slot location.

Step 2 tells you that the bus error occurred in slot 5 in the rack. Note that the "Byte Bit #" value will be used in step 4 to help pinpoint the bit at which the error occurred.

3. Interpret the least significant bits of the hex value according to the type of module found in the slot.

For this example, we will assume that the module in slot 5 is a Network Communications module. In this case, we will use the following bit pattern to decode the drop, register, and bit number where the error occurred.

**Network Communications Module  
Least Significant 16 Bits**

BIT																
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Always Fixed				Drop				Register				b				
0	0	0	0	0	0	0	0	1	1	0	0	0	0	1	0	0
							3			2			0			

The first line under the figure above describes the meaning of the pattern. The second line shows the equivalent hexadecimal value. The third line shows the decimal value corresponding to the hexadecimal value in the second line. It is the decimal values that are used to decode the bus error register location. In the case of Network or Remote/O modules, this step also tells you the drop location where the error occurred.

Step 3 tells you that the error occurred in register 2 on drop 3. Note that the "b" value is used in the next step to determine the bit.

4. In order to determine the bit number at which the error occurred, use the following formula:

$$\text{bit number} = \text{Byte Bit \#} + (8 \times b)$$

To continue with our sample value, the equation would look like this:

$$\begin{aligned} \text{bit number} &= 3 + (8 \times 0) \\ \text{bit number} &= 3 + 0 \\ \text{bit number} &= 3 \end{aligned}$$


Note that if "Byte Bit #" and  $8 \times b$  both equal 0, the address may have been accessed as either an integer (16 bits) or bit 0 of byte 0.

5. Use the figures below to determine the register and bit number when bus errors occur on the modules specified. The slot number and "Bit Byte #" are always decoded using the figure in step 2 above. The formula used to find the bit is the same as in step 4 above.

**Any Local I/O Module  
Least Significant 16 Bits**




**A Modbus Interface Module M/N 57C414  
Least Significant 16 Bits**




where R is a local register address, which may be used with the I/O monitor. Determine the Modbus register number from the following table:

R (Decimal)	Modbus Register (Decimal)
64 - 319	$[(R - 64) * 16] + \text{BYTE BIT\#} + 8 * b + 1$
320 - 575	$[(R - 320) * 16] + \text{BYTE BIT\#} + 8 * b + 10001$
576 - 1599	$(R - 576) + 30001$
1600 - 2623	$(R - 1600) + 40001$

**A Remote I/O Module M/N 57C416  
Least Significant 16 Bits**




**An AutoMate Interface Module M/N 57C417  
Least Significant 16 Bits**



where R is a local register address, which may be used with the I/O monitor. Determine the AutoMate register number from the following table:

R (Decimal)	AutoMate Register (Octal)
64 - 319	0000.00 - 0377.17
320 - 575	0400.00 - 0777.17
576 - 1599	2000 - 3777
1600 - 2623	4000 - 5777

**An Allen-Bradley Interface Module M/N 57C418  
Least Significant 16 Bits**




where R is a local register address, which may be used with the I/O monitor. Determine the A-B register number from the following table:

R (Decimal)	A-B File	A-B Register (Decimal)
64 - 319	B0	R - 64
320 - 575	B1	R - 320
576 - 1599	N0	R - 576
1600 - 2623	N1	R - 1600

# Decoding Error Code 37

When a 37 error code occurs on the Processor module, examine the Error Log for the module using the Programming Executive software. Decode the hexadecimal code found in the Error Log as follows.



**Corrective action:** Reset the Drive Controller module. If this does not correct the problem, systematically replace the Drive Controller module and then the Processor module.

# Appendix C

## Summary of Common DOS Commands

CD	Change to specified directory
CD\ CD..	Change to root directory Change to parent directory of current directory
CHKDSK	Checks and displays the condition of a specified disk or file. If no disk drive is specified the command operates on the default drive.
CHKDSK/V	Executes the CHKDSK command and displays all files
CHKDSK/F	Executes the CHKDSK command and fixes any problems found during the check
COPY	Copies a file(s) from one disk or directory to another specified disk or directory e.g. copy (src drv):\(\dir)\file.ext (dest drv):\(\dir)\file.ext
DEL	Deletes specified file(s)
DISKCOPY	Copies contents of one disk to another
DIR	Lists all files in the default directory
DIR/W	Selects wide display for DIR command
DIR/P	Selects page mode for DIR command
FORMAT	Formats the disk in the specified drive (NOTE: This command erases all files on the disk)
MD	Makes (creates) a new directory
PATH	Sets or displays a command search path e.g. PATH=C:\DCS
PATH;	Sets a null path (i.e. deletes existing path)
PROMPT	Changes the normal MS-DOS prompt e.g. PROMPT=\$p\$g With this command the prompt will now show the default directory
RD	Removes (deletes) specified directory (NOTE: All files within specified directory must first be deleted or copied before operation)
TYPE	Displays specified file (NOTE: To display a file one screen at a time use the  MORE command) e.g. TYPE filename.ext  MORE

# Appendix D

## Windows Command Summary

Access via:	Keyboard	Mouse
Control menu	ALT,SPACEBAR	Click on menu
Menus	ALT,RIGHT(orLEFT), ENTER ALT,underlined letter	Click on menu
Commands	DOWN(orUP),ENTER Type underlined letter	Click on command
Making a Selection	1. DOWN (or UP) to locate item 2. SPACEBAR to select	Click on item
Making Multiple Selections	1. CTRL+DOWN(orUP) to locate item 2. CTRL+SPACEBAR to select 3. Repeat for each item to be selected	CTRL+ click on each item to be selected.
Moving in a Dialog Box	1. TAB to area 2. Use DIRECTION keys ALT+ underlined letter  SPACEBAR toggle choices	Click on desired area, Click on desired item  Click to toggle
Text Box	1. Use DIRECTION keys to locate text 2. SHIFT+DIRECTION to select text	Drag to select text
List Box	1. Use DIRECTION keys, HOME, END, PAGE UP, PAGE DOWN 2. SPACEBAR to select	Use scroll bar, then click on item
Moving a Window or Icon	1. ALT+ESC 2. ALT+SPACEBAR 3. Press M 4. Use DIRECTION keys 5. ENTER	Window - Drag title bar Icon - Drag icon
Changing Size of a Window	1. ALT+ESC 2. ALT+SPACEBAR 3. Press S 4. Use DIRECTION keys to select and move border 5. ENTER	Drag border or corner
Enlarging a Window	1. ALT+ESC 2. ALT+SPACEBAR 3. Press X	Click on Maximize box (upper-right corner)
Shrinking a Window	1. ALT+ESC 2. ALT+SPACEBAR 3. Press N	Click on Minimize box (upper-right corner)
Restoring a Window	1. ALT+ESC 2. ALT+SPACEBAR 3. Press R	Click on Restore box (upper-right corner)

Restoring an icon	ALT+TAB	Double-click on icon
Scrolling: rows, columns	Use DIRECTION keys	Drag scroll box
Top of list	HOME	Drag scroll box to top of scroll bar
End of list	END	Drag scroll box to bottom of scroll bar
up 1 screen	PAGE UP	Click above scroll box
down 1 screen	PAGE DOWN	Click below scroll box
Cancel a Command	ESC	Click on empty space
End session	<ol style="list-style-type: none"> <li>1. ALT+first letter of left-most menu</li> <li>2. X to select Exit Windows command</li> <li>3. OK at dialog box</li> </ol>	Double click on Control menu, then click on OK at dialog box





## For additional information

1 Allen-Bradley Drive

Mayfield Heights, Ohio 44124 USA

Tel: (800) 241-2886 or (440) 646-3599

<http://www.reliance.com/automax>

[www.rockwellautomation.com](http://www.rockwellautomation.com)

#### Corporate Headquarters

Rockwell Automation, 777 East Wisconsin Avenue, Suite 1400, Milwaukee, WI, 53202-5302 USA, Tel: (1) 414.212.5200, Fax: (1) 414.212.5201

#### Headquarters for Allen-Bradley Products, Rockwell Software Products and Global Manufacturing Solutions

Americas: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444

Europe/Middle East/Africa: Rockwell Automation SA/NV, Vorstlaan/Boulevard du Souverain 36, 1170 Brussels, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640

Asia Pacific: Rockwell Automation, 27/F Citicorp Centre, 18 Whitefield Road, Causeway Bay, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846

#### Headquarters for Dodge and Reliance Electric Products

Americas: Rockwell Automation, 6040 Ponders Court, Greenville, SC 29615-4617 USA, Tel: (1) 864.297.4800, Fax: (1) 864.291.2433

Europe/Middle East/Africa: Rockwell Automation, Brühlstraße 22, D-74834 Elchingen, Germany, Tel: (49) 6261 9410, Fax: (49) 6261 17741

Asia Pacific: Rockwell Automation, 55 Newton Road, #11-01/02 Revenue House, Singapore 307987, Tel: (65) 6356-8077, Fax: (65) 6356-9011

Publication J-3669-1 - December 1998

Copyright © 2002 Rockwell Automation, Inc.  
All rights reserved. Printed in U.S.A.