

PowerFlex Active Front End – Frame 13

Catalog Number 20Y
PowerFlex AFE/PowerFlex 700AFE
(400V/480V and 600V/690V)



Important User Information

Read this document and the documents listed in the additional resources section about installation, configuration, and operation of this equipment before you install, configure, operate, or maintain this product. Users are required to familiarize themselves with installation and wiring instructions in addition to requirements of all applicable codes, laws, and standards.

Activities including installation, adjustments, putting into service, use, assembly, disassembly, and maintenance are required to be carried out by suitably trained personnel in accordance with applicable code of practice.

If this equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.

In no event will Rockwell Automation, Inc. be responsible or liable for indirect or consequential damages resulting from the use or application of this equipment.

The examples and diagrams in this manual are included solely for illustrative purposes. Because of the many variables and requirements associated with any particular installation, Rockwell Automation, Inc. cannot assume responsibility or liability for actual use based on the examples and diagrams.

No patent liability is assumed by Rockwell Automation, Inc. with respect to use of information, circuits, equipment, or software described in this manual.

Reproduction of the contents of this manual, in whole or in part, without written permission of Rockwell Automation, Inc., is prohibited

Throughout this manual, when necessary, we use notes to make you aware of safety considerations.



WARNING: Identifies information about practices or circumstances that can cause an explosion in a hazardous environment, which may lead to personal injury or death, property damage, or economic loss.



ATTENTION: Identifies information about practices or circumstances that can lead to personal injury or death, property damage, or economic loss. Attentions help you identify a hazard, avoid a hazard, and recognize the consequence.

IMPORTANT Identifies information that is critical for successful application and understanding of the product.

Labels may also be on or inside the equipment to provide specific precautions.



SHOCK HAZARD: Labels may be on or inside the equipment, for example, a drive or motor, to alert people that dangerous voltage may be present.



BURN HAZARD: Labels may be on or inside the equipment, for example, a drive or motor, to alert people that surfaces may reach dangerous temperatures.



ARC FLASH HAZARD: Labels may be on or inside the equipment, for example, a motor control center, to alert people to potential Arc Flash. Arc Flash will cause severe injury or death. Wear proper Personal Protective Equipment (PPE). Follow ALL Regulatory requirements for safe work practices and for Personal Protective Equipment (PPE).

	Preface	
	Summary of Changes	7
	Intended Audience	7
	What Is in This Manual	7
	What Is Not in This Manual	7
	Additional Resources	8
	Spare Parts	8
	Additional Support Available on the Internet	8
	General Precautions for Class 1 Light-emitting Diode Product	9
	Chapter 1	
Troubleshooting and Error Codes	Create Fault Reports	12
	Addressing PowerFlex Active Front End Faults	12
	Common Symptoms and Corrective Actions	17
	Chapter 2	
Active Front End System Overview	AFE in IP20 2500 MCC Style Enclosure	19
	Main Component Sections	19
	Main Component Locations	20
	Main Bus Bar Locations	21
	AFE in IP21 Rittal Enclosure	22
	Main Component Sections	22
	Main Component Locations	23
	Bus Bar Locations	24
	AFE in IP00 Open Chassis Configuration	25
	Chapter 3	
Component Test Procedures	View the Status Indicators	28
	Perform Visual Inspections	28
	Inspect the Cooling Tunnels	28
	Inspect the Power Structure	29
	Perform Forward and Reverse Biased Diode Tests for Power Structure	29
	Check the Fiber-optic Connections	31
	Perform Gate Driver Board Resistance Measurements	33
	Check the AFE Power Structure Fan Inverter Fuses	34
	Chapter 4	
AFE Power Structure Component Section	Understand the Torque Figures in Assembly Diagrams	36
	Torque Specifications	36
	Remove Power from the AFE	37
	Control Frame Access Procedures	38
	Remove the DPI Interface Assembly	38
	Install the DPI Interface Assembly	39

Remove the I/O Circuit Boards and Control Box 39

Install the I/O Circuit Boards and Control Box 40

Remove the Fiber-optic Adapter Circuit Board 40

Install the Fiber-optic Adapter Circuit Board 42

Remove the Control Frame (only for AFE in IP21 Rittal enclosure)..... 43

Replace the Control Frame..... 43

Power Structure Access Procedures 44

 Remove AFE Protective Barriers 44

 Install AFE Protective Barriers..... 45

 Remove the AFE Airflow Plate 46

 Install the AFE Airflow Plate 46

 Remove Protective Covers from the Power Structure 47

 Install Protective Covers on the Power Structure 47

 Remove the Gate Driver Circuit Boards 47

 Install the Gate Driver Circuit Boards..... 49

 Remove the ASIC Circuit Board..... 50

 Install the ASIC Circuit Board 53

 Remove and Install the Power Structure Fan System..... 53

 Remove the Power Structure from the Enclosure 54

 Install the Power Structure in the Enclosure 59

 Remove the U, V, or W Phase Assembly from the Power Structure 59

 Remove the Power Module from the U, V, or W Phase Assembly..... 62

 Install the Power Module on the U, V, or W Phase Assembly.. 67

 Remove the U, V, or W Phase Assembly DC Bus Capacitors .. 67

 Install the U, V, or W Phase Assembly DC Bus Capacitors.... 68

 Replace the Existing Power Structure with a New Power Structure 68

Chapter 5

AC Line Switchgear Component Section

AFE in IP20 2500 MCC Style Enclosure..... 72

AFE in IP21 Rittal Enclosure..... 72

Chapter 6

Precharge Component Section

Precharging Functions 74

Replace the Precharge Fuse..... 74

Test the Control Transformer (T4) and 24V DC Power Supply (T10)..... 75

 For AFE in IP20 2500 MCC Style Enclosure 75

 For AFE in IP21 Rittal Enclosure 77

Test the Precharge Bridge Using the Power Structure Terminals .. 78

Replace the Precharge Bridge 79

Test the Precharge Resistor..... 79

Replace the Precharge Resistor Assembly 81

	AFE in IP20 2500 MCC Style Enclosure	81
	AFE in IP21 Rittal Enclosure	81
	Chapter 7	
LCL Filter Component Section	Remove the LCL Filter Protective Barriers and Vented Cover	84
	Install the LCL Filter Protective Barriers and Vented Cover	84
	Replace the LCL Filter DC Fan Fuses	84
	Remove the LCL Filter Fan DC Power Supply	85
	Install the LCL Filter Fan DC Power Supply	87
	Replace the LCL Filter Fan	87
	Remove the LCL Filter	88
	From the IP20 2500 MCC Style Enclosure	88
	From the IP21 Rittal Enclosure	90
	Install the LCL Filter in the Enclosure	91
	Chapter 8	
DC Fuses Component Section	Overview	93
	Fuse Replacement Guidelines	94
	Chapter 9	
Startup After Repair	Technical Support	97
	Before Applying Power to the AFE	97
	Appendix A	
Service Tools and Equipment	Software Tools	99
	Service Tools	99
	Appendix B	
Schematic Diagrams	Frame 13 Circuit Board Connections	101
	Frame 13 Power Structure Power Circuitry Block Diagram	102
	Frame 13 Power Module Circuitry	103
	Frame 13 Power Structure Main Fan Connections	104
	Frame 13 Power Structure Main Fan Connections	105
	Control Wiring Diagram for Frame 13 in IP20 2500 MCC Style Enclosure	106
	System Schematics for Frame 13 in IP20 2500 MCC Style Enclosure	108
	Control Wiring Diagram for Frame 13 in IP21 Rittal Enclosure	115
	System Schematics for Frame 13 in IP21 Rittal Enclosure	116
	Appendix C	
Connector Descriptions	Circuit Board Connections	123
	Hardware Connections	126

Disassembly/Assembly Diagrams and Spare Parts	Appendix D	
	AFE Power Structure Assembly	130
	LCL Filter Assembly (used in IP20 and IP21 enclosures)	133
	Precharge Assembly	135
	AC Line Switchgear	137
AFE Power One-line System Application Data	Appendix E	
	Data to Collect.....	139
	Typical Transformer Winding Types	140
	Index	141

Summary of Changes

This manual contains new and updated information as indicated in the following table.


Topic	Page
Updated the basic one-line diagram for a Frame 13 AFE in IP20 2500 MCC style enclosure to include the factory-installed common mode core at the DC bus output.	Figure 1 on page 19
Updated the system schematics for a Frame 13 AFE in IP20 2500 MCC style enclosure to include the factory-installed common mode core at the DC bus output.	Figure 21 on page 108

Intended Audience

This manual is intended for qualified service personnel responsible for troubleshooting and repairing the PowerFlex® Active Front End (AFE). You must have previous experience with, and basic understanding of, electrical terminology, procedures, required troubleshooting equipment, equipment protection procedures and methods, and safety precautions. See safety-related practices that are in Standard for Electrical Safety in the Work Place, publication NFPA 70E.

What Is in This Manual

This manual contains hardware service information for the Frame 13 PowerFlex Active Front End. Verify that you are working on a Frame 13 by checking the data nameplate on the AFE. The frame number is printed just above the serial number.



What Is Not in This Manual

This manual does not contain installation, start-up, and programming information. This information is available in the PowerFlex Active Front End User Manual, publication [20Y-UM001](#).

Additional Resources

These documents contain additional information concerning related products from Rockwell Automation.

Resource	Description
PowerFlex Active Front End User Manual, publication 20Y-UM001	Provides information for installation, startup, and programming for the PowerFlex Active Front End units.
PowerFlex 700H, 700S, and 700AFE Drive Fan Systems Installation Instructions, publication PFLEX-IN029	Provides information for drive fan system service and installation.
Drives in Common Bus Configurations Application Guidelines, publication DRIVES-AT002	Provides guidelines, considerations, and limitations for the proper application of PowerFlex drives used in common bus configurations.
Wiring and Grounding Guidelines for pulse Width Modulated AC Drives, publication DRIVES-IN001	Provides basic information to properly wire and ground Pulse Width Modulated (PWM) AC drives.
Safety Guidelines for the Application, Installation, and Maintenance of Solid-State Control, publication SGI-1.1	Provides general guidelines for the application, installation, and maintenance of solid-state control in the form of individual devices or packaged assemblies with solid-state components.
Guarding Against Electrostatic Damage, publication 8000-4.5.2	Provides an explanation of the causes of Electrostatic Damage, and how you can guard against its effects.
Industrial Automation Wiring and Grounding Guidelines, publication 1770-4.1	Provides general guidelines for installing a Rockwell Automation industrial system.
Product Certifications website, http://www.rockwellautomation.com/global/certification/overview.page	Provides declarations of conformity, certificates, and other certification details.

You can view or download publications at <http://www.rockwellautomation.com/global/literature-library/overview.page>. To order paper copies of technical documentation, contact your local Allen-Bradley distributor or Rockwell Automation sales representative.

Spare Parts

For spare parts information on PowerFlex 7-Class Architecture-Class Low-Voltage AC Drives, including the PowerFlex Active Front End, click this link:

<http://www.ab.com/support/abdrives/powerflex70/PF7ReleasedParts.pdf>

Additional Support Available on the Internet

Additional troubleshooting information and software tools are available on the Allen-Bradley® Drives Service and Support website at <http://www.ab.com/support/abdrives>.

General Precautions for Class 1 Light-emitting Diode Product



ATTENTION: Hazard of permanent eye damage exists when using optical transmission equipment. This product emits intense light and invisible radiation. Do not look into module ports or fiber-optic cable connectors.



ATTENTION: The sheet metal cover and mounting screws on the ASIC Board that is on the power structure are energized at (-) DC bus potential high voltage. Risk of electrical shock, injury, or death exists if someone comes into contact with the assembly.



ATTENTION: To avoid an electric shock hazard, verify that the voltage on the bus capacitors has discharged completely before servicing. Check the DC bus voltage between the +DC and -DC terminals, between the +DC terminal and the chassis, and between the -DC terminal and the chassis. The voltage must be zero for all three measurements.



ATTENTION: Potentially fatal voltages can result from improper usage of an oscilloscope and other test equipment. The oscilloscope chassis can be at a potentially fatal voltage if not properly grounded. Use high-voltage differential voltage probes for all voltage measurements with the oscilloscope chassis that is correctly grounded to an earth ground.



ATTENTION: The PowerFlex Active Front End contains electrostatic discharge (ESD) sensitive parts and assemblies that can be damaged if you do not follow ESD control procedures. Static control precautions are required to install, test, service, or repair this unit. If you are unfamiliar with static control procedures, see Guarding Against Electrostatic Damage, publication [8000-4.5.2](#), or any other applicable ESD protection handbook.



ATTENTION: An incorrectly applied or installed PowerFlex Active Front End can result in component damage or a reduction in product life. Wiring or application errors such as, undersizing the motor, incorrect or inadequate AC supply, or excessive ambient temperatures can result in malfunction of the system.



ATTENTION: Only qualified personnel familiar with adjustable frequency AC drives and associated machinery can plan or implement the installation, start-up, and subsequent maintenance of the system. Failure to comply can result in personal injury and/or equipment damage.

Notes:

Troubleshooting and Error Codes



ATTENTION: To avoid an electric shock hazard, verify that all power to the PowerFlex® Active Front End has been removed before you perform any service or repairs.



ATTENTION: To avoid an electric shock hazard, verify that the voltage on the bus capacitors has discharged completely before servicing. Check the DC bus voltage between the +DC and -DC terminals, between the +DC terminal and the chassis, and between the -DC terminal and the chassis. The voltage must be zero for all three measurements.



ATTENTION: Hot surfaces can cause severe burns. Do not touch the heatsink surface during operation of the PowerFlex Active Front End. After you disconnect power, allow time for cooling.



ATTENTION: The PowerFlex Active Front End contains electrostatic discharge (ESD) sensitive parts and assemblies that can be damaged if you do not follow ESD control procedures. Static control precautions are required to install, test, service, or repair this assembly. If you are unfamiliar with static control procedures, see [Guarding Against Electrostatic Damage](#), publication [8000-4.5.2](#), or any other applicable ESD protection handbook.

Create Fault Reports

Complete fault reports are critical for analysis and repair of modules that are returned to the factory.

At a minimum, perform these tasks:

- Use an Allen-Bradley® drive configuration tool such as Connected Components Workbench™ software, DriveExplorer™ software, or DriveExecutive™ software, do perform these tasks:
 - Upload all parameters from the PowerFlex Active Front End.
 - Run the technical support wizard.
- Collect the AFE system application data that are shown in [Appendix E](#).
- If possible, record the contents of the fault queue (faults and times of occurrence).
- Record the following information:
 - Any burn marks on the rectifying module, DC capacitors, inverter bridge, charging resistors, balancing/precharging resistors, printed circuit boards, bus bars, cabling, and fiber-optic cabling.
 - Any liquid and condensation marks on printed circuit boards, components, and mechanical parts.
 - Amount of dust and other additional particles on drive and drive components.
 - Any mechanical damage to the drive and drive components.
- Record the size and type of main fuses.
- Record any other important marks and damage.
- Note grounding type (solid, high resistance, or floating) and source impedance of the power distribution system.



Addressing PowerFlex Active Front End Faults

No.	Name	Description	Action (if appropriate)
1	PrechargeActv	The AFE is still in precharge, because the charging switch is open: <ul style="list-style-type: none"> • K20, K6, and K1 for AFE in IP20 2500 MCC Style enclosure • K20, K6, and Q1 for AFE in IP21 Rittal enclosure Faulty operation. Component failure.	Reset the fault and restart. If the fault reoccurs, contact technical support.
2	Auxiliary In	The AFE control digital input interlock is open.	Verify wiring to the digital inputs on the AFE control board is correct.
4	DC UnderVolt	The DC bus voltage fell below the minimum value of 333V for 400/480V units, or 461V for 600/690V units. You can enable/disable this fault with parameter 120 [Fault Config].	Monitor the incoming AC line for low voltage or power interruption.
5	DC OverVolt	The DC bus voltage exceeded the maximum value of 911V for 400/480V units, or 1200V for 600/690V units.	Check if the AFE was in a regenerative current limit condition, which can indicate an excess regenerative load. Adjust parameter 076 [Regen Power Lmt]. Monitor incoming AC line for high voltage or voltage transients.

No.	Name	Description	Action (if appropriate)
7	Overload	When input current exceeds 125% for 60 seconds or 150% for 30 seconds. The overload is a linear type in counting up.	Reduce the current consumption of the AFE or increase parameter 133 [Cnvrtr OL Factor].
8	HeatsinkOvrTp	The power structure heatsink temperature has exceeded the maximum allowable value. 85 °C (185 °F) = Alarm 90 °C (194 °F) = Fault	Verify that the maximum ambient temperature has not been exceeded. Check the fans (including the ASIC board on the converter). Check for an excess load. Verify that the airflow plate is installed. See page 46 .
9	IGBT OverTemp	The output transistors have exceeded their maximum operating temperature due to an excessive load.	Verify that the maximum ambient temperature has not been exceeded. Check the fans. Check for an excess load.
10	System Fault	A hardware problem exists in the power structure.	Reset the fault and restart. Verify the fiber-optic connections. Verify ASIC board jumper connections from X9 to X15 (see Figure on page 102). Contact technical support. If the problem persists, replace or repair the power structure.
12	AC OverCurr	The AC line current has exceeded the hardware current limit.	Check for an excessive load or other causes of excess current.
13	Ground Fault	A current path to earth ground exists that is greater than the parameter 082 [Ground I Lvl] value. The current must appear for 800 milliseconds before the unit will fault.	Use a digital voltmeter to check for low impedance to ground, and verify the bus cables/bars between the: Disconnect and AC input lines Power structure and LCL filter For AFE in IP20 enclosure: <ul style="list-style-type: none"> • Q0 input breaker and K1 input contactor, which includes the precharge disconnect • LCL filter and K1 input cont. For AFE in IP21 enclosure: <ul style="list-style-type: none"> • Q1 (MCCB) and Q0 disconnect switch, which includes the precharge disconnect • LCL filter and Q1 (MCCB)
14	Power Structure Fault	A hardware problem exists in the power structure.	Cycle the power. Contact technical support. If the problem persists, replace the converter unit.
17	LineSync Fail	One input of the known phase rotation is missing.	Check all user-supplied fuses. Check the AC input line voltage.
21	Phase Loss	There are zero current in one of the three phases.	Check supply voltage, fuses, and cable.
29	Anlg In Loss	An analog input is configured to fault on a signal loss. A signal loss has occurred. Configure this fault with parameter 203 or 206 [Anlg In x Loss].	Verify parameter 203 or 206 [Anlg In x Loss] setting. Verify that input signal levels are greater than or equal to 1.5V or 3 mA. Check for broken/loose connections at the inputs.
30	MicroWatchdog	A microprocessor watchdog timeout has occurred.	Cycle the power. Replace the control board. See page 39 .
31	IGBT Temp Hw	The AFE input current has exceeded the 1 minute overload rating.	Check for an excess load.

No.	Name	Description	Action (if appropriate)
32	Fan Cooling	The power structure or LCL filter fans are not energized at start command.	If the LCL filter fan is not operating, check the fan DC power supply board in front of the LCL filter fan. If the power structure fan is not operating, check the fan inverter board in back of the converter fan. For additional information, see PowerFlex 700H, 700S, and 700AFE Drive Fan Systems Installation Instructions, publication PFLEX-IN029 .
33	AutoReset Lim	The AFE unsuccessfully attempted to reset a fault and resumed running for the programmed number in parameter 053 [Auto Rstrt Tries]. You can enable/disable this fault with parameter 120 [Fault Config].	Correct the cause and manually clear the fault.
34	CAN Bus Flt	A sent message was not acknowledged.	Cycle the power. Replace the control board on the power structure. See page 39 .
35	Application	Problem in application software with task overload.	Contact technical support.
37	HeatsinkUndTp	The ambient temperature around the power structure heatsink is too low.	Raise the ambient temperature.
44	Device Change	The new power unit or option board that is installed is a different type.	Clear the fault and verify the correct parameters for the new option board.
45	Device Add	A new option board was added.	Clear the fault.
47	NvsReadChksum	There was an error reading parameters 019 [Motoring MWh], 020 [Regen MWh], and 021 [Elapsed Run Time] from EEPROM.	Cycle the power. Replace the control board. See page 39 .
58	Start Prevent	Startup has been prevented.	Cancel prevention of startup if cancellation can be done safely. Remove Run Request.
65	I/O Removed	An I/O option board has been removed.	Clear the fault.
70	Power Unit	Incorrect output power device operation.	Check the power structure for damaged components. Replace if defective. Replace the power structure.
71	Periph Loss	The 20-COMM-x communication adapter has a fault on the network side.	Check the DPI™ device event queue and associated fault information for the device.
81	Port DPI Loss	The DPI port has stopped communicating. A SCANport™ device was connected to a drive operating DPI devices at 500k baud.	Check the HIM connection. If the adapter was not intentionally disconnected, check the wiring to the port. Replace the wiring, port expander, adapters, control board, or complete AFE as required. If an adapter was intentionally disconnected and the [Logic Mask] bit for that adapter is set to '1', this fault occurs. To disable this fault, set the bit in parameter 154 [Logic Mask] to '0' for the port in which the adapter is connected.
94	Hardware Enbl	An enable signal is missing from the control terminal block, only when jumper J5 is removed on the digital I/O board.	Check the control wiring. Check the position of the J5 hardware enable jumper. Check the digital input programming.

No.	Name	Description	Action (if appropriate)
100	Param Chksum	The checksum read from the control board does not match the checksum that is calculated.	Restore the AFE to the default configurations. Cycle the power. Replace the control board in the power structure. See page 39 .
104	PwrBrd Chksum	The checksum read from the EEPROM does not match the checksum that is calculated from the EEPROM data.	Cycle the power. Check the fiber optics between the fiber-optic adapter board and the ASIC board. See Table 9 on page 123 , Table 10 on page 124 , and Figure 36 on page 125 for connections. Replace the fiber-optic adapter board (see page 40) and/or the ASIC board (see page 50) in the converter unit. Contact technical support.
106	MCB-PB Config	The AFE rating information that is stored on the power board is incompatible with the control board.	Reset the fault Cycle the power. Replace the control board on the power structure. See page 39 . Contact technical support.
107	New IO Option	A new option board was added to the control board.	Clear the fault and verify the correct parameters for the new option board. Reprogram parameters as necessary.
113	Fatal App	A Fatal Application error has occurred.	Cycle the power. Replace the control board on the power structure. See page 39 .
120	I/O Change	An option board has been replaced.	Reset the fault.
121	I/O Comm Loss	A defective option board or I/O board slot.	Check the control board-to-I/O option board connection. Verify the ground integrity from the control board to the option board. Replace the control board and/or I/O board. See page 39 .
125	LCL OverTemp	The LCL filter has been overheated or the signal is not connected to input.	Check the LCL filter and signal connection or verify that digital input 5 is closed. See Chapter 7 .

No.	Name	Description	Action (if appropriate)
		<p>There are nine total thermal switches that are connected in series to monitor temperature inside the coil of each filter inductor.</p>  <p>X52 is on the LCL Filter.</p> <p>X52 Approximate Location</p>  <p>Frame 13 LCL Filter</p>	
126	LCL Fan Stop	The LCL fan has been stopped.	<p>Check the LCL fan. See Chapter 7.</p> <p>IMPORTANT: This fault occurs only when a digital input is manually programmed as option '5'.</p>
128	Contact Fdbk	The input of the acknowledge signal from the main contactor is missing.	<p>Check for closure on the following devices:</p> <ul style="list-style-type: none"> • For AFE in IP20 enclosure, input contactor (K1) • For AFE in IP21 enclosure, MCCB (Q1) <p>Check digital input 4 on the control board of the power structure.</p>
133	DigInConflict	Digital input functions are in conflict.	Check the parameter settings of parameters 221 . . . 226.
138	DCRefLowLim	DC voltage reference is less than the limit in parameter 080 [DC Ref Lo Lmt].	<p>Check the parameter setting.</p> <p>Verify the bus voltage to be above the parameter value.</p> <p>Troubleshoot the cause of the low voltage condition.</p>
139	DCRefHighLim	DC voltage reference exceeds the limit in parameter 081 [DC Ref Hi Lmt].	<p>Check the parameter setting.</p> <p>Verify the bus voltage to be below the parameter value.</p> <p>Troubleshoot the cause of the high voltage condition.</p>
140	DCBusLoAlarm	DC voltage is less than the value set by parameter 078 [DC Bus Lo Alarm].	Check the parameter setting.
141	DCBusHiAlarm	DC voltage exceeds the value set by parameter 079 [DC Bus Hi Alarm].	Check the parameter setting.

Common Symptoms and Corrective Actions

AFE does not start from start or run inputs that are wired to the terminal block.

Cause	Indication	Corrective Action
AFE is faulted	Flashing red status light	Clear the fault. Press Stop. Cycle the power. Set parameter 121 [Fault Clear] to '1'. 'Clear Faults' on the HIM Diagnostic menu.
Incorrect input wiring. See the 'Control Wiring' section in the PowerFlex Active Front End User Manual, publication 20Y-UM001 , for information. Important: Jumper from terminal 17...20 is required when using the 24V DC internal supply.	None	Wire inputs correctly and/or install jumper.
Incorrect digital input programming.	None	Program parameters 221...226 [Digital Inx Sel] for correct inputs. Run programming can be missing.
There is some other start inhibit.	Check status bits of parameter 100 [Start Inhibits].	Correct the source of the inhibit.

Instability in the AC line input current and DC bus voltage.

Cause	Indication	Corrective Action
AC line voltage more than 5% above normal.	Instability in AC line current and DC bus voltage. Can trip on fault F7 'Overload'.	Increase parameter 060 [DC Volt Ref] proportional to the percentage of the AC line voltage that is above nominal.
Negative reactive I Ref on parameter 065 [Reactive I Ref] with a soft (high impedance) AC line.	Instability in AC line current and DC bus voltage. Can trip an F7 overload.	Change parameter 065 [Reactive I Ref] value to zero. Verify if the AFE is running on a soft line per the AC line source considerations.

Notes:

Active Front End System Overview

This chapter describes AFE system main components. The chapter groups components that are used in an IP20 2500 MCC Style enclosure, an IP21Rittal enclosure, and main components for the AFE IP00 open chassis configuration.


AFE in IP20 2500 MCC Style Enclosure

Main Component Sections

[Figure 1](#) shows a basic one-line diagram for an AFE system in an IP20 2500 MCC Style enclosure. The main component sections consist of the following items:

- AC line switchgear consisting of the input circuit breaker (Q0), fuses (F1.1...F1.3), and input contactor (K1)
- LCL filter (L1)
- Precharge circuit
- AFE power structure (U1) with AFE control assembly
- DC fuses (F2.1...F2.6)


Figure 1 - Basic One-line Diagram for an AFE Frame 13 in IP20 2500 MCC Style Enclosure



Main Component Locations

Figure 2 shows the main components of the AFE Frame 13 system in an IP20 2500 MCC Style enclosure.

Figure 2 - AFE Frame 13 Main Component Locations in IP20 2500 MCC Style Enclosure



Item	Description	
1	Precharge circuit	
2	Precharge resistor (R6.1)	
3	LCL filter (L1)	
4	Active Front End power structure (U1)	
5	AC line switchgear	Input circuit breaker (Q0)
6		Input fuses (F1.1...F1.3)
7		Input contactor (K1)
8	DC fuses (F2.1...F2.6)	
9	AFE control box assembly (on the AFE door and shown with user-installed HIM)	


Main Bus Bar Locations

There are several sets of bus bars in the AFE Frame 13 system that connect main system components:

- Bus bars between input breaker (Q0) and AC fuses (F1.1...F1.3)
- Bus bars between AC fuses (F1.1...F1.3) and input contactor (K1)
- Bus bars between input contactor (K1) and the LCL filter (L1)
- Bus bars between the AFE power structure (U1) and DC bus

[Figure 3](#) shows these bus bar locations.

Figure 3 - AFE Frame 13 Bus Bar Locations in IP20 2500 MCC Style Enclosure




AFE in IP21 Rittal Enclosure Main Component Sections

Figure 4 shows a basic one-line diagram for an AFE system in an IP21 Rittal enclosure. The main component sections consist of the following items:

- AC line switchgear consisting of the input disconnect (Q0) and MCCB motor-controlled circuit breaker (Q1)
- LCL filter (L1)
- Precharge circuit
- AFE power structure (U1) with AFE control assembly
- DC fuses (F2.1...F2.6)


Figure 4 - Basic One-line Diagram for AFE in IP21 Rittal Enclosure



Main Component Locations

[Figure 5](#) shows the main components of the AFE Frame 13 system in an IP21 Rittal enclosure.

Figure 5 - AFE Frame 13 Main Component Locations in IP21 Rittal Enclosure



Item	Description	
1	Precharge circuit and precharge resistors (R6.1 and R6.2)	
2	LCL filter (L1)	
3	Active Front End power structure (U1)	
4	AC line switchgear	Motor-controlled circuit breaker (Q1)
5		Input disconnect (Q0)
6	AFE control assembly (shown with user-installed HIM)	
7	DC fuses (F2.1...F2.6)	


Bus Bar Locations

There are several sets of bus bars in the AFE Frame 13 system that connect main system components:

- Bus bars between input disconnect (Q0) and MCCB (Q1)
- Bus bars between MCCB (Q1) and the LCL filter (L1)
- Bus bars between the LCL filter (L1) and AFE power structure (U1)
- Bus bars between the AFE power structure (U1) and DC bus bars

Figure 6 shows these bus bar locations.


Figure 6 - AFE Frame 13 Bus Bar Locations in IP21 Rittal Enclosure



AFE in IP00 Open Chassis Configuration

Figure 7 shows a basic one-line diagram for an AFE system in an IP00, NEMA/UL Open Chassis configuration, and the parts the customer must supply.

Figure 7 - Basic One-line Diagram for AFE in IP00 Open Chassis Configuration



Notes:

Component Test Procedures



ATTENTION: The sheet metal cover and mounting screws on the ASIC Board that is on the power structure are energized at (-) DC bus potential high voltage. Risk of electrical shock, injury, or death exists if someone comes into contact with the assembly.



ATTENTION: To avoid an electric shock hazard, verify that all power to the PowerFlex® Active Front End has been removed before you perform any service or repairs.



ATTENTION: To avoid an electric shock hazard, verify that the voltage on the bus capacitors has discharged completely before servicing. Check the DC bus voltage between the +DC and -DC terminals, between the +DC terminal and the chassis, and between the -DC terminal and the chassis. The voltage must be zero for all three measurements.



ATTENTION: Hot surfaces can cause severe burns. Do not touch the heatsink surface during operation of the PowerFlex Active Front End. After you disconnect power, allow time for cooling.



ATTENTION: Hazard of permanent eye damage exists when using optical transmission equipment. This product emits intense light and invisible radiation. Do not look into fiber-optic ports or fiber-optic cable connectors.



ATTENTION: The PowerFlex Active Front End contains electrostatic discharge (ESD) sensitive parts and assemblies that can be damaged if you do not follow ESD control procedures. Static control precautions are required to install, test, service, or repair this assembly. If you are unfamiliar with static control procedures, see Guarding Against Electrostatic Damage, publication [8000-4.5.2](#), or any other applicable ESD protection handbook.

View the Status Indicators

This section describes the status indicators.




Table 1 - AFE Status Indicator Descriptions

Item	Name	Color	State	Description
1	PWR (Power)	Green	Steady	Lights when power is applied to the AFE.
2	PORT ⁽¹⁾	See to the Communication Adapter User Manual, publication 20COMM-UMxxx		Status of DPI™ port internal communication (if present).
	MOD ⁽¹⁾			Status of communication adapter (when installed).
	NET A ⁽¹⁾			Status of network (if connected).
	NET B ⁽¹⁾			Status of secondary network (if connected).

(1) These indicators operate only when a 20-COMM-X communication adapter is installed in the AFE and operating on the connected network.

Perform Visual Inspections

IMPORTANT Always remove power from the Active Front End before you perform visual inspections. See [Remove Power from the AFE on page 37](#).

Inspect the Cooling Tunnels

To inspect the cooling tunnels, follow these steps.

1. Remove the main cooling fans from the bottom of the power structure.
See [Remove and Install the Power Structure Fan System on page 53](#).
2. Inspect the tunnels.
Clean the heatsinks and tunnels if necessary.

Inspect the Power Structure

To inspect the power structure, follow these steps.

1. Remove the protective barriers.
See [Remove AFE Protective Barriers on page 44](#).
2. Remove the protective front covers and terminal covers from the power structure for each phase (U, V, and W).
See [Remove Protective Covers from the Power Structure on page 47](#).
3. Check components for burn marks, breakage, or foil delamination on circuit boards.

Check all boards on the power structure.


Replace any of these components if they show evidence of burn marks, breakage, or foil delamination.

Perform Forward and Reverse Biased Diode Tests for Power Structure

A forward biased diode test checks the semiconductor junctions between the terminals and measures the voltage drop across those junctions. To pass each test, the meter must display a voltage near 0.5V. If the test finds a short, the meter displays '.000'. If the test finds an open circuit or reversed polarity, the meter displays '.0L' (zero load).

IMPORTANT The actual voltage readings can vary depending upon your equipment. If your readings are not near the indicated values in the following tables, verify that the actual voltage that is measured is consistent for the Power module.

A reverse biased diode test finds an open circuit, and the meter displays '.0L' (zero load).



To perform forward and reverse biased diode tests for the power structure, follow these steps.

1. Remove power from the AFE.
See [Remove Power from the AFE on page 37](#).
2. Remove the protective barriers.

See [Remove AFE Protective Barriers on page 44](#).

3. Disconnect any drives that are connected to the DC bus from the DC bus, or remove the DC bus fuses from the AFE.
4. Conduct forward and reverse biased diode tests on the power structure.

Figure 8 - Measurement Points for Forward and Reverse Diode Tests




Table 2 - Forward Biased Diode Tests on Power Structure

Meter Leads		Location (see Figure 8)	Nominal Meter Reading
+	-		
DC-	U/T1	1	Value gradually rises to about 0.5V ⁽¹⁾
DC-	V/T2		
DC-	W/T3		
U/T1	DC+	2	
V/T2	DC+		
W/T3	DC+		

(1) The actual voltage reading can vary depending upon your equipment. If your readings are not near 0.5V, verify that the actual voltage that is measured is consistent for the power structure.

Table 3 - Reverse Biased Diode Tests on Power Structure

Meter Leads		Location (see Figure 8)	Nominal Meter Reading
+	-		
U/T1	DC-	1	Meter displays '.0L' (zero load)
V/T2	DC-		
W/T3	DC-		
DC+	U/T1	2	
DC+	V/T2		
DC+	W/T3		

If the AFE fails any of these measurements, replace all power modules for each line phase in the power structure, or the complete power structure. To replace the components, follow one of these options:


- Contact your local representative to schedule on-site services.
- Contact your local representative to make arrangements to return the power structure to the factory for repair by Remanufacturing Services.
- For an AFE not covered under factory warranty, a customer has the option of repairing the power structure using procedures that are described in this manual.

Check the Fiber-optic Connections

Damaged or improperly connected fiber-optic cables can cause apparent gate driver board malfunctions. For fiber-optic cable connections, see [Table 9 on page 123](#), [Table 10 on page 124](#), and [Figure 36 on page 125](#).

To check the fiber-optic connection, follow these steps.

1. Remove power from the AFE.
See [Remove Power from the AFE on page 37](#).
2. If present, remove the protective barriers.
See [Remove AFE Protective Barriers on page 44](#).
3. Remove the protective front covers and terminal covers from the power structure.
See [Remove Protective Covers from the Power Structure on page 47](#).
4. Locate the three gate driver boards on the front of the power structure (right-side AFE enclosure).



5. Verify that the fiber-optic cables are properly connected between the gate driver boards and the ASIC board.

IMPORTANT The minimum inside bend radius for fiber-optic cable is 25.4 mm (1 in.). Any bends with a shorter inside radius can permanently damage the fiber-optic cable. Signal attenuation increases with decreased inside bend radii.

6. Verify that the fiber-optic cables are properly connected between the ASIC board and the fiber-optic adapter circuit board.
7. Disconnect the cables and inspect them for scratches and cracks, and overall integrity.

IMPORTANT When mishandled, the ability of fiber-optic cables to transmit data is greatly diminished.

8. Reconnect the cables, replacing any damaged cables.

Perform Gate Driver Board Resistance Measurements

To measure the gate driver board resistance, follow these steps.

1. Remove power from the AFE.

See [Remove Power from the AFE on page 37](#).

2. If present, remove the protective barriers.

See [Remove AFE Protective Barriers on page 44](#).

3. Remove the protective front covers and terminal covers from the power structure for each phase (U, V, and W).


See [Remove Protective Covers from the Power Structure on page 47](#).

There are three gate driver boards on the power structure, one for each phase (U, V, and W).

4. Measure the power transistor gate interface resistance for each phase (U, V, and W):

- The resistance from each ignition pin to the branch emitter pin (connectors X10 and X11) is approximately 166 Ω .
- The resistance from the X10 branch emitter pin to the same branch power terminal (U/T1, V/T2, and W/T3) is approximately 0.5 Ω .
- The resistance from the X11 branch emitter to the same branch DC-bus terminal is approximately 0.5 Ω .


If any of the gate interfaces fails this test, replace the appropriate (left, middle, or right) power module. See [Remove the Power Module from the U, V, or W Phase Assembly on page 62](#).



Check the AFE Power Structure Fan Inverter Fuses

To check the AFE power structure fan inverter fuse, follow these steps.

1. Remove power from the AFE.
See [Remove Power from the AFE on page 37](#).
2. If present, remove the protective barriers.
See [Remove AFE Protective Barriers on page 44](#).
3. Remove the protective front covers and terminal covers from the power structure for each phase (U, V, and W).
See [Remove Protective Covers from the Power Structure on page 47](#).
4. A pair of fuses (F1 and F2) feed DC bus power to each fan inverter.
 - a. Locate these fuses (shown below) and remove them.
 - b. Use a multi-meter to verify that the fuses are not open.



5. Reinstall the good fuses and replace any open fuse with an equivalent-rated fuse.

AFE Power Structure Component Section



ATTENTION: To avoid an electric shock hazard, verify that all power to the PowerFlex® Active Front End has been removed before you perform any service or repairs.



ATTENTION: To avoid an electric shock hazard, verify that the voltage on the bus capacitors has discharged completely before servicing. Check the DC bus voltage between the +DC and -DC terminals, between the +DC terminal and the chassis, and between the -DC terminal and the chassis. The voltage must be zero for all three measurements.



ATTENTION: The sheet metal cover and mounting screws on the ASIC Board that is on the power structure are energized at (-) DC bus potential high voltage. Risk of electrical shock, injury, or death exists if someone comes into contact with the assembly.



ATTENTION: Hot surfaces can cause severe burns. Do not touch the heatsink surface during operation of the PowerFlex Active Front End. After you disconnect power, allow time for cooling.



ATTENTION: Hazard of permanent eye damage exists when using optical transmission equipment. This product emits intense light and invisible radiation. Do not look into fiber-optic ports or fiber-optic cable connectors.




ATTENTION: The PowerFlex Active Front End contains electrostatic discharge (ESD) sensitive parts and assemblies that can be damaged if you do not follow ESD control procedures. Static control precautions are required to install, test, service, or repair this assembly. If you are unfamiliar with static control procedures, see Guarding Against Electrostatic Damage, publication [8000-4.5.2](#), or any other applicable ESD protection handbook.

Use the instructions in this chapter to remove and install components from the Active Front End. To remove and install components on the power structure and to remove a power module from the power structure, see [Power Structure Access Procedures on page 44](#).

Understand the Torque Figures in Assembly Diagrams

Icons and numbers in the assembly diagrams indicate how to tighten hardware.



Torque Specifications

The following table lists fastener torque specifications for the circuit boards and main components of the Active Front End.

Item	Hardware	Final Torque	
AC input terminals	M10 nut	40 N•m (354 lb•in)	
ASIC circuit board (mounting)	M4 x 8 Poizidriv screws	0.9 N•m (8 lb•in)	
ASIC circuit board cover	M4 x 8 Poizidriv screws	0.9 N•m (8 lb•in)	
ASIC fan	M4 x 16 Poizidriv screws	0.4 N•m (3.5 lb•in)	
Capacitor	M4 x 8 self-tapping screws	1 N•m (9 lb•in)	
DC-/DC+ terminals	M6 x 20 Poizidriv screws	5 N•m (44 lb•in)	
DC connective bus bars	M10 x 20 hexagonal screws	8 N•m (71 lb•in)	
	M8 x 25 hexagonal socket-head screws	8 N•m (71 lb•in)	
	M6 x 12 Poizidriv screws	4 N•m (35 lb•in)	
DPI/HIM assembly door	M3 x 6 Phillips screws	0.9 N•m (8 lb•in)	
DPI/HIM assembly (mounting)	M3 x 6 Phillips screws	0.9 N•m (8 lb•in)	
Fan inverter assembly	M5 x 10 Poizidriv screws	4 N•m (35 lb•in)	
Fan inverter fuse base	M4 x 8 Poizidriv screws	3 N•m (27 lb•in)	
Fan inverter fuse holder	M4 x 8 Poizidriv screws	3 N•m (27 lb•in)	
Gate driver circuit board (mounting)	M4 x 8 Poizidriv screws	1.35 N•m (12 lb•in)	
Main cooling fan (mounting)	M5 x 10 Poizidriv screws	3 N•m (27 lb•in)	
Precharge bridge assembly	Wire fasteners	M5 x 12 machine screws	4.5 N•m (40 lb•in)
	Mounting	M5 nuts	3.9 N•m (35 lb•in)
Precharge bridge resistor assembly	M5 x 12 Torx self-tapping screws	4.5 N•m (40 lb•in)	
LCL filter upper front bracket	In IP20 enclosure	M8 x 20	6.7 N•m (60 lb•in)
		M6 x 16 screws	4.5 N•m (40 lb•in)
	In IP21 enclosure	M5 x 12 Torx self-tapping screws	4.5 N•m (40 lb•in)

Item		Hardware	Final Torque
Power structure input terminals (U, V, W)	In IP20 enclosure	M10 x 40 bolt	37.9 N•m (336 lb•in)
	In IP21 enclosure	M8 x 20 bolt	20 N•m (177 lb•in)
Power structure block (mounting)		M10 x 12 hexagonal screw	20 N•m (177 lb•in)
Power structure DC bus terminals	In IP20 enclosure		
	In IP21 enclosure	M6 x 16 Pozidriv	
Protective covers on power structure	Front	M5 x 10 Pozidriv	3 N•m (27 lb•in)
	Terminal	M5 x 16 Pozidriv	3 N•m (27 lb•in)

Remove Power from the AFE



ATTENTION: To avoid an electric shock hazard, verify that the voltage on the bus capacitors has discharged completely before servicing. Check the DC bus voltage between the +DC and -DC terminals, between the +DC terminal and the chassis, and between the -DC terminal and the chassis. The voltage must be zero for all three measurements.


Remove power before you make or break cable connections. When you remove or insert a cable connector with power applied, an electric arc can occur. An electric arc can cause personal injury or property damage by these actions:

- Sends an erroneous signal to the system field devices, which causes unintended machine motion.
- Causes an explosion in a hazardous environment.

Electrical arcing causes excessive wear to contacts on both the module and its mating connector. Worn contacts can create electrical resistance.

To remove power from the AFE, follow these steps.

1. Turn off and lockout input power.



2. Wait 5 minutes.
3. Verify that there is no voltage at the AFE input power terminals.
4. Check the DC bus voltage between the +DC and -DC terminals, between the +DC terminal and the chassis, and between the -DC terminal and the chassis.

The voltage must be zero for all three measurements before proceeding.

Control Frame Access Procedures

Remove the DPI Interface Assembly

To remove the DPI™ interface assembly, follow these steps.


1. Remove power from the AFE.

See [Remove Power from the AFE on page 37](#).

IMPORTANT Before you remove the connections and wires, mark them to avoid incorrect wiring during assembly.

2. For an AFE in an IP20 2500 MCC Style enclosure, disregard this step.


For an AFE in an IP21 Rittal enclosure, locate the control assembly (item 6 in [Figure 5 on page 23](#)), and remove the two screws from the front of the DPI hinged assembly.




3. For an AFE in an IP20 2500 MCC Style enclosure, open the control box door to access the DPI interface board.

For an AFE in an IP21 Rittal enclosure, open the hinged assembly that holds the DPI interface board.

4. Unplug the DPI cable from the X2 connector on the DPI interface board.



5. Remove the four screws and the assembly from the control frame.



Install the DPI Interface Assembly

Install the DPI interface assembly in the reverse order of removal, while referring to [Torque Specifications on page 36](#).

Remove the I/O Circuit Boards and Control Box

To remove the I/O circuit boards and control box, follow these steps.


1. Remove power from the AFE.
See [Remove Power from the AFE on page 37](#).
2. For an AFE in an IP20 2500 MCC Style enclosure, open the control box and carefully unplug the DPI cable and any I/O cables.

For an AFE in an IP21 Rittal enclosure, open the enclosure that contains the control and I/O circuit boards and carefully unplug the DPI cable and any I/O cables.


3. Remove the I/O boards from the control board and enclosure.

Note the order of the boards and the keys that help prevent placement of boards in incorrect slots.

IMPORTANT: Do not remove the enclosure cover from the control frame. For clarity, the enclosure is shown without the cover.





- Unplug the serial connection from X7 of the control board.



- To remove the control box, remove the three screws that secure it to the control frame.

IMPORTANT: Do not remove the enclosure cover from the control frame. For clarity, the enclosure is shown without the cover.



Install the I/O Circuit Boards and Control Box


Install the control box and I/O circuit boards in reverse order of removal. See [Torque Specifications on page 36](#).

Remove the Fiber-optic Adapter Circuit Board

To remove the fiber-optic adapter circuit board, follow these steps.


- Remove power from the AFE.
See [Remove Power from the AFE on page 37](#).
- For an AFE in an IP20 2500 MCC Style enclosure, open the control box on the enclosure door to access the control assembly.

For an AFE in an IP21 Rittal enclosure, see the following drawing and do perform these substeps:



- a. To access the control frame, open the enclosure door.
 - b. To open the control frame, loosen the T8 screws.
 - c. Open the control frame, which exposes the back of the control box to access the fiber-optic adapter board.
3. Disconnect the cables from X2 and X3 of the fiber-optic adapter board.

IMPORTANT Note polarity when removing X2 and X3 wires. If polarity is not maintained when reinstalling these wires, the ASIC board or fiber-optic board can be damaged.



4. Carefully disconnect the fiber-optic cables from the right side of the circuit board, and carefully set them aside.




ATTENTION: Hazard of permanent eye damage exists when using optical transmission equipment. This product emits intense light and invisible radiation. Do not look into fiber-optic ports or fiber-optic cable connectors.

IMPORTANT When mishandled, the ability of fiber-optic cables to transmit data is greatly diminished.

IMPORTANT The minimum inside bend radius for fiber-optic cable is 25.4 mm (1 in.). Any bends with a shorter inside radius can permanently damage the fiber-optic cable. Signal attenuation increases with decreased inside bend radii.

5. Remove the four screws that secure the fiber-optic adapter board to the stand-offs on the back of the control box (IP20) or control frame (IP21) and remove the fiber-optic adapter board.



Install the Fiber-optic Adapter Circuit Board


Install the fiber-optic adapter circuit board in reverse order of removal. See [Torque Specifications on page 36](#).

Remove the Control Frame (only for AFE in IP21 Rittal enclosure)


To remove the control frame for an AFE in an IP21 Rittal enclosure, follow these steps.

1. Remove power from the AFE.

See [Remove Power from the AFE on page 37](#).



2. Loosen the T8 Torx-head screws, which secure the control frame to the AFE enclosure.
3. Swing the control frame out and away from the power structure.
4. Lift the control frame from the hinges and remove it.



Replace the Control Frame

Replace the control frame in reverse order of removal. See [Torque Specifications on page 36](#).

Power Structure Access Procedures


Follow these instructions to remove and install components on the power structure, and to remove power modules from the power structure.


IMPORTANT To replace power modules, you must remove the power structure from the AFE enclosure.

Remove AFE Protective Barriers

To remove the AFE protective barriers, follow these steps.

1. Remove power from the AFE.
See [Remove Power from the AFE on page 37](#).
2. Remove the screws that secure the protective barriers to the AFE enclosure.
3. Remove the protective barriers.





Install AFE Protective Barriers

Install the protective barriers in reverse order of removal.

Remove the AFE Airflow Plate



You must remove the airflow plate to remove the power structure from the AFE.

To remove the AFE airflow plate, follow these steps.

1. Remove power from the AFE.
See [Remove Power from the AFE on page 37](#).
2. If present, remove the protective barriers.
See [Remove AFE Protective Barriers on page 44](#).
3. For an AFE in an IP20 2500 MCC Style enclosure, remove the four M6 x 16 screws that secure the airflow plate to the AFE, and remove the two M6 x 16 screws that secure the airflow plate to the LCL filter.

For an AFE in an IP21 Rittal enclosure, remove the four T8 Torx-head screws that secure the airflow plate to the AFE.

4. Slide the airflow plate from the AFE.



Install the AFE Airflow Plate

Install the airflow plate in reverse order of removal.


Remove Protective Covers from the Power Structure

You must remove the protective covers to access internal components of the power structure.

To remove the protective covers from the power structure, follow these steps.

1. Remove power from the AFE.
See [Remove Power from the AFE on page 37](#).
2. If present, remove the protective barriers.
See [Remove AFE Protective Barriers on page 44](#).
3. Remove the four M5 Pozidriv screws that secure the protective front covers and terminal covers to the power structure.
4. Remove the covers.

IMPORTANT Remove only the terminal covers to gain access to the cooling fan connections.



Install Protective Covers on the Power Structure

Install the protective covers on the power structure in reverse order of removal. See [Torque Specifications on page 36](#) for torque specifications.

Remove the Gate Driver Circuit Boards

There are three gate driver circuit boards on the front of the power structure.

To remove the gate driver circuit boards, follow these steps.

1. Remove power from the AFE.

See [Remove Power from the AFE on page 37](#).

2. If present, remove the protective barriers.

See [Remove AFE Protective Barriers on page 44](#).

3. Remove the airflow plate.

See [Remove the AFE Airflow Plate on page 46](#).

4. Remove the protective front covers and terminal covers from the power structure.

See [Remove Protective Covers from the Power Structure on page 47](#).

5. Unscrew the terminals for the DC +/- supply from X1 of the first gate driver board.

Observe polarity when removing for later reattachment.

6. Carefully unplug the fiber-optic cables from sockets along the bottom of the gate driver board, and carefully set them aside.




ATTENTION: Hazard of permanent eye damage exists when using optical transmission equipment. This product emits intense light and invisible radiation. Do not look into fiber-optic ports or fiber-optic cable connectors.

IMPORTANT When mishandled, the ability of fiber-optic cables to transmit data is greatly diminished.


IMPORTANT The minimum inside bend radius for fiber-optic cable is 25.4 mm (1 in.). Any bends with a shorter inside radius can permanently damage the fiber-optic cable. Signal attenuation increases with decreased inside bend radii.

7. Disconnect the X13, X14, and X15 cables from sockets of the gate driver board, and set them aside.

8. Remove the five screws that secure the gate driver board and support bracket to the power structure.



9. Carefully remove the gate driver board and the board support bracket.
10. Carefully remove the two plastic screws that secure the gate driver board screening plate to the power structure and remove the screening plate.
11. Remove the two stand-offs that support the gate driver board.



12. Repeat [step 5](#) through [step 11](#) for each of the remaining gate driver boards.

Install the Gate Driver Circuit Boards

Install the gate driver circuit boards in the reverse order of removal.

Remove the ASIC Circuit Board


To remove the ASIC circuit board, follow these steps.

1. Remove power from the AFE.
See [Remove Power from the AFE on page 37](#).
2. If present, remove the protective barriers.
See [Remove AFE Protective Barriers on page 44](#).
3. Remove the airflow plate.
See [Remove the AFE Airflow Plate on page 46](#).
4. Remove the protective front covers and terminal covers from the power structure.
See [Remove Protective Covers from the Power Structure on page 47](#).



ATTENTION: The sheet metal cover and mounting screws on the ASIC circuit board that is on the power structure are energized at (-) DC bus potential high voltage. Risk of electrical shock, injury, or death exists if someone comes into contact with the assembly.

5. Remove the four screws that secure the ASIC cover to the ASIC assembly, remove the -DC bus connection from the ACSIC cover, and remove the ASIC cover.



6. Unplug the fan, which mounts on the cover, from connector X11 of the ASIC circuit board.

7. Carefully unplug the fiber-optic cables H1 through H7 from sockets on the ASIC board, and carefully set them aside.



ATTENTION: Hazard of permanent eye damage exists when using optical transmission equipment. This product emits intense light and invisible radiation. Do not look into fiber-optic ports or fiber-optic cable connectors.

IMPORTANT When mishandled, the ability of fiber-optic cables to transmit data is greatly diminished.


IMPORTANT The minimum inside bend radius for fiber-optic cable is 25.4 mm (1 in.). Any bends with a shorter inside radius can permanently damage the fiber-optic cable. Signal attenuation increases with decreased inside bend radii.

8. Disconnect the X9 terminal block and the X15 terminal connectors.


IMPORTANT When replacing the existing ASIC board with a new board, the X9 and X15 connectors must be transferred and connected to the new board before installation.

9. Disconnect the X3, X4, X5, X6, and X10 cables from sockets on the front of the ASIC board, and set them aside.

10. Remove the four screws that secure the ASIC assembly to the power structure and remove the ASIC assembly.




11. Remove the screw and detach the four plastic standoffs that secure the ASIC board to the ASIC chassis, and remove the ASIC board.




If the plastic insulator requires replacement, follow these steps:

- a. Remove the four screws that secure the board holder to the metal frame, and remove the metal frame and insulator.



- b. Carefully remove the four fasteners that secure the insulator to the metal frame, and remove the insulator.



- c. Replace the insulator.

Install the ASIC Circuit Board

Install the ASIC circuit board in reverse order of removal. See [Torque Specifications on page 36](#). Reconnect cables and jumpers to the ASIC board, while referring to [Figure on page 102](#).



ATTENTION: The sheet metal cover and mounting screws on the ASIC circuit board that is on the power structure are energized at (-) DC bus potential high voltage. Risk of electrical shock, injury, or death exists if someone comes into contact with the assembly. Verify that the -DC bus wire is properly connected to the ASIC chassis cover.

Remove and Install the Power Structure Fan System

There are three main cooling fans on the power structure. For complete details on all fan system-related information, see the PowerFlex 700S, 700H, and 700AFE Drive Fan Systems Installation Instructions, publication [PFLEX-IN029](#), including removal and installation of the following items:

- AC fan inverters
- AC fan capacitors
- AC main cooling fans
- DC fan power supplies
- DC main cooling fans
- Fan fusing

Remove the Power Structure from the Enclosure

IMPORTANT Power structure removal is required only when the power structure, or its internal components (power module, DC bus capacitors, balancing resistors, and so forth) are replaced.

To remove the power structure from the enclosure, follow these steps.

1. Remove power from the AFE.
See [Remove Power from the AFE on page 37](#).
2. If present, remove the protective barriers.
See [Remove AFE Protective Barriers on page 44](#).
3. Remove the airflow plate.
See [Remove the AFE Airflow Plate on page 46](#).
4. Remove the DC+ and DC- wires from the Fan Inverter Fuse assemblies.
5. Disconnect the seven fiber-optic cables that are connected to the fiber-optic adapter board located behind the control assembly (for AFE in IP20 2500 MCC Style enclosure) or the control frame (for AFE in IP21 Rittal enclosure).


For location of connections, see [Remove the Fiber-optic Adapter Circuit Board on page 40](#).

6. Depending on the enclosure in which the AFE is installed, follow the appropriate procedure to remove the power structure from the enclosure.
 - [AFE in IP20 2500 MCC Style Enclosure on page 54](#).
 - [AFE in IP21 Rittal Enclosure on page 57](#).

AFE in IP20 2500 MCC Style Enclosure


If your AFE is in an IP20 2500 MCC enclosure, continue to remove the power structure with these steps.

- a. Disassemble the four M10 x 50 bolts and associated hardware that secure the DC+ and DC- bus bars of the AFE power structure to the MCC bus.



- b. Remove the U/T1, V/T2, and W/T3 connections from the power structure at the bottom front of the power structure.
- c. Remove the ground connections of the power structure from the enclosure PE terminals.

- d. Remove eight M6 x 16 screws that secure the cart assembly to the enclosure.



ATTENTION: The cart assembly is heavy. To avoid personal injury or damage to the equipment, use caution when removing the cart assembly from the enclosure.


- e. Roll the cart assembly that contains the power structure outward from the enclosure.

IMPORTANT Ramps can be required due to floor mismatch.


When replacing the complete power structure, continue with the following substeps. When replacing components within an individual phase assembly, see [Remove the U, V, or W Phase Assembly from the Power Structure on page 59](#).

- f. Secure appropriate cables or chains to the recommended lift points on the power structure, and tighten the cables or chains.
For details, see Lifting and Mounting the PowerFlex Active Front End (AFE)—Frames 10 and 13, publication [20Y-IN001](#).
- g. To detach the power structure from its cart assembly, remove the six hexagonal bolts from the upper portion of the chassis backside.

- h. Remove the six hexagonal bolts from the lower portion of the chassis backside.



- i. To detach the power structure from its cart assembly, remove the six hexagonal screws (three on each lower side).



- j. Remove the six DC output fuses (two per phase) from the power structure bus bars.


For DC fuse removal instructions, see [Fuse Replacement Guidelines on page 94](#).

- k. Separate the power structure from its cart assembly, and remove the power structure by using appropriate lifting equipment.


AFE in IP21 Rittal Enclosure

If your AFE is in an IP21 Rittal enclosure, continue to remove the power structure with these steps.

- a. Remove the six DC bus fuses from the terminal connections at the top of the power structure.



- b. Remove the U/T1, V/T2, and W/T3 connections from the power structure at the front of the power structure.
- c. Remove the ground connections of the power structure from the enclosure PE terminals.
- d. Remove the output cable screws, and the two hexagonal screws that secure the power structure to the AFE frame.



- e. Install the maintenance stand (catalog number 20-MAINSTD) onto the power structure rails.

See PowerFlex 700S and 700H Frame 10...14 Drives Maintenance Stand Installation Instructions, publication [PFLEX-IN014](#).



ATTENTION: The power structure is heavy. To avoid personal injury or damage to the equipment, use caution when removing the power structure from the enclosure.

- f. Slide the power structure outward onto the rails of the optional Maintenance Stand.

Install the Power Structure in the Enclosure

Install the power structure in reverse order of removal. See the PowerFlex Active Front End User Manual, publication [20Y-UM001](#), for fastener torques of AC supply, DC bus input, and ground connection terminations.


Remove the U, V, or W Phase Assembly from the Power Structure

IMPORTANT Do not attempt to disassemble the power module within the U, V, or W phase assembly.


To remove the U, V, or W phase assembly from the power structure, follow these steps.

1. Remove the power structure from the AFE enclosure.
See [Remove the Power Structure from the Enclosure on page 54](#).
2. Remove the ASIC Circuit board.
See [Remove the ASIC Circuit Board on page 50](#).


3. Remove the M10 x 25 hexagonal screws that secure the input power cables to the input power terminals on the power structure.




4. Remove the insulators from between the DC+ and DC- bus bars.



- Remove the M6 x 12 screws that secure the connective DC bus bars and insulators to the phase assembly.




Location	Fasteners	Qty	Torque
1	M10 x 20 hexagonal screws, M10 spring washers and M10 washers	6	8 N·m (70 lb·in)
2	M8 x 25 hexagonal screws, M8 spring washers and M8 washers	6	8 N·m (70 lb·in)
3	M6 x 12 screws	2	4 N·m (35 lb·in)



- Remove the three M8 x 20 hexagonal screws from the top section of each phase assembly (U, V, or W) that you want to remove.

IMPORTANT Only two screws are shown for each phase assembly in the top section of the drawing.



7. Remove three M8 x 20 hexagonal screws from the bottom section of each phase assembly (U, V, or W) that you want to remove.

IMPORTANT Only one screw is shown for each phase assembly in the bottom section of the drawing.

8. Disconnect the three input power cables from the lower section of the phase assembly that you want to remove.
9. Remove the phase assembly by using appropriate lifting equipment.

Remove the Power Module from the U, V, or W Phase Assembly


IMPORTANT Do not attempt to disassemble the power module within the U, V, or W phase assembly.

IMPORTANT When replacing a damaged power module, it is recommended to replace all three power modules to avoid potential failure on the remaining power modules due to residual damage.

The following procedure describes removing the power module from one phase assembly. Repeat this procedure for each phase assembly.

To remove the power module from the U, V, or W phase assembly, follow these steps.


1. Remove the power structure from the AFE enclosure.
See [Remove the Power Structure from the Enclosure on page 54](#).
2. Remove the U, V, or W phase assembly from the power structure.
See [Remove the U, V, or W Phase Assembly from the Power Structure on page 59](#).
3. Remove the insulator holding plate from between the bus bar terminals.
4. Remove the M5 Pozidriv screws that secure the bus bar terminals to the power structure.
5. Slide the bus bar terminals out of the phase assembly.
6. If the bus bar airflow channel is damaged, remove and replace it.




7. Remove the M8 x 20 hexagonal screws that secure the input power cables to the input power bus bar.

Tightening torque for reassembly is 14 N•m (124 lb•in).

8. Cut and remove the cable ties that secure the input power cables to the EMC cover plate and remove the cables.




9. Remove the M5 x 10 Pozidriv and M4 x 8 Pozidriv screws that secure the EMC cover to the AFE, and remove the cover.
10. Remove the screws that secure the snubber capacitors to the U, V, or W phase assembly, and remove the snubber capacitors.



11. Remove the screws that secure the power bus bar and support insulators to the power structure.
12. Remove the power bus bar and insulators.

Tightening torque for reassembly is 14 N•m (124 lb•in).



13. Disconnect the balancing resistor wires from the DC bus bars.

Older Style Balancing Resistors

Remove the wire connections from DC bus bar end.

	P2 4 N•m (35 lb•in)		PZ2 3 N•m (27 lb•in)
--	---------------------------	--	----------------------------


Balancing Resistor Assembly Screws

Newer Style Balancing Resistors

	P2 4 N•m (35 lb•in)		PZ2 3 N•m (27 lb•in)
--	---------------------------	--	----------------------------

Balancing Resistor Assembly Screws


14. Remove the screws that secure the balancing resistor assemblies to the U, V, or W phase assembly.




15. Remove the balancing resistor assemblies (see step 13 picture for screw locations).

16. Remove the connective DC bus bars and insulators.

Tightening torque for reassembly is 4 N•m (35 lb•in).



17. Remove the M4 x 8 screws that secure the power module to the U, V, or W phase assembly.
18. Remove the power module.



19. Repeat [step 10](#) through [step 18](#) for each remaining phase assembly.

Install the Power Module on the U, V, or W Phase Assembly


Install the power module in reverse order of removal. See [Torque Specifications on page 36](#).

Remove the U, V, or W Phase Assembly DC Bus Capacitors

To remove the U, V, or W phase assembly DC bus capacitors, follow these steps.

1. Remove the power structure from the AFE enclosure.
See [Remove the Power Structure from the Enclosure on page 54](#).
2. Remove the U, V, or W phase assembly from the AFE.
See [Remove the U, V, or W Phase Assembly from the Power Structure on page 59](#).
3. Remove the power module from the U, V, or W phase assembly—but do not perform the last three steps ([step 17](#) through [step 19](#)) in that procedure.
See [Remove the Power Module from the U, V, or W Phase Assembly on page 62](#).
4. Note the polarity of the capacitors.

- Remove the four M4 x 8 screws that secure the capacitor to the power structure.



- Remove the capacitor.
Tightening torque for reassembly is 1.35 N•m (12 lb•in). We recommend replacing all capacitors at the same time.
- Repeat [step 5](#) and [step 6](#) for each remaining DC bus capacitor being removed.

Install the U, V, or W Phase Assembly DC Bus Capacitors

Install the capacitors in reverse order of removal. Make sure to observe the polarity of the capacitors as noted in removal [step 4](#) above.

Replace the Existing Power Structure with a New Power Structure

IMPORTANT When replacing the existing AFE Frame 13 power structure with a new power structure, (SK-Y1-PWRMOD-D1K3 for 400/480V, or SK-Y1-PWRMOD-E1K0 for 600/690V), you must perform these tasks to avoid possible equipment malfunction:


- Remove the common mode capacitors in the new power structure.
- Remove the power supply voltage feedback board from the new power structure.

To replace the existing power structure with a new power structure, follow these steps.

- Remove the old power structure from the enclosure.
See [Remove the Power Structure from the Enclosure on page 4-54](#).
- Remove the common mode capacitors from the new Frame 13 power structure that is replacing the old power structure.

For the procedure to remove the common mode capacitors, see the PowerFlex Active Front End User Manual, publication [20Y-UM001](#). See Chapter 2, section 'Disconnect Common Mode Capacitors', and subsection 'Frame 13 Power Structure'. These instructions apply to an AFE in an IP20 2500MCC Style enclosure or an AFE in an IP21 Rittal enclosure.

3. To remove the power supply voltage feedback board from the new Frame 13 power structure that is replacing the old power structure, follow the steps.
 - a. Disconnect the DC bus connection cable from connector J2, and the motor feedback connection cable from connector J1 at the top of the power supply voltage feedback board.



- b. Carefully disconnect the fiber-optic cables from sockets J4 and J5 on the side of the power supply voltage feedback board.
 - c. Secure the cables to the adjacent fan housing so that they are out of the way.



ATTENTION: Hazard of permanent eye damage exists when using optical transmission equipment. This product emits intense light and invisible radiation. Do not look into fiber-optic ports or fiber-optic cable connectors.

- d. Remove the four screws that secure the power supply voltage feedback board and cover to the V phase assembly module fan housing.
 - e. Carefully remove the power supply voltage feedback board and cover.
 - f. Disconnect the cable from connector J8 on the power supply voltage feedback board.

- g. Secure the cable to the adjacent fan housing so that it is out of the way.
4. Install the new (replacement) power structure.

See [Install the Power Structure in the Enclosure on page 59](#).

AC Line Switchgear Component Section



ATTENTION: To avoid an electric shock hazard, verify that all power to the PowerFlex® Active Front End has been removed before you perform any service or repairs.



ATTENTION: To avoid an electric shock hazard, verify that the voltage on the bus capacitors has discharged completely before servicing. Check the DC bus voltage between the +DC and -DC terminals, between the +DC terminal and the chassis, and between the -DC terminal and the chassis. The voltage must be zero for all three measurements.



ATTENTION: The sheet metal cover and mounting screws on the ASIC Board on the power structure are energized at (-) DC bus potential high voltage. Risk of electrical shock, injury, or death exists if someone comes into contact with the assembly.



ATTENTION: Hot surfaces can cause severe burns. Do not touch the heatsink surface during operation of the PowerFlex Active Front End. After you disconnect power, allow time for cooling.



ATTENTION: Hazard of permanent eye damage exists when using optical transmission equipment. This product emits intense light and invisible radiation. Do not look into fiber-optic ports or fiber-optic cable connectors.



ATTENTION: The PowerFlex Active Front End contains electrostatic discharge (ESD) sensitive parts and assemblies that can be damaged if you do not follow ESD control procedures. Static control precautions are required to install, test, service, or repair this assembly. If you are unfamiliar with static control procedures, see Guarding Against Electrostatic Damage, publication [8000-4.5.2](#), or any other applicable ESD protection handbook.

AFE in IP20 2500 MCC Style Enclosure

For a PowerFlex AFE system in the IP20 2500 MCC Style enclosure, the AC line switchgear components are the input circuit breaker (Q0), AC input fuses (F1.1...F1.3), and input contactor (K1).

The input circuit breaker either connects or disconnects the AFE system to the AC line. The input contactor connects the internal AFE system AC line to the AFE power structure through the LCL filter. The AFE power structure contains the control logic that opens or closes the input contactor.

See the PowerFlex Active Front End User Manual, publication [20Y-UM001](#), for the AC input fusing and circuit breaker protection recommendations.

AFE in IP21 Rittal Enclosure

For a PowerFlex AFE system in the IP21 Rittal enclosure, the AC line switchgear components are the input disconnect (Q0) and MCCB (Q1).

The input disconnect either connects or disconnects the AFE system to the AC line. The MCCB connects the internal AFE system AC line to the AFE power structure through the LCL filter. The AFE power structure contains the control logic that enables or disables the resettable trip mechanism that is integrated into the MCCB. The trip mechanism controls the MCCB functionality.

See the PowerFlex Active Front End User Manual, publication [20Y-UM001](#), for the AC input fusing and MCCB protection recommendations.

Precharge Component Section



ATTENTION: To avoid an electric shock hazard, verify that all power to the PowerFlex® Active Front End has been removed before you perform any service or repairs.



ATTENTION: To avoid an electric shock hazard, verify that the voltage on the bus capacitors has discharged completely before servicing. Check the DC bus voltage between the +DC and -DC terminals, between the +DC terminal and the chassis, and between the -DC terminal and the chassis. The voltage must be zero for all three measurements.



ATTENTION: The sheet metal cover and mounting screws on the ASIC Board that is on the power structure are energized at (-) DC bus potential high voltage. Risk of electrical shock, injury, or death exists if someone comes into contact with the assembly.



ATTENTION: Hot surfaces can cause severe burns. Do not touch the heatsink surface during operation of the PowerFlex Active Front End. After you disconnect power, allow time for cooling.



ATTENTION: Hazard of permanent eye damage exists when using optical transmission equipment. This product emits intense light and invisible radiation. Do not look into fiber-optic ports or fiber-optic cable connectors.



ATTENTION: The PowerFlex Active Front End contains electrostatic discharge (ESD) sensitive parts and assemblies that can be damaged if you do not follow ESD control procedures. Static control precautions are required to install, test, service, or repair this assembly. If you are unfamiliar with static control procedures, see Guarding Against Electrostatic Damage, publication [8000-4.5.2](#), or any other applicable ESD protection handbook.

Precharging Functions

The precharge circuitry has two main functions:

- It provides AFE system enclosure control power.
- It provides the precharge circuitry to charge the DC bus.

The AFE system is available in both 400/480V AC and 600/690V AC system voltage configurations. Control logic voltages are as follows:

- For an AFE in an IP20 2500 MCC Style enclosure, it is 120V AC single phase and also 24V DC power.
- For an AFE in an IP21 Rittal enclosure, it is 230V AC single phase and also 24V DC power.

The precharge circuitry lets the DC capacitors, which are located in the AFE power structure, to be properly charged with in-line current limiting resistors to DC bus voltage magnitudes.

See the PowerFlex Active Front End User Manual, publication [20Y-UM001](#), for the minimum and maximum system capacitance requirements.

Replace the Precharge Fuse

The precharge fuse assembly for an AFE in an IP20 enclosure is located in the Input Power enclosure. For an AFE in an IP21 enclosure, the precharge fuse assembly is located in the power structure enclosure.

To replace the precharge fuse, follow these steps.

1. Remove power from the AFE.
See [Remove Power from the AFE on page 37](#).
2. Open the appropriate enclosure door.
3. If present, remove the protective barriers.
See [Remove AFE Protective Barriers on page 44](#).
4. Slide the fuse sleeve out from the fuse holder.
5. Remove the fuse from the sleeve and appropriately discard the old fuse.
6. See [Table 4](#) and [Table 5](#) for the recommended new replacement fuse, and install the fuse in reverse order of removal.

Table 4 - 400/480 Volt Precharge Fuse Rating

Frame Size	Enclosure Style	Fuse		Fuse Holder ⁽³⁾
		Amps	Type	Type
13	IP20 2500 MCC	50	Bussmann DFJ-50 ⁽¹⁾	Bussmann CH60J3
	IP21 Rittal	32	ABB OFAF000H32 ⁽²⁾	ABB 0540D12000

(1) Precharge fuse designation is F5 for AFE in IP20 2500 MCC style enclosure.

(2) Precharge fuse designation is F6 for AFE in IP 21 Rittal enclosure.

(3) Precharge fuse holder holds a quantity of three fuses.

Table 5 - 600/690 Volt Precharge Fuse Rating

Frame Size	Enclosure Style	Fuse		Fuse Holder ⁽³⁾
		Amps	Type	Type
13	IP20 2500 MCC	50	Bussmann DFJ-50 ⁽¹⁾	Bussmann CH60J3
	IP21 Rittal	32	ABB OFAA000GG32 ⁽²⁾	ABB 0540D12000

(1) Precharge fuse designation is F5 for AFE in IP20 2500 MCC style enclosure.

(2) Precharge fuse designation is F6 for AFE in IP 21 Rittal enclosure.

(3) Fuse holder holds a quantity of three fuses.

Test the Control Transformer (T4) and 24V DC Power Supply (T10) For AFE in IP20 2500 MCC Style Enclosure

To test the control transformer (T4) and 24V DC power supply (T10) in an IP20 2500 MCC enclosure, follow these steps.

1. If present, remove the protective barriers.


See [Remove AFE Protective Barriers on page 44](#).



ATTENTION: Perform these tests only with qualified personnel. During these tests, the AFE is powered. Take proper precautions to avoid injury from electric shock.

2. Locate the control transformer (T4) and 24V DC power supply (T10).

The control transformer (T4) is at the bottom of the left-most enclosure (AC input switchgear). The 24V DC power supply (T10) is located in the bottom of the control box.



3. Use a digital voltmeter to test the control transformer (T4).
 - a. Measure the primary AC line voltage, which is at the 400...480V AC or 600...690V AC system voltage.
 - b. Measure the control transformer (T4) output voltage, which is approximately 120V AC.
If these measurements are not within $\pm 10\%$, perform these other steps.
 - c. Power down the AFE.
 - d. Remove the output (secondary) wires.
 - e. Power up the AFE and retest by repeating [step a](#) and [step b](#).
The control transformer (T4) can require replacement if these measurements continue to be outside of the $\pm 10\%$ tolerance.
4. Use a digital voltmeter to test the 24V DC power supply (T10).
 - a. Measure the primary voltage, which is 120V AC.
 - b. Measure the power supply (T10) output voltage, which is approximately 24V DC.
If these measurements are not within $\pm 10\%$, perform these other steps.
 - c. Power down the AFE.
 - d. Remove the 24V DC output wires of the power supply (T10).
 - e. Power up the AFE and retest by repeating [step a](#) and [step b](#).

The 24V DC power supply (T10) can require replacement if these measurements continue to be outside of the $\pm 10\%$ tolerance.

For AFE in IP21 Rittal Enclosure

To test the control transformer (T4) and 24V DC power supply (T10) in an IP21 Rittal enclosure, follow these steps.

1. If present, remove the protective barriers.


See [Remove AFE Protective Barriers on page 44](#).



ATTENTION: Perform these tests only with qualified personnel. During these tests, the AFE is powered. Take proper precautions to avoid injury from electric shock.

2. Locate the control transformer (T4) and 24V DC power supply (T10).

The control transformer (T4) is located behind the control frame. The 24V DC power supply (T10) is on a subpanel in front of the components that are shown in the front view.



3. Use a digital voltmeter to test the control transformer (T4).
 - a. Measure the primary AC line voltage, which is at the 400...480V AC or 600...690V AC system voltage.
 - b. Measure the control transformer (T4) output voltage, which is approximately 230V AC.

If these measurements are not within $\pm 10\%$, perform these steps.

- c. Power down the AFE.
- d. Remove the output (secondary) wires.
- e. Power up the AFE and retest by repeating [step a](#) and [step b](#).

The control transformer (T4) can require replacement if these measurements continue to be outside of the $\pm 10\%$ tolerance.

- 4. Use a digital voltmeter to test the 24V DC power supply (T10).
 - a. Measure the primary voltage, which is 230V AC.
 - b. Measure the power supply (T10) output voltage, which is approximately 24V DC.

If these measurements are not within $\pm 10\%$, perform these steps.


- c. Power down the AFE.
- d. Remove the 24V DC output wires of the power supply (T10).
- e. Power up the AFE and retest by repeating [step a](#) and [step b](#).

The 24V DC power supply (T10) can require replacement if these measurements continue to be outside of the $\pm 10\%$ tolerance.

Test the Precharge Bridge Using the Power Structure Terminals

- 1. Remove power from the AFE.
See [Remove Power from the AFE on page 37](#).
- 2. If present, remove the protective barriers.
See [Remove AFE Protective Barriers on page 44](#).
- 3. To test the precharge bridge, measure the points on the power structure that is listed in [Table 6](#).

Table 6 - Precharge Bridge Tests on Power Structure

Meter Leads		Nominal Meter Reading	Test Point Locations
+	-		
DC-	L1	Value gradually rises to about 0.48V ⁽¹⁾	
DC-	L2		
DC-	L3		
L1	DC+		
L2	DC+		
L3	DC+		
L1	DC-	Meter displays charging voltage.	
L2	DC-		
L3	DC-		
DC+	L1		
DC+	L2		
DC+	L3		

(1) The actual voltage reading can vary depending upon your equipment. If your readings are not near 0.48V, verify that the actual voltage that is measured is consistent for the power structure.

Replace the Precharge Bridge

1. Remove power from the AFE.
See [Remove Power from the AFE on page 37](#).
2. Open the power structure enclosure door.
3. If present, remove the protective barriers.
See [Remove AFE Protective Barriers on page 44](#).
4. Remove the protective front covers and terminal covers from the power structure.
See [Remove Protective Covers from the Power Structure on page 47](#).
5. Remove the four POZIDRIVE screws that secure the bridge protective cover.
6. Remove the bridge protective cover.
7. Before removal, note the locations of the DC+, DC-, L1, L2, and L3 wires, and then disconnect these wires.
8. Remove the precharge bridge mounting nuts.
9. Remove and appropriately discard the old precharge bridge.
10. Install the new precharge bridge in reverse order of removal. See [Torque Specifications on page 36](#).

Test the Precharge Resistor

To test the precharge resistor, follow these steps.

1. Remove power from the AFE.
See [Remove Power from the AFE on page 4-37](#).
2. Open the LCL filter enclosure door.
3. If present, remove the protective barriers.
See [Remove AFE Protective Barriers on page 4-44](#).
4. Measure the resistance between the following two points with an ohmmeter:
 - Between the (+) side of the precharge resistor R6.1 and the (+) terminal on the TB of the precharge circuit.

IMPORTANT This measurement applies to an AFE in either an IP20 2500 MCC Style enclosure or an AFE in an IP21 Rittal enclosure.

- Between the (-) side of the precharge resistor R6.2 and the (-) terminal on the TB of the precharge circuit.

IMPORTANT This measurement only applies to an AFE in an IP21 Rittal enclosure.

The precharge resistance is approximately $11\ \Omega$ for each measurement for an AFE in an IP20 2500 MCC Style enclosure, or $20\ \Omega$ for each measurement for an AFE in an IP21 Rittal enclosure. If the measured value is not correct, disconnect a resistor wire and remeasure again. If the measured value is still not correct, replace the precharge resistor.

IMPORTANT Verify that the precharge resistor has not been engineered to another value by the system engineer to accommodate a larger system capacitance. The engineered value can change the value of the precharge resistance. See the PowerFlex Active Front End User Manual, publication [20Y-UM001](#), for total DC bus capacitance limits for the precharging circuit.

Replace the Precharge Resistor Assembly

AFE in IP20 2500 MCC Style Enclosure

To replace the precharge resistor assembly in an IP20 2500 MCC enclosure, follow these steps.

1. Remove power from the AFE.
See [Remove Power from the AFE on page 37](#).
2. Open the LCL filter enclosure door.
3. If present, remove the protective barriers.
See [Remove AFE Protective Barriers on page 44](#).
4. Disconnect the R6.1 precharge resistor wires from the resistor terminals on the precharge resistor assembly.
5. Remove the two precharge resistor assembly mounting screws that secure the assembly to the bracket on the LCL enclosure bay.
6. Remove the mounting screws from the failed precharge resistor, and appropriately discard the resistor.
7. Install the new precharge resistor in reverse order of removal. See [Torque Specifications on page 36](#).

AFE in IP21 Rittal Enclosure

To replace the precharge resistor assembly in an IP21 Rittal enclosure, follow these steps.

1. Remove power from the AFE.
See [Remove Power from the AFE on page 37](#).
2. Open the LCL filter enclosure door.
3. If present, remove the protective barriers.
See [Remove AFE Protective Barriers on page 44](#).
4. Disconnect the wires from the (+) and (-) terminals on the precharge resistor assembly.
5. Verify that the capacitor on the bridge (+) and (-) terminals is still in the circuit.
6. Disconnect the white wires from the terminal block by the bridge.
7. Remove the mounting screws from the failed precharge resistor, and appropriately discard the resistor.
8. Install the new precharge resistor in reverse order of removal. See [Torque Specifications on page 36](#).

Notes:

LCL Filter Component Section



ATTENTION: To avoid an electric shock hazard, verify that all power to the PowerFlex® Active Front End has been removed before you perform any service or repairs.



ATTENTION: To avoid an electric shock hazard, verify that the voltage on the bus capacitors has discharged completely before servicing. Check the DC bus voltage between the +DC and -DC terminals, between the +DC terminal and the chassis, and between the -DC terminal and the chassis. The voltage must be zero for all three measurements.



ATTENTION: The sheet metal cover and mounting screws on the ASIC Board that is on the power structure are energized at (-) DC bus potential high voltage. Risk of electrical shock, injury, or death exists if someone comes into contact with the assembly.



ATTENTION: Hot surfaces can cause severe burns. Do not touch the heatsink surface during operation of the PowerFlex Active Front End. After you disconnect power, allow time for cooling.



ATTENTION: Hazard of permanent eye damage exists when using optical transmission equipment. This product emits intense light and invisible radiation. Do not look into fiber-optic ports or fiber-optic cable connectors.




ATTENTION: The PowerFlex Active Front End contains electrostatic discharge (ESD) sensitive parts and assemblies that can be damaged if you do not follow ESD control procedures. Static control precautions are required to install, test, service, or repair this assembly. If you are unfamiliar with static control procedures, see Guarding Against Electrostatic Damage, publication [8000-4.5.2](#), or any other applicable ESD protection handbook.

Remove the LCL Filter Protective Barriers and Vented Cover

1. Remove power from the AFE.
See [Remove Power from the AFE on page 37](#).
2. Remove the protective barriers from the LCL filter enclosure.
For an AFE in an IP20 MCC Style enclosure, see [Remove AFE Protective Barriers on page 44](#). For an AFE in an IP21 Rittal enclosure, see [Figure 9](#).
3. Remove the four T25 Torx self-tapping screws that secure the front bracket that is shown in the [Figure 9](#).
This bracket holds the LCL filter in the enclosure.
4. To access the DC fan fuses, fan, and DC power supply, remove the vented cover from the bottom of the LCL filter.

Figure 9 - Removing Protective Barriers and Vented Cover from LCL Filter



Install the LCL Filter Protective Barriers and Vented Cover

Reinstall the protective barriers and vented cover in reverse order of removal. See [Torque Specifications on page 36](#).

Replace the LCL Filter DC Fan Fuses

The LCL filter DC fan fuses are located behind the vented cover at the bottom of the LCL filter.

IMPORTANT Replace LCL filter fan fuses with only ATQ8 (Ferraz Shawmut) fuses.

For complete details on LCL fan system information, see PowerFlex 700H, 700S, and 700AFE Drive Fan Systems Installation Instructions, publication [PFLEX-IN029](#).

Remove the LCL Filter Fan DC Power Supply

The following figures show the LCL filter fan DC Power Supply wiring diagram with the connections to the AFE power structure and DC bus.

For complete details on LCL fan system information, see the PowerFlex 700H, 700S, and 700AFE Drive Fan Systems Installation Instructions, publication [PFLEX-IN029](#).

Figure 10 - LCL Filter Fan DC Power Supply Wiring Diagram (older version)






Figure 11 - LCL Filter Fan DC Power Supply Wiring Diagram (newer version)



IMPORTANT Before doing any work, disconnect the AFE power structure from the AC supply, and wait until the fan stops and the indicators on the keypad turn off. (If a keypad is not attached, see the indicator through the keypad base.) Wait 5 more minutes before doing any work on the DC-to-DC power supply to let it completely discharge. Do not open the cover until after this time has expired.



To remove the LCL filter fan DC power supply, follow these steps.

1. Remove the LCL filter protective barriers.

See [Remove the LCL Filter Protective Barriers and Vented Cover on page 7-84.](#)


2. Remove the two M4 x 10 mm Pozidriv screws that secure the cover.




3. Remove the cover.



4. Remove the connectors X1, X3, X4, and X8.



5. Remove the six fasteners that secure the DC-to-DC power supply.



Install the LCL Filter Fan DC Power Supply

Install the DC-to-DC power supply in reverse order of removal. See [Torque Specifications on page 36](#).


Replace the LCL Filter Fan

To replace the LCL filter fan, follow these steps.

1. Remove the LCL filter protective barriers.

See [Remove the LCL Filter Protective Barriers and Vented Cover on page 84](#).

2. Disconnect terminal blocks X51 and X53.



3. Lower the front fan sheet metal edge and slide it forward to remove the alignment studs from their respective holes in the fan frame sheet metal.
4. Slide out the fan assembly.
5. Remove the LCL filter fan DC power supply.
See [Remove the LCL Filter Fan DC Power Supply on page 85](#).
6. Reinstall the LCL filter fan in reverse order of removal. See [Torque Specifications on page 36](#).

Note the following LCL filter airflow cooling requirements.

LCL Filter	Required Airflow
LCL 460	1100 m ³ /hr
LCL 1300	1300 m ³ /hr

Remove the LCL Filter

The procedures to remove the LCL filter are different depending on the enclosure in which it is installed.


From the IP20 2500 MCC Style Enclosure

To remove the LCL filter from an IP20 2500 MCC enclosure, follow these steps.

1. Remove power from the AFE.
See [Remove Power from the AFE on page 37](#).
2. Remove the LCL filter protective barriers.
See [Remove the LCL Filter Protective Barriers and Vented Cover on page 84](#).
3. Remove the airflow plate.
See [Remove the AFE Airflow Plate on page 46](#).
4. Remove the X51 and X53 terminal blocks from the LCL fan assembly.


5. Remove the X52 terminal block from the LCL filter assembly (upper-right side).
6. Remove the top and bottom brackets that hold the LCL filter in the enclosure (see [Figure 12](#)).
 - a. See Detail A and remove the six M8 x 20 screws.
 - a. See Detail B and remove the six M8 x 20 screws.

Figure 12 - Remove LCL Filter from AFE in IP20 2500 MCC Style Enclosure



7. See [Figure 13 on page 90](#), Detail C, and remove the six M10 x 10 washer hex nuts and associated hardware that secure the input bus bars to the LCL filter.

Figure 13 - Remove Input Bus Bar Connections



8. See [Figure 13](#), Detail D and remove the 12 M6 x16 screws that secure the LCL filter output bus bars to the AFE power structure.



ATTENTION: The LCL filter is heavy. To avoid personal injury or damage to the equipment, use caution when removing the LCL filter from the enclosure.

9. See [Figure 13](#) and slide the LCL filter out of the enclosure.

IMPORTANT Ramps can be required due to enclosure floor mismatch.

From the IP21 Rittal Enclosure

To remove the LCL filter from an IP21 Rittal enclosure, follow these steps.

1. Remove power from the AFE.
See [Remove Power from the AFE on page 37](#).
2. Remove the LCL filter protective barriers.
See [Remove the LCL Filter Protective Barriers and Vented Cover on page 84](#).
3. Remove the X51 and X53 terminal blocks from the LCL fan assembly.

4. Remove the X52 terminal block from the LCL filter assembly (upper right side).
5. Remove the four T25 Torx self-tapping screws that secure the front bracket that is shown in [Figure 9 on page 84](#).

This bracket holds the LCL filter in the enclosure.

6. Remove the MCCB-to-LCL filter bus bars (L1, L2, L3).
For bus bar locations, see [Figure 6 on page 24](#).
7. Remove the LCL filter-to-AFE power structure bus bars (U, V, W).
For bus bar locations, see [Figure 6 on page 24](#).
8. Disconnect the ground wire from the LCL filter chassis.



ATTENTION: The LCL filter is heavy. To avoid personal injury or damage to the equipment, use caution when removing the LCL filter from the enclosure.

9. Slide the LCL filter out of the enclosure.

IMPORTANT Ramps can be required due to enclosure floor mismatch.

Install the LCL Filter in the Enclosure

Install the LCL filter in reverse order of removal. See [Torque Specifications on page 36](#).

Notes:

DC Fuses Component Section



ATTENTION: To avoid an electric shock hazard, verify that all power to the PowerFlex® Active Front End has been removed before you perform any service or repairs.



ATTENTION: To avoid an electric shock hazard, verify that the voltage on the bus capacitors has discharged completely before servicing. Check the DC bus voltage between the +DC and -DC terminals, between the +DC terminal and the chassis, and between the -DC terminal and the chassis. The voltage must be zero for all three measurements.



ATTENTION: The sheet metal cover and mounting screws on the ASIC Board that is on the power structure are energized at (-) DC bus potential high voltage. Risk of electrical shock, injury, or death exists if someone comes into contact with the assembly.



ATTENTION: Hot surfaces can cause severe burns. Do not touch the heatsink surface during operation of the PowerFlex Active Front End. After you disconnect power, allow time for cooling.



ATTENTION: Hazard of permanent eye damage exists when using optical transmission equipment. This product emits intense light and invisible radiation. Do not look into fiber-optic ports or fiber-optic cable connectors.



ATTENTION: The PowerFlex Active Front End contains electrostatic discharge (ESD) sensitive parts and assemblies that can be damaged if you do not follow ESD control procedures. Static control precautions are required to install, test, service, or repair this assembly. If you are unfamiliar with static control procedures, see Guarding Against Electrostatic Damage, publication [8000-4.5.2](#), or any other applicable ESD protection handbook.

Overview

An AFE system in an IP20 2500 MCC Style enclosure or IP21 Rittal enclosure contains the protective DC bus fuses.

IMPORTANT For PowerFlex AFE systems in the IP00 open chassis configuration, you must supply the output fuses.

See the PowerFlex Active Front End User Manual, publication [20Y-UM001](#), for the DC bus output fusing recommendations.

Fuse Replacement Guidelines

DC bus fuses are required for short circuit protection. [Table 7](#) and [Table 8](#) list the recommended DC bus fuses.

Table 7 - 400/480 Volt DC Fusing


Frame Size	AFE Enclosure Style	Fuse		
		Amps	Bussman Type	Ferraz Shawmut Type
13	IP20 2500 MCC	1100	170M6499	—
	IP21 Rittal	1100	—	PC73UD95V11CTF
		1250	170M6566	—

Table 8 - 600/690 Volt DC Fusing

Frame Size	AFE Enclosure Style	Fuse		
		Amps	Bussman Type	Ferraz Shawmut Type
13	IP20 2500 MCC	630	170M6454	—
	IP21 Rittal	630	—	PC73UD13C630TF
		700	170M6305	—

To replace the fuses, follow these steps.

1. Remove power from the AFE.
See [Remove Power from the AFE on page 37](#).
2. Open the power structure enclosure door.
3. If present, remove the protective barriers.
See [Remove AFE Protective Barriers on page 44](#).
4. Remove and discard the blown fuse.
5. Insert the fuse body between the bus bars.
6. Turn the threaded rod into the fuse body.
7. Place the Belleville (domed) washer and hexagonal nut on the threaded rod and hand tighten.
8. Hold the threaded rod with the hex key while tightening the nut to the specified torque.



Stud Type	Stud Tightening Torque, Max	Nut Tightening Torque, Max
M8 x 30 M8 x 35	10 N·m (88.5 lb·in)	13.5 N·m (132.8 lb·in)
M10 x 30 M10 x 50	15 N·m (132.8 lb·in)	26 N·m (230.1 lb·in)
M12 x 35 M12 x 50	15 N·m (132.8 lb·in)	46 N·m (407.1 lb·in)
M12 x 40	15 N·m (132.8 lb·in)	46 N·m (407.1 lb·in)

IMPORTANT Do not apply torque or twisting force to the fuse body. Too much force can damage the fuse.

For information about Bussmann fuses, click this link:

<http://www.cooperindustries.com>.

For information about Ferraz Shawmut fuses, click this link:

<http://www.ferrazfuses.com>.

Notes:

Startup After Repair



ATTENTION: The sheet metal cover and mounting screws on the ASIC Board that is on the power structure are energized at (-) DC bus potential high voltage. Risk of electrical shock, injury, or death exists if someone comes into contact with the assembly.



ATTENTION: Power must be applied to the PowerFlex® Active Front End to perform the following start-up procedure. Some of the voltages present are at incoming line potential.

To avoid electric shock hazard or damage to equipment, only qualified service personnel can perform the following procedure.

Thoroughly read and understand the procedure before beginning.

During startup, if one of these pre-powerup checks reveals a concern, do not proceed. Remove power, including user-supplied control voltages.

User-supplied voltages can exist even when main AC power is not applied to the PowerFlex Active Front End. Correct the malfunction before continuing.

Technical Support

See the back cover for Rockwell Automation support contact information.

Be prepared to provide the following information when you contact Allen-Bradley® drives technical support:

- Product catalog number
- Product serial number
- Firmware revision level

Before Applying Power to the AFE

1. Open the power structure enclosure door.
2. If present, remove the protective barriers.
See [Remove AFE Protective Barriers on page 44](#).
3. Check for zero volts between DC+ and DC-.
4. Use a digital multimeter to perform forward and reverse biased diode tests.
See [Perform Forward and Reverse Biased Diode Tests for Power Structure on page 29](#).
5. Confirm that all wiring to the AFE (AC input, ground, DC bus, and I/O) is connected to the correct AFE terminals, and is secure.

6. Verify that AC line power at the disconnect device is within the rated value of the AFE.
7. Verify that the control power voltage is correct.
8. Whenever possible, isolate the AFE from the rest of the DC bus system to enable the AFE to be powered separately.

Service Tools and Equipment

Software Tools

Connected Components Workbench™ software, DriveExecutive™ software, or DriveExplorer™ software are tools that can be used to upload, download, and monitor system parameters

Service Tools

This table lists the basic tools that are needed for repair and maintenance.

Item	Description	Details
1	Oscilloscope	Portable, digitizing, dual-channel scope with isolation
2	Current clamp	1000 A (AC, rms), signal output
3	High-voltage differential probe	P5210 or equivalent
4	Soldering station	Soldering / de-soldering
5	Flash light	—
6	Multi-meter	Digital multimeter, capable of AC and DC voltage, continuity, resistance, capacitance measurements, and forward diode bias tests. Fluke Model 87 III or equivalent.
7	Insulation tester	1000V DC
8	Torque wrench	1...12 N·m
9	Torque wrench	6...50 N·m
10	Box wrench	7 mm, 8 mm, 10 mm, 13 mm, 17 mm, 19 mm, 22 mm
11	Socket extension	230 mm
12	Wrench	7 mm, 8 mm, 10 mm, 13 mm, 17 mm, 19 mm, 22 mm
13	Allen wrench	—
14	Wire cutter	—
15	Needle-nose pliers	—
16	Crimping tools	For cable terminals 1, 5...240
17	Angle wrench	—
18	Screwdriver	7 x 2 mm
19	Pozidriv screwdriver	#1, #2, #3
20	Phillips screwdriver	#1, #2, #3
21	Torx screwdriver	#25
22	Hexagonal wrench	#4, #5, #6
23	ESD-protected place of work	Working surface, floor covering, seat, and ground connections
24	ESD-protective clothing	Wrist wrap, shoes, overall clothing (coat)
25	Power supply (service)	Capacity of three-phase service 400/500/690V AC, 30 A
26	20-MAINSTND maintenance stand	Maintenance stand for removing power structure from AFE enclosure
27	Fiber-optic repair kit	Agilent HFBR-4593 Polishing Kit, consisting of a Polishing Fixture, 600 grit abrasive paper, and 3 mm pink lapping film (3M Company, OC3-14). For Agilent HFBR-4532 latching connectors and HFBR-RL cable. See Agilent publications 5988-9777EN and 5988-3625EN.


Notes:

Schematic Diagrams

Frame 13 Circuit Board Connections


This section provides schematic diagrams.

Figure 14 - Frame 13 Circuit Board Connections



Frame 13 Power Structure Power Circuitry Block Diagram

Figure 15 - Frame 13 Power Structure Power Circuitry Block Diagram



Frame 13 Power Module Circuitry




Figure 16 - Frame 13 Power Module Circuitry

Frame 13 Power Structure Main Fan Connections




Figure 17 - Frame 13 Power Structure Main DC Fan Connections – newer version

Frame 13 Power Structure Main Fan Connections




Figure 18 - Frame 13 Power Structure Main AC Fan Connections – older version

Control Wiring Diagram for Frame 13 in IP20 2500 MCC Style Enclosure

Figure 19 - Control Wiring Diagram for Frame 13 in IP20 2500 MCC Style Enclosure





Figure 20 - Control Wiring Diagram for Frame 13 in IP20 2500 MCC Style Enclosure (continued)



System Schematics for Frame 13 in IP20 2500 MCC Style Enclosure

The following system schematics are for the AFE Frame 13 in an IP20 2500 MCC Style enclosure. The PowerFlex® AFE catalog number has an enclosure code of P for standard color (or W for optional gray color) as shown in the example catalog string. For other enclosure designs, contact the supplier of the system for the system schematics.

		Position														
1...3	4	5...7	8	9	10	11	12	13	14	15	16					
20Y	D	1K3	P	O	A	N	N	A	N	A	O					
a	b	c	d	e	f	g	h	i	j	k	l					




Figure 21 - Frame 13 in IP20 2500 MCC Style Enclosure – Sheet 6 (400/480V and 600/690V)




Figure 22 - Frame 13 in IP20 2500 MCC Style Enclosure – Sheet 7 (400/480V and 600/690V)




Figure 23 - Frame 13 in IP20 2500 MCC Style Enclosure – Sheet 8 (400/480V and 600/690V)




Figure 24 - Frame 13 in IP20 2500 MCC Style Enclosure -- Sheet 9 (400/480V and 600/690V)




Figure 25 - Frame 13 in IP20 2500 MCC Style Enclosure -- Sheet 10 (400/480V and 600/690V)




Figure 26 - Frame 13 in IP20 2500 MCC Style Enclosure – Sheet 11 (400/480V and 600/690V)





Figure 27 - Frame 13 in IP20 2500 MCC Style Enclosure -- Sheet 12 (Terminal Block Layout, and Circuit Breaker and Fuse Ratings)

Control Wiring Diagram for Frame 13 in IP21 Rittal Enclosure

Figure 28 - Control Wiring Diagram for Frame 13 in IP21 Rittal Enclosure



System Schematics for Frame 13 in IP21 Rittal Enclosure

The following system schematics are for the Frame 13 AFE in an IP21 Rittal enclosure. The PowerFlex AFE catalog number has an enclosure code of A as shown in the example catalog string. For other enclosure designs, contact the supplier of the system for the system schematics.

		Position															
1...3	4	5...7	8	9	10	11	12	13	14	15	16						
20Y	D	1K3	A	O	A	N	N	A	N	A	O						
a	b	c	d	e	f	g	h	i	j	k	l						




Figure 29 – Frame 13 in IP21 Rittal Enclosure – Sheet 6 (400/480V and 600/690V)




Figure 30 - Frame 13 in IP21 Rittal Enclosure -- Sheet 7 (400/480V and 600/690V)




Figure 31 - Frame 13 in IP21 Rittal Enclosure – Sheet 8A (only 400/480V)




Figure 32 - Frame 13 in IP21 Rittal Enclosure – Sheet 8B (only 600/690V)




Figure 33 - Frame 13 in IP21 Rittal Enclosure - Sheet 9 (400/480V and 600/690V)




Figure 34 - Frame 13 in IP21 Rittal Enclosure -- Sheet 10 (400/480V and 600/690V)

Connector Descriptions

Circuit Board Connections

The following tables detail the connection points for the Frame 13 PowerFlex® Active Front End circuit boards and components.

Table 9 - Fiber-optic Adapter Board-to-ASIC Circuit Board Connections

Fiber-optic Adapter Connector	Type	Signal Description: Reference to ASIC Board	Type	ASIC Board Fiber Connector ⁽¹⁾
H1	TX	Gate_Enable	RX	H1
H2	TX	U_Gate	RX	H2
H3	TX	V_Gate	RX	H3
H4	TX	W_Gate	RX	H4
H5	TX	A/D Convert	RX	H5
H6	TX	VBUS_RX	RX	H6
H7	RX	VBUS_TX	TX	H7
X2	From	+24V DC Power	To	X10
X3	From	Auxiliary 24V DC Power Supply	To	T10 power supply on control panel

(1) See [Figure 36 on page 125](#) for ASIC board Fiber-optic connectors.



ATTENTION: Hazard of permanent eye damage exists when using optical transmission equipment. This product emits intense light and invisible radiation. Do not look into fiber-optic ports or fiber-optic cable connectors.

IMPORTANT When mishandled, the ability of fiber-optic cables to transmit data is greatly diminished.


IMPORTANT The minimum inside bend radius for fiber-optic cable is 25.4 mm (1 in.). Any bends with a shorter inside radius can permanently damage the fiber-optic cable. Signal attenuation increases with decreased inside bend radii.

Table 10 - ASIC Board-to-Gate Driver Board Connections

ASIC Board	Gate Driver Board	Signal Description		
X3	X1	'U' phase	Ribbon Cable	Signal Description
			Pin 1	U_Feedback
			Pin 2	U_Power_OK
			Pin 3	U_DTR ⁽¹⁾
			Pin 4	U_ETR ⁽²⁾
			Pin 5	U_ITR ⁽³⁾
			Pin 6	U_DC-
			Pin 7	UI
			Pin 8	U_DC-_I
			Pin 9	U_TEMP
Pin 10	U_DC-T			
X4	X1	'V' phase	Ribbon Cable	Signal Description
			Pin 1	V_Feedback
			Pin 2	V_Power_OK
			Pin 3	V_DTR ⁽¹⁾
			Pin 4	V_ETR ⁽²⁾
			Pin 5	V_ITR ⁽³⁾
			Pin 6	V_DC-
			Pin 7	VI
			Pin 8	V_DC-_I
			Pin 9	V_TEMP
Pin 10	V_DC-T			
X5	X1	'W' phase	Ribbon Cable	Signal Description
			Pin 1	W_Feedback
			Pin 2	W_Power_OK
			Pin 3	W_DTR ⁽¹⁾
			Pin 4	W_ETR ⁽²⁾
			Pin 5	W_ITR ⁽³⁾
			Pin 6	W_DC-
			Pin 7	WI
			Pin 8	W_DC-_I
			Pin 9	W_TEMP
Pin 10	W_DC-T			
H13 (WL) H12 (WH) H11 (VL) H10 (VH) H9 (UL) H8 (UH)	(WL) H4 (WH) H2 (VL) H4 (VH) H2 (UL) H4 (UH) H2	Fiber-optic gate signals (connect UH to UH, UL to UL, and so forth)		

(1) DTR = N Desat
(2) ETR = Phase I²T
(3) ITR = Phase overcurrent

Figure 36 - Fiber-optic Cable Routing



Hardware Connections

Figure 37 - AFE Power Structure Fan Inverter Circuit Board Connectors




Table 11 - ASIC Board - AFE Power Structure V Phase Fan Inverter Board Connections

ASIC Board Connector ⁽¹⁾	Pin	Signal Description	Pin	Phase V Fan Inverter Board Connector
X11	From 2	ASIC_+15V	To 2	X8
	From 3	FAN_CONTROL	To 3	
	To 4	FAN_ALARM	From 7	

(1) See [Figure 36 on page 125](#) for ASIC board connectors.

Table 12 - Phase V Fan Inverter Board - W Phase Fan Inverter Board Connections

Phase V Fan Inverter Board Connector	Pin	Signal Description	Pin	Phase W Fan Inverter Board Connector
X3	From 2	+15V	To 2	X8
	From 3	FAN_CONTROL NEXT	To 3	
	To 4	FAN_ALARM	From 7	

Table 13 - Phase W Fan Inverter Board - U Phase Fan Inverter Board Connections

Phase W Fan Inverter Board Connector	Pin	Signal Description	Pin	Phase U Fan Inverter Board Connector
X3	From 2	+15V	To 2	X8
	From 3	FAN_CONTROL NEXT	To 3	
	To 4	FAN_ALARM	From 7	

For part number information, see the PowerFlex 700H, 700S, and 700AFE Drive Fan Systems Installation Instructions, publication [PFLEX-IN029](#).

Figure 38 - LCL Filter Fan Inverter Circuit Board Connectors




Table 14 - LCL Filter Fan Inverter Circuit Board Connections

LCL Filter DC Fan Inverter Board	LCL Filter DC Fan Assembly
X1	X1
X3	X3
X8	X51
X4	X53

Notes:


Disassembly/Assembly Diagrams and Spare Parts

Diagram	Figure and Page
AFE Power Structure Assembly External Components	Figure 39 on page 130
AFE Power Structure Internal Components (U, V, or W Phase Assembly)	Figure 40 on page 131
AFE Power Structure ASIC Assembly	Figure 41 on page 132
LCL Filter Assembly	Figure 42 on page 133
LCL Filter Power Supply Assembly	Figure 43 on page 134
LCL Filter Fan Assembly	Figure 44 on page 134
Precharge Assembly for AFE in IP20 2500 MCC Style Enclosure	Figure 45 on page 135
Precharge Assembly for AFE in IP21 Rittal Enclosure	Figure 46 on page 136
AC Line Switchgear Components for AFE in IP20 2500 MCC Style Enclosure	Figure 47 on page 137
AC Line Switchgear Components for AFE in IP21 Rittal Enclosure	Figure 48 on page 138


Diagrams in this section illustrate disassembly and assembly of the AFE and its subsystems, and include a list of spare part numbers, where applicable.

When ordering spare parts, you must provide the serial number of the PowerFlex® Active Front End. The serial number is on the data nameplate on the control frame just above the bar code.

Data Nameplate on AFE in IP20
2500 MCC Style Enclosure



Data Nameplate on AFE in IP21
Rittal Enclosure



A complete list of spare parts for the Frame 13 PowerFlex Active Front End is available on the Allen-Bradley website at <http://www.ab.com/support/abdrives/powerflex70/PF7ReleasedParts.pdf>.

AFE Power Structure Assembly

Figure 39 - AFE Power Structure Assembly External Components



ATTENTION: The sheet metal cover and mounting screws on the ASIC Board that is on the power structure are energized at (-) DC bus potential high voltage. Risk of electrical shock, injury, or death exists if someone comes into contact with the assembly.




Table 15 - AFE Power Structure Assembly External Component Part Numbers

Part Name		Part No.
ASIC assembly upgrade kit (without ASIC board)		20-FR10850
Bus bar assembly		N/A
Fuse holders for fan inverters (only AC fan system)		20-PP01094 ⁽¹⁾
Fan inverter fuse (only AC fan system)		20-PP20202 ⁽¹⁾
Terminal covers		N/A
Front covers		N/A
Power structure	400/480V (1300 A)	SK-Y1-PWRMOD-D1K3
	600/690V (1030 A)	SK-Y1-PWRMOD-E1K0
Maintenance stand		20-MAINSTD

(1) For additional AC fan system information, see publication [PELEX-IN029](#).

Figure 40 - AFE Power Structure Internal Components (U, V, or W Phase Assembly)




Table 16 - AFE Power Structure Internal Component Part Numbers for U, V, or W Phase Assembly

Part Name		Cat. No.
Airflow channel		N/A
Balancing resistors		N/A
DC bus bar assembly		N/A
DC bus bar terminal assembly		N/A
Electrolytic capacitors	ELKO 3300 μ F 420V for 400/480V AFE	20-PP01005
	ELKO 5600 μ F 420V for 600/690V AFE	20-PP01099
EMC cover		N/A
Gate driver board	400/480V	SK-H1-GDB1-F1314D
	600/690V	SK-H1-GDB1-F1314E
Power module	400/480V	SK-H1-QOUT-D1K3
	600/690V	SK-H1-QOUT-E1K0

Table 16 - AFE Power Structure Internal Component Part Numbers for U, V, or W Phase Assembly (Continued)

Part Name	Cat. No.
Power bus bar	N/A
Screening plate (for gate driver board)	N/A
Snubber capacitor assembly	N/A



ATTENTION: The sheet metal cover and mounting screws on the ASIC Board that is on the power structure are energized at (-) DC bus potential high voltage. Risk of electrical shock, injury, or death exists if someone comes into contact with the assembly.

Figure 41 - AFE Power Structure ASIC Assembly




Table 17 - AFE Power Structure ASIC Assembly Part Numbers

Part Name	Cat. No.	
ASIC assembly bracket	Included in 20-FR10850	
ASIC assembly cover		
ASIC assembly insulator		
ASIC board ⁽¹⁾	400/480V AFE	SK-H1-ASICBD-D1300
	600/690V AFE	SK-H1-ASICBD-E1030
Fiber-optic cable set	20-PP09017	

(1) The ASIC board is unprogrammed.

LCL Filter Assembly (used in IP20 and IP21 enclosures)

Figure 42 - LCL Filter Assembly




Table 18 - LCL Filter Assembly Catalog Numbers

Part Name		Cat. No.
LCL filter assembly	400/480V	SK-Y1-LCL1-D1K3
	600/690V	SK-Y1-LCL1-E1K0
LCL high-frequency capacitor assembly	25 μ F 400/480V	SK-Y1-CAPHF3-DF
	20 μ F 600/690V	SK-Y1-CAPHF2-DF
LCL capacitor assembly	120 μ F 400/480V	SK-Y1-CAPLCL1-D1K3
	53 μ F 600/690V	SK-Y1-CAPLCL1-F1K0
LCL filter inverter fan fuse		SK-Y1-F11-F10

Figure 43 - LCL Filter Power Supply Assembly



Table 19 - LCL Filter Power Supply Assembly Catalog Numbers

Part Name		Cat. No.	
		Universal Kit	Discontinued July 2014 ⁽²⁾
LCL filter power supply	400/480V	SK-Y1-DCPS2-F10 ⁽¹⁾	SK-Y1-DCPS1-D460
	600/690V		SK-Y1-DCPS1-F325
LCL fan wire kit		SK-Y1-HF1-DF	

(1) This kit can be used for either voltage class.

(2) These discontinued kits are no longer available, but spares inventory is applicable.

Figure 44 - LCL Filter Fan Assembly




Table 20 - LCL Filter Fan Assembly Catalog Number

Part Name	Cat. No.
Main fan, 48V DC	SK-Y1-DCFAN1

Precharge Assembly

Figure 45 - Precharge Assembly for AFE in IP20 2500 MCC Style Enclosure




Table 21 - Precharge Assembly Part Numbers for AFE in IP20 2500 MCC Style Enclosure

Part Name	Part No.	
Precharge fuse	SK-Y1-MCCF5-F13	
Precharge fuse holder	SK-Y1-MCCF5FUSEHOLDER-F13	
Precharge kit ⁽¹⁾	SK-Y1-PRE2-F13	
Control transformer (T4), 1500VA	SK-R1-OFANXFMR-F13	
Control transformer primary fuse	400/480V	SK-Y1-MCCF6-D
	600/690V	SK-Y1-MCCF6-F
Control transformer primary fuse holder	SK-Y1-MCCF6FUSEHOLDER	
Control transformer (T10) secondary fuse/holder	SK-Y1-MCCF3F4	

(1) Kit includes diode bridge (V6), one resistor (R6.1), and a snubber capacitor (C1).

Figure 46 - Precharge Assembly for AFE in IP21 Rittal Enclosure




Table 22 - Precharge Assembly Part Numbers for AFE in IP21 Rittal Enclosure

Part Name		Part No.
Precharge fuse	400/480V	SK-Y1-F6-D
	600/690V	SK-Y1-F6-F
Fuse disconnect switch		SK-Y1-F6-DISC-DF
Precharge kit ⁽¹⁾		SK-Y1-PRE1-F13DF
Control transformer (T4), 750VA	400/480V	SK-Y1-T4-D
	600/690V	SK-Y1-T4-F
Control transformer motor protection relay		SK-Y1-Q4-DF
Control transformer circuit breaker, 4 A	400/480V	SK-Y1-F3-D
	600/690V	SK-Y1-F3-F
24V DC power supply (T10)		SK-Y1-T10-DF
24V DC power supply circuit breaker, 2 A		SK-Y1-F10-DF
Precharge motor protection relay		SK-Y1-Q5-F13

(1) Kit includes diode bridge (V6), contactor (K6), two resistors (R6.1 and R6.2), and a snubber capacitor (C1).

AC Line Switchgear

Figure 47 - AC Line Switchgear Components for AFE in IP20 2500 MCC Style Enclosure




Table 23 - AC Line Switchgear Part Numbers for AFE in IP20 2500 MCC Style Enclosure

Part Name	Part No.	
AC input fuses	400/480V	SK-Y1-MCCF1-F13D
	600/690V	SK-Y1-MCCF1-F13F
DC bus fuses	400/480V	SK-Y1-MCCF2-D
	600/690V	SK-Y1-MCCF2-F
Input circuit breaker	400/480V	SK-Y1-MCCQ0-F13
	600/690V	
Input contactor	SK-Y1-MCCK1-F13	
LCL filter bay door fan kit (two at top of door; not shown)	20-750-FAN3-F8	
Right-side bus splice kit (not shown; optional)	SK-Y1-BUSSPLICE-F13R	
Left-side bus splice kit (not shown; optional)	SK-Y1-BUSSPLICE-F13L	
MCC bus splice barrier kit (not shown; optional) ⁽¹⁾	SK-Y1-MCCBARRIER	

(1) The MCC bus splice barrier kit must be used when installing a right-side bus splice kit (SK-Y1-BUSSPLICE-F13R) or a left-side bus splice kit (SK-Y1-BUSSPLICE-F13L).

Figure 48 - AC Line Switchgear Components for AFE in IP21 Rittal Enclosure




Table 24 - AC Line Switchgear Part Numbers for AFE in IP21 Rittal Enclosure

Part Name		Part No.
Control circuit relay	230V AC	SK-Y1-K20-DF
	24V DC	SK-Y1-K4-DF
Input disconnect switch		SK-Y1-Q0-F13
Motor controlled circuit breaker		SK-Y1-Q1-F13

AFE Power One-line System Application Data

Data to Collect

Collect the following AFE system data before contacting Allen-Bradley technical support.

The diagram shows a power system starting from a utility source connected to a transformer. The secondary of this transformer is connected to a cable, which then feeds into another transformer. Following this second transformer, there are two parallel paths: one containing a line reactor or isolation transformer, and the other containing an input contactor. Both paths lead to an SCR bus supply. From the SCR bus supply, the power goes to an AFE (Active Front End) unit, which then passes through an output contactor to a drive unit. The drive unit is connected to a motor. A second identical path exists for a second drive and motor.

Utility	Transformer	
Type		Delta-Delta, Delta-Wye, or Other
Input Volts		
Output Volts		
kVA		
Z		None, Solid, High Resistive
Ground		

Cable Length: _____ Cable Type: _____

Secondary	Transformer	
Type		
Input Volts		
Output Volts		
kVA		
Z		None, Solid, High Resistive
Ground		

Cable Length: _____ Cable Type: _____

Line Reactor Mfgr./Cat. No.: _____ % Impedance: _____

Isolation Xfmr Mfgr./Cat. No.: _____ % Impedance: _____

Input Contactor

AFE Cat. No.: _____ SCR Cat. No.: _____

Output Contactor

Cable Length: _____ Cable Type: _____

Drive Cat. No.: _____

Output Reactor Mfgr./Cat. No.: _____

Terminator Mfgr./Cat. No.: _____

Cable Length: _____ Cable Type: _____

Motor Manufacturer	
Volts	
Amps	
RPM	
Hz	
Power	
Design No.	
Encoder	
Brake	
Motor Heater	

Typical Transformer Winding Types

The following diagrams show typical transformer winding types.

Figure 49 - Delta-Wye with Grounded Wye Neutral




Figure 50 - Delta-Delta with Grounded Leg or Four-Wire Connected Secondary Delta





Figure 51 - Ungrounded Secondary



A**AC line switchgear**

- components
 - AFE in IP20 2500 MCC Style enclosure 137
 - AFE in IP21 Rittal enclosure 138
- overview 71

Active Front End system overview 19**AFE power structure**

- ASIC assembly parts 132
- checking fan inverter fuses 34
- external components 130
- internal components for U, V, or W phase assembly 131

assembly/disassembly diagrams 129**B****bus bar locations**

- AFE in IP20 2500 MCC Style enclosure 21
- AFE in IP21 Rittal enclosure 24

C**checking**

- fan inverter fuses 34
- fiber optic connections 31

circuit board connections 123**common symptoms and corrective actions 17****component test procedures 27****connections for**

- circuit boards 123
- fiber optic cable routing 125

control transformer and 24V DC power**supply testing 75****control wiring diagram**

- AFE in IP20 2500 MCC Style enclosure 106
- AFE in IP21 Rittal enclosure 115

creating fault reports 12**D****DC fuses**

- overview 93
- replacement guidelines 94

de-energizing the AFE 37**diagnostic status indicators 28****diode tests**

- forward biased 29
- reverse biased 29

disassembly/assembly diagrams 129**E****external components of AFE power structure**

130

F**fan inverter fuse checking 34****faults**

- creating reports 12
- list 12

fiber optic

- cable routing connections 125
- connection checking 31

forward biased diode test 29**G****gate driver board resistance measurements**

33

general precautions 9**H****hardware connections 126****hardware faults 12****I****input disconnect**

- AFE in IP20 2500 MCC Style enclosure 72
- AFE in IP21 Rittal enclosure 72

inspecting

- cooling tunnels 28
- power structure 29

internal components of AFE power structure for U, V, or W phase assembly 131**L****LCL filter**

- assembly parts 133
- fan DC power supply
 - installation 87
 - removal 85
- fan replacement 87
- fuse replacement 84
- removing from
 - IP20 2500 MCC Style enclosure 88
 - IP21 Rittal enclosure 90
- removing protective covers 84

M**main component locations**

- AFE in IP20 2500 MCC Style enclosure 20
- AFE in IP21 Rittal enclosure 23

main component sections

- AFE in IP20 2500 MCC Style enclosure 19
- AFE in IP21 Rittal enclosure 22

measurement points for forward and reverse diode tests 30**motor-controlled circuit breaker (MCCB) 72**

O**one-line diagram**

- AFE in IP00 open chassis configuration 25
- AFE in IP20 2500 MCC Style enclosure 19
- AFE in IP21 Rittal enclosure 22

P**performing**

- forward biased diode test 29
- gate driver board resistance measurements 33
- reverse biased diode test 29
- visual inspections 28

powering down 37**precharge**

- assembly parts
 - AFE in IP20 2500 MCC Style enclosure 135
 - AFE in IP21 Rittal enclosure 136
- bridge replacement 79
- bridge testing 78
- fuse replacement 74
- resistor replacement 81
- testing control transformer and 24V DC power supply 75
- testing resistor 79

precharging functions 74**R****removing**

- AFE air flow plate 46
- AFE protective barriers 44
- ASIC circuit board 50
- control frame (only AFE in IP21 Rittal enclosure) 43
- DPI/HIM assembly 38
- fiber optic adapter circuit board 40
- gate driver circuit boards 47
- I/O circuit boards and control board 39
- LCL filter
 - fan DC power supply 85
 - from IP20 2500 MCC Style enclosure 88
 - from IP21 Rittal enclosure 90
 - protective covers 84
- power from AFE 37
- power modules from U, V, or W phase assembly 62
- power structure DC bus capacitors from U, V, or W phase assembly 67
- power structure from enclosure 54
- power structure main cooling fans 53
- protective covers from the power structure 47
- U, V, or W phase assembly from AFE power structure 59

replacing power structure with a new power structure 68**reverse biased diode tests 29****S****schematic diagrams 101****service tools 99****software tools 99****spare parts 8**

- information 129
- website 8, 129

startup after repair 97**status indicators 28****system overview 19****T****technical support 8****testing**

- control transformer and 24V DC power supply 75
- forward biased diode 29
- gate driver board resistance 33
- precharge bridge 78
- precharge resistor 79
- reverse biased diode 29

torque specifications 36**troubleshooting and error codes 11****turning off the AFE 37****V****viewing the status indicators 28****visual inspections 28****W****website**

- spare parts 8, 129

Rockwell Automation Support

Use the following resources to access support information.

Technical Support Center	Knowledgebase Articles, How-to Videos, FAQs, Chat, User Forums, and Product Notification Updates.	https://rockwellautomation.custhelp.com/
Local Technical Support Phone Numbers	Locate the phone number for your country.	http://www.rockwellautomation.com/global/support/get-support-now.page
Direct Dial Codes	Find the Direct Dial Code for your product. Use the code to route your call directly to a technical support engineer.	http://www.rockwellautomation.com/global/support/direct-dial.page
Literature Library	Installation Instructions, Manuals, Brochures, and Technical Data.	http://www.rockwellautomation.com/global/literature-library/overview.page
Product Compatibility and Download Center (PCDC)	Get help determining how products interact, check features and capabilities, and find associated firmware.	http://www.rockwellautomation.com/global/support/pcdc.page

Documentation Feedback

Your comments will help us serve your documentation needs better. If you have any suggestions on how to improve this document, complete the How Are We Doing? form at http://literature.rockwellautomation.com/idc/groups/literature/documents/du/ra-du002_-en-e.pdf.

Rockwell Automation maintains current product environmental information on its website at <http://www.rockwellautomation.com/rockwellautomation/about-us/sustainability-ethics/product-environmental-compliance.page>.

Allen-Bradley, Connected Components Workbench, DPI, DriveExecutive, DriveExplorer, PowerFlex, SCANport, Rockwell Automation, and Rockwell Software are trademarks of Rockwell Automation, Inc.

Trademarks not belonging to Rockwell Automation are property of their respective companies.

Rockwell Otomasyon Ticaret A.Ş., Kar Plaza İş Merkezi E Blok Kat:6 34752 İçerenköy, İstanbul, Tel: +90 (216) 5698400

www.rockwellautomation.com

Power, Control and Information Solutions Headquarters

Americas: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444

Europe/Middle East/Africa: Rockwell Automation NV, Pegasus Park, De Kleetlaan 12a, 1831 Diegem, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640

Asia Pacific: Rockwell Automation, Level 14, Core F, Cyberport 3, 100 Cyberport Road, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846

Publication 20Y-TG002C-EN-P - April 2017

Supersedes Publication 20Y-TG002B-EN-P - February 2015

Copyright © 2017 Rockwell Automation, Inc. All rights reserved. Printed in the U.S.A.