




**Bulletin 1334
3-10 HP Series B
15-50 HP Series A
Adjustable Frequency AC Drives**

Instruction Manual



Important User Information

Because of the variety of uses for this equipment and because of the differences between this solid state equipment and electromechanical equipment, the user of and those responsible for applying this equipment must satisfy themselves as to the acceptability of each application and use of the equipment. **In no event** will Allen-Bradley Company be responsible or liable for indirect or consequential damages resulting from the use or application of this equipment.

The illustrations shown in this manual are intended solely to illustrate the text of this manual. Because of the many variables and requirements associated with any particular installation, the Allen-Bradley Company **cannot** assume responsibility or liability for actual use based upon the illustrative uses and applications.

No patent liability is assumed by Allen-Bradley Company with respect to use of information, circuits or equipment described in this text.

Reproduction of the content of this manual, in whole or in part, without written permission of the Allen-Bradley Company is prohibited.



WARNINGs tell readers where people may be hurt if procedures are not followed properly.



CAUTIONs tell readers where machinery may be damaged or economic loss can occur if procedures are not followed properly.

Both of these Reader Alerts:

- Identify possible trouble spots.
- Tell what causes the trouble.
- Give the result of improper actions.
- Tell the reader how to avoid trouble.

Additionally:



SHOCK HAZARD labels may be located on or inside the Drive to alert people of hazards if service procedures are not followed properly.

**Repair or Repair/Exchange
Procedure**

For your convenience, the Allen-Bradley Motion Control Division, and the Allen-Bradley Support Division, provide an efficient and convenient method of returning equipment eligible for repair or repair/exchange.

A **Product Service Report (P.S.R.)** number is required to return any equipment for repair. This may be obtained from your local Allen-Bradley Area Sales/Support Center.

Return any equipment to be repaired to the Area Sales/Support Center nearest you. Be sure to reference the P.S.R. number on the carton and packing slip. Include your company name and address, your repair purchase order number, and a brief description of the problem. This will facilitate quick return of your equipment.

A complete listing of Area Sales/Support Centers is available from your local Allen-Bradley Distributor or Sales Office.

Manual Objective

This Instruction Manual defines the installation, startup, operation and troubleshooting procedures for the Allen-Bradley Bulletin 1334 3 through 10 HP Series B and 15 through 50 HP Series A Adjustable Frequency AC Drive and is intended for use by personnel familiar with the functions of solid state Drive equipment.

**CAUTION**

This assembly may contain ESD (Electrostatic Discharge) sensitive parts and assemblies. Static control precautions are required when testing, servicing or repairing this assembly. Component damage may result if ESD control procedures are not followed when testing, servicing or repairing this assembly. If you are not familiar with static control procedures, before servicing, reference U.S. Department of Defense, DOD-HDBK-263, Electrostatic Discharge Control Handbook for Protection of Electronic Parts, Assemblies and Equipment or any other applicable ESD Protection Handbook.

TABLE OF CONTENTS

Section	Title	page
Chapter 1 Bulletin 1334 Pre-Installation Care		
1.0	Pre-Installation & Operation	1-1
1.1	Receiving	1-1
1.2	Storage	1-1
1.3	Handling	1-1
1.4	Shipping	1-1
1.5	ESD Precautions	1-2
Chapter 2 Bulletin 1334 Drive Data		
2.0	Catalog Number Explanation	2-1
Chapter 3 Bulletin 1334 Specifications		
3.0	Specification Table	3-1
Chapter 4 Bulletin 1334 Installation Procedures		
4.0	General Environmental Requirements	4-1
4.1	Nonventilated Sheet Metal Enclosures	4-1
4.1.1	Enclosure Sizing – Drive Chassis & Heatsink Inside the Enclosure	4-2
	table 4.1.1 – Watt & BTU Dissipation Data – Heatsink Inside the Enclosure	4-2
4.1.2	Enclosure Sizing – Drive Chassis Inside the Enclosure – Heatsink Outside the Enclosure ...	4-2
	table 4.1.2 – Watt & BTU Dissipation Data – Heatsink Outside the Enclosure	4-2
4.2	Dimensions and Weights	4-3
	3-10 HP Series B Open Chassis & NEMA Type 12	4-3
	15-25 HP Series A Open Chassis	4-4
	15-25 HP Series A NEMA Type 12	4-5
	30-50 HP Series A Open Chassis	4-6
	30-50 HP Series A NEMA Type 1	4-7
	30-50 HP Series A NEMA Type 12	4-8
4.3	General Wiring Practices	4-9
4.3.1	Contingency STOP	4-10
4.3.2	Recommended Control Signal Wiring, Power Wiring & Conduit Entry Area	4-10
	figure 4.3.2a – Bulletin 1334 Series B 3-10 HP	4-11
	figure 4.3.2b – Bulletin 1334 Series A 15-25 HP	4-11
	figure 4.3.2c – Bulletin 1334 Series A 30-50 HP	4-11
4.3.3	Chassis Ground, Power Input & Output Connections	4-12
	figure 4.3.3a – Bulletin 1334 Series B 3-10 HP Power Input & Output Connections	4-13
	figure 4.3.3b – Bulletin 1334 15-50 HP Power Input & Output Connections	4-13

Section	Title	page
4.4	Control Wiring	4-14
4.4.1	Terminal Block TB1 or 1TB Interconnection Notes	4-14
4.4.2	Terminal Block TB1 – 3-10 HP Series B Standard Interconnection Diagram	4-15
4.4.3	Terminal Block 1TB – 15-50 HP Series A Standard Interconnection Diagram	4-16
4.4.4	Interconnection Diagram – 3-10 HP Field Installed RUN/STOP Control (120V AC)	4-17
4.4.5	Interconnection Diagram – 15-50 HP Field Installed RUN/STOP Control (120V AC)	4-17
4.4.6	Interconnection Diagram – Field Installed RUN/STOP Control (90V AC)	4-18
4.4.7	Interconnection Diagram – Field Installed Remote Mounted Speed Pot	4-18
4.4.8	Interconnection Diagram – Field Installed Motor Thermostatic Switch	4-19
4.4.9	Interconnection Diagram – Field Installed Motor O.L. Relay & Thermostatic Switch	4-19

Chapter 5 Bulletin 1334 Startup & Adjustment Procedures

5.0	Prepower Check	5-1
5.1	Initial Operation	5-1
5.2	Bulletin 1334 Drive Data Log Sheets	5-4
5.3	Adjustment Procedures	5-6
5.3.1	Modulator Logic Board Potentiometer Settings	5-6
	figure 5.3.1 – Modulator Logic Board A1	5-7
5.3.2	Modulator Logic Board Jumper Settings	5-8
5.3.3	Modulator Logic Board Switch Settings	5-9
	S1 ACCEL & S2 DECEL Rate Adjustments	5-9
	S3 DC Boost Adjustment	5-11
5.3.4	Driver Board Jumper Settings	5-13
	figure 5.3.4a – 3 & 5 HP Driver Board – 7½ & 10 HP Driver Board	5-14
	figure 5.3.4b – 15 & 20 HP Driver Board	5-15

Chapter 6 Bulletin 1334 Operation

6.0	Principles of Operation	6-1
	figure 6.0a – Voltage/Frequency Curve	6-1
	figure 6.0b – Output Voltage Waveform	6-2
6.1	Main Circuit Overview	6-2
6.2	The Power Section	6-3
	figure 6.2 – Bulletin 1334 Power Section	6-3
6.2.1	Incoming AC Line Power & Precharge Current Limiting Circuits	6-3
6.2.2	Bridge Rectifier, DC Bus, & Bus Discharge Circuits	6-3
6.2.3	Output Inverting Circuits	6-4
6.3	The Logic and Control Section	6-5
	figure 6.3 – Bulletin 1334 Logic and Control Section	6-6
6.3.1	Controlling the Startup Sequence	6-6
6.3.2	Generating Control Signals	6-7
6.3.3	Providing an Interface	6-7
6.3.4	Providing an Orderly Rated Stop or Coast-to-Stop	6-9
6.3.5	Monitoring of Fault and Protection Circuits	6-9
6.4	General Application	6-11

Section	Title	page
Chapter 7 Bulletin 1334 380/415 Volt Specifications & Adjustments		
7.0	380V Specification Table	7-1
7.1	415V Specification Table	7-2
7.2	Adjustments	7-3
7.2.1	Transformer Adjustments	7-3
7.2.2	Volts-per-Hertz Adjustment	7-3
Appendix A Bulletin 1334 3-10 HP Series B Component Index		
3-10 HP	Recommended Spare Parts	A-1
3-10 HP	Component Access & Location	A-2
3-10 HP	Component Location & Wiring	A-6
3-10 HP	Component Wiring List	A-8
Appendix B Bulletin 1334 15-25 HP Series A Component Index		
15-25 HP	Recommended Spare Parts	B-1
15-25 HP	Drives	B-3
15 & 20 HP	Component Location	B-4
25 HP	Component Location	B-6
Appendix C Bulletin 1334 30-50 HP Series A Component Index		
30-50 HP	Recommended Spare Parts	C-1
30-50 HP	Drives	C-3
30 HP	Component Location	C-4
40 & 50 HP	Component Location	C-6
Appendix D Bulletin 1334 3-10 HP Series B Troubleshooting		
3-10 HP	Diagnostic LED Display and DS1 Location	D-1
3-10 HP	Troubleshooting Procedures	D-2
Appendix E Bulletin 1334 15-25 HP Series A Troubleshooting		
15-25 HP	Diagnostic LED Display and DS1 Location	E-1
15-25 HP	Troubleshooting Procedures	E-2
Appendix F Bulletin 1334 30-50 HP Series A Troubleshooting		
30-50 HP	Diagnostic LED Display and DS1 Location	F-1
30-50 HP	Driver Board LED Indication	F-2
30-50 HP	Troubleshooting Procedures	F-3

Title	page
Appendix G Bulletin 1334 3-10 HP Series B Drive Schematics	
3-10 HP Unit Schematic	G-1
3-10 HP Power Distribution Board Schematic	G-2
Appendix H Bulletin 1334 15-25 HP Series A Drive Schematics	
15 & 20 HP Unit Schematic	H-1
25 HP Unit Schematic	H-2
Appendix I Bulletin 1334 30-50 HP Series A Drive Schematics	
30 HP Unit Schematic	I-1
40 & 50 HP Unit Schematic	I-2
Appendix J Bulletin 1334 Modulator Logic Board Interconnection Diagrams	
3-10 HP Series B Modulator Logic Board Interconnection Diagram	J-1
15-50 HP Series A Modulator Logic Board Interconnection Diagram	J-2
Bulletin 1334 Modulator Logic Board Plug-In Options	J-3
CARD EDGE CONNECTOR J107	J-3
CARD EDGE CONNECTOR J102	J-4
CARD EDGE CONNECTOR J104	J-5
CARD EDGE CONNECTOR J105	J-6
CARD EDGE CONNECTOR J103	J-7

Bulletin 1334 Pre-Installation Care

**1.0
Pre-Installation & Operation**

Before installing and operating your Bulletin 1334, carefully read this manual and observe all precautions. The catalog number of your Drive as explained in **Chapter 2** lists the Drive rating, type of enclosure, nominal line voltage, phase and frequency, as well as any additional options that were specified. Specifications for all Bulletin 1334 Drives including standard controls, adjustment range, diagnostics, and environmental qualifications are listed in **Chapter 3**. 380 & 415V Bulletin 1334 specifications and adjustments are detailed in **Chapter 7**.

**1.1
Receiving**

Once you have received your Bulletin 1334 Drive, careful inspection for shipping damage should be made. Damage to the shipping carton is usually a good indication that it has received rough handling. Any and all damage should be immediately reported to the freight carrier and your nearest Allen-Bradley Area Sales/Support Center.

Carefully unpack the Drive taking care to save the shipping carton and any packing material should return be necessary. Verify that the items on the packing list or bill of lading agree with your order.

**1.2
Storage**

If the Drive will not immediately be installed, it should be stored in a clean, dry area where the ambient temperature is not less than -25°C nor more than $+65^{\circ}\text{C}$. The Drive must not be stored in a corrosive environment or subject to conditions in excess of the storage environment parameters stated in the **Specification Table**, Chapter 3.

**1.3
Handling**

Depending upon the rating and options ordered, in its shipping carton your Bulletin 1334 can weigh anywhere from 67 to over 500 lbs. Proper safety precautions and practices should be observed whenever the Drive is being moved from one location to another.

**1.4
Shipping**

The carton and materials that came with your Drive have been designed and tested to provide reasonable protection against damage during transit. Should shipment of the Drive to another location be required, it is recommended that the original shipping carton and packing material be used to protect the Drive from damage during transit.

1.5
ESD Precautions



CAUTION

This assembly may contain ESD (Electrostatic Discharge) sensitive parts and assemblies. Static control precautions are required when testing, servicing or repairing this assembly. Component damage may result if ESD control procedures are not followed when testing, servicing or repairing this assembly. If you are not familiar with static control procedures, before servicing, reference U.S. Department of Defense, DOD-HDBK-263, Electrostatic Discharge Control Handbook for Protection of Electronic Parts, Assemblies and Equipment or any other applicable ESD Protection Handbook.


ESD (Electrostatic Discharge) generated by static electricity can damage the CMOS devices on various Drive boards. To guard against this type of damage when circuit boards are removed or installed, it is recommended that the following minimum precautions be observed.

- *Wear a wrist type grounding strap that is grounded to the Drive chassis.*
- *DO NOT remove the new circuit board from its conductive wrapper unless a ground strap is worn.*
- *When removing any circuit board from the Drive, immediately place it in conductive packing material.*

Bulletin 1334 Drive Data

2.0
Catalog Number Explanation

The following is an explanation of the catalog numbering system for Bulletin 1334 Adjustable Frequency AC Drives. The catalog number for your Drive can be found both on the packing carton and the Drive nameplate.



For Multiple Options, code letters are strung together as necessary separated by a dash.

IMPORTANT

For 380 or 415V AC operation a Function Expander Card (Option L) or Euro Card is required to provide proper volts-per-hertz for 50 Hz motors (the Euro Card is provided as standard for all 380 or 415V AC, 50 Hz Drives).

Bulletin 1334 Specifications

3.0
Specification Table

The following table lists all specifications for Bulletin 1334 Adjustable Frequency AC Drives. All Bulletin 1334 Drives are 460V, sine-weighted, PWM type voltage source inverters that have the capability of operating at 415V AC or 380V AC — 380 & 415V Bulletin 1334 specifications and adjustments are detailed in Chapter 7. Unless otherwise specified, all descriptions of operation and performance throughout this manual will reference the 460V AC, 60 Hz unit.

IMPORTANT

The Bulletin 1334 produces a sine-weighted, PWM output voltage at a variable output frequency for application to a standard 3 phase, NEMA Design B induction motor. For applications other than standard NEMA Design B motors, consult your nearest Allen-Bradley Area Sales/Support Center.

Model Number	1334-B _ B	1334-C _ B	1334-D _ B	1334-E _ B
① Nominal HP	3	5	7½	10
Input Voltage	460	460	460	460
Output Voltage	0-460	0-460	0-460	0-460
Input Frequency	60	60	60	60
Output Frequency	0-200	0-200	0-200	0-200
Input Amps	4.25	6.5	9.7	13.0
Output Amps	5.0	7.5	11.3	15.0
Input kVA	3.0	5.0	7.7	10.3
Output kVA	4.0	6.0	9.0	12.0

Model
and
Ratings
3-10 HP

Model Number	1334-F _ B	1334-G _ B	1334-R _ B
① Nominal HP	15	20	25
Input Voltage	460	460	460
Output Voltage	0-460	0-460	0-460
Input Frequency	60	60	60
Output Frequency	0-200	0-200	0-200
Input Amps	18.75	25.0	33.0
Output Amps	21.3	27.6	35.0
Input kVA	15.0	20.0	26.5
Output kVA	17.0	22.0	28.0

Model
and
Ratings
15-25 HP

IMPORTANT: ① The HP rating shown is for Drives supplied from a 460V AC, 60 Hz power line and is nominal. The limiting factor in the application and use of the Bulletin 1334 Drive is the Output Amp Rating of the Drive.

3.0
Specification Table
(continued)

Model Number	1334-H _ B	1334-J _ B	1334-K _ B	
Model and Ratings 30-50 HP	① Nominal HP	30	40	50
	Input Voltage	460	460	460
	Output Voltage	0-460	0-460	0-460
	Input Frequency	60	60	60
	Output Frequency	0-200	0-200	0-200
	Input Amps	39.0	51.0	62.0
	Output Amps	41.4	54.0	67.8
	Input kVA	31.0	41.0	49.4
	Output kVA	33.0	43.0	54.0

Power Supply	Allowable Variation	Input Voltage — 460V, 3Ø, ±10% Input Frequency — 60 Hz, ±2%
Control Specifications	Output Waveform Control Scheme	Sine Weighted PWM Control
	Output Switching Device	Transistor Power Switching Module
	Output Frequency Regulation	±0.6Hz at 0-40°C Ambient (Analog Input Mode)
	Voltage – Operator Controls	90V AC (12V DC for Local Reversing)
	Overload Capability	150% (Nominal) of Rated Drive Output Current for 60 Seconds
	Starting Torque	150% (Nominal) for 60 Seconds
Standard Controls and Adjustments	② Volts-per-Hertz Selection	3.8V/Hz or 7.6V/Hz (Standard)
	DC Boost	0-34 Volts
	START/STOP	Push Buttons Mounted on Drive Enclosure Door
	Speed Adjustment	Single Turn Potentiometer (1kΩ, 2W) Mounted on Drive Enclosure Door
	Minimum Speed Pot Setting	0-40Hz
	Maximum Speed Pot Setting	40-200Hz
	③ ACCEL/DECEL Rate Adjustment	ACCEL/DECEL Time of 0.4-50 Sec at 0-60Hz Independently Selectable Rates From 1.2 to 152.4 Hz/ Sec
	Stop Mode	Ramp-to-Stop or Coast-to-Stop

- IMPORTANT:**
- ① The HP rating shown is for Drives supplied from a 460V AC, 60 Hz power line and is nominal. The limiting factor in the application and use of the Bulletin 1334 Drive is the Output Amp Rating of the Drive.
 - ② For 380 or 415V AC operation, refer to **Chapter 7**.
 - ③ When an analog speed command is applied to the Drive, total ACCEL/DECEL time will be 0.5 to 1.6 seconds longer due to an RC type exponential tapering into the new speed. Rates specified are accurate when a speed command from a Digital Thumbwheel Card (option G, G2) or a BCD Interface Card (option G4) is used.

3.0
Specification Table
(continued)

Protection Circuits and Devices	Input Protection	Fused for 200,000 Amps Symmetrical Interrupting Capacity
	Power Loss Ride-Thru	Nominal .05 Seconds
	Input Transient Protection	Up to 5,000 Volts Peak at 150Ω Line Impedance
	Momentary Overload Protection	Allows Drive to "Ride-Thru" Nominal 150% Overloads for up to 1 Minute by Limiting Output Current
	① Input Under Voltage	414 Volts Nominal
	Output Phase-to-Phase Short Circuit	Monitors Excessive Current in Each Transistor (200% Nominal of Rated Drive Output Current)
	Drive Over Temperature	N.C. Thermal Switch on Heatsink
	Output Ground Short Circuit	Protects Drive Against Output Phase-to-Ground Faults
Diagnostics	Power ON Light	LED Indication When AC Line Power Is Applied to the Drive
	Momentary Overload Protection	LED Indication When a Momentary Drive Overload Occurs or a Momentary Drive Overload has Caused the Drive to Shut Down
	Input Under Voltage	LED Indication if Input Line Drops Below 10% of Rated Drive Input Voltage
	Bus Over Voltage	LED Indication if Bus Rises Above 760V DC
	A, B or C Phase Protect	Individual LED Indication if Drive Transistor Current in Any Phase Exceeds 200% (Nominal) of Rated Drive Output Current
	Brake Over Temperature	If Optional Dynamic Brake is Installed, LED Indication of Excessive Brake Resistor Temperature
	Drive Over Temperature	LED Indication if the Heat Sink Temperature of the Drive Reaches the Maximum Guideline Temperature of the Components
	Bus Charged	Neon Light Indication When Bus Voltage Is Greater Than 42V DC
	Output Ground	LED Indication if the Drive Output Circuitry Has Shorted to Ground (15-50 HP Series A Units Only)
	Operating Environment	Ambient Operating Temperature
Relative Humidity		5 to 95% Noncondensing
Vibration (Normal Mounting Position)		.006 Displacement, 1G Peak
Shock (Normal Mounting Position)		15G Peak for 11mS Duration (± 1.0mS)
Elevation		All Ratings - 3,300 ft. Without Derating
Noise Immunity		Showering Arc Transients from 350 to 2,000 Volts
Storage Environment	Ambient Storage Temperature	-25°C to 65°C Enclosed and Open Chassis
	Relative Humidity	5 to 95% Noncondensing

IMPORTANT: ① For 380 or 415V AC operation, refer to Chapter 7.

3.0
Specification Table
(continued)

Enclosure	Open Chassis	Available for All Ratings		
	NEMA Type 1	Available for 30-50 HP Ratings Only		
	① NEMA Type 12	Available for All Ratings		
Efficiency	Minimum Efficiency & Input Power Factor at 60 Hz, Full-Load	UNIT	DRIVE EFFICIENCY	② DRIVE POWER FACTOR
		3 HP	93%	.90 kW/kVA
		5 HP	93%	.90 kW/kVA
		7½ HP	94%	.90 kW/kVA
		10 HP	95%	.92 kW/kVA
		15 HP	96%	.91 kW/kVA
		20 HP	96%	.92 kW/kVA
		25 HP	95%	.91 kW/kVA
		30 HP	95%	.92 kW/kVA
		40 HP	96%	.92 kW/kVA
		50 HP	96%	.92 kW/kVA

IMPORTANT: ① The Bulletin 1334 NEMA Type 12 enclosure is suitable for use in NEMA Type 12 applications unless the Door Mounted Digital Thumbwheel Switch (option G) is installed. If this option is installed, the enclosure is only suitable for NEMA Type 1 applications.

② Drive displacement angle power factor is 0.95 to 0.97 constant. Listed values are displacement plus distortion power factor (kW/kVA).

Bulletin 1334 Installation Procedures

**4.0
General
Environmental Requirements**

The Bulletin 1334 should be installed in an area where the following installation and environmental guidelines can be met.

- *Cabinet mounting is upright, leaving room for door clearance and a minimum clearance of (6) inches on all sides for proper ventilation.*
- *The Drive is easily accessible for maintenance and troubleshooting.*
- *The rated altitude does not exceed 3,300 ft. (1,006 meters).*
- *Vibration will be kept to a minimum as outlined in the **Specification Table**, Chapter 3.*
- *The ambient atmosphere is free of corrosive gases.*
- *The relative humidity is kept to within 95% for all Drive ratings.*

For NEMA Types 1 & 12 Drives

- *The rated ambient temperature should not exceed 40°C.*

For Open Chassis Drives

- *The rated heatsink ambient temperature should not exceed 40°C.*
- *The rated chassis component ambient temperature should not exceed 50°C.*

If the ambient temperature and/or altitude of the Drive installation site exceeds these values, contact your nearest Allen-Bradley Area Sales/Support Center for derating information.

**4.1
Nonventilated
Sheet Metal Enclosures**

There are two ways in which an open chassis Drive can be installed in a NEMA Type 1 or 12 enclosure.

1. With both the Drive chassis and heatsink inside the enclosure.
2. With the Drive chassis inside the enclosure and the heatsink extended out the back of the enclosure.

In either case, each Drive chassis must have a customer supplied fan installed that will supply at least 100CFM to circulate air up through the Drive chassis. For 40 & 50 HP Drives which already have an integrally mounted fan, an additional 100 CFM fan must be mounted directly above the chassis to draw air up through the Drive chassis.

- Allow a minimum clearance of at least (6) inches between each Drive chassis when mounting them in a common enclosure.
- Determine the total watt dissipation of all Drives and other heat generating components to be mounted inside the enclosure such as transformers, etc. Total watt dissipation for Bulletin 1334 Drives with both the Drive chassis and heatsink inside the enclosure is shown in **table 4.1.1**.
- Follow the manufacturer's guidelines and any additional codes and standards applicable to your application.

**4.1.1
Enclosure Sizing
– Drive Chassis and
Heatsink Inside the Enclosure**

Although the Drive chassis (excluding the heatsink) is rated for a maximum ambient air temperature of 50°C, the Drive heatsink itself is rated for a maximum ambient air temperature of 40°C. When mounting an open chassis type Drive with the heatsink inside the enclosure, use **table 4.1.1** in combination with the enclosure manufacturer’s guidelines for sizing the enclosure. Follow the guidelines listed in **section 4.1** to help ensure that the temperature within the enclosure does not exceed 40°C.

HP	VOLTS	FULL LOAD OUTPUT AMPS	WATTS DISSIPATED	BTUs/HR DISSIPATED
3	460	5.0	215	734
5	460	7.5	320	1,093
7½	460	11.3	440	1,502
10	460	15.0	490	1,673
15	460	21.3	560	1,911
20	460	27.6	740	2,526
25	460	35.0	1,205	4,113
30	460	41.4	1,440	4,915
40	460	54.0	1,520	5,188
50	460	67.8	1,850	6,315

**table 4.1.1 – Watt & BTU Dissipation Data for Open Chassis Drives
with Heatsink Inside the Enclosure**

**4.1.2
Enclosure Sizing
– Drive Chassis
Inside the Enclosure
– Heatsink Outside the Enclosure**

Even when the Drive is mounted with the heatsink outside the enclosure, there is still heat dissipated within the enclosure by the Drive chassis. **Table 4.1.2** lists the heat dissipation of only the Drive chassis with the Drive heatsink mounted outside the enclosure in a 40°C ambient. Use **table 4.1.2** in combination with the enclosure manufacturer’s guidelines for sizing the enclosure. Follow the guidelines listed in **section 4.1** to help ensure that the temperature within the enclosure does not exceed 50°C when the Drive chassis is mounted inside the enclosure while the Drive heatsink is mounted outside the enclosure.


HP	VOLTS	FULL LOAD OUTPUT AMPS	WATTS DISSIPATED	BTUs/HR DISSIPATED
3	460	5.0	65	222
5	460	7.5	96	328
7½	460	11.3	140	478
10	460	15.0	150	512
15	460	21.3	160	546
20	460	27.6	240	819
25	460	35.0	355	1,212
30	460	41.4	440	1,502
40	460	54.0	470	1,605
50	460	67.8	550	1,878

**table 4.1.2 – Watt & BTU Dissipation Data for Open Chassis Drives
with Heatsink Outside the Enclosure**

4.2 3-10 HP Series B
Dimensions and Weights Open Chassis & NEMA Type 12

NOMINAL DIMENSIONS
IN INCHES AND (MILLIMETERS)

	A	B	C	D	E	F	G	M	N1	N2	N3
OPEN CHASSIS	20.00 (508.0)	17.50 (444.5)	11.44 (290.6)	19.00 (482.6)	16.00 (406.4)	0.50 (12.7)	0.75 (19.1)	18.00 (457.2)	3.50 (88.9)	7.94 (201.7)	
NEMA TYPE 12	20.00 (508.0)	18.38 (466.9)	13.12 (333.2)	19.00 (482.6)	16.00 (406.4)	0.50 (12.7)	1.19 (30.2)	18.88 (479.6)	3.50 (88.9)	6.12 (155.5)	3.50 (88.9)



NOMINAL WEIGHTS
IN POUNDS AND (KILOGRAMS)


MOUNTING WEIGHT		SHIPPING WEIGHT	
OPEN CHASSIS	NEMA TYPE 12	OPEN CHASSIS	NEMA TYPE 12
53.00 (24.0)	75.00 (34.0)	67.00 (30.4)	89.00 (40.4)

4.2
Dimensions and Weights
(continued)

15-25 HP Series A
Open Chassis

NOMINAL DIMENSIONS
IN INCHES AND (MILLIMETERS)

A	B	C 15 & 20 HP	C 25 HP	D	E	F	G
38.00 (965.2)	17.50 (444.5)	13.38 (339.9)	13.88 (352.6)	37.00 (939.8)	16.00 (406.4)	0.50 (12.7)	0.75 (19.1)



NOMINAL WEIGHTS
IN POUNDS AND (KILOGRAMS)


MOUNTING WEIGHT			SHIPPING WEIGHT		
15 HP	20 HP	25 HP	15 HP	20 HP	25 HP
143 (64.9)	146 (66.2)	177 (80.3)	165 (74.8)	168 (76.2)	199 (90.3)

4.2
Dimensions and Weights
(continued)

15-25 HP Series A
NEMA Type 12

NOMINAL DIMENSIONS
IN INCHES AND (MILLIMETERS)

A	B	C 15 & 20 HP	C 25 HP	D	E	F	G1	G2
38.00 (965.2)	22.50 (571.5)	15.00 (381.0)	15.50 (393.7)	37.00 (939.8)	16.00 (406.4)	0.50 (12.7)	2.25 (57.2)	4.25 (108.0)



NOMINAL WEIGHTS
IN POUNDS AND (KILOGRAMS)


MOUNTING WEIGHT			SHIPPING WEIGHT		
15 HP	20 HP	25 HP	15 HP	20 HP	25 HP
230 (104.3)	233 (105.7)	265 (120.2)	252 (114.3)	255 (115.7)	315 (142.9)

4.2
Dimensions and Weights
(continued)

30-50 HP Series A
Open Chassis

NOMINAL DIMENSIONS
IN INCHES AND (MILLIMETERS)

A	A	B	C	D	D	E	F	G
30 HP	40 & 50 HP			30 HP	40 & 50 HP			
44.00 (1,117.6)	50.00 (1,270.0)	17.50 (444.5)	13.88 (352.6)	43.00 (1,092.2)	49.00 (1,244.6)	15.50 (393.7)	0.50 (12.7)	1.00 (25.4)



NOMINAL WEIGHTS
IN POUNDS AND (KILOGRAMS)


MOUNTING WEIGHT			SHIPPING WEIGHT		
30 HP	40 HP	50 HP	30 HP	40 HP	50 HP
172 (78.0)	208 (94.3)	210 (95.3)	222 (100.7)	258 (117.0)	260 (117.9)

4.2
Dimensions and Weights
(continued)

30-50 HP Series A
NEMA Type 1

NOMINAL DIMENSIONS
IN INCHES AND (MILLIMETERS)

A 30 HP W/O Floor Stand	A 40 & 50 HP W/O Floor Stand	B	C	D 30 HP	D 40 & 50 HP	E	F	G1	G2	H
44.00 (1,117.6)	50.00 (1,270.0)	22.50 (571.5)	15.50 (393.7)	43.00 (1,092.2)	49.00 (1,244.6)	15.50 (393.7)	0.50 (12.7)	2.50 (63.5)	4.50 (114.3)	6.00 (152.4)



NOMINAL WEIGHTS
IN POUNDS AND (KILOGRAMS)


MOUNTING WEIGHT			SHIPPING WEIGHT		
30 HP	40 HP	50 HP	30 HP	40 HP	50 HP
262 (118.8)	298 (135.2)	300 (136.1)	312 (141.5)	348 (157.9)	350 (158.8)

4.2
Dimensions and Weights
(continued)

30-50 HP Series A
NEMA Type 12

NOMINAL DIMENSIONS
IN INCHES AND (MILLIMETERS)

A	B	C	L	N1	N2
<i>With Floor Stand</i>					
72.00 (1,828.8)	37.38 (949.5)	16.38 (416.1)	12.00 (304.8)	3.50 (88.9)	12.00 (304.8)



NOMINAL WEIGHTS
IN POUNDS AND (KILOGRAMS)

MOUNTING WEIGHT			SHIPPING WEIGHT		
30 HP	40 HP	50 HP	30 HP	40 HP	50 HP
374 (169.6)	385 (174.6)	387 (175.5)	499 (226.3)	510 (231.3)	512 (232.2)

**4.3
General Wiring Practices**

Depending on the Drive model number ordered, the Bulletin 1334 Adjustable Frequency Drive is designed to operate from either:

- A 3 \emptyset , 60 Hz, 460V AC Input Source
- A 3 \emptyset , 50 Hz, 380V AC Input Source
- A 3 \emptyset , 50 Hz, 415V AC Input Source

Unless otherwise specified, the following information references the 460V AC, 60Hz unit. Refer to **Chapter 7** for 380 & 415V information.

The Drive maximum output voltage is approximately equal to the applied input voltage. Since the Drive maximum continuous current rating does not change with input voltage, the Drive output kVA rating decreases directly with input voltage.

For input AC supply voltages other than those listed in the specifications, an input transformer must be used and connected as indicated on the transformer.

The National Electrical Code (NEC) and local regulations govern the installation and wiring of the Bulletin 1334 Drive. Input power wiring, output power wiring, control wiring, and conduit must be sized and installed in accordance with these codes, the Drive nameplate data, and any Allen-Bradley information supplied with your Drive.

IMPORTANT

- 1) The National Electrical Code (NEC) requires that branch circuit protection of the AC line input power to the Drive be provided by circuit breaker or fusible disconnect switch. The standard Bulletin 1334 Drive does not provide this requirement.
- 2) The National Electrical Code requires that motor overload protection be provided in the motor branch circuit. The standard Bulletin 1334 Drive does not provide this requirement.

Eutectic Alloy or bi-metal overload relays can be utilized to provide running overcurrent protection. Due to the reduced cooling capacity of motors running at low speed (full load), overload relays typically can not provide accurate protection against overheating below 50% of base speed.

Inverse time protection against motor overload can be obtained by means of the Bulletin 1334 Motor Overload Relay, Option T through T9.

Refer to article 430 of the NEC and any additional local codes for specific requirements and additional information.

**4.3.1
Contingency STOP**



WARNING

The START/STOP control circuitry in the Bulletin 1334 Drive includes solid state components that can malfunction. If hazards due to accidental contact with moving machinery or unintentional flow of liquid, gas or solids exist, an additional hard wired contingency stop circuit may be required. Refer to codes and standards applicable to your particular system for specific requirements and additional information. A device that removes AC input power when a contingency stop is initiated can be used. When AC input power is removed however, there will be a loss of inherent regenerative braking effect and the motor will coast to a stop. An auxiliary braking method may be required.

After an emergency stop has been initiated, allow at least (5) seconds to elapse before reapplying AC input power to the Drive. The allowable number of contingency start/stops are (5) cycles of (3) starts per minute at (20) second intervals. Wait (5) minutes before attempting the next (5) cycles.

**4.3.2
Recommended
Control Signal Wiring,
Power Wiring &
Conduit Entry Area**



CAUTION

When drilling into the Drive enclosure, be sure to protect Drive components from metal chips that could cause damage to the Drive once power is applied.

All power wiring, control wiring and conduit to the Bulletin 1334 must be made through the top of the Drive enclosure as shown in figures 4.3.2a, b and c on the following page. Connections to the Drive should be made as described in the following sections and in accordance with any additional interconnection diagrams packed with the Drive. Verify that shielded cable and/or steel conduit is used if indicated on any interconnection diagram.

figure 4.3.2a
Bulletin 1334 Series B
3-10 HP
(TOP VIEW)




figure 4.3.2b
Bulletin 1334 Series A
15-25 HP
(TOP VIEW)





figure 4.3.2c
Bulletin 1334 Series A
30-50 HP
(TOP VIEW)

	A	B	C
NEMA Type 1	2.00"	22.50"	2.00"
NEMA Type 12	5.00"	37.38"	5.00"



4.3.3 Chassis Ground, Power Input & Output Connections

The input and output power connections to the Drive discussed in this section are for the standard Bulletin 1334 Drive. The standard Bulletin 1334 Drive does not include any of the available options. Additional Drive option information and connection drawings are supplied with the Drive as supplements to this manual.



WARNING

Bulletin 1334 Drives have two ground lugs labeled **GND** provided at the top of the Drive back panel. To guard against shock hazards or equipment damage, one of these lugs must be connected to earth ground as shown. Additionally, the motor frame must also be connected to earth ground.



CAUTION

Power factor correction capacitors connected to the Drive output cannot be used. The switching of power factor correction capacitors on the input AC line of the Drive may cause damage to the Drive.

If your application requires the use of power factor correction capacitors or output contactors, consult your nearest Allen-Bradley Area Sales/Support Center.

IMPORTANT

The Bulletin 1334 produces a sine-weighted, PWM output voltage at a variable output frequency for application to a standard 3 phase, NEMA Design B induction motor. For applications other than standard NEMA Design B motors, consult your nearest Allen-Bradley Area Sales/Support Center.




figure 4.3.3a – Bulletin 1334 Series B 3-10 HP Power Input & Output Connections




figure 4.3.3b – Bulletin 1334 Series A 15-50 HP Power Input & Output Connections

**4.4
Control Wiring**

The information on the following pages references control wiring, either factory supplied or field installed. All control wiring should be connected as shown in the following interconnection diagrams. The control and interconnection wiring to the Drive discussed in this section are for the standard Bulletin 1334 Drive. The standard Bulletin 1334 Drive does not include any of the available options. Additional Drive option information and connection drawings are supplied with the Drive as supplements to this manual.

**4.4.1
Terminal Block TB1 or 1TB
Interconnection Notes**

Terminal Blocks TB1 (3-10 HP Series B Drives) and 1TB (15-50 HP Series A Drives) have identical control wiring interconnections except as noted in **sections 4.4.2 – 4.4.5.**



CAUTION

Motor Thermostatic Switch

Direct connection of a motor thermostatic switch to the Drive control circuit may damage the Drive. If a motor thermostatic switch is required to be connected to the Drive control circuit:

Use an interposing N.O. relay contact (customer furnished) to isolate the thermostatic switch from the Drive control circuit. Connect the relay contact between terminals 10 & 11 at Terminal Block TB1 or 1TB as shown in section 4.4.8.

If the Drive is equipped with a Motor Overload Relay, the interposing relay contact from the motor thermostatic switch should be wired in series with the normally closed contact of the Motor Overload Relay as shown in section 4.4.9.

Control Signal Wiring

- 1) **All** Control Signal Wiring must be run separate from power wiring in its own separate ferrous metal conduit.
- 2) If **Control Signal Wiring is Required**, any nearby relays, solenoids, or brake coils can produce electrical noise transients and cause erratic Drive behavior. An R-C suppressor device should be added across the coils of these devices. As an alternate, a 220Ω resistor in series with a 0.5μF, 600V capacitor can be used as a suppressor in 120V AC circuits.

Remote Mounted Speed Pot

- 1) Wiring must be twisted, three conductor wire, having (2) to (3) twists per inch.
- 2) Wiring must be run in separate ferrous metal conduit to minimize the possibility of electrical noise.
- 3) If **Shielded Wire is Required**, the shield must be connected to ground only at Terminal Block TB1 or 1TB, term. 11 – The other end must be left floating.

Field Installed START/STOP Control

- 1) If **Remotely Mounted**, wiring must be run in conduit separate from any speed reference or power wiring.
 - 2) **When Using Remote (3) Wire STOP/START Pushbutton Control**, the local STOP pushbutton must be wired in series with the remote STOP pushbutton. Disconnect existing wires from terminals 8 & 9 and remove the START pushbutton. Install a closing plug and remove or cover the START legend. Refer to **sections 4.4.2 & 4.4.3.**
 - 3) **When Using (2) Wire START/STOP Control Via a Relay Contact**, disconnect existing wires from terminals 7, 8 & 9 and remove both the START & STOP pushbuttons. Install closing plugs and remove or cover both the START and STOP legends. Refer to **sections 4.4.4, 4.4.5 & 4.4.6.**
-



WARNING

When using (2) wire START/STOP control via a maintained START or RUN contact, the Drive will automatically restart after loss of AC input power once power is restored. Personal injury may occur if labels are not located at the Drive and associated machinery to warn operators/service personnel of the potential hazard. Warnings should include procedures to lock-out power at the disconnect device when servicing equipment.

4.4.2
Terminal Block TB1
3-10 HP Series B
Standard Interconnection Diagram


IMPORTANT

TERMINAL BLOCK TB1 INTERCONNECTIONS

The maximum wire size TB1 will accept is 18 AWG – **Stranded wire recommended.**


Terminal Block TB1 has captive termination screws.

- Do Not Back Screws Completely Out
- Do Not Lug Terminations




- ① Components May be Supplied by User or Allen-Bradley
- ② When Using Remote (3) Wire STOP/START Control, the Local STOP Pushbutton Must Be Wired in Series with the Remote STOP Pushbutton
 - Disconnect Existing START Pushbutton Wires From Terminals 8 & 9 and Remove the START Pushbutton
 - Install a NEMA Type 12 Closing Plug and Remove or Cover the START Legend
- ③ Remove Jumper When Connecting Option
- ⚡ Drive Common
- ⏏ Chassis Ground


4.4.3
Terminal Block 1TB
15-50 HP Series A Standard
Interconnection Diagram



- ① Components May be Supplied by User or Allen-Bradley
- ② When Using Remote (3) Wire STOP/START Control, the Local STOP Pushbutton Must Be Wired in Series with the Remote STOP Pushbutton
 - Disconnect Existing START Pushbutton Wires From Terminals 8 & 9 and Remove the START Pushbutton
 - Install a NEMA Type 12 Closing Plug and Remove or Cover the START Legend
- ③ Remove Jumper When Connecting Option
- ↕ Drive Common
- ⏏ Chassis Ground




- ① When Using This Control Scheme, If Drive Has Factory Installed START/STOP Pushbuttons
– Disconnect Existing START/STOP Wires From Terms. 7, 8 & 9 and Remove Both the START & STOP Pushbuttons
– Install NEMA Type 12 Closing Plugs and Remove or Cover Both the START & STOP Legends
- ↕ Drive Common
⏏ Chassis Ground




- ① When Using This Control Scheme, If Drive Has Factory Installed START/STOP Pushbuttons
– Disconnect Existing START/STOP Wires From Terms. 7, 8 & 9 and Remove Both the START & STOP Pushbuttons
– Install NEMA Type 12 Closing Plugs and Remove or Cover Both the START & STOP Legends
- ↕ Drive Common
⏏ Chassis Ground

4.4.6
Interconnection Diagram
– Field Installed
Run/Stop Control
(2-Wire 90V AC, Drive Supplied)




- ① When Using This Control Scheme, If Drive Has Factory Installed START/STOP Pushbuttons
- Disconnect Existing START/STOP Wires From Terms. 7, 8 & 9 and Remove Both the START & STOP Pushbuttons
 - Install NEMA Type 12 Closing Plugs and Remove or Cover Both the START & STOP Legends


4.4.7
Interconnection Diagram
– Field Installed
Remote Mounted Speed Pot



4.4.8
Interconnection Diagram
– Field Installed
Motor Thermostatic Switch



4.4.9
Interconnection Diagram
– Field Installed
Motor Overload Relay & Thermostatic Switch



Bulletin 1334 Startup & Adjustment Procedures

**5.0
Prepower Check**

Each Drive is functionally tested at the factory. It has been adjusted for the output voltage and frequency range indicated on the Drive nameplate. If new settings must be made to meet additional equipment requirements or operator preferences, refer to **section 5.3, Adjustment Procedures**.

Prior to operating the Drive, become familiar with the Drive by locating and identifying all major components for your Drive in **Appendix A, B, or C**. Refer to the **Diagnostic Display Panel** for your Drive in **Appendix D, E, or F** to become familiar with the fault indication features. Once the Drive has been installed and wired as outlined in **section 4.3, General Wiring Practices**, and **section 4.4, Control Wiring**, proceed as follows.

**WARNING**

Use specified incoming line fuses to guard against equipment damage and hazards due to ruptured electrolytic capacitors.

Hazardous voltage levels exist on some printed circuit boards and the Drive components.

If diagnostic LED(s) **PROT. A, PROT. B, or PROT. C** are lit, hazardous voltages can be present at the output terminals even though the STOP pushbutton has been depressed.

For 3-10 HP Drives if neon light **DS1** on Power Distribution Board A2 is lit, hazardous voltages are present in the Drive cabinet.

For 15-50 HP Drives if neon light **DS1** on Bus Indicator Board A5 is lit (or the Brake Board if installed), hazardous voltages are present in the Drive cabinet.

To guard against personal injury when boards or wires are being disconnected or reconnected or fuses are being replaced always:

Remove Power to the Drive at the Disconnect Device

- For 3-10 HP Series B Drives, wait (60) seconds, and ensure that **DS1** is not lit before servicing. Use a DVM to check for zero volts between pins 11 (+ BUS) & 15 (- BUS) at connector **J202** on Power Distribution Board A2 as shown on page A-3.
- For 15-50 HP Series A Drives, wait (5) seconds, and ensure that **DS1** is not lit before servicing. Use a DVM to check for zero volts between terminals 1 (+ BUS) & 5 (- BUS) at terminal block **4TB** on the Drive backpanel as shown in Appendixes B and C.

**5.1
Initial Operation**

Before applying input power to the Drive for the first time:

- Verify that all wiring to the Drive is correct and in compliance with the **Installation Procedures** as stated in **Chapter 4** and any additional or supplemental information provided with the Drive.
- With an ohmmeter set to its highest scale, check for grounds between the Drive output terminals and chassis ground (**GND**), as well as between the Drive input terminals and chassis ground (**GND**). Should any unintentional grounds be found, determine their cause and eliminate them prior to applying input power to the Drive.

5.1
Initial Operation
(continued)

The Bulletin 1334 employs “power loss ride-thru” which prevents the Drive from shutting down on intermittent loss of input voltage for a nominal 50mS (3 cycles or less). Due to this, the total time between pressing the STOP pushbutton and shut down of the Drive will be a minimum of approximately 50mS. Additional time may elapse before the motor comes to a complete stop depending upon the stop mode selected by the **RTD S/OFF** jumper on the Modulator Logic Board. If the **RTD S/OFF** jumper is set to **OFF**, the output Power Switching Modules will be turned off after approximately 50mS in response to either a STOP command or the removal of input AC line power to the Drive.

If the **RTD S/OFF** jumper is set to **RTD S**, the 50mS delay will again occur when a STOP command is received, but the Drive will decelerate along the set decel ramp to a stop while maintaining excitation to the motor.

In the **RTD S** position when a rated stop occurs and the motor is at rest, a minimum DC Boost is still applied to the motor. This minimum value of excitation however, will not be enough to overheat the motor.



CAUTION : To Guard Against Equipment Damage, Before Pressing the START Pushbutton:

- Set the Speed Pot or speed reference to **MINIMUM** (fully CCW).
 - Set the **FWD/REV Switch** (if present), to the proper position.
 - Set any **AUTO/MAN** switches to **MAN**.
 - Uncouple the motor from its mechanical load.
-

IMPORTANT

Drive Fault Trips

Before resetting any fault trip refer to the Bulletin 1334 Troubleshooting Appendix for your Drive — **D, E or F** — to isolate and correct the fault.

Determine the Correct Direction of Motor Rotation

Step 1 With power removed to the Drive at the disconnect device, set operator switches.

- If the BCD Interface or Isolated Signal Conditioner Card is installed, ensure that the card mounted **AUTO/MAN** switch is set to **MAN**.
- If the Drive is equipped with a **FWD/REV** switch, set the switch to **FWD** and ensure that the **REV/NO REV** jumper on the Modulator Logic Board is in the **REV** position.
- If the Drive is equipped with a **RUN/JOG** switch, set the switch to **JOG**.
- If the Drive is not equipped with a **RUN/JOG** switch, remove the **RUN/JOG** jumper between terminals 5 & 6 at Terminal Block TB1 or 1TB. This will permit the Drive to jog when the **START** pushbutton is depressed.

Step 2 Apply power to the Drive at the disconnect device.

Contactors **K1** or **1CON** should close. The amber **POWER ON LED** on the Diagnostic Display Panel should light.

For 3-10 HP Series B Drives, **DS1** the “bus charged” light on Power Distribution Board A2 should light.

5.1
Initial Operation
(continued)

Step 3 Set the speed pot or speed reference to 10% speed. Check for correct motor rotation by pressing and releasing the **START** pushbutton (Drive will stop if the **START** pushbutton is not held in).

If the motor runs backwards, wait for the motor to coast-to-stop, remove input power to the Drive at the disconnect device and wait (60) seconds. To reverse direction, switch any two motor leads at:

TB2 for 3-10 HP Series B Drives.

2TB for 15-50 HP Series A Drives.

Check again for correct motor rotation by repeating **Steps 2 & 3**. The motor should now rotate in the correct direction.

Once Correct Rotation Has Been Established

Step 1 If the Drive is equipped with a **RUN/JOG** switch, release the **START** pushbutton and set the **RUN/JOG** switch to **RUN**.

Step 2 If the Drive is not equipped with a **RUN/JOG** switch, release the **START** pushbutton and remove power to the Drive at the disconnect device. Wait (60) seconds for 3-10 HP Series B Drives, (5) seconds for 15-50 HP Series A Drives, and reinstall the **RUN/JOG** jumper between terminals 5 & 6 at Terminal Block TB1 or 1TB.

Step 3 Set the **Speed Pot** to **MINIMUM** (fully CCW). Should a minimum speed other than 0 Hz be required, refer to section 5.3.1, **MIN Speed Pot R26** adjustment.

Step 4 If required, reapply power to the Drive at the disconnect device. Press the **START** pushbutton and slowly turn the speed pot CW. The motor should turn and not trip out when the **START** pushbutton is released. Should the Drive trip, refer to **Appendix D, E, or F, Bulletin 1334 Troubleshooting**, before resetting the Drive.

Step 5 If the Drive is equipped with a **FWD/REV** switch its operation must be checked while the motor is running.

Turn the Switch to **REV**. The motor should decelerate to zero speed, reverse direction, then accelerate to the same speed as before.

Slowly run the motor up to full speed and observe its operation. The motor should accelerate up to full speed without the occurrence of a fault trip. Should a maximum speed other than 60 Hz be required, refer to section 5.3.1, **MAX Speed Pot R25** adjustment.

Step 6 Press the **STOP** pushbutton. Restart the Drive and check the motor current at several different speed settings. Continuous currents for approximately (1) minute above the motor rated full load current may seriously damage the motor windings.


IMPORTANT

Clamp on type amp probes and current transformers are frequency sensitive. Inaccurate current readings at frequencies other than 60 Hz may be observed. It is recommended that a true RMS reading clamp on ammeter be used.

5.2
Bulletin 1334
Drive Data Log Sheets

The information below and on the following page should be filled in prior to making any Drive field changes. Any readjustment of Drive factory settings or option changes should be recorded here and on the following page.

Drive Nameplate Data



**BULLETIN 1334
ADJUSTABLE FREQUENCY
MOTOR DRIVE**

SERIAL NO. _____ Series _____
CATALOG NO. 1334- _____

	INPUT	OUTPUT
VOLTS		
AMPS		
PHASE		
KVA		
FREQ		

THE STANDARD UNIT DOES NOT PROVIDE
MOTOR OVERLOAD PROTECTION IN
ACCORDANCE WITH NEC.

Motor Nameplate Data

Mfg. : _____

Frame : _____ Type : _____

HP : _____

Volts : _____

Amps : _____

Hertz : _____

RPM : _____

Temp. Rise : _____

Modulator Logic Board **POTENTIOMETER SETTINGS**

MAX Speed Pot R25 – set for _____

MIN Speed Pot R26 – set for _____

Modulator Logic Board **SWITCH SETTINGS**

ACCEL SWITCH S1 – set for _____ Hz/Sec

DECEL SWITCH S2 – set for _____ Hz/Sec

DC BOOST SWITCH S3 – set for _____ Volts

Modulator Logic Board **JUMPER SETTINGS**

90/200 Frequency Range Jumper – set for _____

H BST/L BST Jumper – set for _____

RTD S/OFF Jumper – set for _____

STD/THRD Jumper – set for _____

IFB/XFB Jumper – set for _____

REV/NO REV Jumper – set for _____

VCO/EXT-C Jumper – set for _____

V/Hz Jumper – set for _____

NORM/DEC HOLD Jumper – set for _____

3 thru 10 HP Series B Driver Board **JUMPER SETTINGS**

Overload Current Limit Threshold Adjustment
Jumpers S100 & S101 set for ___ HP, position ___
Jumpers S200 & S201 set for ___ HP, position ___
Jumpers S300 & S301 set for ___ HP, position ___

15 & 20 HP Series A Driver Board **JUMPER SETTINGS**

Overload Current Limit Threshold Adjustment
A3A Jumpers S1 & S2 set for ___ HP, position ___
A3B Jumpers S1 & S2 set for ___ HP, position ___
A3C Jumpers S1 & S2 set for ___ HP, position ___

5.3
Adjustment Procedures

Once initial operation has been verified and the Bulletin 1334 Drive Data Log Sheets filled in, the motor should be connected to the load and the Drive operated under load conditions. All Drive setup adjustments, with the exception of the overload current limit threshold level adjustment, are located on the Modulator Logic Board. The following adjustments must be made to conform to your specific load requirements and any options installed in your Drive.

MAX Speed Pot R25

MIN Speed Pot R26

ACCEL & DECEL Rate Adjustments

DC Boost Adjustment

Additional settings and adjustments may be required. Refer to the following information and any additional option instructions included with your Drive for final setup procedures.

5.3.1
Modulator Logic Board
Potentiometer Settings



CAUTION

Potentiometers **R18** – Brake Adjust, **R19** – Over Voltage Trip Adjust, and **R124** – Voltage Sense Adjust, which have been factory set and sealed, *must not* be readjusted. Readjustment of these pots may cause damage to the motor and/or Drive.



MAX Speed Pot R25

Normally Set to 60 Hz at the Factory. Sets the Drive maximum speed when the Drive speed is controlled from the Manual Speed Pot, or the BCD Interface Card, Option G4.



MIN Speed Pot R26

Normally Set to 0 Hz at the Factory. Independent of **MAX Speed**. Sets the Drive minimum speed when the Drive speed is controlled from the Manual Speed Pot.

IMPORTANT

If the **Isolated Signal Conditioner Card** (option or N or N4) is installed, the **MIN** and **MAX** speed pots are inoperative when the AUTO mode has been selected on the Isolated Signal Conditioner Card.

If either the **Digital Thumbwheel Card** (options G or G2) or the **BCD Interface Card** (option G4) has been installed, the **MIN** speed pot on the card is inoperative when the AUTO mode has been selected.




figure 5.3.1 - Modulator Board A1

5.3.2

Modulator

Logic Board Jumper Settings

∩ 90/200 Frequency Range Jumper Selection	Normally set to 90 Hz at the Factory. Sets the Drive operating frequency range for either 0-90 Hz or 0-200 Hz.
∩ STD/THRD Jumper	Normally set to STD (standard) at the Factory. For either Local or Remote Thread Speed operation, the jumper is set to the THRD (thread) position.
∩ IFB/XFB Jumper	Normally set to IFB at the Factory. Selects either IFB (internal feedback) or XFB (external feedback).
∩ RTD S/OFF	Normally set to OFF at the Factory. Selects either normal coast-to-stop (OFF position), or rated stop (RTD S position). In the RTD S position, the Drive will decel at whatever the decel rate switch S2 is set for when the STOP pushbutton is depressed.
∩ REV/NO REV Jumper	Normally set to NO REV at the Factory. Used to enable or disable the Drive's ability to respond to a REVERSE command.
∩ V/Hz Jumper	<p>Normally Set to B at the Factory. If option L, The Function Expander Card or the Euro Card is used, the volts-per-hertz jumper must be removed, otherwise it is set for A or B.</p> <p>In the A position, the Drive will produce an output of 230V at 60 Hz and 460V at 120 Hz — 3.8 Volts-per-Hertz.</p> <p>In the B position, the Drive will produce 460V at 60 Hz — 7.6 Volts-per-Hertz.</p> <p>Once the output V/Hz has been established by setting the V/Hz jumper, it can still be affected by:</p> <ul style="list-style-type: none">● <i>Setting the H BST/L BST Jumper and Switch S3 – DC Boost</i>● <i>Variations in Drive Input Line Voltage</i>● <i>Operating the Drive at Frequencies Above the Frequency at Which Maximum Voltage Occurs</i> <p>Or any combination of the above.</p>
∩ H BST/L BST Jumper Selection	Normally Set to L BST at the Factory. Sets the Drive DC boost range for either 0-20 volts (low boost – L BST) or 0-34 volts (high boost – H BST).
∩ VCO/EXT-C Jumper	Normally Set to VCO (voltage controlled oscillator) at the Factory. In the VCO position it connects the manual speed reference to the speed control circuit. The EXT-C position is used with option N or N4, the Isolated Signal Conditioner Card. It allows the option card to supply the frequency reference to the Drive.

5.3.2
Modulator
Logic Board Jumper Settings
(continued)

 **NORM/DEC HOLD Jumper**

Normally set to **DEC HOLD** (Deceleration Hold). Used to avoid overvoltage trips during deceleration of high inertia or regenerative loads.

In **DEC HOLD** the DC bus voltage is monitored by the Decel Hold circuit for a high voltage condition. If a high voltage condition is sensed — usually caused by decelerating a high inertia load too quickly — the deceleration of the Drive will be paused until the bus voltage decreases. Whenever the Decel Hold circuit is active, LED **CR53 FREQ HOLD** on the Modulator Logic Board will light.

In **NORM** the deceleration hold circuit is disabled. If a high Bus voltage occurs, the Drive will continue at the set deceleration rate. If the Bus voltage rises to the overvoltage trip level, the Drive will trip on an overvoltage fault. The **OVER VOLTS** fault LED will light at the diagnostic display but the **FREQ HOLD** will not be lit.

1. If the **MOPC**, or **PROT. A, B** or **C** LED comes on during deceleration, a reduction in the DC boost setting and/or a slower Decel rate may correct the problem.
2. If an **OVER VOLTS** fault trip occurs during deceleration and selecting **DEC HOLD** or a slower decel rate does not correct the problem, consult your nearest Allen-Bradley Sales/Support Center for additional information.
3. If the Dynamic Brake option is used with the Drive, it is recommended to use the **DEC HOLD** position.

5.3.3
Modulator Logic Board
Switch Settings



**S1 ACCEL and S2 DECEL
Rate Adjustments**

Both S1 and S2 are (6) position **ON/OFF** designated slide switches that select the **ACCEL** and **DECEL** rates within the range of 1.2 Hz/Sec to 152.4 Hz/Sec. **ACCEL** and **DECEL** rates are binary weighted as follows. Sliding a given switch from the **ON** to the **OFF** position produces a faster rate of change.

BIT WEIGHTS	
● POSITION 1 =	2.4 Hz/Sec
● POSITION 2 =	4.8 Hz/Sec
● POSITION 3 =	9.6 Hz/Sec
● POSITION 4 =	19.2 Hz/Sec
● POSITION 5 =	38.4 Hz/Sec
● POSITION 6 =	76.8 Hz/Sec

IMPORTANT

- 1) If an **M.O.P.C.** fault trip occurs during **ACCEL** and readjustment of the DC boost does not prevent the fault trip from reoccurring, a slower **ACCEL** rate may be required.
- 2) If the **M.O.P.C.** LED comes on or a phase protect trip occurs during **DECEL**, the **DEC HOLD** function and a reduction in the DC boost setting and/or a slower **DECEL** rate may correct the problem.
- 3) If an **OVER VOLTS** fault trip occurs during **DECEL** and a slower decel rate or the **DEC HOLD** function does not correct the problem, consult your nearest Allen-Bradley Area Sales/Support Center for additional information.

5.3.3
Modulator Logic Board
Switch Settings
(continued)

Setting The ACCEL and DECEL Rates


The rates shown below are accurate when a speed command from a Digital Thumbwheel Card (option G, G2) or a BCD Interface Card (option G4) is used. When an analog speed reference is used, total ACCEL/DECEL time will be 0.5 to 1.6 seconds longer than rates shown due to an RC type exponential tapering into the new speed.



CAUTION

Never set switches using a ball point pen or pencil. Switches contaminated with conductive debris may cause erratic Drive behavior.

1	2	3	4	5	6	Hz/Sec
ON	ON	ON	ON	ON	ON	1.2
OFF	ON	ON	ON	ON	ON	3.6
ON	OFF	ON	ON	ON	ON	6.0
OFF	OFF	ON	ON	ON	ON	8.4



ON	ON	OFF	ON	ON	ON	10.8
OFF	ON	OFF	ON	ON	ON	13.2
ON	OFF	OFF	ON	ON	ON	15.6
OFF	OFF	OFF	ON	ON	ON	18.0
ON	ON	ON	OFF	ON	ON	20.4
OFF	ON	ON	OFF	ON	ON	22.8
ON	OFF	ON	OFF	ON	ON	25.2
OFF	OFF	ON	OFF	ON	ON	27.6
ON	ON	OFF	OFF	ON	ON	30.0
OFF	ON	OFF	OFF	ON	ON	32.4
ON	OFF	OFF	OFF	ON	ON	34.8
OFF	OFF	OFF	OFF	ON	ON	37.2
ON	ON	ON	ON	OFF	ON	39.6
OFF	ON	ON	ON	OFF	ON	42.0
ON	OFF	ON	ON	OFF	ON	44.4
OFF	OFF	ON	ON	OFF	ON	46.8
ON	ON	OFF	ON	OFF	ON	49.2
OFF	ON	OFF	ON	OFF	ON	51.6
ON	OFF	OFF	ON	OFF	ON	54.0
OFF	OFF	OFF	ON	OFF	ON	56.4
ON	ON	ON	OFF	OFF	ON	58.5
OFF	ON	ON	OFF	OFF	ON	61.2
ON	OFF	ON	OFF	OFF	ON	63.6

1	2	3	4	5	6	Hz/Sec
OFF	OFF	ON	OFF	OFF	ON	66.0
ON	ON	OFF	OFF	OFF	ON	68.4
OFF	ON	OFF	OFF	OFF	ON	70.8
ON	OFF	OFF	OFF	OFF	ON	73.2
OFF	OFF	OFF	OFF	OFF	ON	75.6
ON	ON	ON	ON	ON	OFF	78.0
OFF	ON	ON	ON	ON	OFF	80.4
ON	OFF	ON	ON	ON	OFF	82.8
OFF	OFF	ON	ON	ON	OFF	85.2
ON	ON	OFF	ON	ON	OFF	87.6
OFF	ON	OFF	ON	ON	OFF	90.0
ON	OFF	OFF	ON	ON	OFF	92.4
OFF	OFF	OFF	ON	ON	OFF	94.8
ON	ON	ON	OFF	ON	OFF	97.2
OFF	ON	ON	OFF	ON	OFF	99.6
ON	OFF	ON	OFF	ON	OFF	102.0
OFF	OFF	ON	OFF	ON	OFF	104.4
ON	ON	OFF	OFF	ON	OFF	106.8
OFF	ON	OFF	OFF	ON	OFF	109.2
ON	OFF	OFF	OFF	ON	OFF	111.6
OFF	OFF	OFF	OFF	ON	OFF	114.0
ON	ON	ON	ON	OFF	OFF	116.4
OFF	ON	ON	ON	OFF	OFF	118.8
ON	OFF	ON	ON	OFF	OFF	121.2
OFF	OFF	ON	ON	OFF	OFF	123.6
ON	ON	OFF	ON	OFF	OFF	126.0
OFF	ON	OFF	ON	OFF	OFF	128.4
ON	OFF	OFF	ON	OFF	OFF	130.8
OFF	OFF	OFF	ON	OFF	OFF	133.2
ON	ON	ON	OFF	OFF	OFF	135.6
OFF	ON	ON	OFF	OFF	OFF	138.0
ON	OFF	ON	OFF	OFF	OFF	140.4
OFF	OFF	ON	OFF	OFF	OFF	142.8
ON	ON	OFF	OFF	OFF	OFF	145.2
OFF	ON	OFF	OFF	OFF	OFF	147.6
ON	OFF	OFF	OFF	OFF	OFF	150.0
OFF	OFF	OFF	OFF	OFF	OFF	152.4

5.3.3
Modulator Logic Board
Switch Settings
(continued)

○
○
S3 DC Boost Adjustment

S3 works in conjunction with the **H BST/L BST** jumper to set the Drive DC boost. Switch S3 consists of (4) rocker switches which allow up to (16) possible DC boost settings.

IMPORTANT

Two types of rocker switches are used on the Modulator Logic Board. The switch illustrated below adds more boost when the switch is rocked to **OPEN**. The alternate switch is **CLOSED** when the number on the switch is depressed.


				BOOST VOLTS	
1	2	3	4	L BST	H BST
CLOSE	CLOSE	CLOSE	CLOSE	0	0
OPEN	CLOSE	CLOSE	CLOSE	1.33	2.27
CLOSE	OPEN	CLOSE	CLOSE	2.67	4.53
OPEN	OPEN	CLOSE	CLOSE	4.00	6.80
CLOSE	CLOSE	OPEN	CLOSE	5.33	9.07
OPEN	CLOSE	OPEN	CLOSE	6.67	11.33
CLOSE	OPEN	OPEN	CLOSE	8.00	13.60
OPEN	OPEN	OPEN	CLOSE	9.33	15.90
CLOSE	CLOSE	CLOSE	OPEN	10.70	18.10
OPEN	CLOSE	CLOSE	OPEN	12.00	20.40
CLOSE	OPEN	CLOSE	OPEN	13.30	22.70
OPEN	OPEN	CLOSE	OPEN	14.70	24.90
CLOSE	CLOSE	OPEN	OPEN	16.00	27.20
OPEN	CLOSE	OPEN	OPEN	17.30	29.50
CLOSE	OPEN	OPEN	OPEN	18.70	31.70
OPEN	OPEN	OPEN	OPEN	20.00	34.00

Adding DC Boost

Generally, less DC boost is required as developed motor HP and efficiency increases and starting torque demand decreases. Conversely, more DC boost is required as HP decreases, motor efficiency decreases, and starting load torque increases.


Too little boost will cause the motor to draw more in-phase current, while too much boost may increase the magnetizing current to the motor to the point of saturation. Generally, the best DC boost setting is the lowest value that will consistently start the load. Start with zero boost and increase the setting until capable of developing the required breakaway or starting torque.

5.3.3
Modulator Logic Board
Switch Settings
(continued)



Decelerating a large inertia load with excessive DC boost may cause the Drive to go into **M.O.P.C.** or experience a phase protect fault trip due to saturation of the motor.

Reducing the DC boost and/or using a slower DECEL rate will usually correct the problem. Reducing the DC boost however, may reduce the motor's ability to start the load. Should this occur, contact your nearest Allen-Bradley Area Sales/Support Center for application assistance.



**5.3.4
Driver Board
Jumper Settings**

IMPORTANT

Driver Board Jumpers for 3-20 HP ratings have been preset at the factory at the HP rating specified on the Drive Nameplate. Field adjustment should not be necessary. Should the Driver Board require replacement, the jumpers should be set as described below and on the following pages prior to installation.

There are no adjustment settings for Bulletin 1334 25-50 HP Driver Boards, however 30-50 HP Driver Boards provide fuse status indication as described in **Appendix F**.

**∩ 3-10 HP Series B
M.O.P.C.
Threshold Level Adjustment**

There are two jumpers for each section of the Driver Board – **S100 & S101 for SECTION A, S200 & S201 for SECTION B, S300 & S301 for SECTION C**. These jumpers establish the threshold level at which the **M.O.P.C.** function becomes active.

All jumpers must be set to the same position as shown in **figure 5.3.4a** to correspond to either a 3, 5, 7½ or 10 HP Drive.

The Driver Board shown, 50905-002, is used by both the 7½ & 10 HP Bulletin 1334. For 7½ HP Drives, all jumpers on this board should be set to the “**A**” position. For 10 HP Drives, all jumpers should be set to the “**B**” position.

The 3 & 5 HP Bulletin 1334 uses a similar Driver Board, 50905-001. For 3 HP Drives, all jumpers on this board should be set to the “**A**” position. For 5 HP Drives, all jumpers should be set to the “**B**” position.

**∩ 15 & 20 HP
M.O.P.C.
Threshold Level Adjustment**

There are two jumpers, **S1 & S2**, for each of the three Driver Boards, **A3A, A3B, & A3C**. These jumpers establish the threshold level at which the **M.O.P.C.** function becomes active.

All jumpers must be set to the same position as shown in **figure 5.3.4b** on each board to correspond to either a 15 or 20 HP Drive.




figure 5.3.4a - P/N 50905-001 - 3 & 5 HP Driver Board
- P/N 50905-002 - 7 1/2 & 10 HP Driver Board




figure 5.3.4b - P/N 50399 - 15 & 20 HP Driver Board

6.0 Principles of Operation

The Bulletin 1334 Drive provides a three phase motor with variable frequency and voltage utilizing PWM (Pulse Width Modulated) technology. Varying the frequency of the applied power to the motor varies the speed of the motor. Maintaining a constant relationship between applied frequency and voltage within the base speed range of the motor results in *Constant Motor Torque* capability.

Typically the nameplate data on motors used in the U.S.A. specify base speed at a frequency of 60 Hz.

To achieve *Constant Horsepower* operation above base speed, the motor voltage remains constant while the frequency is increased. In the motoring mode of operation, the RMS output voltage of the Drive cannot be any greater than the RMS value of its applied AC input voltage. This results in constant horsepower operation of the motor out to a speed that is approximately 1.5 times the motor base speed.

In the constant horsepower range of operation, the motor horsepower remains reasonably constant. The motor output torque drops off inversely as the square of the difference in speed between the motor nameplate base speed, and the operating speed of the motor above base speed.

Figure 6.0a shows the relationship between the output voltage and frequency for a drive system that includes a motor having a base speed of 60 Hz. The output of the Drive is a sine weighted, pulse width modulated pattern.




figure 6.0a – Voltage/Frequency Curve

Figure 6.0b illustrates this phase-to-phase output voltage waveform. To illustrate the approximate RMS value, an AC sine wave has been superimposed over the pulse width waveform.

6.0
Principles of Operation
(continued)




figure 6.0b – Output Voltage Waveform

The “ON” pulse width is decreased to obtain lower RMS voltages and increased for higher voltages. As the Drive output frequency is varied, the number of pulses per hertz changes such that the lower the output voltage, the greater the number of pulses per hertz.

The Bulletin 1334 Drive utilizes transistorized power switching modules that are sourced from a DC power bus in the inverter power section. The switching of these power modules is under the control of a special LSI chip located on the Modulator Logic Board. As the Drive output frequency is varied over its range, the LSI chip establishes the number of pulses per hertz and the duration of these pulses.

6.1
Main Circuit Overview

All Bulletin 1334 Drives can basically be divided into two sections, the **Power Section** and the **Logic and Control Section**.

The **Power Section** contains all of the high voltage and current power devices to convert AC input power to DC. It then inverts the DC to a variable frequency, PWM voltage for application to the AC motor.

The **Logic and Control Section** includes all of the low power signal generating and processing circuits, as well as the logic circuits that control the performance characteristics of the Drive. All customer control functions are interfaced to the Logic and Control Section of the Drive.




figure 6.2 – Bulletin 1334

6.2
The Power Section

As shown below in figure 6.2, the Power Section for Bulletin 1334 Drives includes the following circuits:

- Incoming AC Line Power & Precharge Current Limiting Circuits
- Bridge Rectifier, DC Bus & Bus Discharge Circuits
- Output Inverting Circuits

6.2.1
Incoming AC Line Power
& Precharge
Current Limiting Circuits

Input AC line power connections are made at a terminal block on the Drive that is directly connected to input line fuses. These input line fuses are coordinated with the Drive fault circuitry for protect against short circuits up to a maximum of 200,000 symmetrical amps.

Drive faults are electronically sensed. If a fault is detected, the Drive will shut down in an orderly fashion, and in most cases, without the loss of line fuses. The fault condition is simultaneously annunciated on a Diagnostic Display Board in the Drive.


When input AC line power is first applied to the Drive, depending on the Drive rating, one or more resistors function to limit the inrush current of the DC bus capacitors. Once the capacitors have charged to approximately 90% of their final value, the Modulator Logic Board directs either a precharge relay or contactor to pickup and bypass these resistors.

6.2.2
Bridge Rectifier, DC Bus,
& Bus Discharge Circuits

The diode bridge rectifier, along with one or more DC bus chokes (depending on the Drive rating), ensures that the Drive presents a high kW/kVA power factor to the incoming AC line. Depending on the Drive rating, metal oxide varistors or suppression devices provide additional protection against voltage transients to the DC bus. The bus chokes, along with the bus capacitors provides filtering that minimizes the RMS current required from the incoming AC line.

The DC bus sources DC voltage to the output power devices. Resistors connected across the bus capacitors ensures that bus voltage is equally distributed across the capacitors.

The working DC bus potential is nominally 1.414 times the RMS value of the incoming AC line voltage. For a 460V AC line, the DC bus potential would be 650V DC.



6.2.2
**Bridge Rectifier, DC Bus,
& Bus Discharge Circuits**
(continued)

To avoid leaving high voltage on the DC bus and bus capacitors after power is removed, resistors drain off the bus capacitors to 42 volts within sixty seconds for Series B Drives. For Series A Drives, an additional board has been provided that allows the DC bus to fall below 42 volts within five seconds. For all Drives, a neon glow tube is illuminated whenever the DC bus potential is greater than 42V DC.

6.2.3
Output Inverting Circuits

The output inverting circuits invert the DC bus voltage to three phase AC voltage for the motor. Depending on the Drive rating, the main power components in these circuits are either three or six transistorized power switching modules.

Whether three or six switching modules are used, the modules are gated "ON" and "OFF" at the proper time by one or more driver boards. Each driver board, (or if only one master driver board is used, each section of the master driver board), controls the modules for a single phase – A, B or C. Each individual board, or section of the master driver board, is in turn under the direction of the LSI chip on the Modulator Logic Board. In this way, a variable frequency, pulse-width modulated output voltage is applied to the motor.

A typical three phase, sine weighted, PWM output wave form is illustrated in figure 6.2.3a. Proper 120° phase shift between output phases A, B and C remains constant over the entire output frequency range.




figure 6.2.3a – Three Phase, Sine Weighted, Output Voltage Waveforms

6.2.3
Output Inverting Circuits
(continued)

Typical applied motor voltage and resulting current waveforms for one of the output phases at 60 Hz, full load, is shown in **figure 6.2.3b**. From this figure it can be seen that although the voltage is a series of pulses, the resultant current is nearly sinusoidal.




figure 6.2.3b – Applied Motor Voltage and Current Waveforms

6.3
The Logic and Control Section

The logic and control section of the Bulletin 1334 Drive accepts commands from operator elements and other external interfaces to control the output of the Drive. Most of the circuits operate at logic levels. All interfacing to the power section is electrically isolated so that the logic may be referenced to ground potential.

Five general tasks are accomplished by the logic and control section.

- **Controlling the Startup Sequence**
- **Generating Control Signals** for Output Power Switching Modules
- **Providing an Interface** for Control Signals and Auxiliary Functions
- **Providing an Orderly Rated Stop or Coast-to-Stop**
- **Monitoring of Fault and Protection Circuits**

Depending on the Drive rating, various printed circuit boards are used to accomplish these functions. All Drive ratings, however, use the Modulator Logic Board to direct the control of the other logic and control boards.




figure 6.3 – Bulletin 1334 Logic and Control Section

6.3.1 Controlling the Startup Sequence

Two functions must occur when AC power is applied to the Drive. One is Power-On-Reset of the logic circuit. The other is monitoring the precharge of the DC bus and energizing the precharge contactor once precharge is complete.

6.3.1 Controlling the Startup Sequence (continued)

Power-On-Reset (POR), is accomplished by the Modulator Logic Board. A time delay circuit generates the POR signal when power is first applied. This signal resets the fault trip circuit, as well as the LSI chip. It changes state to "normal" approximately 0.2 seconds after power is applied to the Drive.

The Modulator Logic Board also receives two signals from the voltage sensing section of the Drive. One signal is proportional to the line voltage, the other to the actual DC bus voltage. These signals are compared and when the DC bus reaches a level of approximately 90% of AC line level, precharge is considered complete. The precharge relay or contactor is then energized by the Modulator Logic Board and the Drive is now functionally operational.

6.3.2 Generating Control Signals

The control signals for the output power switching modules are all generated by the LSI chip located on the Modulator Logic Board. These signals are then fed to the appropriate section of the master Driver Board, or to the individual Driver Boards. Each section isolates the logic signals from the high voltage bus and buffers them to the proper driving level for its own switching module.

6.3.3 Providing an Interface

The LSI chip requires several inputs to generate switching signals. Many of these are programmable inputs located on the Modulator Logic Board and are available for customer adjustment. These adjustments include –

Volts per Hertz – In the motoring mode of operation, the RMS output voltage of the Drive cannot be any greater than the RMS value of its applied AC input voltage. The RMS output voltage must also vary directly with the RMS value of the input voltage. Two ranges are predetermined by jumper selection, 7.6 V/Hz or 3.8 V/Hz.

With an AC line input voltage of 460 volts and the jumper set at 7.6 V/Hz, the Drive will produce an output voltage of 460V at 60 Hz. With the same input line voltage applied but the jumper set at 3.8 V/Hz, the Drive will produce an output of 230V at 60 Hz and 460V at 120 Hz.

Accel Rate and Decel Rate – The accel and decel rates at which the Drive changes its output frequency in response to a step change in input speed command are independently selectable.

Two, six position ON/OFF slide switches, one for accel and one for decel, provide the means for a binary weighted rate selection. The standard range of adjustment is from 1.2 Hz/Sec (slow), to 152.4 Hz/Sec (very fast). Additional information and actual switch settings are detailed in Chapter 5, **Startup & Adjustment Procedures**.

Minimum and Maximum Speed Adjust – These two adjustment pots on the Modulator Logic Board normally establish the minimum and maximum output frequency of the Drive.

Minimum speed is normally adjustable over the range of 0-40 Hz. When the frequency range jumper is set to 90 Hz, **maximum speed** is normally adjustable from 40-120 Hz.

6.3.3
Providing an Interface
(continued)

When the frequency range jumper is set to 200 Hz, **maximum speed** is normally adjustable from 40-200 Hz. However, certain options installed in the Drive will cause either the minimum or maximum speed pots to be ineffective.

The **minimum speed** pot is ineffective if any of the options listed below are installed.

1. The **Local Digital Thumbwheel Switch**, option G
2. The **Remote Digital Thumbwheel Switch**, option G2, when the AUTO mode is selected.
3. The **BCD Interface Card**, option G4, when the AUTO mode is selected.

If any one of these options are installed, the **maximum speed** pot then sets the maximum speed that can be commanded by either the Digital Thumbwheel Switch or the BCD Interface commands received by the Drive.

Both the minimum and maximum speed pots are ineffective if the Isolated Signal Conditioner Card is installed and set to the AUTO mode of operation. The OFFSET and GAIN adjustments on the option card now set the minimum and maximum Drive speed respectively. Only when the MANUAL mode of operation is selected will both the minimum and maximum speed pots be effective.

Frequency Range – Two preprogrammed ranges are jumper selectable, 0-90 Hz or 0-200 Hz. Selecting either range “*brackets*” the overall operating frequency within the range set by the minimum and maximum speed pots as explained above.

DC Boost and Boost Range – These two adjustments, one a switch setting, the other a jumper setting, establish the amount by which the V/Hz output of the Drive is increased in the lower output frequency range of operation. Boost is used to optimize the starting torque of the motor. The jumper selects either LOW or HIGH BOOST and the switch performs a binary selection of voltage values in the range of 0-20 volts or 0-34 volts.

Increasing the DC boost will increase the motors ability to develop torque at low speed by compensating for the IR drop of the motor. Too much boost however, will increase the magnetizing current drawn by the motor causing the motor to saturate. As this condition occurs, the peak currents drawn by the motor increase rapidly to the point where they can cause the Drive to trip out on either a PHASE PROTECT or M.O.P.C. trip.

Operator Speed Control – The standard Drive configuration with no options installed, receives its speed command from a 1k Ω pot that is connected across a DC source of 3.2 volts. The output of the potentiometer supplies a 0-3.2 volt speed command signal to the Modulator Logic Board. There it is conditioned by various circuits and applied to a VCO (Voltage Controlled Oscillator) that produces a frequency proportional to the speed command voltage. The VCO output frequency is 384 times the required Drive output frequency (384f). This 384f signal drives the LSI chip which uses it to generate the Drive output frequency.

6.3.4
Providing an Orderly
Rated Stop or Coast-to-Stop

The RTD S/OFF jumper on the Modulator Logic Board allows the motor to either ramp-to-stop by following the decel rate down, or coast-to-stop in response to a Drive STOP command.

In the RTD S (rated stop) mode, the motor remains energized during the decel period. When at rest, it has a reduced value of DC boost applied to it. This low value of DC boost however will not cause the motor to overheat.

In the OFF (coast-to-stop) mode, 50mS after the Drive receives a STOP command, the Drive output Power Switching Modules are commanded OFF and the motor coasts to a stop with no excitation applied to it.

6.3.5
Monitoring of Fault
and Protection Circuits

Drive circuitry continuously monitors its own operation as well as the incoming AC line. If a fault condition occurs, the Drive is designed to protect itself against the fault by tripping off and annunciating the fault condition by a series of LEDs located on a display panel on the front of the Drive.

IMPORTANT

Drive Fault Trips

Before resetting any fault trip refer to the Bulletin 1334 Troubleshooting Appendix for your Drive, D, E, or F, to isolate and correct the fault.

Fault trips are reset by first giving the Drive a STOP command, followed by a START command, or by removing power to the Drive for a minimum of (2) seconds.

The fault and monitoring circuits include:

Over Voltage – This circuit monitors the DC bus. If the bus voltage ever exceeds 760 volts, the circuit will shut down the Drive and turn on the “**OVER VOLTS**” LED.

Under Voltage – This circuit compares a signal from the incoming AC line with a regulated reference. If the line voltage is less than 414V for a 460V AC Drive, less than 373V for a 415V AC Drive, or less than 342V for a 380V AC Drive, the Drive will shut down and the “**UNDER VOLTS**” LED will come on.

Drive Over Temperature – The Drive has a thermal switch located on the Power Switching Module heat sink. If the heat sink temperature rises above the rated point due to overload or environmental conditions, the thermal switch will open, the Drive will shut down, and the “**DRIVE OVER TEMP.**” LED will come on.

Brake Over Temperature – When the Dynamic Brake option is used, a thermal over load switch located in the brake resistor assembly monitors the resistor temperature. Should the temperature ever exceed its preset limit, the thermal switch will open, the Drive will shut down, and the “**BRAKE OVER TEMP.**” LED will come on.

6.3.5
Monitoring of Fault
and Protection Circuits
(continued)

IMPORTANT : To reset a Brake Over Temperature Trip

1. *Remove input power to the Drive at the disconnect device.*
 2. *Wait a few minutes to allow the O.L. heater and brake resistor to cool down.*
 3. *Open the conduit box on the resistor cage assembly. Manually reset Thermal O.L. Relay 2TAS by depressing the plunger until a "click" is either heard or felt.*
 4. *Reapply power to the Drive at the disconnect device.*
 5. *Reset the Drive by giving it a STOP command followed by a START command.*
-

Phase A, B or C Fault Protection – Depending on the Drive rating, each section of the Driver Board, or each individual Driver Board, is designed to monitor the Power Switching Module or modules for the phase it is controlling. If a short circuit or output ground fault occurs, excessive fault current may flow in the transistors when they are turned on.

Each driver section or individual board can sense this and directly turn off the Power Switching Module(s) for that phase to help avoid failure. This condition is reported to the Modulator Logic Board, annunciated by a phase **A, B, or C "PROT."** LED at the display panel, and the Drive is shut down.

Momentary Overload Protection Circuit (M.O.P.C.) – In addition to monitoring for fault currents, the Driver Board monitors the continuous current drawn by the motor. If the current exceeds a preset level of 150%, a signal is given to the Modulator Logic Board. The Modulator Logic Board responds by reducing the voltage and frequency to the motor and starting a timer.

Reducing the voltage and frequency will usually reduce the current drawn by the motor. This permits the Drive to operate the motor through a momentary overload without tripping off. Once the load is reduced below set point, the Drive will reaccelerate back to set speed at the selected ACCEL rate set by switch S1 on the Modulator Logic Board. If the overload continues, the Drive will continue to ramp down the voltage and frequency until a frequency is reached where the motor stalls out.

If this condition continues for approximately one minute after the timer starts, the Drive will shut off removing Drive output voltage to the motor. This condition will cause the M.O.P.C. LED to remain constantly lit after the Drive has tripped off. During momentary overload conditions, the M.O.P.C. LED will flicker on and off for the duration of the overload.

Output Ground – In the event of a ground fault at the output, the Drive will shut down on a phase protection trip. For 15-50 HP Series A Drives, the "**OUTPUT GND**" LED will also be lit.

6.4 General Application

Special considerations must be taken when applying a variable frequency drive to an existing motor. At slower speeds, cooling is not as effective due to reduced fan speed. Extended operation at full load torque at slow speeds may damage the motor due to overheating. The Bulletin 1334 is best suited for use with standard NEMA Design B induction motors. Consult your nearest Allen-Bradley Distributor or Sales Office before connecting any other type of motor to your Drive.

Due to harmonics in the Drive output waveform (inherent in all inverter type drives), the motor current will increase by approximately 5% when compared to the same load superimposed on a sinusoidal waveform.

Figure 6.4 shows a typical curve, plotting torque vs. speed. At slow speeds, if torque requirements continuously exceed levels shown (10 minutes or longer), a motor rated for the required speed and torque operation should be substituted.




figure 6.4 – Torque vs. Frequency



CAUTION

Motors may overheat when operated at rated torque for long periods of time below $\frac{1}{2}$ base speed due to the decreased air flow of the motor fan. Motors may require special balancing if operated at more than 125% of base speed. Refer to the motor manufacturer for proper sizing of the motor for the intended application.

Bulletin 1334 380/415V Specifications & Adjustments

7.0

380V Specification Table

Model Number	1334-B _ N	1334-C _ N	1334-D _ N	1334-E _ N
① Nominal HP	3	5	7½	10
Input Voltage	380	380	380	380
Output Voltage	0-380	0-380	0-380	0-380
Input Frequency	50	50	50	50
Output Frequency	0-200	0-200	0-200	0-200
Input Amps	4.25	6.5	9.7	13.0
Output Amps	5.0	7.5	11.3	15.0
Input kVA	2.5	4.1	6.4	8.6
Output kVA	3.3	4.9	7.4	9.9

Model
and
Ratings
3-10 HP

Model Number	1334-F _ N	1334-G _ N	1334-R _ N
① Nominal HP	15	20	25
Input Voltage	380	380	380
Output Voltage	0-380	0-380	0-380
Input Frequency	50	50	50
Output Frequency	0-200	0-200	0-200
Input Amps	18.75	25.0	33.0
Output Amps	21.3	27.6	35.0
Input kVA	12.4	16.5	21.7
Output kVA	14.0	18.2	23.0

Model
and
Ratings
15-25 HP

Model Number	1334-H _ N	1334-J _ N	1334-K _ N
① Nominal HP	30	40	50
Input Voltage	380	380	380
Output Voltage	0-380	0-380	0-380
Input Frequency	50	50	50
Output Frequency	0-200	0-200	0-200
Input Amps	39.0	51.0	62.0
Output Amps	41.4	54.0	67.8
Input kVA	25.7	33.6	40.8
Output kVA	27.2	35.5	44.6

Model
and
Ratings
30-50 HP

Power Supply

Input Voltage — 380V, 3Ø, ±10%
Input Frequency — 50 Hz, ±2%

Output Volts-per-Hertz

7.6V/Hz (380V at 50 Hz) with Eurocard or Function Expander Card Installed

DC Boost Adjustment

0-28 Volts

Input Under Voltage Protection

342 Volts Nominal

IMPORTANT: ① The HP rating shown is for Drives supplied from a 380V AC, 50 Hz power line and is nominal. The limiting factor in the application and use of the Bulletin 1334 Drive is the Output Amp Rating of the Drive.

7.1
415V Specification Table

Model Number	1334-B_W	1334-C_W	1334-D_W	1334-E_W
① Nominal HP	3	5	7½	10
Input Voltage	415	415	415	415
Output Voltage	0-415	0-415	0-415	0-415
Input Frequency	50	50	50	50
Output Frequency	0-200	0-200	0-200	0-200
Input Amps	4.25	6.5	9.7	13.0
Output Amps	5.0	7.5	11.3	15.0
Input kVA	2.7	4.5	7.0	9.3
Output kVA	3.6	5.4	8.1	10.8

Model and Ratings
3-10 HP

Model Number	1334-F_W	1334-G_W	1334-R_W
① Nominal HP	15	20	25
Input Voltage	415	415	415
Output Voltage	0-415	0-415	0-415
Input Frequency	50	50	50
Output Frequency	0-200	0-200	0-200
Input Amps	18.75	25.0	33.0
Output Amps	21.3	27.6	35.0
Input kVA	13.5	18.0	23.7
Output kVA	15.3	19.8	25.2

Model and Ratings
15-25 HP

Model Number	1334-H_N	1334-J_N	1334-K_N
① Nominal HP	30	40	50
Input Voltage	415	415	415
Output Voltage	0-415	0-415	0-415
Input Frequency	50	50	50
Output Frequency	0-200	0-200	0-200
Input Amps	39.0	51.0	62.0
Output Amps	41.4	54.0	67.8
Input kVA	28.0	36.7	44.6
Output kVA	29.8	38.8	48.7

Model and Ratings
30-50 HP

Power Supply

Input Voltage — 415V, 3Ø, ±10%
Input Frequency — 50 Hz, ±2%

Output Volts-per-Hertz

8.3V/Hz (415V at 50 Hz) with Eurocard or Function Expander Card Installed

DC Boost Adjustment

0-31 Volts

Input Under Voltage Protection

373 Volts Nominal

IMPORTANT: ① The HP rating shown is for Drives supplied from a 415V AC, 50 Hz power line and is nominal. The limiting factor in the application and use of the Bulletin 1334 Drive is the Output Amp Rating of the Drive.

**7.2
Adjustments**

The Bulletin 1334 Adjustable Frequency Drive has the capability of operating from AC input line voltages of 380 or 415V only when the following adjustments are made to the Drive.

- The Drive logic and power supply transformers must be re-tapped to the correct voltage levels.
- Either the Eurocard or the Function Expander Card must be installed to produce the correct volts-per-hertz output from the Drive.

Unless the Drive is ordered from the factory as a 380 or 415V unit, the following adjustments must be made.

**7.2.1
Transformer Adjustments**

Determine the model number of the Drive to be modified from the Drive nameplate. Determine the number and location of the transformers that require re-tapping from the information below.

As shown in the **Drive Schematics in Appendixes G-I**, power supply transformers are normally set for 460V operation, but have 460/415/380V primary taps. All transformer primaries are marked as follows.

TAP #	VOLTAGE
1	COMMON — For All Voltages
2	380V AC Input
3	415V AC Input
4	460V AC Input

MODEL	TRANSFORMER	LOCATION REFERENCE	SCHEMATIC REFERENCE
1334-B _ (3 HP)	1T	Appendix A	Appendix G
1334-C _ (5 HP)	1T	Appendix A	Appendix G
1334-D _ (7½ HP)	1T	Appendix A	Appendix G
1334-E _ (10 HP)	1T	Appendix A	Appendix G
1334-F _ (15 HP)	1T & 2T	Appendix B	Appendix H
1334-G _ (20 HP)	1T & 2T	Appendix B	Appendix H
1334-R _ (25 HP)	1T & 2T	Appendix B	Appendix H
1334-H _ (30 HP)	1T & 2T	Appendix C	Appendix I
1334-J _ (40 HP)	1T, 2T, & 3T	Appendix C	Appendix I
1334-K _ (50 HP)	1T, 2T, & 3T	Appendix C	Appendix I

**7.2.2
Volts-per-Hertz Adjustment**

For the Drive to produce the correct volts-per-hertz at either 380 or 415V, the V/Hz jumper located on the Modulator Logic Board must be unplugged and removed from the board (jumper location is shown in **figure 5.3.1, Chapter 5**). Once the jumper has been removed, either the Eurocard or Option L — the Function Expander Card — must then be installed in the Drive. Either card plugs unto Modulator Logic Board connector **J104**. If the Eurocard is used, additional volts-per-hertz adjustments are not required. If the Function Expander Card is used, follow the instructions provided with the kit to complete installation. Note all changes made to the Drive on both the **Drive Data Log Sheets, Section 5.2**, and on the Drive Nameplate in the Drive. Follow the installation and adjustment procedures as outlined in **Chapters 4 & 5**.

Bulletin 1334 3-10 HP Series B Component Index

3-10 HP Recommended Spare Parts

Description	Identification	Part No	Value	Used On	Recommended Stock
Modulator Logic Board	A1	<u>50387-002</u>	—	<u>All Ratings</u>	1
Power Distribution Board	A2	50906	—	3 – 10 HP	1
Driver Board	A3	50905-001	—	3 & 5 HP	1
		50905-002	—	7½ & 10 HP	1
Diagnostic Board	A7	<u>50382</u>	—	<u>All Ratings</u>	0
Fuse	F1, F2, F3	201669	10A, 600V (KTK 10)	3 HP	6
		201009	12A, 600V (KTK 12)	5 HP	6
		200935	15A, 600V (KTK 15)	7½ HP	6
		201925	20A, 600V (KTK 20)	10 HP	6
Fuse	F4, F5	101775	0.6A, 600V (FNQ 6/10 or ATQ 6/10)	3 – 10 HP	2
Bus Capacitor	2C, 3C	201676	650µF, 450V DC	3 & 5 HP	1
		201906	1400µF, 450V DC	7½ & 10 HP	1
Control Transformer	1T	91854	—	3 – 10 HP	0
MOV Assembly	MOV 4	40401	—	3 – 10 HP	0
Inductor	1L	91889	4.2mH, 7.5A	3 & 5 HP	0
		91864	2.9mH, 11.2A	7½ HP	0
		91865	2.2mH, 14.9A	10 HP	0
Inductor	2L	91849	15mH, 1.3A	3 – 10 HP	0
Power Switching Module	1Q, 2Q, 3Q	201050	—	3 & 5 HP	1
		201051	—	7½ & 10 HP	1
Snubber Assembly	1SN, 2SN, 3SN	40410	—	3 – 10 HP	0
Temperature Sensor	1TAS	201667	—	3 – 10 HP	0
Rectifier Assembly	1REC	201525	—	3 – 10 HP	1
Resistor	2R, 3R	40413-001	25kΩ, 25W, 3%	3 & 5 HP	0
		40413-002	16kΩ, 25W, 3%	7½ & 10 HP	0

Recommended quantities for (1–4) Drives in one location. For more than (4) Drives, all parts should be stocked, additional quantities may be required.

3-10 HP Component Access & Location




CAUTION

ESD Precautions

ESD (Electrostatic Discharge) generated by static electricity can damage the CMOS devices on various Drive boards. To guard against this type of damage, it is recommended that when circuit boards are removed or installed the following precautions be observed.

- *Wear a wrist type grounding strap that is grounded to the Drive chassis.*
 - *DO NOT remove the new circuit board from its conductive wrapper unless a ground strap is worn.*
 - *When removing any circuit board from the Drive, immediately place it in conductive packing material.*
-



Diagnostic Board
A7

3-10 HP Component Access & Location


(Power Distribution Board A2)

Step 1 Disconnect molex connectors **J201**, **J203**, & **J204** and berg connector **J205** at Power Distribution Board A2.

Step 2 Disconnect push on connectors **E13**, **E16**, **E17**, **E21** & **E22** from Power Distribution Board A2.

Step 3 Remove the (4) nylon thumb screws from the board.

Step 4 Lift up the (2) latch fasteners at the bottom of the board. The Power Distribution Board will now be free to swing up.




3-10 HP Component Access & Location

Step 5 To lock the Power Distribution Board in the raised position, tighten the phillips head screws (or wing nuts), on the board's (2) locking hinges. To lower the Power Distribution Board, back off the screws (or wing nuts) $\frac{1}{2}$ - turn.

(Driver Board A3)

Step 6 To remove Driver Board A3, disconnect moxex connectors J302A, J302B, & J302C and berg connector J301 at the board.


Step 7 Release the (6) $\frac{1}{4}$ - turn standoffs as shown. The Driver Board may now be lifted out.




3-10 HP Component Access & Location

- Temperature Sensor 1TAS
- Rectifier Assembly 1REC
- Snubber Assemblies 1SN, 2SN & 3SN
- Power Switching Modules 1Q, 2Q & 3Q
- Resistors 2R & 3R
- Inductors 1L & 2L
- MOV4 Assembly
- Transformer 1T
- Bus Capacitors 2C & 3C


Wiring connections to the above components are shown on the following pages.



3-10 HP Component Location & Wiring



3-10 HP Component Location & Wiring



3-10 HP Component Wiring List

As shown on page A-3, wires going to interconnection points **E1**, **E2**, & **E5-22**, are marked and color coded on Power Distribution Board A2. These same points are referenced in the troubleshooting procedures for your Drive in Appendix D. These points may be accessed by slightly lifting up the insulated connectors.

COLOR	to	from
gray	Control Transformer 1T (pin 6)	Power Distribution Board E1
green	Chassis Ground	Power Distribution Board E2
blue	Power Switching Module 3Q (C2/E1)	Power Distribution Board E5
green	Power Switching Module 2Q (C2/E1)	Power Distribution Board E6
violet	Power Switching Module 1Q (C2/E1)	Power Distribution Board E7
red	Rectifier Assembly 1 REC (AC3)	Power Distribution Board E8
brown	Rectifier Assembly 1 REC (AC2)	Power Distribution Board E9
black	Rectifier Assembly 1 REC (AC1)	Power Distribution Board E10
brown	Control Transformer 1T (pin 1)	Power Distribution Board E11
green	Control Transformer 1T (pin 4)	Power Distribution Board E12
red	- BUS	Power Distribution Board E13
green	Temperature Sensor 1TAS	Power Distribution Board E14
black	Temperature Sensor 1TAS	Power Distribution Board E15
black	Inductor 1L (pin 2)	Power Distribution Board E16
green	Bus Capacitor 2C (+)	Power Distribution Board E17
white	Control Transformer 1T (pin 7)	Power Distribution Board E18
black	Control Transformer 1T (pin 8)	Power Distribution Board E19
yellow	Control Transformer 1T (pin 9)	Power Distribution Board E20
black	Inductor 2L (pin 1)	Power Distribution Board E21
red	Inductor 2L (pin 2)	Power Distribution Board E22
gray	- BUS	Rectifier Assembly 1REC (-)
white	Inductor 1L (pin 1)	Rectifier Assembly 1REC (+)
blue	+ BUS	Bus Capacitor 2C (+)
violet	- BUS	Bus Capacitor 3C (-)
black	Bus Capacitor 2C (-)	Bus Capacitor 3C (+)
yellow	Bus Capacitor 2C (+)	Resistor 2R
blue	Bus Capacitor 3C (+)	Resistor 2R
yellow	Bus Capacitor 3C (-)	Resistor 3R
blue	Bus Capacitor 3C (+)	Resistor 3R

B**Bulletin 1334 15-25 HP Series A Component Index****15-25 HP Recommended Spare Parts**

Description	Identification	Part No	Value	Used On	Recommended Stock
Modulator Logic Board	A1	<u>50387-002</u>	—	<u>All Ratings</u>	1
Driver Board	A3A, A3B, A3C	50399	—	15 & 20 HP	1
		50399-001	—	25 HP	1
Voltage Sensing Board	A4	50386	—	15 – 25 HP	0
Bus Discharge Board	A5	50390	—	15 – 25 HP	1
Logic Power Supply Board	A6	50389	—	15 – 25 HP	1
Diagnostic Board	A7	<u>50382</u>	—	<u>All Ratings</u>	0
Output Ground Sensor Board	A8	50385	—	15 – 25 HP	1
Contactorm Interface Board	A9	50404-001	—	15 – 25 HP	1
Fuse	1FU, 2FU, 3FU	201258	25A, 600V (JKS 25)	15 HP	6
		200384	30A, 600V (JKS 30)	20 HP	6
		201463	50A, 600V (JKS 50)	25 HP	6
Fuse	4FU, 5FU	201590	1A, 500V (FNQ 1)	15 – 25 HP	4
Fuse	6FU	248010	3A, 500V (KTK 3)	15 – 25 HP	2
Bus Capacitor	2C1, 2C2, 3C1, 3C2	200364	2400 μ F, 450V DC	15 – 25 HP	2
Control Transformer	1T	91854	—	15 – 25 HP	0
Transformer	2T	91880	—	15 – 25 HP	0
Current Transformer	1CT	91824	—	15 – 25 HP	0

Recommended quantities for (1–4) Drives in one location. For more than (4) Drives, all parts should be stocked, additional quantities may be required.


15-25 HP Recommended Spare Parts

(continued)


Description	Identification	Part No	Value	Used On	Recommended Stock
MOV Assembly	1 SUP, 2 SUP, 3 SUP	41475	—	15 – 25 HP	1
Inductor	1L	91866	—	15 HP	0
		91867	—	20 HP	0
		91871	—	25 HP	0
Inductor	2L	91849	—	15 – 25 HP	0
Power Switching Module	1Q1, 2Q1, 3Q1 1Q2, 2Q2, 3Q2	201051	—	15 – 25 HP	2
Temperature Sensor	1TAS	201000	—	15 & 20 HP	0
		201667	—	25 HP	0
Rectifier Assembly	1REC	201525	—	15 & 20 HP	1
	1 REC, 2 REC, 3 REC	201445	—	25 HP	2
Precharge Contactor	1 CON	201458	—	15 – 25 HP	0
Resistor	2R, 3R	202102	4.2k Ω , 50W, 3%	15 – 25 HP	0

Recommended quantities for (1–4) Drives in one location. For more than (4) Drives, all parts should be stocked, additional quantities may be required.

15-25 HP Drives




15 & 20 HP Component Location




(BACK PANEL)

15 & 20 HP Component Location




(LEFT HAND PANEL)




(RIGHT HAND PANEL)

25 HP Component Location




(BACK PANEL)

25 HP Component Location



(LEFT HAND PANEL)



(RIGHT HAND PANEL)

Bulletin 1334 30-50 HP Series A Component Index

30-50 HP Recommended Spare Parts

Description	Identification	Part №	Value	Used On	Recommended Stock
Modulator Logic Board	A1	<u>50387-002</u>	—	<i>All Ratings</i>	1
Driver Board	A3A, A3B, A3C	50403	—	30 – 50 HP	1
Voltage Sensing Board	A4	50386	—	30 – 50 HP	0
Bus Discharge Board	A5	50405	—	30 – 50 HP	1
Logic Power Supply Board	A6	50389	—	30 – 50 HP	1
Diagnostic Board	A7	<u>50382</u>	—	<i>All Ratings</i>	0
Output Ground Sensor Board	A8	50385	—	30 – 50 HP	1
Contacting Interface Board	A9	50404-001	—	30 – 50 HP	1
Driver Power Supply Board	A10	50406	—	30 – 50 HP	1
Fuse	1FU, 2FU, 3FU	201753	60A, 600V (JKS 60)	30 HP	3
		201749	100A, 600V (JKS 100)	40 & 50 HP	3
Fuse	4FU	201590	1A, 500V (FNQ 1)	30 – 50 HP	1
Fuse	5FU	201708	1.5A, 500V (FNQ 1.5)	30 – 50 HP	1
Fan Fuse	7FU	201478	.2A, 500V (FNQ .2)	40 & 50 HP	0
Bus Fuse	8FU	201575	70A, 600V (FWP 70)	30 HP	1
		201466	125A, 700V (FWP 125)	40 & 50 HP	1
Bus Capacitor	2C1, 2C2 3C1, 3C2	200364	2400 μ F, 450V DC	30 HP	1
	2C1, 2C2, 2C3 3C1, 3C2, 3C3			40 & 50 HP	1
Snubber Capacitor	4C, 5C, 6C	201455	10 μ F, 660V DC	30 – 50 HP	0
Control Transformer	1T	91854	—	30 – 50 HP	0
Transformer	2T	91880	—	30 – 50 HP	0
Fan Transformer	3T	91885	—	40 & 50 HP	0
Current Transformer	1CT	91824	—	30 – 50 HP	0

Recommended quantities for (1–4) Drives in one location. For more than (4) Drives, all parts should be stocked, additional quantities may be required.

30-50 HP Recommended Spare Parts
(continued)

Description	Identification	Part No	Value	Used On	Recommended Stock
MOV Assembly	1 SUP, 2 SUP, 3 SUP	41475	—	30 HP	1
		41484	—	40 & 50 HP	1
Inductor	1L1, 1L2	91872	—	30 HP	0
		91886	—	40 HP	0
		91874	—	50 HP	0
Inductor	2L	91849	—	30 – 50 HP	0
Inductor	3L, 4L, 5L	91887	—	30 HP	0
		91879	—	40 & 50 HP	0
Power Switching Module	1Q1, 2Q1, 3Q1	201412	—	30 HP	1
	1Q1, 2Q1, 3Q1 1Q2, 2Q2, 3Q2	120784	—	40 & 50 HP	2
Temperature Sensor	1TAS	201000	—	30 – 50 HP	0
Rectifier Assembly	1 REC, 2 REC, 3 REC	201445	—	30 – 50 HP	2
Precharge Contactor	1 CON	201458	—	30 HP	0
		201459	—	40 & 50 HP	0
Fan	1FN	201508	—	40 & 50 HP	0
Snubber Diode	1D	201423	—	30 – 50 HP	0
Resistor	2R, 3R	201446	6k Ω , 50W, 3%	30 – 50 HP	0



Recommended quantities for (1–4) Drives in one location. For more than (4) Drives, all parts should be stocked, additional quantities may be required.




CAUTION: To avoid damage to the Drive, **Power Switching Modules** connected in parallel must use the same part number. This may require changing both modules in a phase even though only one module needs to be replaced.

40 & 50 HP Drives


30 HP Drives




30 HP Component Location



30 HP Component Location




(LEFT HAND PANEL)




(RIGHT HAND PANEL)

40 & 50 HP Component Location




(BACK PANEL)

40 & 50 HP Component Location




(LEFT HAND PANEL)








(RIGHT HAND PANEL)

40 & 50 HP Power Switching Modules

POWER SWITCHING MODULE ARRANGEMENT — P/N 201411



POWER SWITCHING MODULE ARRANGEMENT — P/N 120784



CAUTION: To avoid damage to the Drive, **Power Switching Modules** connected in parallel must use the same part number. This may require changing both modules in a phase even though only one module needs to be replaced.

D

Bulletin 1334 3-10 HP Series B Troubleshooting

3-10 HP Diagnostic LED Display

- Power ON** – Indicates input power is connected when illuminated.
- Momentary Overload Protection Circuit** – When constantly illuminated indicates an overload condition exceeded (60) seconds – Momentarily illuminated whenever circuit is activated.
- Under Voltage Protection** – When illuminated indicates that the Drive has tripped **OFF** due to an input voltage that is less than 414 volts for a 460V Drive, 373 volts for a 415V Drive, or 342 volts for a 380V Drive.
- Over Voltage Protection** – When illuminated indicates that the Drive has tripped **OFF** due to the bus voltage exceeding 760V DC.
- "A" Phase Protection Trip** – When illuminated indicates either:
 - An Overload Condition Greater Than 200%
 - A Shorted "A" Phase Output Transistor
 - Section "A" of the Driver Board is Malfunctioning
- "B" Phase Protection Trip** – When illuminated indicates either:
 - An Overload Condition Greater Than 200%
 - A Shorted "B" Phase Output Transistor
 - Section "B" of the Driver Board is Malfunctioning
- "C" Phase Protection Trip** – When illuminated indicates either:
 - An Overload Condition Greater Than 200%
 - A Shorted "C" Phase Output Transistor
 - Section "C" of the Driver Board is Malfunctioning
- Brake Resistor Over Temperature Protection Trip** – When illuminated indicates excessive brake resistor temperature.
- Drive Over Temperature Protection Trip** – When illuminated indicates that the heatsink temperature of the Drive has exceeded the maximum safe operating limit.
- Output Ground Fault Protection Trip Indication** – *NOT UTILIZED ON 3, 5, 7½ & 10 HP DRIVES*

Symptom 1, 2 & 3

Symptom 4, 5, 6 & 7

Symptom 8

Symptom 9



Symptom 10

Symptom 10

Symptom 10

Symptom 11

Symptom 12



Symptom 13

DS1 – Located on Power Distribution Board A2 – When illuminated indicates that the bus potential is in excess of 42V DC.

3-10 HP Troubleshooting Procedures

IMPORTANT

Drive Fault Trips

Before resetting any fault trip, refer to the following troubleshooting procedures to isolate and correct the fault.

The location of boards & Drive components are illustrated in **Appendix A** on pages **A-2, A3, A4 & A-5**.

All Drive interconnection wiring & interconnection points are illustrated in **Appendix A** on pages **A-6 & A-7**.

All voltage values & polarities referenced in the following troubleshooting procedures are shown in the Drive Schematics in **Appendix G** or the Modulator Logic Board Interconnection Diagram in **Appendix J**.



WARNING

Hazardous voltage levels exist on some printed circuit boards and Drive components.

If diagnostic LED(s) **PROT. A**, **PROT. B**, or **PROT. C** are lit, hazardous voltages can be present at the output terminals even though the STOP pushbutton has been depressed.

If neon light **DS1** on Power Distribution Board A2 is lit, hazardous voltages are present in the Drive cabinet.

To guard against personal injury when boards or wires are being disconnected or reconnected, or fuses are being replaced, **always remove power to the Drive at the disconnect device, wait (60) seconds, and ensure that DS1 is not lit before servicing. Use a DVM to check for zero volts between pins 11 (+ BUS) & 15 (- BUS) at connector J202 on Power Distribution Board A2.**



CAUTION : To Guard Against Equipment Damage When Troubleshooting the Drive, Before Pressing the START Pushbutton Always:

- Set the **Speed Pot** or speed reference to **MINIMUM**.
 - Set the **FWD/REV Switch** (if present), to the proper position.
 - Uncouple the motor from its mechanical load.
-

IMPORTANT

ESD Precautions

ESD (Electrostatic Discharge) generated by static electricity can damage the CMOS devices on various Drive boards. To guard against this type of damage, it is recommended that when circuit boards are removed or installed the following precautions be observed.

- *Wear a wrist type grounding strap that is grounded to the Drive chassis.*
 - *DO NOT remove the new circuit board from its conductive wrapper unless a ground strap is worn.*
 - *When removing any circuit board from the Drive, immediately place it in conductive packing material.*
-

Symptom 1

DIAGNOSTIC PROCEDURE

Drive does not start. Amber **POWER ON LED** is not illuminated.

Check for possible loss of input line voltage by measuring line voltage between L1, L2 and L3.

If voltage is present, measure voltage across Input line fuses **F1**, **F2** and **F3**. Measure voltage across input primary fuse **F4**. A voltage reading across any of these fuses indicates an open condition. Before replacing blown fuses complete **STEPS 1, 2 & 3**.

STEP 1 – Remove input power to the Drive. Before proceeding, wait (60) seconds. **DS1**, the bus charged neon light on Power Distribution Board A2, should not be lit. Use a DC voltmeter to verify that the DC bus is fully discharged by measuring the voltage between connectors **E17 (+ BUS)** and **E13 (- BUS)** on Power Distribution Board A2. Start with the voltmeter on its highest scale (x 1000) and range downward to the lowest voltmeter scale.

Connections Listed in Steps 2 & 3 are shown on pages A-6 & A-7

STEP 2 – Check Rectifier Assembly **1REC**.

Unplug connectors **E8**, **E9**, **E10** & **E13** at the Power Distribution Board.

Unplug connector **1L-1** at Inductor **1L**.

With an ohmmeter set on the x1 scale, check the resistance of **1REC** at the leads as follows.

<u>OHMMETER</u>		<u>READING</u>
<u>+ LEAD</u>	<u>- LEAD</u>	
1L-1 (1REC+)	E10 (1REC-AC1)	INFINITE
1L-1 (1REC+)	E9 (1REC-AC2)	INFINITE
1L-1 (1REC+)	E8 (1REC-AC3)	INFINITE
E10 (1REC-AC1)	E13 (1REC-)	INFINITE
E9 (1REC-AC2)	E13 (1REC-)	INFINITE
E8 (1REC-AC3)	E13 (1REC-)	INFINITE

If any of the above readings are not as shown, replace Rectifier Assembly **1REC**.

IMPORTANT : When replacing Rectifier Assembly **1REC** clean all surfaces. Apply a thin layer of thermal grease (Dow Corning 340) to the back of the assembly. Torque mounting screws to 17-26 in-lbs max.

STEP 3 – With the ohmmeter set on the x100 scale, check Bus Capacitors **2C** & **3C** for a shorted condition as follows.

Disconnect leads to Bus Capacitors **2C** & **3C**.

Connect the (+) POSITIVE lead of the ohmmeter to the (+) POSITIVE terminal of the capacitor. Connect the (-) NEGATIVE lead of the ohmmeter to the (-) NEGATIVE terminal of the capacitor.

The ohmmeter should immediately read low, then slowly increase to approximately 20kΩ. A sustained low reading indicates a shorted capacitor that requires replacement.

After completing **STEPS 1, 2 & 3**, replace blown fuses and reapply input power.

Symptom 2

DIAGNOSTIC PROCEDURE

Drive does not start. Amber **POWER ON** LED is illuminated. No red fault LEDs are illuminated.

Check for line out condition at fuse **F3** by measuring the AC line voltage from L3 to either L1 or L2. If voltage is present, measure voltage across **F3**. A voltage across **F3** indicates that it is open and must be replaced. Before replacing **F3**, perform **STEPS 1, 2 & 3** in **Symptom 1**, then the following nine steps.

STEP 1 – Check precharge circuit fuse **F5** for an open condition.

STEP 2 With input power to the Drive removed at the disconnect device, check that all jumpers on Modulator Logic Board A1 are in their proper position, particularly the VCO/EXT-C jumper and the IFB/XFB jumper.

STEP 3 With input power to the Drive removed at the disconnect device, check installed options, particularly those with AUTO/MAN selection (both local and remote). Depending upon the options installed the maximum speed pot adjustment **R25** or the minimum speed pot adjustment **R26** may be ineffective. Refer to section 5.3.1, **Minimum and Maximum Speed Adjust**.

- If option **N, N4, G2 or G4** is installed, ensure that:

The AUTO/MAN switch on the card is set to the MAN mode.

A 1k Ω , 2W, linear taper speed pot has been properly connected to Terminal Block **TB1** between terminals **14, 15 & 16**.

- If option **G** is installed, ensure that the 1k Ω resistor included with the option kit has been installed at Terminal Block **TB1** between terminals **14 & 16**.
- If option **K7** is installed, check for continuity across the Brake Over Temperature circuit at Terminal Block **TB1** between terminals **17 & 18**.
- If option **T, T1, T2 or T3** is installed, check for continuity across the Motor Overload Relay contact circuit at Terminal Block **TB1** between terminals **10 & 11**.

(REFER TO THE OPTION KIT INSTRUCTIONS FOR CORRECT SETUP PROCEDURES)

STEP 4 – Check for an open speed pot at Terminal Block **TB1**. Measure the voltage at Terminal Block **TB1** between terminals **14 & 16**. There should be 3.2V DC. If voltage is 12V DC, the speed pot may be open or there may be an open wire between the speed pot and terminals **14, 15 & 16**. Check for an inoperative speed pot by turning the pot from 0 to 100%. The voltage between terminals **15 & 16** should vary from 0 to 3.2V DC. Replace or correct as required.

STEP 5 – Check the voltage between terminals **9 & 11** at Terminal Block **TB1**.

- If standard START/STOP configuration is used, there should be 90V AC between terminals **9 & 11**. If not, the START/STOP circuit is open. Check the START/STOP circuit connections to **TB1**.
- If field installed 2-wire, 90V AC, RUN/STOP control is used, there should be 90V AC between terminals **9 & 11**. If not, the RUN/STOP circuit is open. Ensure that the circuit has been installed as specified in section 4.4.6.
- If field installed 2-wire, 120V AC, RUN/STOP control is used, there should be 120V AC between terminals **9 & 11**. If not, the RUN/STOP circuit is open. Ensure that the circuit has been installed as specified in section 4.4.4.

Symptom 2

DIAGNOSTIC PROCEDURE

(continued)

Drive does not start. Amber **POWER ON LED** is illuminated. No red fault LEDs are illuminated.

STEP 6 – Measure the output voltages in the secondary circuits of Transformer 1T. The following voltages should be present at the Power Distribution Board.

- molex connector **J204** between pins 4 & 1 14V AC
- molex connector **J204** between pins 2 & 1 14V AC
- molex connector **J204** between pins 5 & 6 15V AC
- between connector **E1** & molex connector **J204**, pin 1 90V AC
- between connectors **E20** & **E19** 12V AC
- between connectors **E18** & **E19** 12V AC

If any one voltage is absent, remove input power and check all connections to 1T. If all connections are correct, replace Transformer 1T.

STEP 7 – Measure all logic power supply output voltages at the Power Distribution Board. The following voltages should be present at molex connector **J203** with respect to Drive common, **J203**, pin 8. If any one voltage is absent, replace Power Distribution Board A2.

- J203**, pin 1 -17V DC
- J203**, pin 5 + 17V DC
- J203**, pin 6 14V AC
- J203**, pin 7 + 11 to + 13V DC (nominal)
- J203**, pin 9 + 11 to + 13V DC (nominal)

STEP 8 – Measure contactor **K1** supply voltage at Power Distribution Board A2. There should be + 9 to + 15V DC between pins 7 & 10 at molex connector **J203**. There should also be + 9 to + 15V DC between points 3 & 4 at the contactor. If 9 to 15 volts is measured and **K1** is not picked-up, the contactor may be inoperative. If inoperative, replace the Power Distribution Board.

STEP 9 – Check pin 10 at molex connector **J203** with respect to pin 8, Drive common. If a TTL level "0" is not measured, replace Modulator Logic Board A1.

Symptom 3	DIAGNOSTIC PROCEDURE
<p>Precharge cycle excessively long or not complete. Amber POWER ON LED may or may not be illuminated.</p>	<p>The DC bus precharge cycle should be completed within (5) seconds after input line power is applied to the Drive.</p> <p>Check precharge circuit fuse F5 for an open condition first, then perform the following three steps.</p> <p>STEP 1 – Check Rectifier Assembly 1REC and Bus Capacitors 2C & 3C as specified in STEPS 1, 2 & 3, symptom 1.</p> <p>STEP 2 – Check for an inoperative K1 Contactor. Measure contactor coil supply voltage at Power Distribution Board A2. There should be +9 to +15V DC between pins 7 & 10 at molex connector J203. There should also be +9 to +15V DC between points 3 & 4 at the contactor. If 9 to 15 volts is measured and K1 is not picked-up, the contactor may be inoperative. If inoperative, replace the Power Distribution Board.</p> <p>STEP 3 – Check pin 10 at molex connector J203 with respect to pin 8, Drive common. If a TTL level "0" is not measured, replace Modulator Logic Board A1.</p>

Symptom 4	DIAGNOSTIC PROCEDURE
<p>Drive trips on momentary overloads causing phase protection indication. M.O.P.C. circuit not functioning properly. Red M.O.P.C. fault LED is not illuminated.</p>	<div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> <p>IMPORTANT : <i>If the Drive will not restart or reset after a fault trip, always check fuse F5 for an open condition. Replace if necessary.</i></p> </div> <p>With the motor rotor locked and boost set to zero, adjust the ACCEL RATE setting, switch S1 on Modulator Logic Board A1, to 1.2 Hz/Sec. Set the operator speed pot or speed reference to zero.</p> <p>After completing the above, start the Drive and slowly increase the speed while monitoring the output motor current on any phase using a true RMS reading clamp on ammeter.</p> <p>The M.O.P.C. LED should light when the current reaches a nominal value of 150%. If the M.O.P.C. LED does not light, use an oscilloscope to check for a pulsed waveform at the following pins on connector J113 of the Modulator Logic Board with respect to Drive common.</p> <p style="text-align: center;">Pin 5 – ØA Driver Signal Pin 16 – ØB Driver Signal Pin 27 – ØC Driver Signal</p> <p>If pulse signals that go to a TTL level "0" are not present, replace Driver Board A3.</p> <p>If pulse signals are present on all (3) sections of the Driver Board, replace Modulator Logic Board A1.</p> <p>Return the boost and accel rate adjustments to their normal settings.</p>

Symptom 5	DIAGNOSTIC PROCEDURE
<p>Drive starts momentarily then trips off or Drive trips off during normal operation. Red M.O.P.C. fault LED is illuminated.</p>	<div data-bbox="418 342 1456 426" style="border: 1px solid black; padding: 5px;"> <p>IMPORTANT : <i>If the Drive will not restart or reset after a fault trip, always check fuse F5 for an open condition. Replace if necessary.</i></p> </div> <p>An illuminated M.O.P.C. LED indicates that the Drive has tripped off due to a nominal 150% overload condition which has exceeded the (60) second time period.</p> <div data-bbox="418 531 1456 678" style="border: 1px solid black; padding: 5px;"> <p>IMPORTANT : <i>During acceleration or start-up (breakaway), it is normal for the M.O.P.C. LED to illuminate momentarily. This merely indicates that a momentary overload current of 150% has been sensed and that the M.O.P.C. circuit has been activated. The LED will also flash momentarily when AC line power is first applied.</i></p> </div> <p>If the M.O.P.C. LED is constantly activated during start-up (breakaway), or if there is excessive LED activity at low frequency operation, less DC boost must be used.</p> <p>Refer to the DC Boost Adjustment, section 5.3.3 and V/Hz Jumper Setting in section 5.3.2.</p> <p>If Option L, the Function Expander Card is installed, REFER TO THE OPTION KIT INSTRUCTIONS FOR CORRECT SETUP PROCEDURES.</p>
Symptom 6	DIAGNOSTIC PROCEDURE
<p>Motor does not return to full set speed after stalling. Red M.O.P.C. fault LED is illuminated.</p>	<p>The load torque is exceeding the torque capability of the Drive. Check for problems with the mechanical load.</p> <p>If the mechanical load checks out, try increasing the DC boost as outlined in section 5.3.3. If this does not correct the condition, consult your nearest Allen-Bradley Area Sales/Support Center for application assistance.</p> <div data-bbox="418 1381 1456 1528" style="border: 1px solid black; padding: 5px;"> <p>IMPORTANT: <i>If a 150% continuous overload current demand exists, the motor will ramp down to a stalled condition and remain there until the overload condition no longer exists. If however the overload condition is sustained for (60) seconds, the Drive will trip and illuminate the M.O.P.C. LED on the Diagnostic Display Panel.</i></p> </div>
Symptom 7	DIAGNOSTIC PROCEDURE
<p>Red M.O.P.C. Fault LED is illuminated during DECEL or at (0) Hz.</p>	<p>Boost voltage set too high. Decrease the boost voltage by setting the DC boost switch lower and/or set the Decel switch to provide a slower ramp (Refer to DC Boost Adjustment, ACCEL/DECEL Rate Adjustments, section 5.3.3).</p>

Symptom 8	DIAGNOSTIC PROCEDURE
<p>Drive starts momentarily then trips off or Drive trips off during normal operation. Red UNDER VOLTS fault LED is illuminated.</p>	<div data-bbox="418 331 1451 415" style="border: 1px solid black; padding: 5px;"><p>IMPORTANT : <i>If the Drive will not restart or reset after a fault trip, always check fuse F5 for an open condition. Replace if necessary.</i></p></div> <p>An illuminated UNDER VOLTS LED indicates that Drive has tripped off due to an input line voltage that is less than:</p> <ul style="list-style-type: none">● 414V AC at the 460V AC Tap on Transformer 1T● 373V AC at the 415V AC Tap on Transformer 1T (50 Hz Input Power)● 342V AC at the 380V AC Tap on Transformer 1T (50 Hz Input Power) <p>STEP 1 – Check input primary fuse F4 for an open condition.</p> <p>STEP 2 – Check the input voltage to Transformer 1T by measuring the voltage between connectors E11 & E12 on Power Distribution Board A2. If proper voltage is present, replace Modulator Logic Board A1.</p>
Symptom 9	DIAGNOSTIC PROCEDURE
<p>Drive starts momentarily then trips off or Drive trips off during normal operation or deceleration. Red OVER VOLTS fault LED is illuminated.</p>	<p>An illuminated OVER VOLTS LED indicates that the Drive has tripped off due to a bus voltage greater than 760V DC. Three conditions can cause an over voltage trip.</p> <ul style="list-style-type: none">● Excessively High Input Voltage● DC Boost Set too High● Deceleration Rate too High for the Motor/Load Inertia <p>STEP 1 – Check the input line voltage across each phase at L1, L2, and L3. The voltage should not be greater than 506V AC.</p> <p>STEP 2 – If trip occurred during deceleration, check the position of the NORM/DEC HOLD jumper on the Modulator Logic Board. The jumper should be set to the DEC HOLD position.</p> <p>Monitor LED CR53 FREQ HOLD on the Modulator Logic Board. During deceleration, with the NORM/DEC HOLD jumper in the DEC HOLD position, the LED should light before an overvoltage trip occurs. If the LED lights, decrease the DECEL RATE, the DC BOOST, or both. Refer to the Modulator Logic Board Switch Settings in section 5.3.3. If the LED does not light, replace the Modulator Logic Board.</p> <p>STEP 3 – If the Drive trips out on over voltage during deceleration and a slower decel ramp is not acceptable, consult your nearest Allen-Bradley Area Sales/Support Center.</p>

Symptom 10

DIAGNOSTIC PROCEDURE

Drive starts momentarily then trips off or Drive trips off during normal operation. Red **PROT. A**, **PROT. B**, or **PROT. C** fault LED is illuminated.

IMPORTANT : *If the Drive will not restart or reset after a fault trip, always check fuse F5 for an open condition. Replace if necessary.*

An illuminated **A**, **B** or **C** phase protection LED indicates:

- **An output overcurrent condition greater than 200% due to either:**

- 1) An output phase-to-phase short (Drive output, motor windings, or wiring to the motor).
- 2) An output overcurrent condition greater than 200% due to an output phase-to-ground short.

In either case, remove input power to the Drive at the disconnect device. Disconnect the motor leads from the Drive at Terminal Block **TB2**. Reapply power to the Drive and give the Drive a **START** command. If the Drive can be operated without a phase protect trip occurring, the problem is in either the wiring to the motor or the motor itself.

A ground fault can be found using an ohmmeter between the wiring to the motor and ground. Find the cause and correct it before reconnecting the motor leads to the Drive and reapplying power.

A shorted motor winding is harder to detect because of the low resistance of the motor windings. Substitute a known, good motor for the suspected bad motor. Connect the substitute motor to the Drive output terminals and try running the Drive. If successful operation of the Drive and substitute motor is achieved, then the problem most likely is the motor originally connected to the Drive.

- **Deceleration of an inertia type motor load at too high a value of DC boost or too fast a DECEL rate.**

Under the right conditions, the motor can appear as a short circuit to the Drive. With excessive DC boost applied the motor can saturate, resulting in a peak current in excess of 200% causing a phase protect trip. Decrease the **DC BOOST**, the **DECEL RATE** or both. Refer to section 5.3.3, **DC Boost Adjustment, ACCEL/DECEL Rate Adjustment** for additional information.

- **Excessive DC boost causing a phase protection trip during acceleration.**

Excessive DC boost can cause a phase protection trip to occur during acceleration of the Drive and motor due to saturation of the motor windings.

If reducing the DC boost setting eliminates the phase protection trip but does not produce sufficient torque to enable the motor to accelerate the load, consult your nearest Allen-Bradley Area Sales/Support Center for application assistance.

Reset the Drive by giving it a STOP command followed by a START command. If proper operation cannot be obtained without the reoccurrence of a phase protect trip and you have eliminated the preceding possibilities, the problem is most likely caused by one of the following.

Symptom 10

DIAGNOSTIC PROCEDURE

(continued)

Drive starts momentarily then trips off or Drive trips off during normal operation. Red **PROT. A**, **PROT. B**, or **PROT. C** fault LED is illuminated.

- **A shorted output transistor in one of the Power Switching Modules.**
Phase "A" ... 1Q
Phase "B" ... 2Q
Phase "C" ... 3Q
Perform the following four steps to isolate and correct the problem.
- **A malfunctioning Driver Board.**
Phase "A" ... Section A of the Driver Board
Phase "B" ... Section B of the Driver Board
Phase "C" ... Section C of the Driver Board
Perform the following four steps to isolate and correct the problem.
- **A malfunctioning Driver Board causing an output power Switching Module to be ON when it shouldn't be.**
Phase "A" ... Section A of the Driver Board
Phase "B" ... Section B of the Driver Board
Phase "C" ... Section C of the Driver Board
Perform the following four steps to isolate and correct the problem.
- **A malfunctioning Modulator Logic Board causing an abnormal Drive output voltage waveform.**
Perform the following four steps to isolate and correct the problem.

STEP 1 – Remove input power to the Drive. Before proceeding, wait (60) seconds. **DS1**, the bus charged neon light on Power Distribution Board A2, should not be lit. Use a DC voltmeter to verify that the DC bus is fully discharged by measuring the voltage between connectors **E17 (+BUS)** and **E13 (-BUS)** on Power Distribution Board A2. Start with the voltmeter on its highest scale (x 1000) and range downward to the lowest voltmeter scale.

Symptom 10

DIAGNOSTIC PROCEDURE

(continued)

Drive starts momentarily then trips off or Drive trips off during normal operation. Red **PROT. A**, **PROT. B**, or **PROT. C** fault LED is illuminated.

Connections Listed in Step 2 are shown on pages A-6 & A-7

STEP 2 – Check for a shorted output transistor module for the indicated phase as follows.

Unplug connectors **E5, E6, E7 & E13** at the Power Distribution Board.

Unplug the molex connector for the indicated phase at the Driver Board (**J302A, B or C**).

With an ohmmeter set on the x1 scale, measure the resistance between the collector and emitter of both upper and lower power switching transistors at molex connector **J302A, B or C** as follows.

<u>OHMMETER</u>		<u>READING</u>
<u>+ LEAD</u>	<u>- LEAD</u>	
J302, pin 1 (c1)	J302, pin 6 (E1)	INFINITE
J302, pin 6 (c2)	J302, pin 13 (E2)	INFINITE

With an ohmmeter set on the x1 scale, measure the resistance between the collector and base of both upper and lower power switching transistors at molex connector **J302A, B or C** as follows.

<u>OHMMETER</u>		<u>READING</u>
<u>+ LEAD</u>	<u>- LEAD</u>	
J302, pin 1 (c1)	J302, pin 5 (B1)	INFINITE
J302, pin 6 (c2)	J302, pin 12 (B2)	INFINITE

- If a collector to base short is found in either the upper or lower power switching transistor, replace the module.
- If either transistor has a collector to base short, replace the module and the Driver Board.

IMPORTANT : When replacing power switching modules clean all surfaces. Apply a thin layer of thermal grease (Dow Corning 340) to the back of each module. Torque mounting screws to 17-26 in-lbs max.

STEP 3 – Before reconnecting the motor, reapply input power to the Drive and ensure that the Drive operates properly in the manual operating mode. Depending upon the options installed, switch to **MANUAL** control if required. No diagnostic LEDs should be illuminated. If satisfactory operation is achieved, reconnect the motor and check operation again. If satisfactory operation is not achieved, replace the Modulator Logic Board.

STEP 4 – Once proper operation is achieved in the manual mode, depending on the options installed check operation in the auto or normal operating mode. If the Drive is not functioning properly in the normal mode, check all Modulator Board jumper settings and input signals to the option cards. If satisfactory operation is not achieved, replace the Modulator Logic Board.

(REFER TO THE OPTION KIT INSTRUCTIONS FOR CORRECT SETUP PROCEDURES)

Symptom 11

DIAGNOSTIC PROCEDURE

Drive starts momentarily then trips off or Drive trips off during normal operation. Red **BRAKE OVER TEMP.** fault LED is illuminated.

(Used only when equipped with the Dynamic Brake Option).

IMPORTANT : *If Drive will not restart or reset after a fault trip, always check fuse F5 for an open condition. Replace if necessary.*

An illuminated **BRAKE OVER TEMPERATURE** LED indicates an excessive brake resistor assembly temperature. This condition is normally caused by either excessive braking or a deceleration rate too high for the motor/load inertia. When the Dynamic Brake Option is used, it is recommended that the **NORM/DEC HOLD** jumper be set to the **DEC HOLD** position.

If neither of the above is true, check for:

- **Open Precharge Fuse F5 and/or Shorted Brake Transistor 4Q**
- **Malfunctioning Brake Resistor Thermal O.L.** (2TAS on Brake Resistor Assembly)
- **Poorly Ventilated Resistor Enclosure**

Check and repair as required.

IMPORTANT : **To reset a Brake Over Temperature Trip:**

1. *Remove input power to the Drive at the disconnect device.*
2. *Wait a few minutes to allow the O.L. heater and brake resistor to cool down.*
3. *Open the conduit box on the resistor cage assembly. Manually reset Thermal O.L. Relay 2TAS by depressing the plunger until a reset "click" is either heard or felt.*
4. *Reapply power to the Drive at the disconnect device.*
5. *Reset the Drive by giving it a STOP command followed by a START command.*

Symptom 12

DIAGNOSTIC PROCEDURE

Drive starts momentarily then trips off or Drive trips off during normal operation. Red **DRIVE OVER TEMP.** fault LED is illuminated.

IMPORTANT : *If the Drive will not restart or reset after a fault trip, always check fuse F5 for an open condition. Replace if necessary.*

An illuminated **DRIVE OVER TEMPERATURE** LED indicates that the Drive has tripped off due to an over temperature condition. Allow Drive to cool down for approximately (15) minutes before restarting. After restarting, if over temperature condition occurs again, check for the following conditions.

- **Ambient Temperature that Exceeds the Drive Rating.** Measure the ambient temperature surrounding the Drive per the Specification Table, Chapter 3.
- **Heat Flow Obstruction within the Heat Sink Assembly.** Visually inspect for unobstructed spacing between fins. Clean if necessary.
- **Thermal Overloading Caused by Duty Cycle Demands Exceeding 100% of Current Over an Extended Period of Time.** Using an AC clamp on ammeter, measure the motor current over an extended period of time.

IMPORTANT : *Clamp on type amp probes and current transformers are frequency sensitive. Inaccurate current readings at frequencies other than 60 Hz may be observed. It is recommended that a true RMS reading clamp on ammeter be used.*

- **Malfunctioning Temperature Sensor 1TAS.** If all of the above conditions have been checked and the problem still remains, replace Temperature Sensor 1TAS.

IMPORTANT : *When replacing Temperature Sensor 1TAS clean all surfaces. Apply a thin layer of thermal grease (Dow Corning 340) to the back of the sensor. Torque mounting screws to 2.6-3.0 in-lbs max.*

Symptom 13

DIAGNOSTIC PROCEDURE

Bus voltage does not discharge within (60) seconds when input power is removed. Neon light **DS1** on Power Distribution Board A2 is illuminated.

After input power is removed the bus voltage should discharge to 42V DC in approximately (60) seconds. If the discharge cycle is not taking place, check to see if resistor **2R** or **3R** has opened.

If neither resistor is open, check for open wiring between the resistors and Bus Capacitors **2C** & **3C**. If all wiring is correct, replace Power Distribution Board A2.

If either resistor is open, replace and reapply input power.

IMPORTANT : *When replacing resistor 2R or 3R, clean all surfaces. Apply a thin layer of thermal grease (Dow Corning 340) to the back of the resistor. Torque mounting screws to 2.6-3.0 in-lbs Max.*

Check for proper bus discharge cycle. Measure the DC voltage between connectors **E17 (+ BUS)** and **E13 (- BUS)** on Power Distribution Board A2. After approximately (60) seconds the voltage should be below 42 volts. If discharge cycle is still not taking place and/or either resistor opens again, replace Power Distribution Board A2.

E

Bulletin 1334 15-25 HP Series A Troubleshooting

15-25 HP Diagnostic LED Display

Power ON – Indicates input power is connected when illuminated.

Symptom
1, 2 & 3

Momentary Overload Protection Circuit – When constantly illuminated indicates an overload condition exceeded (60) seconds – Momentarily illuminated whenever circuit is activated.

Symptom
4, 5, 6 & 7

Under Voltage Protection – When illuminated indicates that the Drive has tripped **OFF** due to an input voltage that is less than 414 volts for a 460V Drive, 373 volts for a 415V Drive, or 342 volts for a 380V Drive.

Symptom
8

Over Voltage Protection – When illuminated indicates that the Drive has tripped **OFF** due to the bus voltage exceeding 760V DC.

Symptom
9

"A" Phase Protection Trip – When illuminated indicates either:

- An Overload Condition Greater Than 200%
- A Shorted "A" Phase Output Transistor
- Section "A" of the Driver Board is Malfunctioning

Symptom
10

"B" Phase Protection Trip – When illuminated indicates either:

- An Overload Condition Greater Than 200%
- A Shorted "B" Phase Output Transistor
- Section "B" of the Driver Board is Malfunctioning

Symptom
10

"C" Phase Protection Trip – When illuminated indicates either:

- An Overload Condition Greater Than 200%
- A Shorted "C" Phase Output Transistor
- Section "C" of the Driver Board is Malfunctioning

Symptom
10

Brake Resistor Over Temperature Protection Trip – When illuminated indicates excessive brake resistor temperature.

Symptom
11

Drive Over Temperature Protection Trip – When illuminated indicates that the heatsink temperature of the Drive has exceeded the maximum safe operating limit.



Symptom
12

Output Ground Fault Protection Trip Indication – When illuminated indicates that the Drive circuitry has shorted to GROUND.

Symptom
13

DS1 – Located on Bus Discharge Board A5 (or Dynamic Brake Board when installed) – When illuminated indicates that the bus potential is in excess of 42V DC.

Symptom
14



15-25 HP Troubleshooting Procedures

IMPORTANT

Drive Fault Trips

Before resetting any fault trip, refer to the following troubleshooting procedures to isolate and correct the fault.

The location of boards & Drive components are illustrated in **Appendix B** on pages **B-3 & B-4**.

All voltage values & polarities referenced in the following troubleshooting procedures are shown in the Drive Schematics in **Appendix H** or the Modulator Logic Board Interconnection Diagram in **Appendix J**.



WARNING

Hazardous voltage levels exist on some printed circuit boards and Drive components.

If diagnostic LED(s) **PROT. A**, **PROT. B**, or **PROT. C** are lit, hazardous voltages can be present at the output terminals even though the **STOP** pushbutton has been depressed.

If neon light **DS1** on Bus Discharge Board A5 (or the Brake Board if installed) is lit, hazardous voltages are present in the Drive cabinet.

To guard against personal injury when boards or wires are being disconnected or reconnected, or fuses are being replaced, always remove power to the Drive at the disconnect device, wait (5) seconds, and ensure that **DS1** is not lit before servicing. Use a **DVM** to check for zero volts between terminals **1 (+ BUS)** & **5 (- BUS)** at terminal block **4TB** on the Drive backpanel.



CAUTION : To Guard Against Equipment Damage When Troubleshooting the Drive, *Before Pressing the START Pushbutton Always:*

- Set the **Speed Pot** or speed reference to **MINIMUM**.
 - Set the **FWD/REV Switch** (if present), to the proper position.
 - Uncouple the motor from its mechanical load.
-

IMPORTANT

ESD Precautions

ESD (Electrostatic Discharge) generated by static electricity can damage the CMOS devices on various Drive boards. To guard against this type of damage, it is recommended that when circuit boards are removed or installed the following precautions be observed.

- *Wear a wrist type grounding strap that is grounded to the Drive chassis.*
 - *DO NOT remove the new circuit board from its conductive wrapper unless a ground strap is worn.*
 - *When removing any circuit board from the Drive, immediately place it in conductive packing material.*
-

Symptom 1

DIAGNOSTIC PROCEDURE

Drive does not start. Amber **POWER ON LED** is not illuminated.

Check for possible loss of input line voltage by measuring line voltage between L1, L2 and L3.

If voltage is present, measure voltage across input line fuses 1FU, 2FU, and 3FU. Measure voltage across input primary fuse 4FU at transformer 1T. A voltage reading across any of these fuses indicates an open condition. Before replacing blown fuses complete **STEPS 1 – 4**.

STEP 1 – Remove input power to the Drive. Before proceeding, wait (5) seconds. The Bus Indicator neon light on Bus Discharge Board A5 (or Brake Board if installed), should not be lit. Use a DC voltmeter to verify that the DC bus is fully discharged. Start with the voltmeter on its highest scale (x 1000) and range downward to the lowest voltmeter scale.

STEP 2 – For 15 & 20 HP Drives, with an ohmmeter set on the x1 scale, check Rectifier Assembly 1 REC as follows:

OHMMETER		READING
+ LEAD	– LEAD	
GREEN (1 REC +)	ORANGE (1 REC - AC1)	Infinite
GREEN (1 REC +)	GRAY (1 REC - AC2)	Infinite
GREEN (1 REC +)	YELLOW (1 REC - AC3)	Infinite
ORANGE (1 REC - AC1)	WHITE (1 REC -)	Infinite
GRAY (1 REC - AC2)	WHITE (1 REC -)	Infinite
YELLOW (1 REC - AC3)	WHITE (1 REC -)	Infinite

If any of the above readings are not as shown, replace Rectifier Assembly **1 REC**.

STEP 3 – For 25 HP Drives, with an ohmmeter set on the x1 scale, check Rectifier Assembly **1 REC, 2 REC, 3 REC** as follows:

OHMMETER		READING
+ LEAD	– LEAD	
BLACK (1 REC +)	ORANGE (1 REC - AC1)	Infinite
BLACK (1 REC +)	YELLOW (2 REC - AC2)	Infinite
BLACK (1 REC +)	GREEN (3 REC - AC3)	Infinite
ORANGE (1 REC - AC1)	WHITE (1 REC -)	Infinite
YELLOW (2 REC - AC2)	WHITE (1 REC -)	Infinite
GREEN (3 REC - AC3)	WHITE (1 REC -)	Infinite

If any of the above readings are not as shown, replace Rectifier Assembly **1 REC, 2 REC, 3 REC**.

Symptom 1

DIAGNOSTIC PROCEDURE

(continued)

Drive does not start. Amber **POWER ON LED** is not illuminated.

IMPORTANT : *When replacing the Rectifier Assembly clean all surfaces. Apply a thin layer of thermal grease (Dow Corning 340) to the back of the assembly. Torque mounting screws to 17-26 in-lbs max.*

STEP 4 – With the ohmmeter set on the x100 scale, check Bus Capacitors **2C1**, **3C1**, **2C2**, & **3C2** for a shorted condition as follows.

Remove the capacitor support block and (+) POSITIVE bus bars.

Connect the (+) POSITIVE lead of the ohmmeter to the (+) POSITIVE terminal of the capacitor. Connect the (-) NEGATIVE lead of the ohmmeter to the (-) NEGATIVE capacitor bus bar.

The ohmmeter should immediately read low, then slowly increase to approximately 20kΩ. A sustained low reading indicates a shorted capacitor that requires replacement.

After completing **STEPS 1 – 4**, replace blown fuses and reapply input power.

Symptom 2

DIAGNOSTIC PROCEDURE

Drive does not start. Amber **POWER ON LED** is illuminated. No red fault LEDs are illuminated.

Check for line out condition at fuse **3FU** by measuring the AC line voltage from L3 to either L1 or L2. If voltage is present, measure voltage across **3FU**. A voltage across **3FU** indicates that it is open and must be replaced. Before replacing **3FU**, perform **STEPS 1 – 4** in **Symptom 1**, then the following eleven steps.

STEP 1 – Check precharge circuit fuse **5FU** for an open condition.

STEP 2 With input power to the Drive removed at the disconnect device, check that all jumpers on Modulator Logic Board A1 are in their proper position, particularly the VCO/EXT-C jumper and the IFB/XFB jumper.

STEP 3 With input power to the Drive removed at the disconnect device, check installed options, particularly those with AUTO/MAN or AUTO/OFF/MANUAL selection (both local and remote). Depending upon the options installed the maximum speed pot adjustment **R25** or the minimum speed pot adjustment **R26** may be ineffective. Refer to section 5.3.1, **Minimum and Maximum Speed Adjust**.

- If option **N, N4, G2 or G4** is installed, ensure that:
The AUTO/MAN switch on the card is set to the MAN mode.
A 1k Ω , 2W, linear taper speed pot has been properly connected to Terminal Block **1TB** between terminals **14, 15 & 16**.
- If option **G** is installed, ensure that the 1k Ω resistor included with the option kit has been installed at Terminal Block **TB1** between terminals **14 & 16**.
- If option **K8 or K9** is installed, check for continuity across the Brake Over Temperature circuit at Terminal Block **TB1** between terminals **17 & 18**.
- If option **T4, T5 or T6** is installed, check for continuity across the Motor Overload Relay contact circuit, terminals **10 & 11** at Terminal Block **1TB**.

(REFER TO THE OPTION KIT INSTRUCTIONS FOR CORRECT SETUP PROCEDURES)

STEP 4 – Check for an open speed pot at Terminal Block **1TB**. Measure the voltage at Terminal Block **1TB** between terminals **14 & 16**. There should be 3.2V DC. If voltage is 12V DC, the speed pot may be open or there may be an open wire between the speed pot and terminals **14, 15 & 16**. Check for an inoperative speed pot by turning the pot from 0 to 100%. The voltage between terminals **15 & 16** should vary from 0 to 3.2V DC. Replace or correct as required.

STEP 5 – Check the voltage between terminals **9 & 11** at Terminal Block **1TB**.

- If standard START/STOP configuration is used, there should be 90V AC between terminals **9 & 11**. If not, the START/STOP circuit is open. Check the START/STOP circuit connections to **1TB**.
- If field installed 2-wire, 90V AC, RUN/STOP control is used, there should be 90V AC between terminals **9 & 11**. If not, the RUN/STOP circuit is open. Ensure that the circuit has been installed as specified in section 4.4.6.
- If field installed 2-wire, 120V AC, RUN/STOP control is used, there should be 120V AC between terminals **9 & 11**. If not, the RUN/STOP circuit is open. Ensure that the circuit has been installed as specified in section 4.4.5.

Symptom 2

DIAGNOSTIC PROCEDURE

(continued)

Drive does not start. Amber **POWER ON** LED is illuminated. No red fault LEDs are illuminated.

STEP 6 – Measure the output voltages in the secondary circuits of Transformer 1T.

The following voltages should be present at Power Supply Board A6.

- molex connector **J602** between pins **4** & **1** 14V AC
- molex connector **J602** between pins **2** & **1** 14V AC
- molex connector **J602** between pins **5** & **6** 15V AC

The following voltage should be present at terminal block 1TB.

- between terminals **1** & **11** 90V AC

If any one voltage is absent, remove input power and check all connections to 1T. If all connections are correct, replace Transformer 1T.

STEP 7 – Go to Logic Power Supply Board A6 and measure all output voltages. The following voltages should be present at molex connector **J601** with respect to Drive common, **J601** Pin 1. If any one voltage is absent, replace A6.

- J601**, pin **2** 14V AC
- J601**, pin **3** + 17V DC
- J601**, pin **5** + 9 to + 15V DC (nominal)
- J601**, pin **6** + 9 to + 15V DC (nominal)
- J601**, pin **9** -17V DC

STEP 8 – Measure the output voltage across the secondary circuit of Transformer 2T, pins 5 & 6. If 17V AC is absent, replace 2T.

STEP 9 – If 2T checks out, Contactor Interface Board A9 may be inoperative. The following voltages should be present with respect to Drive common, **J901** Pin 1.

- J901**, pin **4** + 24V DC
- J901**, pin **6** 0V DC (nominal)
- J901**, pin **7** 0V DC (nominal)
- J901**, pin **8** + 11V DC

STEP 10 – If Transformer 2T and Contactor Interface Board A9 check out, measure the control voltage at contactor 1CON. There should be + 24V DC between points C1 & C2 at the contactor. If + 24V DC is measured and 1CON is not picked-up, the contactor may be inoperative. Replace if required.

If the problem cannot be found after completing **STEPS 1 – 10**, replace Modulator Logic Board A1.

Symptom 3	DIAGNOSTIC PROCEDURE						
<p>Precharge cycle excessively long or not complete. Amber POWER ON LED may or may not be illuminated.</p>	<p>The DC bus precharge cycle should be completed within (5) seconds after input line power is applied to the Drive.</p> <p>Check precharge circuit fuse 5FU for an open condition first, then perform the following three steps.</p> <p>STEP 1 – Check Rectifier Assemblies and Bus Capacitors as specified in STEPS 1 – 4, symptom 1.</p> <p>STEP 2 – Check Precharge Contactor Interface Board A9 The following voltages should be present at connector J901 on the Contactor Interface Board. Replace if required.</p> <table data-bbox="529 701 1318 793"> <tr> <td>Transformer 2T secondary voltage</td> <td>17V AC between pins 2 & 3</td> </tr> <tr> <td>Contactor 1CON control voltage</td> <td>+ 24V DC between pins 4 & 6</td> </tr> <tr> <td></td> <td>+ 11V DC between pins 7 & 8</td> </tr> </table> <p>If the problem cannot be found after completing STEPS 1 & 2, replace Modulator Logic Board A1.</p>	Transformer 2T secondary voltage	17V AC between pins 2 & 3	Contactor 1CON control voltage	+ 24V DC between pins 4 & 6		+ 11V DC between pins 7 & 8
Transformer 2T secondary voltage	17V AC between pins 2 & 3						
Contactor 1CON control voltage	+ 24V DC between pins 4 & 6						
	+ 11V DC between pins 7 & 8						

Symptom 4	DIAGNOSTIC PROCEDURE						
<p>Drive trips on momentary overloads causing phase protection indication. M.O.P.C. circuit not functioning properly. Red M.O.P.C. fault LED is not illuminated.</p>	<div data-bbox="435 1157 1474 1234" style="border: 1px solid black; padding: 5px;"> <p>IMPORTANT : <i>If the Drive will not restart or reset after a fault trip, always check fuse 5FU for an open condition. Replace if necessary.</i></p> </div> <p>With the motor rotor locked and boost set to zero, adjust the ACCEL RATE setting, switch S1 on Modulator Logic Board A1, to 1.2 Hz/Sec. Set the operator speed pot or speed reference to zero.</p> <p>After completing the above, start the Drive and slowly increase the speed while monitoring the output motor current on any phase using a true RMS reading clamp on ammeter.</p> <p>The M.O.P.C. LED should light when the current reaches a nominal value of 150%. If the M.O.P.C. LED does not light, use an oscilloscope to check for a pulsed waveform at the following pins on connector J113 of the Modulator Logic Board with respect to Drive common.</p> <table data-bbox="792 1612 1101 1724"> <tr> <td>Pin 5</td> <td>– ØA Driver Signal</td> </tr> <tr> <td>Pin 16</td> <td>– ØB Driver Signal</td> </tr> <tr> <td>Pin 27</td> <td>– ØC Driver Signal</td> </tr> </table> <p>If pulse signals that go to a TTL level “0” are not present, replace the Driver Board in question.</p> <p>If pulse signals are present on all (3) Driver Boards, replace Modulator Logic Board A1.</p> <p>Return the boost and accel rate adjustments to their normal settings.</p>	Pin 5	– ØA Driver Signal	Pin 16	– ØB Driver Signal	Pin 27	– ØC Driver Signal
Pin 5	– ØA Driver Signal						
Pin 16	– ØB Driver Signal						
Pin 27	– ØC Driver Signal						

Symptom 5	DIAGNOSTIC PROCEDURE
<p>Drive starts momentarily then trips off or Drive trips off during normal operation. Red M.O.P.C. fault LED is illuminated.</p>	<div data-bbox="402 327 1438 415" style="border: 1px solid black; padding: 5px;"><p>IMPORTANT : <i>If the Drive will not restart or reset after a fault trip, always check fuse 5FU for an open condition. Replace if necessary.</i></p></div> <p>An illuminated M.O.P.C. LED indicates that the Drive has tripped off due to a nominal 150% overload condition which has exceeded the (60) second time period.</p> <div data-bbox="402 520 1438 663" style="border: 1px solid black; padding: 5px;"><p>IMPORTANT : <i>During acceleration or start-up (breakaway), it is normal for the M.O.P.C. LED to illuminate momentarily. This merely indicates that a momentary overload current of 150 % has been sensed and that the M.O.P.C. circuit has been activated. The LED will also flash momentarily when AC line power is first applied.</i></p></div> <p>If the M.O.P.C. LED is constantly activated during start-up (breakaway), or if there is excessive LED activity at low frequency operation, less DC boost must be used.</p> <p>Refer to the DC Boost Adjustment, section 5.3.3 and V/Hz Jumper Setting in section 5.3.2.</p> <p>If Option L, the Function Expander Card is installed, REFER TO THE OPTION KIT INSTRUCTIONS FOR CORRECT SETUP PROCEDURES.</p>

Symptom 6	DIAGNOSTIC PROCEDURE
<p>Motor does not return to full set speed after stalling. Red M.O.P.C. fault LED is illuminated.</p>	<p>The load torque is exceeding the torque capability of the Drive. Check for problems with the mechanical load.</p> <p>If the mechanical load checks out, try increasing the DC boost as outlined in section 5.3.3. If this does not correct the condition, consult your nearest Allen-Bradley Area Sales/Support Center for application assistance.</p> <div data-bbox="402 1367 1438 1516" style="border: 1px solid black; padding: 5px;"><p>IMPORTANT: <i>If a 150 % continuous overload current demand exists, the motor will ramp down to a stalled condition and remain there until the overload condition no longer exists. If however the overload condition is sustained for (60) seconds, the Drive will trip and illuminate the M.O.P.C. LED on the Diagnostic Display Panel.</i></p></div>

Symptom 7	DIAGNOSTIC PROCEDURE
<p>Red M.O.P.C. fault LED is illuminated during DECEL or at (0) Hz.</p>	<p>Boost voltage set too high. Decrease the boost voltage by setting the DC boost switch lower and/or set the Decel switch to provide a slower ramp (Refer to DC Boost Adjustment, ACCEL/DECEL Rate Adjustments, section 5.3.3).</p>

Symptom 8

DIAGNOSTIC PROCEDURE

Drive starts momentarily then trips off or Drive trips off during normal operation. Red **UNDER VOLTS** fault LED is illuminated.

IMPORTANT : *If the Drive will not restart or reset after a fault trip, always check fuse 5FU for an open condition. Replace if necessary.*

An illuminated **UNDER VOLTS** LED indicates that Drive has tripped off due to an input line voltage that is less than 414V AC at the 460V AC Tap on Transformer 1T

- **414V AC at the 460V AC Tap on Transformer 1T**
- **373V AC at the 415V AC Tap on Transformer 1T** (50 Hz Input Power)
- **342V AC at the 380V AC Tap on Transformer 1T** (50 Hz Input Power)

STEP 1 – Check input primary fuse 4FU for an open condition.

STEP 2 – Measure the input voltage to Transformer 1T. If proper voltage is present, replace Modulator Logic Board A1.

Symptom 9

DIAGNOSTIC PROCEDURE

Drive starts momentarily then trips off or Drive trips off during normal operation or deceleration. Red **OVER VOLTS** fault LED is illuminated.

An illuminated **OVER VOLTS** LED indicates that the Drive has tripped off due to a bus voltage greater than 760V DC. Three conditions can cause an over voltage trip.

- **Excessively High Input Voltage**
- **DC Boost Set too High**
- **Deceleration Rate too High for the Motor/Load Inertia**

STEP 1 – Check the input line voltage across each phase at L1, L2, and L3. The voltage should not be greater than 506V AC.

STEP 2 – If trip occurred during deceleration, check the position of the **NORM/DEC HOLD** jumper on the Modulator Logic Board. The jumper should be set to the **DEC HOLD** position.

Monitor LED **CR53 FREQ HOLD** on the Modulator Logic Board. During deceleration, with the **NORM/DEC HOLD** jumper in the **DEC HOLD** position, the LED should light before an overvoltage trip occurs. If the LED lights, decrease the **DECEL RATE**, the **DC BOOST**, or both. Refer to the **Modulator Logic Board Switch Settings** in section 5.3.3. If the LED does not light, replace the Modulator Logic Board.

STEP 3 – If the Drive trips out on over voltage during deceleration and a slower decel ramp is not acceptable, consult your nearest Allen-Bradley Area Sales/Support Center.

Symptom 10

DIAGNOSTIC PROCEDURE

Drive starts momentarily then trips off or Drive trips off during normal operation. Red **PROT. A**, **PROT. B**, or **PROT. C** fault LED is illuminated.

IMPORTANT : *If the Drive will not restart or reset after a fault trip, always check fuse 5FU for an open condition. Replace if necessary.*

An illuminated **A**, **B** or **C** phase protection LED indicates:

- **An output overcurrent condition greater than 200% due to either:**

- 1) An output phase-to-phase short (Drive output, motor windings, or wiring to the motor).
- 2) An output overcurrent condition greater than 200% due to an output phase-to-ground short.

In either case, remove input power to the Drive at the disconnect device. Disconnect the motor leads from the Drive at Terminal Block **2TB**. Reapply power to the Drive and give the Drive a **START** command. If the Drive can be operated without a phase protect trip occurring, the problem is in either the wiring to the motor or the motor itself.

A ground fault can be found using an ohmmeter between the wiring to the motor and ground. Find the cause and correct it before reconnecting the motor leads to the Drive and reapplying power.

A shorted motor winding is harder to detect because of the low resistance of the motor windings. Substitute a known, good motor for the suspected bad motor. Connect the substitute motor to the Drive output terminals and try running the Drive. If successful operation of the Drive and substitute motor is achieved, then the problem most likely is the motor originally connected to the Drive.

- **Deceleration of an inertia type motor load at too high a value of DC boost or too fast a DECEL rate.**

Under the right conditions, the motor can appear as a short circuit to the Drive. With excessive DC boost applied, the motor can saturate, resulting in a peak current in excess of 200% causing a phase protect trip. Decrease the **DC BOOST**, the **DECEL RATE** or both. Refer to section 5.3.3, **DC Boost Adjustment, ACCEL/DECEL Rate Adjustment** for additional information.

- **Excessive DC boost causing a phase protection trip during acceleration.**

Excessive DC boost can cause a phase protection trip to occur during acceleration of the Drive and motor due to saturation of the motor windings.

If reducing the DC boost setting eliminates the phase protection trip but does not produce sufficient torque to enable the motor to accelerate the load, consult your nearest Allen-Bradley Area Sales/Support Center for application assistance.

Reset the Drive by giving it a STOP command followed by a START command. If proper operation cannot be obtained without the reoccurrence of a phase protect trip and you have eliminated the preceding possibilities, the problem is most likely caused by one of the following.

Symptom 10

DIAGNOSTIC PROCEDURE

(continued)

Drive starts momentarily then trips off or Drive trips off during normal operation. Red **PROT. A**, **PROT. B**, or **PROT. C** fault LED is illuminated.

- **A shorted output transistor in one of the Power Switching Modules.**
Phase "A" ... 1Q1, 1Q2
Phase "B" ... 2Q1, 2Q2
Phase "C" ... 3Q1, 3Q2
Perform the following four steps to isolate and correct the problem.
- **A malfunctioning Driver Board.**
Phase "A" ... A3A
Phase "B" ... A3B
Phase "C" ... A3C
Perform the following four steps to isolate and correct the problem.
- **A malfunctioning Driver Board causing an output power Switching Module to be ON when it shouldn't be.**
Phase "A" ... A3A
Phase "B" ... A3B
Phase "C" ... A3C
Perform the following four steps to isolate and correct the problem.
- **A malfunctioning Modulator Logic Board causing an abnormal Drive output voltage waveform.**
Perform the following four steps to isolate and correct the problem.

STEP 1 – Remove input power to the Drive. Before proceeding, wait (5) seconds. **DS1**, the bus charged neon light on Bus Discharge Board **A5** (or Brake Board if installed), should not be lit. Use a DC voltmeter to verify that the DC bus is fully discharged by measuring the voltage at connector **J402** between pins **5** (+ BUS) and **1** (- BUS) on Voltage Sensing Board **A4**. Start with the voltmeter on its highest scale (x 1000) and range downward to the lowest voltmeter scale.


Symptom 10

DIAGNOSTIC PROCEDURE

(continued)

Drive starts momentarily then trips off or Drive trips off during normal operation. Red **PROT. A**, **PROT. B**, or **PROT. C** fault LED is illuminated.

Connections Listed in Step 2 are shown in detail on pages B-4 & B-6



STEP 2 – Check for a shorted output transistor module for the indicated phase as follows.

Disconnect the (+) BUS lead at **C1** for the indicated phase at the Power Switching Module.

Disconnect the (-) BUS lead at **E2** at the Power Switching Module.

Unplug the molex connector for the indicated phase at the Driver Board (**J302A, B** or **C**).

Disconnect one end of the jumper bar that is connected between terminals **E1, C2** on the two Power Switching Modules and the output phase lead to terminal **2TB**. This will enable you to check all four transistors independently.

With an ohmmeter set on the x1 scale, measure the resistance between the collector and emitter of both upper and lower power switching transistors for each module as follows.

<u>OHMMETER</u>		<u>READING</u>
<u>+ LEAD</u>	<u>- LEAD</u>	
C1	E1	INFINITE
C2	E2	INFINITE

With an ohmmeter set on the x1 scale, measure the resistance between the collector and base of both upper and lower power switching transistors for each module as follows.

<u>OHMMETER</u>		<u>READING</u>
<u>+ LEAD</u>	<u>- LEAD</u>	
C1	B1	INFINITE
C2	B2	INFINITE

- If a collector to emitter short is found in either the upper or lower power switching transistor, replace the module.
- If either transistor has a collector to base short, replace the module and the Driver Board.

IMPORTANT : When replacing power switching modules clean all surfaces. Apply a thin layer of thermal grease (Dow Corning 340) to the back of each module. Torque mounting screws to 17-26 in-lbs max.

Symptom 10

DIAGNOSTIC PROCEDURE

(continued)

Drive starts momentarily then trips off or Drive trips off during normal operation. Red **PROT. A**, **PROT. B**, or **PROT. C** fault LED is illuminated.

STEP 3 – Before reconnecting the motor, reapply input power to the Drive and ensure that the Drive operates properly in the manual operating mode. Depending upon the options installed, switch to **MANUAL** control if required. No diagnostic LEDs should be illuminated. If satisfactory operation is achieved, reconnect the motor and check operation again. If satisfactory operation is not achieved, replace the Modulator Logic Board.

STEP 4 – Once proper operation is achieved in the manual mode, depending on the options installed, check operation in the auto or normal operating mode. If the Drive is not functioning properly in the normal mode, check all Modulator Board jumper settings and input signals to the option cards. If satisfactory operation is not achieved, replace the Modulator Logic Board.

(REFER TO THE OPTION KIT INSTRUCTIONS FOR CORRECT SETUP PROCEDURES)

Symptom 11

DIAGNOSTIC PROCEDURE

Drive starts momentarily then trips off or Drive trips off during normal operation. Red **BRAKE OVER TEMP.** fault LED is illuminated.
(Used only when equipped with the Dynamic Brake Option).

IMPORTANT : *If Drive will not restart or reset after a fault trip, always check fuse 5FU for an open condition. Replace if necessary.*

An illuminated **BRAKE OVER TEMPERATURE** LED indicates an excessive brake resistor assembly temperature. This condition is normally caused by either excessive braking or a deceleration rate too high for the motor/load inertia. When the Dynamic Brake Option is used, it is recommended that the **NORM/DEC HOLD** jumper be set to the **DEC HOLD** position.

If neither of the above is true, check for:

- **Open Precharge Fuse 5FU and/or Shorted Brake Transistor 4Q**
- **Malfunctioning Brake Resistor Thermal O.L.** (2TAS on Brake Resistor Assembly)
- **Poorly Ventilated Resistor Enclosure**

Check and repair as required.

IMPORTANT : **To reset a Brake Over Temperature Trip:**

1. *Remove input power to the Drive at the disconnect device.*
2. *Wait a few minutes to allow the O.L. heater and brake resistor to cool down.*
3. *Open the conduit box on the resistor cage assembly. Manually reset Thermal O.L. Relay 2TAS by depressing the plunger until a reset "click" is either heard or felt.*
4. *Reapply power to the Drive at the disconnect device.*
5. *Reset the Drive by giving it a STOP command followed by a START command.*

Symptom 12	DIAGNOSTIC PROCEDURE
<p>Drive starts momentarily then trips off or Drive trips off during normal operation. Red DRIVE OVER TEMP. fault LED is illuminated.</p>	<div data-bbox="410 321 1442 405" style="border: 1px solid black; padding: 5px;"><p>IMPORTANT : <i>If the Drive will not restart or reset after a fault trip, always check fuse 5FU for an open condition. Replace if necessary.</i></p></div> <p>An illuminated DRIVE OVER TEMPERATURE LED indicates that the Drive has tripped off due to an over temperature condition. Allow Drive to cool down for approximately (15) minutes before restarting. After restarting, if over temperature condition occurs again, check for the following conditions.</p> <ul style="list-style-type: none">● Ambient Temperature that Exceeds the Drive Rating. Measure the ambient temperature surrounding the Drive per the Specification Table, Chapter 3.● Heat Flow Obstruction within the Heat Sink Assembly. Visually inspect for unobstructed spacing between fins. Clean if necessary.● Thermal Overloading Caused by Duty Cycle Demands Exceeding 100% of Current Over an Extended Period of Time. Using an AC clamp on ammeter, measure the motor current over an extended period of time. <div data-bbox="410 846 1442 961" style="border: 1px solid black; padding: 5px;"><p>IMPORTANT : <i>Clamp on type amp probes and current transformers are frequency sensitive. Inaccurate current readings at frequencies other than 60 Hz may be observed. It is recommended that a true RMS reading clamp on ammeter be used.</i></p></div> <ul style="list-style-type: none">● Malfunctioning Temperature Sensor 1TAS. If all of the above conditions have been checked and the problem still remains, replace Temperature Sensor 1TAS. <div data-bbox="410 1108 1442 1224" style="border: 1px solid black; padding: 5px;"><p>IMPORTANT : <i>When replacing Temperature Sensor 1TAS clean all surfaces. Apply a thin layer of thermal grease (Dow Corning 340) to the back of the sensor. Torque mounting screws to 2.6-3.0 in-lbs max.</i></p></div>

Symptom 13	DIAGNOSTIC PROCEDURE
<p>Drive starts momentarily then trips off or Drive trips off during normal operation. Red OUTPUT GND fault LED is illuminated.</p>	<div data-bbox="410 1461 1442 1545" style="border: 1px solid black; padding: 5px;"><p>IMPORTANT : <i>If the Drive will not restart or reset after a fault trip, always check fuse 5FU for an open condition. Replace if necessary.</i></p></div> <p>An illuminated OUTPUT GROUND LED indicates that the Drive circuitry has shorted to ground or there is a malfunctioning Output Ground Sensor Board A8.</p> <p>Remove input power to the Drive and disconnect the motor from the Drive. Reapply input power and start the Drive.</p> <p>If the Drive does not trip, check the motor for a grounded phase condition. Replace or repair the motor if required.</p> <p>If the Drive trips with the motor disconnected, check wire insulation and terminal connections on the Drive chassis for shorts to ground. If the problem still cannot be located, replace Output Ground Sensor Board A8.</p>

Symptom 14

DIAGNOSTIC PROCEDURE

Bus voltage does not discharge within (5) seconds when input power is removed. Neon light **DS1** on Bus Discharge Board A5 (or Brake Board if installed) is illuminated.

After input power is removed the bus voltage should discharge to 42V DC in approximately (5) seconds. If the discharge cycle is not taking place, check to see if fuse **6FU** or resistor **4R** has opened.

STEP 1 - If neither the fuse nor the resistor is open, measure the AC voltage at Bus Discharge Board A5, connector **J502**, between pins 1 & 4. The voltage should be approximately 12V AC.

If voltage is present, replace Bus Discharge Board A5

If voltage is not present, check fuse **4FU**.

If **4FU** is good, replace Control Transformer **1T**.

STEP 2 - If either **6FU** or **4R** is open, replace and reapply input power. Check for proper bus discharge cycle by measuring the DC Bus voltage at Bus Discharge Board A5, connector **J503**, between pins 1 (+ BUS) and 11 or 12 (- BUS). After approximately (5) seconds the voltage should be below 42V DC. If discharge cycle is still not taking place and/or either the fuse or resistor opens again, replace Bus Discharge Board A5.

Bulletin 1334 30-50 HP Series A Troubleshooting

30-50 HP Diagnostic LED Display

Power ON – Indicates input power is connected when illuminated.

Symptom
1, 2 & 3

Momentary Overload Protection Circuit – When constantly illuminated indicates an overload condition exceeded (60) seconds – Momentarily illuminated whenever circuit is activated.

Symptom
4, 5, 6, 7 & 8

Under Voltage Protection – When illuminated indicates that the Drive has tripped **OFF** due to an input voltage that is less than 414 volts for a 460V Drive, 373 volts for a 415V Drive, or 342 volts for a 380V Drive.

Symptom
9

Over Voltage Protection – When illuminated indicates that the Drive has tripped **OFF** due to the bus voltage exceeding 760V DC.

Symptom
10

"A" Phase Protection Trip – When illuminated indicates either:

- An Overload Condition Greater Than 200%
- A Shorted "A" Phase Output Transistor
- Section "A" of the Driver Board is Malfunctioning

Symptom
11

"B" Phase Protection Trip – When illuminated indicates either:

- An Overload Condition Greater Than 200%
- A Shorted "B" Phase Output Transistor
- Section "B" of the Driver Board is Malfunctioning

Symptom
11

"C" Phase Protection Trip – When illuminated indicates either:

- An Overload Condition Greater Than 200%
- A Shorted "C" Phase Output Transistor
- Section "C" of the Driver Board is Malfunctioning

Symptom
11

Brake Resistor Over Temperature Protection Trip – When illuminated indicates excessive brake resistor temperature.

Symptom
12

Drive Over Temperature Protection Trip – When illuminated indicates that the heatsink temperature of the Drive has exceeded the maximum safe operating limit.



Symptom
13

Output Ground Fault Protection Trip Indication – When illuminated indicates that the Drive circuitry has shorted to GROUND.

Symptom
14


DS1 – Located on Bus Discharge Board A5 (or Dynamic Brake Board when installed) – When illuminated indicates that the bus potential is in excess of 42V DC.

Symptom
15



30-50 HP Driver Board LED Indication

There are no adjustment settings for Bulletin 1334 30-50 HP Driver Boards. Each Driver Board does however provide fuse status indication. Two LEDs, CR18 and CR19, indicate the status of fuses F1 and F2 on each Driver Board respectively. An illuminated LED means that its associated fuse has opened as described in **Symptom 11** in the following troubleshooting procedures.



LED CR18

When Illuminated Indicates Fuse F1 is Open

LED CR19

When Illuminated Indicates Fuse F2 is Open

30 thru 50 HP Troubleshooting Procedures

IMPORTANT

Drive Fault Trips

Before resetting any fault trip, refer to the following troubleshooting procedures to isolate and correct the fault.

The location of boards & Drive components are illustrated in **Appendix C** on pages **C-3** & **C-4**.

All **voltage values & polarities** referenced in the following troubleshooting procedures are shown in the Drive Schematics in **Appendix I** or the Modulator Logic Board Interconnection Diagram in **Appendix J**.



WARNING

Hazardous voltage levels exist on some printed circuit boards and Drive components.

If diagnostic LED(s) **PROT. A**, **PROT. B**, or **PROT. C** are lit, hazardous voltages can be present at the output terminals even though the STOP pushbutton has been depressed.

If neon light **DS1** on Bus Discharge Board A5 (or the Brake Board if installed) is lit, hazardous voltages are present in the Drive cabinet.

To guard against personal injury when boards or wires are being disconnected or reconnected, or fuses are being replaced, **always remove power to the Drive at the disconnect device, wait (5) seconds, and ensure that DS1 is not lit before servicing.** Use a DVM to check for zero volts between terminals **1 (+ BUS) & 5 (- BUS)** at terminal block 4TB on the Drive backpanel.



CAUTION : To Guard Against Equipment Damage When Troubleshooting the Drive, Before Pressing the START Pushbutton Always:

Set the Speed Pot or speed reference to **MINIMUM**.

Set the **FWD/REV Switch** (if present), to the proper position.

Uncouple the motor from its mechanical load.

IMPORTANT

ESD Precautions

ESD (Electrostatic Discharge) generated by static electricity can damage the CMOS devices on various Drive boards. To guard against this type of damage, it is recommended that when circuit boards are removed or installed the following precautions be observed.

- *Wear a wrist type grounding strap that is grounded to the Drive chassis.*
 - *DO NOT remove the new circuit board from its conductive wrapper unless a ground strap is worn.*
 - *When removing any circuit board from the Drive, immediately place it in conductive packing material.*
-

Symptom 1	DIAGNOSTIC PROCEDURE																								
<p>Drive does not start. Amber POWER ON LED is not illuminated.</p>	<p>Check for possible loss of input line voltage by measuring line voltage between L1, L2 and L3.</p> <p>If voltage is present, measure voltage across input line fuses 1FU, 2FU, and 3FU. Measure voltage across input primary fuse 4FU at transformer 1T. A voltage reading across any of these fuses indicates an open condition. Before replacing blown fuses complete STEPS 1, 2 and 3.</p> <p>STEP 1 – Remove input power to the Drive. Before proceeding, wait (5) seconds. The Bus Indicator neon light on Bus Discharge Board A5 (or Brake Board if installed), should not be lit. Use a DC voltmeter to verify that the DC bus is fully discharged. Start with the voltmeter on its highest scale (x 1000) and range downward to the lowest voltmeter scale.</p> <p>STEP 2 – With an ohmmeter set on the x1 scale, check Rectifier Assembly 1 REC, 2 REC, 3 REC as follows:</p> <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th colspan="2" style="text-align: center;">OHMMETER</th> <th style="text-align: center;">READING</th> </tr> <tr> <th style="text-align: center;">+ LEAD</th> <th style="text-align: center;">– LEAD</th> <th></th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">BLACK (1 REC +)</td> <td style="text-align: center;">ORANGE (1 REC - AC1)</td> <td style="text-align: center;">Infinite</td> </tr> <tr> <td style="text-align: center;">BLACK (1 REC +)</td> <td style="text-align: center;">YELLOW (2 REC - AC2)</td> <td style="text-align: center;">Infinite</td> </tr> <tr> <td style="text-align: center;">BLACK (1 REC +)</td> <td style="text-align: center;">GREEN (3 REC - AC3)</td> <td style="text-align: center;">Infinite</td> </tr> <tr> <td style="text-align: center;">ORANGE (1 REC - AC1)</td> <td style="text-align: center;">BLACK (1 REC -)</td> <td style="text-align: center;">Infinite</td> </tr> <tr> <td style="text-align: center;">YELLOW (2 REC - AC2)</td> <td style="text-align: center;">BLACK (1 REC -)</td> <td style="text-align: center;">Infinite</td> </tr> <tr> <td style="text-align: center;">GREEN (3 REC - AC3)</td> <td style="text-align: center;">BLACK (1 REC -)</td> <td style="text-align: center;">Infinite</td> </tr> </tbody> </table> <p>If any of the above readings are not as shown, replace Rectifier Assembly 1 REC, 2 REC, 3 REC.</p> <div style="border: 1px solid black; padding: 5px; margin: 10px 0;"> <p>IMPORTANT : <i>When replacing the Rectifier Assembly clean all surfaces. Apply a thin layer of thermal grease (Dow Corning 340) to the back of the assembly. Torque mounting screws to 17-26 in-lbs max.</i></p> </div> <p>STEP 3 – With the ohmmeter set on the x100 scale, check Bus Capacitors for a shorted condition as follows.</p> <p>(2C1-2, 3C1-2 for 30 HP Drives – 2C1-3, 3C1-3 for 40 & 50 HP Drives)</p> <p>Remove the capacitor support block and (+) POSITIVE bus bars.</p> <p>Connect the (+) POSITIVE lead of the ohmmeter to the (+) POSITIVE terminal of the capacitor. Connect the (-) NEGATIVE lead of the ohmmeter to the (-) NEGATIVE capacitor bus bar.</p> <p>The ohmmeter should immediately read low, then slowly increase to approximately 20kΩ. A sustained low reading indicates a shorted capacitor that requires replacement.</p> <p>After completing STEPS 1, 2 & 3, replace blown fuses and reapply input power.</p>	OHMMETER		READING	+ LEAD	– LEAD		BLACK (1 REC +)	ORANGE (1 REC - AC1)	Infinite	BLACK (1 REC +)	YELLOW (2 REC - AC2)	Infinite	BLACK (1 REC +)	GREEN (3 REC - AC3)	Infinite	ORANGE (1 REC - AC1)	BLACK (1 REC -)	Infinite	YELLOW (2 REC - AC2)	BLACK (1 REC -)	Infinite	GREEN (3 REC - AC3)	BLACK (1 REC -)	Infinite
OHMMETER		READING																							
+ LEAD	– LEAD																								
BLACK (1 REC +)	ORANGE (1 REC - AC1)	Infinite																							
BLACK (1 REC +)	YELLOW (2 REC - AC2)	Infinite																							
BLACK (1 REC +)	GREEN (3 REC - AC3)	Infinite																							
ORANGE (1 REC - AC1)	BLACK (1 REC -)	Infinite																							
YELLOW (2 REC - AC2)	BLACK (1 REC -)	Infinite																							
GREEN (3 REC - AC3)	BLACK (1 REC -)	Infinite																							

Symptom 2

DIAGNOSTIC PROCEDURE

Drive does not start. Amber **POWER ON** LED is illuminated. No red fault LEDs are illuminated.

Check for line out condition at fuse 3FU by measuring the AC line voltage from L3 to either L1 or L2. If voltage is present, measure voltage across 3FU. A voltage across 3FU indicates that it is open and must be replaced. Before replacing 3FU, perform **STEPS 1, 2 & 3** in **Symptom 1**, then the following eleven steps.

STEP 1 – Check precharge circuit fuse 5FU for an open condition.

STEP 2 With input power to the Drive removed at the disconnect device, check that all jumpers on Modulator Logic Board A1 are in their proper position, particularly the VCO/EXT-C jumper and the IFB/XFB jumper.

STEP 3 With input power to the Drive removed at the disconnect device, check installed options, particularly those with AUTO/MAN or AUTO/OFF/MANUAL selection (both local and remote). Depending upon the options installed the maximum speed pot adjustment R25, or the minimum speed pot adjustment R26, may be ineffective. Refer to section 5.3.1, **Minimum and Maximum Speed Adjust**.

- If option N, N4, G2 or G4 is installed, ensure that:

The AUTO/MAN switch on the card is set to the MAN mode.

A 1k Ω , 2W, linear taper speed pot has been properly connected to Terminal Block 1TB between terminals 14, 15 & 16.

- If option G is installed, ensure that the 1k Ω resistor included with the option kit has been installed at Terminal Block TB1 between terminals 14 & 16.
- If option K9 is installed, check for continuity across the Brake Over Temperature circuit at Terminal Block TB1 between terminals 17 & 18.
- If option T7, T8 or T9 is installed, check for continuity across the Motor Overload Relay contact circuit, terminals 10 & 11 at Terminal Block 1TB.

STEP 4 – Check for an open speed pot at Terminal Block 1TB. Measure the voltage at Terminal Block 1TB between terminals 14 & 16. There should be 3.2V DC. If voltage is 12V DC, the speed pot may be open or there may be an open wire between the speed pot and terminals 14, 15 & 16. Check for an inoperative speed pot by turning the pot from 0 to 100%. The voltage between terminals 15 & 16 should vary from 0 to 3.2V DC. Replace or correct as required.

STEP 5 – Check the voltage between terminals 9 & 11 at Terminal Block 1TB.

- If standard START/STOP configuration is used, there should be 90V AC between terminals 9 & 11. If not, the START/STOP circuit is open. Check the START/STOP circuit connections to 1TB.

– For a Standard Drive Without Factory Installed Options –

- If field installed 2-wire, 90V AC, RUN/STOP control is used, there should be 90V AC between terminals 9 & 11. If not, the RUN/STOP circuit is open. Ensure that the circuit has been installed as specified in section 4.4.6.
- If field installed 2-wire, 120V AC, RUN/STOP control is used, there should be 120V AC between terminals 9 & 11. If not, the RUN/STOP circuit is open. Ensure that the circuit has been installed as specified in section 4.4.5.

Symptom 2

DIAGNOSTIC PROCEDURE

(continued)

Drive does not start. Amber **POWER ON** LED is illuminated. No red fault LEDs are illuminated.

STEP 6 – Measure the output voltages in the secondary circuits of Transformer 1T.

The following voltages should be present at Power Supply Board A6.

- molex connector **J602** between pins 4 & 1 14V AC
- molex connector **J602** between pins 2 & 1 14V AC
- molex connector **J602** between pins 5 & 6 15V AC

The following voltage should be present at terminal block **1TB**.

- between terminals 1 & 11 90V AC

If any one voltage is absent, remove input power and check all connections to **1T**. If all connections are correct, replace Transformer 1T.

STEP 7 – Go to Logic Power Supply Board A6 and measure all output voltages. The following voltages should be present at molex connector **J601** with respect to Drive common, **J601** Pin 1. If any one voltage is absent, replace A6.

- J601**, pin 2 14V AC
- J601**, pin 3 + 17V DC
- J601**, pin 5 + 9 to + 15V DC (nominal)
- J601**, pin 6 + 9 to + 15V DC (nominal)
- J601**, pin 9 -17V DC

STEP 8 – Measure the output voltage across the secondary circuit of Transformer 2T, pins 5 & 6. If 17V AC is absent, replace 2T.

STEP 9 – If 2T checks out, Contactor Interface Board A9 may be inoperative. The following voltages should be present with respect to Drive common, **J901** Pin 1.

- J901**, pin 4 + 24V DC
- J901**, pin 6 0V DC (nominal)
- J901**, pin 7 0V DC (nominal)
- J901**, pin 8 + 11V DC

STEP 10 – If Transformer 2T and Contactor Interface Board A9 check out, measure the control voltage at contactor **1CON**. There should be + 24V DC between points **C1** & **C2** at the contactor. If + 24V DC is measured and **1CON** is not picked-up, the contactor may be inoperative. Replace if required.

If the problem cannot be found after completing **STEPS 1 – 10**, replace Modulator Logic Board A1.

Symptom 3

DIAGNOSTIC PROCEDURE

Precharge cycle excessively long or not complete. Amber **POWER ON** LED may or may not be illuminated.

The DC bus precharge cycle should be completed within (5) seconds after input line power is applied to the Drive.

Check precharge circuit fuse **5FU** for an open condition first, then perform the following three steps.

STEP 1 – Check Rectifier Assemblies and Bus Capacitors as specified in **STEPS 1, 2 & 3, symptom 1.**

STEP 2 – Check Precharge Contactor Interface Board A9 The following voltages should be present at connector **J901** on the Contactor Interface Board. Replace if required.

Transformer 2T secondary voltage	17V AC between pins 2 & 3
Contactor 1CON control voltage	+ 24V DC between pins 4 & 6 + 11V DC between pins 7 & 8

If the problem cannot be found after completing **STEPS 1 & 2**, replace Modulator Logic Board A1.

Symptom 4

DIAGNOSTIC PROCEDURE

Drive trips just after input line power is applied before START command is given. Red **M.O.P.C.** fault LED is illuminated.

IMPORTANT : *If the Drive will not restart or reset after a fault trip, always check fuse 5FU for an open condition. Replace if necessary.*

An illuminated **M.O.P.C.** LED indicates that there may be a loss of input power to the Driver Boards.

Check the power supply at all three Driver Boards. Approximately 16V AC should be measured between pins 1 & 2 at each J301 connector. If not, check fuse F1 on Driver Power Supply Board A10.

If the fuse is open, replace Driver Power Supply Board A10.

If voltage is present, perform the diagnostic procedure in **Symptom 5**.

Symptom 5

DIAGNOSTIC PROCEDURE

Drive trips on momentary overloads causing phase protection indication. **M.O.P.C.** circuit not functioning properly. Red **M.O.P.C.** fault LED is not illuminated.

IMPORTANT : *If the Drive will not restart or reset after a fault trip, always check fuse 5FU for an open condition. Replace if necessary.*

With the motor rotor locked and boost set to zero, adjust the ACCEL RATE setting, switch S1 on Modulator Logic Board A1, to 1.2 Hz/Sec. Set the operator speed pot or speed reference to zero.

After completing the above, start the Drive and slowly increase the speed while monitoring the output motor current on any phase using a true RMS reading clamp on ammeter.

The **M.O.P.C.** LED should light when the current reaches a nominal value of 150%. If the **M.O.P.C.** LED does not light, use an oscilloscope to check for a pulsed waveform at the following pins on connector J113 of the Modulator Logic Board with respect to Drive common.

Pin 5 – ØA Driver Signal

Pin 16 – ØB Driver Signal

Pin 27 – ØC Driver Signal

If pulse signals that go to a TTL level "0" are not present, replace the Driver Board in question.

If pulse signals are present on all (3) Driver Boards, replace Modulator Logic Board A1.

Return the boost and accel rate adjustments to their normal settings.

Symptom 6	DIAGNOSTIC PROCEDURE
<p>Drive starts momentarily then trips off or Drive trips off during normal operation. Red M.O.P.C. fault LED is illuminated.</p>	<div data-bbox="418 342 1458 426" style="border: 1px solid black; padding: 5px;"> <p>IMPORTANT : <i>If the Drive will not restart or reset after a fault trip, always check fuse 5FU for an open condition. Replace if necessary.</i></p> </div> <p>An illuminated M.O.P.C. LED indicates that the Drive has tripped off due to a nominal 150% overload condition which has exceeded the (60) second time period.</p> <div data-bbox="418 531 1458 678" style="border: 1px solid black; padding: 5px;"> <p>IMPORTANT : <i>During acceleration or start-up (breakaway), it is normal for the M.O.P.C. LED to illuminate momentarily. This merely indicates that a momentary overload current of 150% has been sensed and that the M.O.P.C. circuit has been activated. The LED will also flash momentarily when AC line power is first applied.</i></p> </div> <p>If the M.O.P.C. LED is constantly activated during start-up (breakaway), or if there is excessive LED activity at low frequency operation, less DC boost must be used.</p> <p>Refer to the DC Boost Adjustment, section 5.3.3 and V/Hz Jumper Setting in section 5.3.2.</p> <p>If Option L, the Function Expander Card is installed, REFER TO THE OPTION KIT INSTRUCTIONS FOR CORRECT SETUP PROCEDURES.</p>
Symptom 7	DIAGNOSTIC PROCEDURE
<p>Motor does not return to full set speed after stalling. Red M.O.P.C. fault LED is illuminated.</p>	<p>The load torque is exceeding the torque capability of the Drive. Check for problems with the mechanical load.</p> <p>If the mechanical load checks out, try increasing the DC boost as outlined in section 5.3.3. If this does not correct the condition, consult your nearest Allen-Bradley Area Sales/Support Center for application assistance.</p> <div data-bbox="418 1350 1458 1493" style="border: 1px solid black; padding: 5px;"> <p>IMPORTANT: <i>If a continuous overload current demand exists, the motor will ramp down to a stalled condition and remain there until the overload condition no longer exists. If however the overload condition is sustained for (60) seconds, the Drive will trip and illuminate the M.O.P.C. LED on the Diagnostic Display Panel.</i></p> </div>
Symptom 8	DIAGNOSTIC PROCEDURE
<p>Red M.O.P.C. fault LED is illuminated during DECEL or at (0) Hz.</p>	<p>Boost voltage set too high. Decrease the boost voltage by setting the DC boost switch lower and/or set the Decel switch to provide a slower ramp (Refer to DC Boost Adjustment, ACCEL/DECEL Rate Adjustments, section 5.3.3).</p>

Symptom 9	DIAGNOSTIC PROCEDURE
<p>Drive starts momentarily then trips off or Drive trips off during normal operation. Red UNDER VOLTS fault LED is illuminated.</p>	<div data-bbox="402 327 1442 415" style="border: 1px solid black; padding: 5px;"><p>IMPORTANT : <i>If the Drive will not restart or reset after a fault trip, always check fuse 5FU for an open condition. Replace if necessary.</i></p></div> <p>An illuminated UNDER VOLTS LED indicates that Drive has tripped off due to an input line voltage that is less than 414V AC at the 460V AC Tap on Transformer 1T</p> <ul style="list-style-type: none">● 414V AC at the 460V AC Tap on Transformer 1T● 373V AC at the 415V AC Tap on Transformer 1T (50 Hz Input Power)● 342V AC at the 380V AC Tap on Transformer 1T (50 Hz Input Power) <p>STEP 1 – Check input primary fuse 4FU for an open condition.</p> <p>STEP 2 – Measure the input voltage to Transformer 1T. If proper voltage is present, replace Modulator Logic Board A1.</p>

Symptom 10	DIAGNOSTIC PROCEDURE
<p>Drive starts momentarily then trips off or Drive trips off during normal operation or deceleration. Red OVER VOLTS fault LED is illuminated.</p>	<p>An illuminated OVER VOLTS LED indicates that the Drive has tripped off due to a bus voltage greater than 760V DC. Three conditions can cause an over voltage trip.</p> <ul style="list-style-type: none">● Excessively High Input Voltage● DC Boost Set too High● Deceleration Rate too High for the Motor/Load Inertia <p>STEP 1 – Check the input line voltage across each phase at L1, L2, and L3. The voltage should not be greater than 506V AC.</p> <p>STEP 2 – If trip occurred during deceleration, check the position of the NORM/DEC HOLD jumper on the Modulator Logic Board. The jumper should be set to the DEC HOLD position.</p> <p>Monitor LED CR53 FREQ HOLD on the Modulator Logic Board. During deceleration, with the NORM/DEC HOLD jumper in the DEC HOLD position, the LED should light before an overvoltage trip occurs. If the LED lights, decrease the DECEL RATE, the DC BOOST, or both. Refer to the Modulator Logic Board Switch Settings in section 5.3.3. If the LED does not light, replace the Modulator Logic Board.</p> <p>STEP 3 – If the Drive trips out on over voltage during deceleration and a slower decel ramp is not acceptable, consult your nearest Allen-Bradley Area Sales/Support Center.</p>

Symptom 11

DIAGNOSTIC PROCEDURE

Drive starts momentarily then trips off or Drive trips off during normal operation. Red **PROT. A**, **PROT. B**, or **PROT. C** fault LED is illuminated.

IMPORTANT : *If the Drive will not restart or reset after a fault trip, always check fuse 5FU for an open condition. Replace if necessary.*

An illuminated **A**, **B** or **C** phase protection LED indicates:

- **An output overcurrent condition greater than 200% due to either:**

- 1) An output phase-to-phase short (Drive output, motor windings, or wiring to the motor).
- 2) An output overcurrent condition greater than 200% due to an output phase-to-ground short.

In either case, remove input power to the Drive at the disconnect device. Disconnect the motor leads from the Drive at Terminal Block **2TB**. Reapply power to the Drive and give the Drive a **START** command. If the Drive can be operated without a phase protect trip occurring, the problem is in either the wiring to the motor or the motor itself.

A ground fault can be found using an ohmmeter between the wiring to the motor and ground. Find the cause and correct it before reconnecting the motor leads to the Drive and reapplying power.

A shorted motor winding is harder to detect because of the low resistance of the motor windings. Substitute a known, good motor for the suspected bad motor. Connect the substitute motor to the Drive output terminals and try running the Drive. If successful operation of the Drive and substitute motor is achieved, then the problem most likely is the motor originally connected to the Drive.

- **Deceleration of an inertia type motor load at too high a value of DC boost or too fast a DECEL rate.**

Under the right conditions, the motor can appear as a short circuit to the Drive. With excessive DC boost applied, the motor can saturate, resulting in a peak current in excess of 200% causing a phase protect trip. Decrease the **DC BOOST**, the **DECEL RATE** or both. Refer to section 5.3.3, **DC Boost Adjustment, ACCEL/DECEL Rate Adjustment** for additional information.

- **Excessive DC boost causing a phase protection trip during acceleration.**

Excessive DC boost can cause a phase protection trip to occur during acceleration of the Drive and motor due to saturation of the motor windings.

If reducing the DC boost setting eliminates the phase protection trip but does not produce sufficient torque to enable the motor to accelerate the load, consult your nearest Allen-Bradley Area Sales/Support Center for application assistance.

Symptom 11

DIAGNOSTIC PROCEDURE

(continued)

Drive starts momentarily then trips off or Drive trips off during normal operation. Red **PROT. A**, **PROT. B**, or **PROT. C** fault LED is illuminated.

Reset the Drive by giving it a STOP command followed by a START command. If proper operation cannot be obtained without the reoccurrence of a phase protect trip and you have eliminated the preceding possibilities, the problem is most likely caused by one of the following.

- **A shorted output transistor in one of the Power Switching Modules.**

Phase "A" ... 1Q1, 1Q2

Phase "B" ... 2Q1, 2Q2

Phase "C" ... 3Q1, 3Q2

Perform the following four steps to isolate and correct the problem.

- **A malfunctioning Driver Board.**

Phase "A" ... A3A

Phase "B" ... A3B

Phase "C" ... A3C

Perform the following four steps to isolate and correct the problem.

- **A malfunctioning Driver Board causing an output power Switching Module to be ON when it shouldn't be.**

Phase "A" ... A3A

Phase "B" ... A3B

Phase "C" ... A3C

Perform the following four steps to isolate and correct the problem.

- **A malfunctioning Modulator Logic Board causing an abnormal Drive output voltage waveform.**

Perform the following four steps to isolate and correct the problem.

STEP 1 – Remove input power to the Drive. Before proceeding, wait (5) seconds. **DS1**, the bus charged neon light on Bus Discharge Board A5 (or Brake Board if Installed), should not be lit. Use a DC voltmeter to verify that the DC bus is fully discharged by measuring the voltage at connector J402 between pins **5** (+ BUS) and **1** (- BUS) on Voltage Sensing Board A4. Start with the voltmeter on its highest scale (x 1000) and range downward to the lowest voltmeter scale.

Connections Listed in Step 2 are shown in detail on pages C4-C6

STEP 2 – Check for a shorted output transistor module for the indicated phase as follows.

Disconnect all leads to **C1** at the Power Switching Module.

Disconnect all leads to **E2** at the Power Switching Module.

Unplug the molex connector for the indicated phase at the Driver Board (**J303A, B, or C**).


Symptom 11

DIAGNOSTIC PROCEDURE


(continued)

Drive starts momentarily then trips off or Drive trips off during normal operation. Red **PROT. A**, **PROT. B**, or **PROT. C** fault LED is illuminated.

For 40 & 50 HP Drives, disconnect one end of the jumper bar that is connected between terminals **E1**, **C2** on the two Power Switching Modules. This will enable you to check each transistor independently.



POWER SWITCHING MODULE ARRANGEMENT — P/N 201411



POWER SWITCHING MODULE ARRANGEMENT — P/N 120784



CAUTION: To avoid damage to the Drive, modules connected in parallel must use the same part number. This may require changing both modules in a phase even though only one module needs to be replaced.


Symptom 11

DIAGNOSTIC PROCEDURE

(continued)

Drive starts momentarily then trips off or Drive trips off during normal operation. Red **PROT. A**, **PROT. B**, or **PROT. C** fault LED is illuminated.

For 30 HP Drives, check both upper and lower transistors.



With an ohmmeter set on the x1 scale, measure the resistance between the collector and emitter of each module as follows.

<u>OHMMETER</u>		<u>READING</u>
+ LEAD	- LEAD	
C1	E1	INFINITE
C2	E2	INFINITE

With an ohmmeter set on the x1 scale, measure the resistance between the collector and base of each module as follows.

<u>OHMMETER</u>		<u>READING</u>
+ LEAD	- LEAD	
C1	B1	INFINITE
C2	B2	INFINITE

If a short is found, replace the module and check the following.

IMPORTANT : When replacing power switching modules clean all surfaces. Apply a thin layer of thermal grease (Dow Corning 340) to the back of each module. Torque mounting screws to 17-26 in-lbs max.

- DC Bus Fuse **8FU** for an open condition.
- Fuse F1 on Driver Power Supply Board A10. If fuse F1 is open, replace the board.
- Fuses F1 & F2 on the Driver Board for the indicated phase. If either fuse is open or it was noted that with input power applied either LED on the Driver Board was illuminated, replace the Driver Board. An illuminated LED indicates an open fuse which usually indicates failed components on the Driver Board.

Symptom 11

DIAGNOSTIC PROCEDURE

(continued)
Drive starts momentarily then trips off or Drive trips off during normal operation. Red **PROT. A**, **PROT. B**, or **PROT. C** fault LED is illuminated.

STEP 3 – Before reconnecting the motor, reapply input power to the Drive and ensure that the Drive operates properly in the manual operating mode. Depending upon the options installed, switch to **MANUAL** control if required. No diagnostic LEDs should be illuminated. If satisfactory operation is achieved, reconnect the motor and check operation again. If satisfactory operation is not achieved, perform **STEP 5** below.

STEP 4 – Once proper operation is achieved in the manual mode, depending on the options installed, check operation in the auto or normal operating mode. If Drive is not functioning properly in the normal mode, check all Modulator Board jumper settings and input signals to the option cards. If satisfactory operation is not achieved, perform **STEP 5** below.

(REFER TO THE OPTION KIT INSTRUCTIONS FOR CORRECT SETUP PROCEDURES)

STEP 5 – Check for proper operation of the current sensing circuits on the Modulator Logic Board and the Driver Board for the indicated phase.

With the motor rotor locked and boost set to zero, adjust the ACCEL RATE setting, switch **S1** on Modulator Logic Board A1, to 1.2 Hz/Sec. Set the operator speed pot or speed reference to zero.

After completing the above, start the Drive and slowly increase the speed while monitoring the output motor current on any phase using a true RMS reading clamp on ammeter.

The **M.O.P.C.** LED on the Modulator Logic Board should light when the current reaches a nominal value of 110%. If the **M.O.P.C.** LED does not light, use an oscilloscope to check for a pulsed waveform at the following pins on connector **J113** of the Modulator Logic Board with respect to Drive common.

Pin 5 – ØA Driver Signal

Pin 16 – ØB Driver Signal

Pin 27 – ØC Driver Signal

If pulse signals that go to a TTL level "0" are not present, replace Driver Board A3.

If pulse signals are present on all (3) sections of the Driver Board, replace Modulator Logic Board A1.

Return the boost and accel rate adjustments to their normal settings.

Symptom 12

DIAGNOSTIC PROCEDURE

Drive starts momentarily then trips off or Drive trips off during normal operation. Red **BRAKE OVER TEMP.** fault LED is illuminated.
(Used only when equipped with the Dynamic Brake Option).

IMPORTANT : *If Drive will not restart or reset after a fault trip, always check fuse 5FU for an open condition. Replace if necessary.*

An illuminated **BRAKE OVER TEMPERATURE** LED indicates an excessive brake resistor assembly temperature. This condition is normally caused by either excessive braking or a deceleration rate too high for the motor/load inertia. When the Dynamic Brake Option is used, it is recommended that the **NORM/DEC HOLD** jumper be set to the **DEC HOLD** position.

If neither of the above is true, check for:

- **Open Precharge Fuse 5FU and/or Shorted Brake Transistor 4Q**
- **Malfunctioning Brake Resistor Thermal O.L.** (2TAS on Brake Resistor Assembly)
- **Poorly Ventilated Resistor Enclosure**

Check and repair as required.

IMPORTANT : **To reset a Brake Over Temperature Trip:**

1. *Remove input power to the Drive at the disconnect device.*
2. *Wait a few minutes to allow the O.L. heater and brake resistor to cool down.*
3. *Open the conduit box on the resistor cage assembly. Manually reset Thermal O.L. Relay 2TAS by depressing the plunger until a reset "click" is either heard or felt.*
4. *Reapply power to the Drive at the disconnect device.*
5. *Reset the Drive by giving it a STOP command followed by a START command.*

Symptom 13

DIAGNOSTIC PROCEDURE

Drive starts momentarily then trips off or Drive trips off during normal operation. Red **DRIVE OVER TEMP.** fault LED is illuminated.

IMPORTANT : *If the Drive will not restart or reset after a fault trip, always check fuse 5FU for an open condition. Replace if necessary.*

An illuminated **DRIVE OVER TEMPERATURE** LED indicates that the Drive has tripped off due to an over temperature condition. Allow the Drive to cool down for approximately (15) minutes before restarting. After restarting, if an over temperature condition occurs again, check for the following conditions.

- **Ambient Temperature that Exceeds the Drive Rating.** Measure the ambient temperature surrounding the Drive per the **Specification Table, Chapter 3.**
- **Heat Flow Obstruction within the Heat Sink Assembly.** Visually inspect for unobstructed spacing between fins. Clean if necessary.
- **Drive Fan Obstruction, Open Fan Fuse 7FU or Malfunctioning Fan.** Check and replace as required.
- **Open Winding or Connection to Transformer 3T.** Check for 115V AC between terminals 5 & 6 on transformer 3T. Replace if required.
- **Thermal Overloading Caused by Duty Cycle Demands Exceeding 100% of Current Over an Extended Period of Time.** Using an AC clamp on ammeter, measure the motor current over an extended period of time.

IMPORTANT : *Clamp on type amp probes and current transformers are frequency sensitive. Inaccurate current readings at frequencies other than 60 Hz may be observed. It is recommended that a true RMS reading clamp on ammeter be used.*

- **Malfunctioning Temperature Sensor 1TAS.** If all of the above conditions have been checked and the problem still remains, replace Temperature Sensor 1TAS.

IMPORTANT : *When replacing Temperature Sensor 1TAS clean all surfaces. Apply a thin layer of thermal grease (Dow Corning 340) to the back of the sensor. Torque mounting screws to 2.6-3.0 in-lbs max.*

Symptom 14

DIAGNOSTIC PROCEDURE

Drive starts momentarily then trips off or Drive trips off during normal operation. Red **OUTPUT GND** fault LED is illuminated.

IMPORTANT : *If the Drive will not restart or reset after a fault trip, always check fuse 5FU for an open condition. Replace if necessary.*

An illuminated **OUTPUT GROUND** LED indicates that the Drive circuitry has shorted to ground or there is a malfunctioning Output Ground Sensor Board A8.

Remove input power to the Drive and disconnect the motor from the Drive. Reapply input power and start the Drive.

If the Drive does not trip, check the motor for a grounded phase condition. Replace or repair the motor if required.

If the Drive trips with the motor disconnected, check wire insulation and terminal connections on the Drive Chassis for shorts to ground. If the problem still cannot be located, replace Output Ground Sensor Board A8.

Symptom 15

DIAGNOSTIC PROCEDURE

Bus voltage does not discharge within (5) seconds when input power is removed. Neon light **DS1** on Bus Discharge Board A5 (or Brake Board if installed) is illuminated.

After input power is removed the bus voltage should discharge to 42V DC in approximately (5) seconds if the discharge cycle is taking place. If the discharge cycle is not taking place, check to see if fuse **F1** or resistor **R13** on Bus Discharge Board A5 has opened.

STEP 1 - If neither the fuse nor the resistor is open, measure the AC voltage at Bus Discharge Board A5, connector **J502**, between pins 1 & 4. The voltage should be approximately 12V AC. If voltage is present, replace Bus Discharge Board A5

STEP 2 - If resistor **R13** is open, replace Bus Discharge Board A5 and reapply input power.

If fuse **F1** is open, replace and reapply input power.

Check for proper bus discharge cycle by measuring the DC Bus voltage at Bus Discharge Board A5, connector **J503**, between pins 1 (+ BUS) and 11 or 12 (- BUS). After approximately (5) seconds the voltage should be below 42V DC. If discharge cycle is still not taking place and/or either the fuse or resistor opens again, replace Bus Discharge Board A5.

G

Bulletin 1334 3-10 HP Series B Drive Schematics


3-10 HP Series B Unit Schematic

- ① REFER TO APPENDIX A FOR FUSE VALUE
- ② DO NOT USE THE 90V AC OPTION SUPPLY FOR ANYTHING OTHER THAN THE CONTROL SCHEMES SHOWN IN SECTION 4.4
- ③ JUMPER REMOVED AND SHUNT INSTALLED WHEN OUTPUT DIGITAL AMMETER IS CONNECTED
- ④ REMOVE JUMPER WHEN CONNECTING OPTION


□ BULLETIN 1334 OPTIONS

—+ BUS


—- BUS




TO TB-17 TO TB-18



3-10 HP Series B Power Distribution Board Schematic




- ① REFER TO BULLETIN 1334 ... 3, 5, 7, 8, & 10 HP UNIT SCHEMATIC
- ② DO NOT USE THE 90V AC OPTION SUPPLY FOR ANYTHING OTHER THAN THE CONTROL SCHEMES SHOWN IN SECTION 4.4
- ③ REMOVE JUMPER WHEN CONNECTING OPTION
- ④ JUMPER REMOVED AND SHUNT INSTALLED WHEN OUTPUT DIGITAL AMMETER IS CONNECTED
- ⑤ REFER TO APPENDIX A FOR FUSE VALUE





H

Bulletin 1334 15-25 HP Series A Drive Schematics

15 & 20 HP Unit Schematic












Bulletin 1334 30-50 HP Series A Drive Schematics




30 HP Unit Schematic






40 & 50 HP Unit Schematic






Bulletin 1334 Modulator Logic Board Interconnection Diagrams


3-10 HP Series B Modulator Logic Board Interconnection Diagram






15-50 HP Series A Modulator Logic Board Interconnection Diagram


- ① DO NOT USE THE 90V AC OPTION SUPPLY FOR ANYTHING OTHER THAN THE CONTROL SCHEMES SHOWN IN SECTION 4.4
- ② REMOVE JUMPER WHEN CONNECTING OPTION




**SET-POINT FREQUENCY CONTACT CARD
OPTION W2**




- LOCAL DIGITAL THUMBWHEEL CARD
OPTION G
— OR —
- REMOTE DIGITAL THUMBWHEEL CARD
OPTION G2
— OR —
- BCD INTERFACE CARD
OPTION G4
— OR —
- ISOLATED SIGNAL CONDITIONER CARD
OPTION N
— OR —
- ISOLATED SIGNAL CONDITIONER CARD
OPTION N4




MODULATOR LOGIC BOARD A1




RIBBON CABLE
TO J701
DIAGNOSTIC BOARD A7



SEGMENT #3 TO DRIVER BOARD A3C
J113-23
TO
J301-1




SEGMENT #2 TO DRIVER BOARD A3B
J113-12
TO
J301-1



SEGMENT #1 TO DRIVER BOARD A3A
J113-1
TO
J301-1

SPLIT 34 WIRE RIBBON CABLE




RIBBON CABLE TO
OUTPUT DIGITAL AMMETER
OPTION A, A2

RIBBON CABLE TO
OUTPUT DIGITAL VOLTMETER CARD
OPTION B, B2

RIBBON CABLE TO
PROGRAMMABLE SPEED METER CARD
OPTION E


Bulletin 1334 Modulator Logic Board Plug-In Options

CARD EDGE CONNECTOR J107




Bulletin 1334 Modulator Logic Board Plug-In Options


CARD EDGE CONNECTOR J102




-OR-



-OR-




-OR-




Bulletin 1334 Modulator Logic Board Plug-In Options

CARD EDGE CONNECTOR J104




Bulletin 1334 Modulator Logic Board Plug-In Options

CARD EDGE CONNECTOR J105




— OR —




Bulletin 1334 Modulator Logic Board Plug-In Options


CARD EDGE CONNECTOR J103




- OR -




- OR -



- OR -



- OR -





How Can We Improve ?

We would appreciate your comments on the usefulness and readability of this manual. Please take a few moments to complete the following questions. If desired, provide specific examples that would make this manual a more useful tool.

PUBLICATION NAME _____

PUBLICATION NUMBER AND DATE _____

✓ PLEASE RATE THE FOLLOWING ITEMS

- COMPARED TO SIMILAR MANUALS, THIS MANUAL IS . . . BETTER AS GOOD POOR
- ORGANIZATION OF MATERIAL IS . . . GOOD ADEQUATE POOR
- EASE OF READING IS . . . GOOD ADEQUATE POOR
- LEVEL OF INFORMATION IS . . . GOOD ADEQUATE POOR
- PHOTOGRAPHS AND/OR ILLUSTRATIONS ARE . . . GOOD ADEQUATE POOR
- THE AMOUNT OF INFORMATION WAS . . . TOO MUCH TOO LITTLE JUST RIGHT
- THE METHOD OF PAGE BINDING IS . . . GOOD ADEQUATE POOR

✓ DID YOU FIND ANY ERRORS ?

PAGE _____ ERROR _____

PAGE _____ ERROR _____

PAGE _____ ERROR _____

✓ WERE THERE ANY AREAS THAT WERE NOT CLEAR OR HARD FOR YOU TO UNDERSTAND ?

PAGE _____ DESCRIBE _____

PAGE _____ DESCRIBE _____

PAGE _____ DESCRIBE _____

✓ COMMENTS?

YOUR POSITION . . . MAINTENANCE ENGINEER MANAGERIAL OTHER _____

EXPERIENCE WITH MOTION CONTROLS . . . VERY EXPERIENCED SOMEWHAT EXPERIENCED LIMITED EXPERIENCE

✓ COMPLETE THE FOLLOWING, IF DESIRED

YOUR NAME _____ TITLE _____

COMPANY NAME _____

ADDRESS _____

CITY _____ STATE _____ ZIP _____

THANK YOU FOR HELPING US TO SERVE YOU BETTER !!

CUT ALONG DOTTED LINE


FOLD HERE

FOLD HERE



BUSINESS REPLY MAIL
FIRST CLASS PERMIT NO. 413 MEQUON, WI

NO POSTAGE
NECESSARY
IF MAILED
IN THE
UNITED STATES



POSTAGE WILL BE PAID BY ADDRESSEE

ALLEN-BRADLEY
Attn: Marketing Communications
Motion Control Division
P.O. Box 760
Mequon, WI 53092-9907



Notes

Notes

Notes

Notes

Notes

Notes



ALLEN-BRADLEY
A ROCKWELL INTERNATIONAL COMPANY

A subsidiary of Rockwell International, one of the world's largest technology companies, Allen-Bradley meets today's automation challenges with over 85 years of practical plant floor experience. More than 12,000 employees throughout the world design, manufacture and apply a wide range of control and automation products and supporting services to help our customers continuously improve quality, productivity and time to market. These products and services not only control individual machines, but also integrate the manufacturing process while providing access to vital plant floor data that can be used to support decision-making throughout the enterprise.

With offices in major cities worldwide.

WORLD HEADQUARTERS

Allen-Bradley
1201 South Second Street
Milwaukee, WI 53204 USA
Tel: (1) 414 382-2000
Telex: 43 11 016
Fax: (1) 414 382-4444

**EUROPE/MIDDLE EAST/
AFRICA HEADQUARTERS**

Allen-Bradley Europe B.V.
Amsterdamseweg 15
1422 AC Uithoorn
The Netherlands
Tel: (31) 2975/43500
Telex: (844) 18042
Fax: (31) 2975/60222

ASIA/PACIFIC HEADQUARTERS

Allen-Bradley (Hong Kong) Limited
Room 1006, Block B, Sea View Estate
2-8 Watson Road
Hong Kong
Tel: (852) 887-4788
Telex: (780) 64347
Fax: (852) 510-9436

CANADA HEADQUARTERS

Allen-Bradley Canada Limited
135 Dundas Street
Cambridge, Ontario N1R 5X1
Canada
Tel: (1) 519 623-1810
Fax: (1) 519 623-8930

**LATIN AMERICA
HEADQUARTERS**

Allen-Bradley
1201 South Second Street
Milwaukee, WI 53204 USA
Tel: (1) 414 382-2000
Telex: 43 11 016
Fax: (1) 414 382-2400