

LX-Series Iron Core Linear Servo Motors

Catalog Numbers

LX030100x, LX030200x, LX030300x, LX030400x, LX030600x, LX030800x,
LX050100x, LX050200x, LX050300x, LX050400x, LX050600x, LX050800x,
LX075100x, LX075200x, LX075300x, LX075400x, LX075600x, LX075800x,
LX100100x, LX100200x, LX100300x, LX100400x, LX100600x, LX100800x,
LX150100x, LX150200x, LX150300x, LX150400x, LX150600x, LX150800x,
LX200100x, LX200200x, LX200300x, LX200400x, LX200600x, LX200800x



Important User Information

Solid-state equipment has operational characteristics differing from those of electromechanical equipment. Safety Guidelines for the Application, Installation and Maintenance of Solid State Controls (publication [SGL-1.1](#) available from your local Rockwell Automation sales office or online at <http://www.rockwellautomation.com/literature/>) describes some important differences between solid-state equipment and hard-wired electromechanical devices. Because of this difference, and also because of the wide variety of uses for solid-state equipment, all persons responsible for applying this equipment must satisfy themselves that each intended application of this equipment is acceptable.

In no event will Rockwell Automation, Inc. be responsible or liable for indirect or consequential damages resulting from the use or application of this equipment.

The examples and diagrams in this manual are included solely for illustrative purposes. Because of the many variables and requirements associated with any particular installation, Rockwell Automation, Inc. cannot assume responsibility or liability for actual use based on the examples and diagrams.

No patent liability is assumed by Rockwell Automation, Inc. with respect to use of information, circuits, equipment, or software described in this manual.

Reproduction of the contents of this manual, in whole or in part, without written permission of Rockwell Automation, Inc., is prohibited.

Throughout this manual, when necessary, we use notes to make you aware of safety considerations.



WARNING: Identifies information about practices or circumstances that can cause an explosion in a hazardous environment, which may lead to personal injury or death, property damage, or economic loss.



ATTENTION: Identifies information about practices or circumstances that can lead to personal injury or death, property damage, or economic loss. Attentions help you identify a hazard, avoid a hazard, and recognize the consequence



SHOCK HAZARD: Labels may be on or inside the equipment, for example, a drive or motor, to alert people that dangerous voltage may be present.



BURN HAZARD: Labels may be on or inside the equipment, for example, a drive or motor, to alert people that surfaces may reach dangerous temperatures.

IMPORTANT Identifies information that is critical for successful application and understanding of the product.

Preface	About This Publication.....	5
	Who Should Use This Manual.....	5
	Additional Resources.....	5
	 Chapter 1	
Safety Considerations	Introduction.....	7
	Labels.....	7
	High Energy Magnets.....	9
	Unpacking and Handling.....	9
	Air Freight Restrictions.....	9
	Vertical or Incline Installation.....	10
	Operational Guidelines.....	11
	 Chapter 2	
Start	Introduction.....	13
	Catalog Number Explanation.....	14
	Linear Motor Components.....	15
	Design Consideration.....	16
	Motor Air Gap.....	16
	Bumpers, Shock Absorbers, or End Stops.....	17
	Linear Encoder.....	17
	Carriage/Heat Sink.....	17
	Maintenance.....	18
	Motor Storage.....	18
	 Chapter 3	
Install the LX-Series Linear Motor	Introduction.....	19
	Unpacking and Inspection.....	19
	Installing Linear Motor Components.....	20
	Required Tools.....	20
	Mount a Single Coil with Multiple Magnet Tracks.....	20
	Mount a Single Coil with a Single Magnet Track.....	25
	 Chapter 4	
LX-Series Linear Motor Connector Data	Introduction.....	29
	Linear Motor Coil Connectors.....	30
	Power Connector.....	30
	Thermal Protection Connector.....	30
	Hall Effect Module Connectors.....	31
	Feedback Connector.....	31
	Thermal Protection Connector.....	33
	Encoder Connector.....	33

Wire the LX-Series Linear Motor	<p>Chapter 5</p> <p>Introduction 35</p> <p>Connect the Linear Motor Coil..... 35</p> <p>Signal and Wire Definitions for Flying Lead Components 37</p> <p style="padding-left: 20px;">Linear Motor Coil 37</p> <p style="padding-left: 20px;">Hall Effect Module 38</p> <p>Making Your Own Extension Cables..... 39</p> <p>Mounting and Wiring Two Identical Coils in Tandem 40</p> <p style="padding-left: 20px;">Cables Exit to the Right 40</p> <p style="padding-left: 20px;">Cables Exit in the Center..... 41</p> <p style="padding-left: 20px;">Cables Exit on Opposite Ends 42</p>
Configure and Start Up the LX-Series Linear Motor	<p>Chapter 6</p> <p>Introduction 43</p> <p>Before You Begin 43</p> <p style="padding-left: 20px;">Motor Direction Defined..... 43</p> <p>What You Need..... 44</p> <p>Required Files 44</p> <p>Follow These Steps 45</p> <p>Update Linear Motor Database..... 45</p> <p>Set Up the Connection to Kinetix 6000, Kinetix 6500/6200, or Kinetix 2000 Drive..... 46</p> <p>Set Up the Connection to an Ultra3000 Drive..... 51</p> <p>Verify Motor Encoder Direction..... 53</p> <p>Verify Motor Encoder Resolution..... 54</p> <p>Verify Linear Motor Wiring and Function..... 54</p> <p>Additional Adjustments for Cooling Plate Option 58</p>
Interconnect Diagrams	<p>Appendix A</p> <p>Introduction 59</p> <p>Wiring Examples 59</p>
Sin/Cos Linear Encoder and Kinetix 6000 Drives	<p>Appendix B</p> <p>Introduction 69</p> <p>Kinetix 6000 Drive Feedback Connection..... 69</p> <p>Encoder Counting Direction 70</p> <p>Set Up the Axis Properties..... 70</p>
	<p>Index</p>

About This Publication

This manual provides detailed installation instructions for mounting, wiring, and maintaining your LX-Series iron core linear servo motors.

Who Should Use This Manual

This manual is intended for engineers or technicians directly involved in the installation, wiring, and maintenance of LX-Series iron core linear motors.

If you do not have a basic understanding of linear motors, contact your local Rockwell Automation sales representative for information on available training courses before using this product.

Additional Resources

These documents contain additional information concerning related Rockwell Automation products.

Resource	Description
LX-Series Iron Core Linear Servo Motor Product Profile publication LX-PP001	Product highlights and catalog number ordering key for LX-Series linear motors
LX-Series Iron Core Linear Servo Motor Technical Data, publication LX-TD001	Specification and outline drawings for LX-Series linear motors
Kinetix 2000 Multi-axis Servo Drive User Manual, publication 2093-UM001	How to install, set up, and troubleshoot a Kinetix 2000 drive
Kinetix 6000 Multi-axis Servo Drive User Manual, publication 2094-UM001	How to install, set up, and troubleshoot a Kinetix 6000 drive
Ultra3000 Digital Servo Drives Installation Manual, publication 2098-IN003	How to install, set up, and troubleshoot an Ultra3000 drive
Ultra3000 Digital Servo Drives Integration Manual, publication 2098-IN005	
Ultra3000 Digital Servo Drives User Manual, publication 2098-UM001	Instruction on configuring Ultra3000 and Ultra5000 drives, creating and configuring project, source, and header files, and creating and running programs
Motion Analyzer CD, download at www.http://ab.com/e-tools	Drive and motor sizing with application analysis software
Motion Modules in Logix5000 Control Systems User Manual, publication LOGIX-UM002	Information on configuring and troubleshooting your ControlLogix and CompactLogix SERCOS interface modules, and using the home to torque-level sequence
System Design for Control of Electrical Noise Reference Manual, publication GMC-RM001	Information, examples, and techniques designed to minimize system failures caused by electrical noise
Kinetix Motion Control Selection Guide, publication GMC-SG001	Information about Kinetix products
Safety Guidelines for the Application, Installation, and Maintenance of Solid State Controls, publication SGI-IN001	Characteristics, application, installation, and maintenance of solid state controls

Resource	Description
Allen-Bradley Industrial Automation Glossary, publication AG-7.1	A glossary of industrial automation terms and abbreviations
Rockwell Automation Product Certification Website, publication available at www.http://www.ab.com	For declarations of conformity (DoC) currently available from Rockwell Automation
National Electrical Code. Published by the National Fire Protection Association of Boston, MA.	An article on wire sizes and types for grounding electrical equipment
Industrial Automation Wiring and Grounding Guidelines, publication 1770-4.1	Provides general guidelines for installing a Rockwell Automation industrial system

You can view or download publications at <http://www.rockwellautomation.com/literature/>. To order paper copies of technical documentation, contact your local Rockwell Automation distributor or sales representative.

Safety Considerations

Introduction

This chapter describes the safety issues encountered while using a linear motor and the precautions you can take to minimize risk. Potential hazards discussed here are identified by labels affixed to the device.

Topic	Page
Labels	7
High Energy Magnets	9
Vertical or Incline Installation	10
Operational Guidelines	11

Labels

Here you will find the safety and identification labels affixed to your linear motor components. To prevent injury and damage to the linear motor, review the safety label and its details and location before using the linear motor.

Table 1 - Safety Labels






Title	Location	Label	Details
Magnetic Field Danger	A		<p>The Magnetic Fields label identifies non-ionizing radiation found in the magnet tracks. Magnet tracks are constructed with strong magnets. Strong magnets can disrupt the functionality of automatic implantable cardioverter defibrillators (AICD); people with a pacemaker should not work near the magnet tracks. Maintenance personnel working near the magnet tracks should avoid the use of metallic tools and secure items, such as a badge clip and other personal effects, that could be attracted by the strong magnets. Strong magnets can erase magnetic media. Never let credit cards or electronic media contact or come near the magnet tracks.</p>

Table 2 - Identification Labels

Title	Location	Label	Details
Coil Nameplate	B		This nameplate shows the coil catalog number, serial number, operating voltage, and frequency.
Magnet Track Nameplate	C		This nameplate shows the magnet track catalog number, serial number, operating voltage, and frequency.
RoHS Compliant	D		LX-Series linear motor components are RoHS compliant.

Label Locations for LX-Series Linear Motor



High Energy Magnets

Linear motor magnets contain high energy magnets that attract ferrous metals from a considerable distance. Precautions must be taken while unpacking, handling, and shipping by air.

Unpacking and Handling

Unpack magnet tracks one at a time. Repack magnet tracks after inspection and before they are stocked or staged for installation. Leave protective wrapping, cardboard, and flux containment plates in place until the magnet track is installed. Clear the inspection and repacking area of any ferrous metals that will be attracted to or attract the magnetic assembly. If magnet tracks must be unpacked at the same time, maintain a distance of 1.5 m (5 ft) between assemblies.

Air Freight Restrictions

When air freighting linear motors special preparations and precautions must be taken. The following information outlines the basic requirements at the publication date of this document. However, regulations are subject to change and additional area or carrier restrictions may be imposed. Always check with your carrier or logistics specialist regarding current local, regional, and national transportation requirements when shipping this product.

Linear motor magnet tracks contain magnetized material, as classified by International Air Transport Association (IATA) Dangerous Goods Regulations. An IATA trained individual must be involved when shipping this product via domestic or international air freight. Packing Instruction 902 provides information regarding the preparation of this product for air transportation. Follow these regulations for general marking and labeling requirements, the application of specific Magnetized Material Handling Labels, and instructions for preparing the Shipper's Declaration for Dangerous Goods.

At a minimum, refer to the following IATA Dangerous Goods Regulations:

- Subsection 1.5: Training
- Subsection 3.9.2.2: Classification as Magnetized Material
- Subsection 4.2: Identification as UN 2807, Magnetized Material, Class 9, Packing Instruction 902
- Subsection 7.1.5: Marking
- Subsection 7.2: Labeling
- Subsection 7.4.1: Magnetized Material Label
- Section 8: Shipper's Declaration for Dangerous Goods

When shipped via ground in the United States, these products are **not** considered a U.S. D.O.T. Hazardous Material and standard shipping procedures apply.

Vertical or Incline Installation

A linear motor driven system mounted vertically or on an incline will not maintain position when the power is removed. Under the influence of gravity, the motion platform and its payload will fall to the low end of travel. Design engineers should allow for this by designing in controlled power-down circuits or mechanical controls to prevent the linear motor driven system and its payload from being damaged when the power fails.



ATTENTION: Linear motors are capable of high accelerations, sudden and fast motion. Rockwell Automation is not responsible for misuse, or improper implementation of this equipment.



ATTENTION: Linear motor driven systems must have end of travel bumpers. They must be designed to take a large impact from uncontrolled motion. The payload must be secured to the system such that it will not shear off in the event of an impact in excess of the bumper ratings.



ATTENTION: The Hall effect module contains an electrostatic discharge (ESD) sensitive device. You are required to follow static-control precautions when you install, test, service, or repair this assembly. If you do not follow ESD control precautions, components can be damaged. If you are not familiar with static control precautions, refer to Guarding Against Electrostatic Damage, publication [8000-4.5.2](#), or any other applicable ESD awareness handbook.



BURN HAZARD: When the linear motors are running at their maximum rating, the temperature of attached heat sinks can reach 100 °C (212 °F).



SHOCK HAZARD: An assembled linear motor will generate power if the coil or magnet track is moved. Unterminated power cables present an electrical shock hazard. Never handle flying leads or touch power pins while moving the motor.

Operational Guidelines

Please read and follow the guidelines shown here to safely operate the linear motor created from these linear motor components.



ATTENTION: Observe maximum safe speed. Linear motors are capable of very high forces, accelerations, and speeds. The maximum obtainable acceleration and speed is based on the drive output (bus voltage and current settings). The allowable maximum speed is application specific and partly based on the linear motion mechanics supplied by others.



ATTENTION: Moving parts can cause injury. Before operating the linear motor, make sure all components are secure and magnet mounting hardware is below the magnet surface. Remove all unused parts from the motor travel assembly to prevent them from jamming in the motor air gap and damaging the coil or flying off and causing bodily injury.

IMPORTANT

You are responsible for making sure the servo control system safely controls the linear motor with regards to maximum safe force, acceleration, and speed, including runaway conditions.

A runaway condition can be caused by incorrect motor, hall effect, and position feedback wiring resulting in violent uncontrolled motion.



ATTENTION: Keep away from the line of motor travel at all times. Always have bumpers in place and securely fastened before applying power to your linear motor.



ATTENTION: High voltage can kill. Do not operate with exposed wires. Do not go near electrically live parts.



ATTENTION: Large Position Error Tolerances, such as those calculated by the Auto Tune function in RSLogix 5000 programming software, or when configuring a new axis with RSLogix 5000 software, can lead to undetected and repetitive high energy impacts against axis end stops if proper precautions are not in place. These tolerances can also lead to undetected and repetitive high energy impacts against unexpected obstructions. Such impacts can lead to equipment damage and/or serious injury.

To identify the safety concerns that you have with default Position Error Tolerance or after an Auto-Tune Function go to the [Rockwell Automation Knowledgebase](#). Click Find Technical Support Answers and search for Answer Id 55937.

Notes:

Start




Introduction

Use this chapter to become familiar with the linear motor components, their maintenance needs, and their configuration.

Topic	Page
Catalog Number Explanation	14
Linear Motor Components	15
Design Consideration	16
Maintenance	18
Motor Storage	18

Catalog Number Explanation


An iron core linear motor is comprised of a coil and one or more magnet tracks. The following keys show the catalog definition for the LX-Series linear motors.



Linear Motor Components

Use the diagrams and descriptions to identify the unique components of the linear motor.

Figure 1 - Components of Iron Core Motor Coil and Magnet Track




Component Number	Component	Description
1	Iron core motor coil	Copper coils are contained in an epoxy form. When powered, the coil interacts with the flux field of the magnet track.
2	Magnet track	High powered static magnets create the flux field the powered coil interacts with.
3	Encoder connector	Connect your encoder here by using the connector kit, catalog number LDC-ENC-CNCT.
4	Feedback connector	Connect to your drive feedback by using either catalog number 2090-CFBM7DF-CDAFxx (for moving coil) or 2090-XXNFMF-Sxx (for moving magnet).
5	Power connector	Connect to your drive power by using either catalog number 2090-CPWM7DF-xxAFxx (for moving coil) or 2090-XXNPMF-xxSxx (for moving magnet).
6	Thermal protection connector	Connects the thermal protection signal to the feedback connector.
7	Hall effect module	This module provides input signals for commutation startup. Replacement catalog numbers for the Hall effect module are LDC-HALL-C for the LXxxxxxxxx1x and LDC-HALL-F for the LXxxxxxxxx0x.

Design Consideration

The information provided here is critical to using linear motor components. Design your system to comply with the following points to run safely and successfully.

Motor Air Gap

Maintaining the air gap is critical to proper installation and operation of the linear motor components. Use the coil, and magnet drawings in the LX-Series Iron Core Linear Servo Motor Technical Data, publication [LX-TD001](#) and the cooling plate drawings in the Kinetix Motion Control Selection Guide, publication [GMC-SG001](#) to calculate the installation envelope dimension. Size the carriage, bearings, and base plate to withstand the force of attraction between the coil and magnet track. By maintaining the installation envelope dimension in your design, the vertical air gap requirement will be met. The following diagram shows the critical dimensions.




Item	Description
1	Magnet track
2	Coil
3	Optional cooling plate assembly

Bumpers, Shock Absorbers, or End Stops

Include in your design a mechanical stop at each end of travel. Design the stops so they can prevent the moving mass from leaving its travel limits. Take into consideration the maximum speed and inertia of your moving mass when designing your mechanical stops. The following diagram shows a minimal system with mechanical stops.

Figure 2 - Mechanical Stops



Item	Description
1	Mechanical stops
2	Carriage/heat sink
3	Encoder readhead
4	Encoder strip

Linear Encoder

Your linear motor components need to be integrated with a linear encoder purchased from a third party.

Carriage/Heat Sink

The linear motor coil requires a heat sink to maintain performance. The heat sink requires a minimal mass and surface area as shown in LX-Series Iron Core Linear Servo Motor Technical Data, publication [LX-TD001](#). It can also serve as the carriage in a moving coil system or be designed into the base in a moving magnet system.

Maintenance

Linear motors require no maintenance when operated in relatively clean environments. For operation in harsh and dirty environments, we recommend cleaning every 6 months.

Clean the metallic debris and other contaminants from the air gap. Use a strip of masking tape to remove the metal debris. Apply a strip of tape on the magnet track and then remove it. Keeping the magnet track clean will prevent witness marks. Witness marks are caused by metal debris being dragged across the surface of the stainless steel by the magnet field of the moving coil. Witness marks have no effect on the performance of the motor.

Motor Storage

The motor storage area should be clean, dry, vibration free, and have a relatively constant temperature. If a motor is stored on equipment, it should be protected from the weather. All motor surfaces subject to corrosion should be protected by applying a corrosion resistant coating.

Install the LX-Series Linear Motor

Introduction

In this section you will unpack, inspect, and install your linear motor components by creating your own linear motor.

Topic	Page
Unpacking and Inspection	19
Installing Linear Motor Components	20
Mount a Single Coil with Multiple Magnet Tracks	20
Mount a Single Coil with a Single Magnet Track	25

Unpacking and Inspection

Read the following guidelines to handle magnet tracks carefully.



ATTENTION: Linear motors contain powerful permanent magnets which require extreme caution during handling. When handling multiple magnet tracks do not allow the tracks to come in contact with each other. Do not disassemble the magnet tracks. The forces between tracks are very powerful and can cause bodily injury. Persons with pacemakers or Automatic Implantable Cardiac Defibrillator (AICD) should maintain a minimum distance of 0.33 m (1 ft) from magnet assemblies. Additionally, unless absolutely unavoidable, a minimum distance of 1.5 m (5 ft) must be maintained between magnet assemblies and other magnetic/ferrous composite materials. Use only non-metallic instrumentation when verifying assembly dimension prior to installation.

Inspect motor components and verify they are damage free. Any damage or suspected damage should be immediately documented. Claims for damage due to shipment are usually made against the transportation company. Contact Rockwell Automation for further advice:

- Compare the purchase order with the packing slip.
- Check the quantity of magnet tracks received matches your job requirements.
- Identify the options that came with your linear motor.
- Inspect the assemblies and confirm the presence of specified options.

Installing Linear Motor Components

Use one of the following procedures to install the magnet track or tracks and the motor coil.

Required Tools

- Aluminum straight edge
- Non-magnetic M4 or M5 hex wrench
- Magnet channel alignment tool

IMPORTANT The alignment tool is shipped attached to the cables next to the Hall effect module. Remove before operating the linear motor.

TIP Use non-magnetic tools and hardware made of beryllium copper, 300 series stainless steel. If these tools are not available, proceed carefully as the magnet track attracts magnetic and ferrous items.

Mount a Single Coil with Multiple Magnet Tracks

Follow these steps to install a single coil with multiple magnet tracks.



ATTENTION: To avoid damage due to the magnetic attraction between the magnet tracks, maintain a minimum distance of 1.5 m (5 ft) between the magnet tracks that are being installed and the magnet tracks awaiting installation. Keep the protective cardboard and the metal plate in place until the installation is complete.



ATTENTION: Never attempt to place the coil assembly directly on the magnet plates. Strong magnetic attraction will cause uncontrolled movement causing a pinch hazard and possible damage to the components.

1. Clear the magnet track mounting surface of foreign material.


If necessary stone the mounting surface, acetone or methanol may be applied as cleaning agent.

IMPORTANT Do not use abrasives to clean the surface.

2. Verify the flatness of the surface to which the magnet track is to be mounted.

Total Indicator Reading (TIR) is 0.127 mm (.005 in.) per 300 mm (12.0 in.). TIR or runout correlates to the overall flatness requirement of the surface.

3. Verify the dimension of the opening for the magnet track, coil, and cooling plate if used.
4. Remove all burrs and clean the motor coil mounting surface.
5. Position the carriage toward the end of travel where you want the cable to exit.
6. Install the motor under the carriage, using M5 x 0.8 bolts that extend through the slide by at least 12 mm (0.5 in.), but no more than 20 mm (0.7 in.).




7. Tighten the screws but do not torque.

8. On the opposite end of the base, install the first magnet track using M5 x 0.8 x 16 mm Socket Head Captive Screw (SHCS).


Do not tighten screws.

IMPORTANT Use non-magnetic tools and hardware such as beryllium copper, 300 series stainless steel. If not available proceed with care since ferrous items will be attracted to the magnet tracks.



9. Install additional magnet tracks.

Place each magnet track on the base and slide towards the previously install magnet track. For correct magnetic polarity the alignment holes should all be on the same side.




- 10.** Move the carriage with motor coil installed over the installed magnet tracks.


There may be some resistance while moving onto the tracks, this is normal.

- 11.** Measure the gap between the motor coil and magnet track using plastic shim stock.

The gap should be 0.79 mm (0.031 in.) to 1.70 mm (0.067 in.). If gap is too large, add a brass or a stainless steel shim between the motor coil and carriage. If the gap is too small, machine the slide or place shims under the bearing pucks.




- 12.** Install the remaining magnet tracks in the order shown.



- 13.** Slightly loosen the mounting screws on the exposed magnet tracks.

Do not loosen the magnet tracks that are covered by the motor coil.

14. Align the magnet tracks with an aluminum straight edge, and the supplied alignment tool.



15. Place the alignment tool in the holes on each of the magnet tracks.
16. Align the edges of the magnet tracks with the aluminum straight edge and tighten the bolts.
17. Position the carriage over the complete sections and continue aligning the remainder of the magnet tracks.

TIP If space limitation prevents the use of an aluminum straight edge. Place a 0.5 mm (0.020 in.) plastic shim between the magnet tracks, tighten the bolts, and then remove the shim.

18. Torque all screws to the values listed in the table, securing assemblies in place by using all mounting holes.

SHCS	SHCS Torque	
	Black Oxide Steel N•m (lb•ft)	Stainless Steel N•m (lb•ft)
M5	9.5 (7.0)	6.36 (4.7)




ATTENTION: Remove the alignment tool and make certain all magnet-track mounting hardware is flush or below the magnet surface to prevent damage to the coil.


Mount a Single Coil with a Single Magnet Track

Follow these steps to install a single coil with single magnet track.

1. Install the magnet track by using M5 x 0.8 x 16 mm SHCS.




2. Remove any burrs and clean the motor-coil mounting surface.
3. Install the motor coil under the carriage, by using M5 x 0.8 screws that extend through the carriage by at least 12 mm (0.5 in.), but no more than 20 mm (0.7 in.).




4. Tighten screws but do not torque them.
5. Slide the carriage assembly onto the bearing pucks.

There will be resistance from magnetic forces while moving onto the bearing pucks; this is normal.




6. Attach the carriage assembly to the bearing pucks.



7. Measure the gap between the motor and magnet by using plastic shim stock.

The gap should be 0.79...1.70 mm (0.031...0.067 in.). If the gap is too large, add a brass or stainless steel shim between the motor and carriage. If the gap is too small, machine the carriage or place shims under the bearing pucks.



8. Torque all screws to the values listed in the table, securing assemblies in place by using all mounting holes.

SHCS	SHCS Torque	
	Black Oxide Steel N•m (lb•ft)	Stainless Steel N•m (lb•ft)
M5	9.5 (7.0)	6.36 (4.7)



ATTENTION: Remove the alignment tool and make certain all the magnet-track mounting hardware is flush or below the magnet surface to prevent damage to the coil.

Notes:

LX-Series Linear Motor Connector Data

Introduction

This chapter provides power, thermistor, and Hall effect cable-connector information for the linear motor coil and Hall effect module.

Topic	Page
Linear Motor Coil Connectors	30
Hall Effect Module Connectors	31


Linear Motor Coil Connectors

There are two connectors on the linear motor coil, catalog number LXxxxxxxxNxxxx; the power connector and the thermal protection connector.

Power Connector

The following tables identifies the power signals for the DIN-style circular connector.

Pin	Color	Signal
A	Red	U (A) Phase
B	White	V (B) Phase
C	Black	W (C) Phase
D	Green/Yellow	Ground
Case	Shield	Cable Shield and GND



Intercontec P/N BKUA090NN00420220000
Mating Connector Kit Allen-Bradley 2090-KPBM4-12AA




ATTENTION: Properly ground the coil as described in this manual and the drive manual.

Thermal Protection Connector


These are the feedback connector pinouts for the LX-Series linear motor, catalog number LXxxxxxxxxSxxx.

Pin	Description	Signal
1	Thermal Switch +	TS+
3	Thermal Switch -	TS-
4	–	Reserved



These are the feedback connector pinouts for the LX-Series linear motor, catalog number LXxxxxxxxxTxxx.

Pin	Description	Signal
1	PTC thermistor +	TS+
3	PTC thermistor -	TS-
4	–	Reserved




Hall Effect Module Connectors

The following tables show the pinouts of the LX-Series linear motors with the Hall effect module, catalog number LXxxxxxxxxHxxxx.

Feedback Connector


These are the feedback connector pinouts for the LX-Series linear motor, catalog number LXxxxxxxxxHSxxx.

Pin	Description	Signal
1	A quad B TTL (1V p-p), + A differential	AM+ (SIN+)
2	A quad B TTL (1V p-p), - A differential	AM- (SIN-)
3	A quad B TTL (1V p-p), + B differential	BM+ (COS+)
4	A quad B TTL (1V p-p), - B differential	BM- (COS+)
5	TTL + index mark differential	IM+
6	TTL - index mark differential	IM-
7	Reserved	-
8		
9	Encoder and Hall sensor power	+5V DC
10	Common	Common
11	Reserved	-
12	Common	Common
13	Thermal switch +	TS+
14	Thermal switch -	TS-
15	TTL - trapezoidal Hall commutation	S1
16	TTL - trapezoidal Hall commutation	S2
17	TTL - trapezoidal Hall commutation	S3
Case	Shield	-



These are the feedback connector pinouts for the LX-Series linear motor catalog number LXxxxxxxxxHTxxx.


Pin	Description	Signal
1	A quad B TTL (1V p-p), + A differential	AM+ (SIN+)
2	A quad B TTL (1V p-p), - A differential	AM- (SIN-)
3	A quad B TTL (1V p-p), + B differential	BM+ (COS+)
4	A quad B TTL (1V p-p), - B differential	BM- (COS+)
5	TTL + index mark differential	IM+
6	TTL - index mark differential	IM-
7	Reserved	-
8		
9	Encoder and Hall sensor power	+5V DC
10	Common	Common
11	Reserved	-
12	Common	Common
13	PTC thermistor sensor +	TS+
14	PTC thermistor sensor -	TS-
15	TTL - trapezoidal Hall commutation	S1
16	TTL - trapezoidal Hall commutation	S2
17	TTL - trapezoidal Hall commutation	S3
Case	Shield	-



Thermal Protection Connector


These are the thermal protection connector pinouts for the LX-Series linear motor, catalog number LXxxxxxxxxHSxxx.

Pin	Description	Signal
1	Thermal switch +	TS+
4	Reserved	–
3	Thermal switch -	TS-



These are the thermal protection connector pinouts for the LX-Series linear motor, catalog number LXxxxxxxxxHTxxx.


Pin	Description	Signal
1	PTC thermistor sensor +	TS+
4	Reserved	–
3	PTC thermistor sensor -	TS-



Encoder Connector

These are the encoder connector pinouts

Pin	Description	Signal
1	A quad B TTL, + A differential	AM+
2	A quad B TTL, + B differential	BM+
3	TTL + index mark differential	IM+
4	A quad B TTL, - A differential	AM-
5	A quad B TTL, - B differential	BM-
6	TTL - index mark differential	IM-
7	5V DC return	Common
8	Encoder and Hall sensor power	+5V DC
9	Shield drain	–



Mating connector available as part of encoder connector kit, catalog number LDC-ENC-CNCT.

Notes:

Wire the LX-Series Linear Motor

Introduction

This section shows you how to wire your LX-Series linear motor.

Topic	Page
Connect the Linear Motor Coil	35
Signal and Wire Definitions for Flying Lead Components	37
Making Your Own Extension Cables	39
Mounting and Wiring Two Identical Coils in Tandem	40

Connect the Linear Motor Coil

Use the following procedure to connect your linear motor, catalog number LXxxxxxxxx1x.

1. Wire your encoder to the connector by using the Encoder Connector Kit, catalog number LDC-ENC-CNCT, and the connector data on [page 33](#).



ATTENTION: Be sure that cables are installed and restrained to prevent uneven tension or flexing at the cable connectors. Use the Bulk Head Connector Kit, catalog number LDC-BULK-HD, for mounting these connectors.

Excessive and uneven lateral force at the cable connectors may result in the connector's environmental seal opening and closing as the cable flexes.

Failure to observe these safety precautions could result in damage to the motor and its components.

2. Connect your encoder to the encoder connector on the Hall effect module.
3. Attach the motor feedback and power cables.



ATTENTION: Do not connect or disconnect the motor feedback cable or the power cable while power is applied. It may result in unexpected motion or cause damage to the components.

- a. If using a quick-connect connector, remove the o-ring before making the connection.

b. If using thread type connectors, leave the o-ring in place.




ATTENTION: Remove the o-ring when using a quick-connect connector. The o-ring will block the locking mechanism, rendering it ineffective.

A threaded connector will fit on the male connector with or without the o-ring. If the o-ring is not used on a threaded connector, the connection will eventually vibrate loose.

c. Align flats on each connector.

Do not apply excessive force when mating the cable and motor connectors. If the connectors do not go together with light hand force, realign and try again.



Item	Description
1	Power connector
2	Feedback connector
3	Encoder connector
4	Connect your encoder using Encoder Connector Kit, catalog number LDC-ENC-CNCT
5	Feedback Extension Cable, catalog number 2090-CFB7DF-CDAFxx or 2090-XXNFMF-Sxx
6	Power Extension Cable, catalog number 2090-CPWM7DF-xxAFxx or 2090-XXNPMF-xxSxx



ATTENTION: Be sure that cables are installed and restrained to prevent uneven tension or flexing at the cable connectors. Excessive and uneven lateral force at the cable connectors may result in the connector's environmental seal opening and closing as the cable flexes. Failure to observe these safety precautions could result in damage to the motor or encoder.

- d. For the quick-connect connector, push the connector on and apply a quarter turn.
- e. For the threaded connector, hand-tighten the knurled collar with five to six turns to fully seat the connector.



ATTENTION: Keyed connectors must be properly aligned and hand-tightened the recommended number of turns. Improper alignment is indicated by the need for excessive force, such as the use of tools, to fully seat connectors. Connectors must be fully tightened for connector seals to be effective. Failure to observe these safety precautions could result in damage to the motor, cables, and connector components.

Signal and Wire Definitions for Flying Lead Components

For linear motors, catalog numbers LXxxxxxxxxxx0x, wire them by using the wiring diagram on [page 61](#). Wire colors and signal types are shown here; for wire gauge information see LX-Series Iron Core Linear Servo Motor Technical Data, publication [LX-TD001](#).

Linear Motor Coil

These are the wire colors and signals for the linear motor-coil power and thermal protection cables, catalog numbers LXxxxxxxxxxx0x.

Table 3 - Power Signals

Color	Signal	Comments
Red	Motor Phase U (A)	<ul style="list-style-type: none"> Observe maximum applied voltage specification. Consult the drive manual or supplier for specific wiring instructions to the drive. Wiring is phase/commutation sensitive.
White	Motor Phase V (B)	
Black	Motor Phase W (C)	
Green	Motor Ground	<ul style="list-style-type: none"> Terminate per drive manual instructions. Shield is not connected to the motor frame.
Shield	Cable Shield	



ATTENTION: Disconnect the input power supply before installing or servicing the motor. Motor lead connections can short and cause damage or injury if not well secured and insulated. Insulate the connections, equal to or better than the insulation on the supply conductors. Properly ground the motor per the selected drive manual.

These are the PTC thermistor sensor wire colors and signals for the linear motor coil power and thermal protection cables, catalog number LXxxxxxxxxSx0x.

Table 4 - PTC Thermistor Sensor Signals

Color	Description Signa	I
Black	PTC thermistor sensor +	TS+
Black	PTC thermistor sensor -	TS-

These are the thermal switch wire colors and signals for the linear motor coil power and thermal protection cables, catalog number LXxxxxxxxxTx0x.

Table 5 - Thermal Switch Signals

Color	Description	Signal
Blue	Thermal switch +	TS+
Blue	Thermal switch -	TS-

Hall Effect Module

This table shows the signal and wire colors for the Hall effect module with flying leads, Rockwell Automation catalog number LDC-HALL-F for LXxxxxxF/Gxxxx motor coils and Anorad part number B91781-D for LXxxxxxD/Exxxx motor coils..

Color	Signal	Signal Spec
Red	+V	5...24V DC Hall supply, 20 mA.
Black	VRTN	Hall effect signal common.
White	S1	-
Blue	S2	
Orange	S3	
Silver braid	Cable shield	Terminate at drive end per drive manual instructions.

Making Your Own Extension Cables

Flying lead coil and Hall effect modules require circular DIN-style connectors to interface with Allen-Bradley extension cables. The following connectors kits are available for terminating flying lead coils and Hall effect modules.

Connector Kit Cat. No.	Application
2090-KFBM7-CAAA	Feedback flex extension cable
2090-KPBM4-12AA	Power flex extension cable
2090-KFBE7-CAAA	Feedback non-flex extension cable
2090-KPBE7-12AA	Power non-flex extension cable

The cable length from the coil to drive should be limited to 10 m (32.8 ft). If longer cables are necessary, a 1321-3Rx-x series line reactor is required. Refer to the 1321 Power Conditioning Products Technical Data, publication [1321-TD001](#), to choose a line reactor for applications requiring cable longer than 10 m (32.8 ft).

Mounting and Wiring Two Identical Coils in Tandem

This type of installation requires a custom motor-database file, which is available upon request. Contact Application Engineering at 631.344.6600 to request this file.

These tables and figures show the wiring and spacing for two identical coils mechanically top mounted to the same plate and driven by one amplifier. There are three configurations shown here for mounting motors in tandem: power and encoder cables exiting on the right, the center, and on opposite ends.



Coils must have identical part numbers. Using mismatched coils will cause a hazardous condition resulting in damage to the equipment and a possible fire.

Cables Exit to the Right

If mounting coils in tandem, such that the power cables exit both the coils on right side, as shown, use the following table to find the mounting distance and the phase wiring.

Figure 3 - Mounting Two Coils with Cables Exit to the Right




Table 6 - Phase Wiring for Right-exit Power Cables

L mm (in.)	Coil # 1 Master ⁽¹⁾	Coil # 2 Slave ⁽²⁾	Amplifier Phase
133.33 (5.249)	Red	Red	U
	White	White	V
	Black	Black	W

(1) Master has Hall effect module.

(2) Slave has no Hall effect module.

Cables Exit in the Center

If mounting coils in tandem, such that the power cables exit in the center as shown, use the following table to find the mounting distance and the phase wiring.

Figure 4 - Mounting Two Coils with Cables Exit in the Center




Table 7 - Phase Wiring for Center-exit Power Cables

L mm (in.)	Coil # 1 Master ⁽¹⁾	Coil # 2 Slave ⁽²⁾	Amplifier Phase
133.33 (5.249)	Red	Black	U
	White	White	V
	Black	Red	W

(1) Master has Hall effect module.

(2) Slave has no Hall effect module.

Cables Exit on Opposite Ends

If mounting coils in tandem such that the power cables exit opposite to each other as shown, use the following table to find the mounting distance and the phase wiring.

Figure 5 - Mounting Two Coils with Cables Exit on Opposite Ends




Table 8 - Phase Wiring for Opposite End-exit Power Cables

L mm (in.)	Coil # 1 Master ⁽¹⁾	Coil # 2 Slave ⁽²⁾	Amplifier Phase
100.00 (3.94)	Red	Red	U
	White	Black	V
	Black	White	W
133.33 (5.249)	Red	Black	U
	White	White	V
	Black	Red	W

(1) Master has Hall effect module.

(2) Slave has no Hall effect module.

Configure and Start Up the LX-Series Linear Motor

Introduction

This section covers the set up and connection verification of a linear motor with either Kinetix 6000, Kinetix 6500/6200, Kinetix 2000, or Ultra3000 drives.

Topic	Pages
Before You Begin	43
What You Need	44
Required Files	44
Follow These Steps	45
Update the Linear Motor Database	45
Set Up the Connection to a Kinetix 6000, Kinetix 6500/6200, or Kinetix 2000 Drive	46
Set Up the Connection to an Ultra3000 Drive	51
Verify Motor Encoder Direction	53
Verify Motor Encoder Resolution	54
Verify Linear Motor Wiring and Function	54

Before You Begin

This chapter assumes you have wired your linear motor and Allen-Bradley drive as shown in wiring diagrams in [Appendix A](#) starting on [page 59](#).

IMPORTANT It is important that the brushless linear motor coil, Hall sensor, and the linear encoder be wired correctly for proper drive commutation and servo operation to get positive motion when commutated. Please read and understand [Motor Direction Defined](#).

Motor Direction Defined


Positive motion is dependent on encoder orientation, encoder wiring, and coil or magnet track motion.

Most linear encoders are attached to the motor coil with the encoder cable facing the same direction as the motor coil cable.

Wire the linear encoder such that the position feedback is positive (phase A+ leads phase B+) when the motor is moving in the positive direction.

When the motor power and Hall sensor wiring is connected as shown in the wiring diagrams in [Appendix A](#), the positive direction of motion is defined as the motor coil moving toward its power cable. This diagram shows positive motion for both a moving coil and a moving magnet track.

Figure 6 - Motor Direction



What You Need

You need a computer with RSLogix 5000 software installed and current files to support your motor.

Required Files

Firmware revisions and software versions required to support the linear motors include the following:


- RSLogix 5000 software, version 16.00 or later
- Kinetix 2000, Kinetix 6000, Kinetix 6200/6500 multi-axis drives, or Ultra3000 with SERCOS multi-axis drives
 - Firmware revision 1.96 or later
 - Customer Motor database, LXxxx.cmf
 - RSLogix 5000 Motion Database Import Tool, version 2.0.0.4 or later, this tool is not compatible with Window 7

- Ultra3000 drives without SERCOS
 - Firmware revision 1.52 or later
 - Ultraware Software, version 1.63 or later
 - Motor Database, motor_LXxxx.mdb

Call Anorad Tech Support 631-344-6600 to obtain the latest files.

Follow These Steps

The following flow chart illustrates the required steps.



Update the Linear Motor Database

Install the current Motion Database, as required, before commissioning your linear motor. See the [Required Files](#) on [page 44](#).

Set Up the Connection to a Kinetix 6000, Kinetix 6500/ 6200, or Kinetix 2000 Drive

This procedure configures the Kinetix 6000, Kinetix 6500/ 6200, or Kinetix 2000 drive for your linear motor and encoder combination.

For help in setting up your linear motor with RSLogix 5000 software, refer to [Additional Resources](#) on [page 5](#). This procedure assumes you are familiar with RSLogix 5000 software.


1. Click the Driver/Motor tab.
2. Click Change Catalog and select the appropriate motor catalog number from the following list.

Your catalog number will have a letter append to the end to indicate what drive you are using to power it: A = 230V drive and B = 460V drive.

Cat. No.	Cat. No.	Cat. No.	Cat. No.	Cat. No.	Cat. No.
LX030100DHxxxxA/B	LX050100DHxxxxA/B	LX075100DHxxxxA/B	LX100100DHxxxxA/B	LX150100DHxxxxA/B	LX200100DHxxxxA/B
LX030100FHxxxxA/B	LX050100FHxxxxA/B	LX075100FHxxxxA/B	LX100100FHxxxxA/B	LX150100FHxxxxA/B	LX200100FHxxxxA/B
LX030200DHxxxxA/B	LX050200DHxxxxA/B	LX075200DHxxxxA/B	LX100200DHxxxxA/B	LX150200DHxxxxA/B	LX200200DHxxxxA/B
LX030200EHxxxxA/B	LX050200EHxxxxA/B	LX075200EHxxxxA/B	LX100200EHxxxxA/B	LX150200EHxxxxA/B	LX200200EHxxxxA/B
LX030200FHxxxxA/B	LX050200FHxxxx	LX075200FHxxxxA/B	LX100200FHxxxxA/B	LX150200FHxxxxA/B	LX200200FHxxxxA/B
LX030200GHxxxxA/B	LX050200GHxxxx	LX075200GHxxxxA/B	LX100200GHxxxxA/B	LX150200GHxxxxA/B	LX200200GHxxxxA/B
LX030300DHxxxxA/B	LX050300DHxxxxA/B	LX075300DHxxxxA/B	LX100300DHxxxxA/B	LX150300DHxxxxA/B	LX200300DHxxxxA/B
LX030300EHxxxxA/B	LX050300EHxxxxA/B	LX075300EHxxxxA/B	LX100300EHxxxxA/B	LX150300EHxxxxA/B	LX200300EHxxxxA/B
LX030300FHxxxxA/B	LX050300FHxxxxA/B	LX075300FHxxxxA/B	LX100300FHxxxxA/B	LX150300FHxxxxA/B	LX200300FHxxxxA/B
LX030300GHxxxxA/B	LX050300GHxxxxA/B	LX075300GHxxxxA/B	LX100300GHxxxxA/B	LX150300GHxxxxA/B	LX200300GHxxxxA/B
LX030400DHxxxxA/B	LX050400DHxxxxA/B	LX075400DHxxxxA/B	LX100400DHxxxxA/B	LX150400DHxxxxA/B	LX200400DHxxxxA/B
LX030400EHxxxxA/B	LX050400EHxxxxA/B	LX075400EHxxxxA/B	LX100400EHxxxxA/B	LX150400EHxxxxA/B	LX200400EHxxxxA/B
LX030400FHxxxxA/B	LX050400FHxxxxA/B	LX075400FHxxxxA/B	LX100400FHxxxxA/B	LX150400FHxxxxA/B	LX200400FHxxxxA/B
LX030400GHxxxxA/B	LX050400GHxxxxA/B	LX075400GHxxxx	LX100400GHxxxxA/B	LX150400GHxxxxA/B	LX200400GHxxxxA/B
LX030600DHxxxxA/B	LX050600DHxxxx	LX075600DHxxxxA/B	LX100600DHxxxxA/B	LX150600DHxxxxA/B	LX200600DHxxxxA/B
LX030600EHxxxxA/B	LX050600EHxxxxA/B	LX075600EHxxxxA/B	LX100600EHxxxxA/B	LX150600EHxxxxA/B	LX200600EHxxxxA/B
LX030600FHxxxxA/B	LX050600FHxxxxA/B	LX075600FHxxxxA/B	LX100600FHxxxxA/B	LX150600FHxxxxA/B	LX200600FHxxxxA/B
LX030600GHxxxxA/B	LX050600GHxxxxA/B	LX075600GHxxxxA/B	LX100600GHxxxxA/B	LX150600GHxxxxA/B	LX200600GHxxxxA/B
LX030800DHxxxxA/B	LX050800DHxxxxA/B	LX075800DHxxxxA/B	LX100800DHxxxxA/B	LX150800DHxxxxA/B	LX200800DHxxxxA/B
LX030800EHxxxxA/B	LX050800EHxxxxA/B	LX075800EHxxxxA/B	LX100800EHxxxxA/B	LX150800EHxxxxA/B	LX200800EHxxxxA/B
LX030800FHxxxxA/B	LX050800FHxxxxA/B	LX075800FHxxxxA/B	LX100800FHxxxxA/B	LX150800FHxxxxA/B	LX200800FHxxxxA/B
LX030800GHxxxxA/B	LX050800GHxxxxA/B	LX075800GHxxxxA/B	LX100800GHxxxxA/	LX150800GHxxxxA/B	LX200800GHxxxxA/B

- Using the screen image as a reference, configure the parameters as shown in the Setting column.

Parameter	Setting	Comment
Loop Configuration	Position Servo	–
Drive Resolution	200	5 µm encoder
	500	2 µm encoder
	1000	1 µm encoder
	2000	0.5 µm encoder
	10,000	0.1 µm encoder
	51200	20 µm pitch Sin/Cos encoder
	25600	40 µm pitch Sin/Cos encoder
Drive Counts per	Motor Millimeter	–
Real Time Axis Information		
Attribute 1	Position Feedback	–



- Click OK.
- Click the Motor Feedback tab.

- Using the screen image as a reference, configure the parameters as shown in the Setting column.

Parameter	Setting	Comment
Feedback Type	TTL or Sin/Cos	For RSLogix 5000 software, version 16
	TTL with Hall or Sin/Cos with Hall	For RSLogix 5000 software, version 17
Cycles	50	5 μ m encoder
	125	2 μ m encoder
	250	1 μ m encoder
	500	0.5 μ m encoder
	2500	0.1 μ m encoder
	50	20 μ m Sin/Cos encoder
	25	40 μ m Sin/Cos encoder
per	Millimeters	—
Interpolation Factor	4	TTL
	1024	Sin/Cos

Figure 7 - RSLogix 5000 Software, Version 15.00 and 16.00, TTL Encoder




Figure 8 - RSLogix 5000 Software, Version 15.00 and 16.00, Sin/Cos Encoder




Figure 9 - RSLogix 5000 Software, Version 17.00 and Later, TTL Encoder





Figure 10 - RSLogix 5000 Software, Version 17.00 and Later, Sin/Cos Encoder




7. Click OK to sets the values.
8. Click the Units tab.
9. Using the screen image as a reference, configure the parameters as shown in the Setting column.

Parameter	Setting
Position Units	mm
Average Velocity Timebase	0.25 s

You can change position units to inches, or other units, on this tab.

EXAMPLE This is an example for a 5 μm resolution encoder:
 200 drive cnts/mm x 25.4 mm/in.
 Conversion Constant = 5080 drive cnts/in.

- Click OK to set the values.



- Click the Conversion tab.
- Using the screen image as a reference, configure the parameters as shown in the Setting column.

Parameter	Setting	Comment
Positioning Mode	Linear	–
Conversion Constant	200	5 µm encoder
	500	2 µm encoder
	1000	1 µm encoder
	2000	0.5 µm encoder
	10,000	0.1 µm encoder
	51200	20 µm pitch Sin/Cos encoder
	25600	40 µm pitch Sin/Cos encoder

- Click OK.



Set Up the Connection to an Ultra3000 Drive

This procedure configures the Ultra3000 drive for your linear motor and encoder combination.

For help using Ultraware software as it applies to setting up your linear motor, refer to [Additional Resources](#) on [page 5](#). This procedure assumes you are familiar with Ultraware software.

1. Open your Motor Configurator Utility.
2. Select the linear motor catalog number.
3. From the Edit menu, choose Duplicate.
4. Rename the Model.
5. Click Encoder Type and select either Incremental or Sin/Cos.
6. Click Lines Per Meter and enter the value.

The following tables list typical values for lines per meter.

Incremental	
Resolution	Value
10 µm	25,000
5 µm	50,000
2 µm	125,000
1 µm	250,000
0.5 µm	500,000
0.1 µm	2,500,000

Sin/Cos	
Encoder Scale Pitch	Value
100 µm	10,000
40 µm	25,000
20 µm	50,000

Figure 11 - Incremental Encoder






Figure 12 - Sin/Cos Encoder



7. Click Close.
8. Open your Ultraware software.
9. Configure your Ultra3000 drive.

10. From the Workspace dialog box, select Motor.
11. Click Motor Model.
12. Choose the model you created from the pull-down menu.
If using an incremental encoder, you are finished. For Sin/Cos encoders, continue with steps 12 and 13.
13. From the Workspace dialog box, select Encoders.
14. Click Motor Encoder Interpolation.
15. Select a value from the pull-down menu.




This table shows the encoder resolutions that could be achieved when using a 20 μm Sin/Cos encoder and different interpolation values.

Value	Encoder Resolution
X4	5 μm
X8	2.5 μm
X16	1.25 μm
X32	0.625 μm
X64	0.3125 μm
X128	0.15625 μm
X256	0.078125 μm
X512	0.0390 μm
X1024	0.01953125 μm

Verify Motor Encoder Direction

In this section, you use the monitor tags to evaluate the encoder installation.



1. Disable the drive.
2. Note the ActualPosition tag value.
3. Move the axis in the positive direction.
See [page 43](#) for definition for positive direction.
4. Verify that the ActualPosition tag value increases as the axis moves.

If the positive direction of travel does not match what has been defined by the motor power and Hall Sensing wiring, then change the direction by rewiring the encoder by using the following table.

Move		To	
Encoder Phase	Drive CN2, Pin	Encoder Phase	Drive CN2, Pin
A+	1	B+	3
A-	2	B-	4
B+	3	A+	1
B-	4	A-	2

Verify Motor Encoder Resolution

This test compares the physically measured distance to the distance calculated by the software. It also verifies the encoder setting in the RSLogix 5000 software.

1. Measure and mark a fixed distance of travel on the axis.
2. Record the ActualPosition tag value with carriage at the starting position.
3. Move the carriage to the end position.
4. Record the ActualPosition tag value.
5. Calculate the distance moved by using the record values.
6. Compare the actual distance and the calculated distance.

If the values do not match, verify the resolution of the installed encoder and the values used in the Motor Feedback, Conversion, and Units tabs.

Verify Linear Motor Wiring and Function

In RSLogix 5000 software, click the Homing and Hookup tabs to check that the motor power, Hall sensing, and the encoder signal wiring is correct.

IMPORTANT The following components must be wired correctly for your drive and linear motor to operate properly:

- Hall effect module
- Coil power wires
- Thermistor or thermal switch
- Encoder


Follow these steps to verify your motor wiring and function.

1. Click the Hookup tab.
2. Configure the parameters.

The following table shows the suggested settings.

Parameter	Suggested Setting
Test Increment	60.00 mm
Drive Polarity	Positive

3. Click OK.



4. Click Test Marker.

Refer to your encoder user documentation for the location and frequency of markers.

5. Position the coil so that it can move 60 mm (2.36 in.) in the forward or reverse direction.
6. Click Test Feedback.

Move the axis by hand at least 60 mm (2.36 in.) when prompted.

When using Allen-Bradley servo drives, match the counting direction of your position feedback encoder to the direction the motor moves when a positive current is applied.

7. Click Test Command & Feedback.

Follow the on-screen instructions.

IMPORTANT Be sure all the tests on the Hookup tab have passed before proceeding.

IMPORTANT When using a Kinetix 6000 or a Kinetix 2000 drive, the Test Command Feedback test may pass even though the Hall effect module is not wired correctly.

8. Click the Tune tab.




WARNING: Large Position Error Tolerances, such as those calculated by the Auto Tune function in the RSLogix 5000 programming software, or when configuring a new axis with the RSLogix 5000 software, can lead to undetected and repetitive high-energy impacts against axis end stops if proper precautions are not in place. These tolerances can also lead to undetected and repetitive high-energy impacts against unexpected obstructions. Such impacts can lead to equipment damage and/or serious injury.

To identify the safety concerns that you have with default Position Error Tolerance or after an Auto Tune Function, go to the [Rockwell Automation Knowledgebase](#). Click Find Technical Support Answers and search for Answer ID 55937.


9. Configure the parameters in the Tune tab as suggested in the Initial Setting column, leaving all other tune options off for your first pass.

If necessary, reduce the Velocity Loop Proportional Gain to maintain stability.



Parameter	Initial Setting	Units	Note
Travel Limit	100	mm	Suggested
Speed	250	mm/sec	–
Torque/Force	50	% Rated	–
Direction	Forward Bi-directional	–	–
Damping Factor	0.8	–	(default)

10. Click the Homing tab.
11. From the Sequence pull-down menu, choose Switch-Marker, or Torque Level-Marker when a repeatable power-up position is desired.



Typical linear TTL and Sin/Cos encoders will home repeatability to within one count of resolution when their index mark is used.

TIP The Torque Level-Marker is not available for the Kinetix 6500 drive or Ultra3000 drive with SERCOS. There is an Add On Instruction for Home to Torque for the Kinetix 6500 drive that is available in the [Sample Code Library](#) under the title [CIP Axis Home To Torque AOI](#).


Additional Adjustments for Cooling Plate Option

If your linear servo motor has the cooling plate option installed, catalog number LDC-xxxxxx-CP, follow these steps to adjust Continuous Torque/Force Limit.

1. Click the Limits tab.
2. Set the Continuous Torque/Force Limit to reflect the motor cooling configuration.

For linear motors, this field data entry is limited to integer values from 0...150%.

Cooling Option Used	Value
No cooling plate	0...100%
Cooling plate with forced air	0...120%
Cooling plate with forced water	0...150%



IMPORTANT Increasing or decreasing the motor continuous current rating does not change the drives' continuous current limiting.

Interconnect Diagrams

Introduction

This appendix provides wiring examples to assist you in wiring an LX-Series linear motor to an Allen-Bradley drive.



Topic	Page
Introduction	59
Wiring Examples	59
Wiring Example for Kinetix 6000, Kinetix 6500/6200 or Kinetix 2000 Drives and LXxxxxxxxHxx1x Linear Motor with a TTL Encoder	60
Wiring Example for Kinetix 6000, Kinetix 6500/6200 or Kinetix 2000 Drives and LXxxxxxxxHxx1x Linear Motor with a Sin/Cos Encoder	61
Wiring Example for Kinetix 6000, Kinetix 6500/6200 or Kinetix 2000 Drives and LXxxxxxxxHxx0x Linear Motor with a TTL Encoder	62
Wiring Example for Kinetix 6000, Kinetix 6500/6200 or Kinetix 2000 Drives and LXxxxxxxxHxx0x Linear Motor with a Sin/Cos Encoder	63
Wiring Example for Ultra3000 Drive and LXxxxxxxxHxx1x Linear Motor with a TTL Encoder	64
Wiring Example for Ultra3000 Drive and LXxxxxxxxHxx1x Linear Motor with a Sin/Cos Encoder	65
Wiring Example for Ultra3000 Drive and LXxxxxxxxHxx0x Linear Motor with a TTL Encoder	66
Wiring Example for Ultra3000 Drive and LXxxxxxxxHxx0x Linear Motor with a Sin/Cos Encoder	67

Wiring Examples

These notes apply to the wiring examples on the pages that follow.


Note	Information
1	Use the cable shield clamp to meet CE requirements. No external connection to ground is required.
1	For motor cable specifications, refer to the Kinetix Motion Control Selection Guide, publication GMC-SG001 .
2	TS + and TS - wires are black for LXxxxxxxxSxxx motor coils and red for LXxxxxxxxTxxx motor coils.
3	When using the Sin/Cos encoder with Kinetix 6000 drives, refer to Appendix B on page 69 .

Figure 13 - Wiring Example for Kinetix 6000, Kinetix 6500/6200 or Kinetix 2000 Drives and LXxxxxxxxHxx1x Linear Motor with a TTL Encoder



(Use 2090-K6CK-D15M connector for Kinetix 6000 drives and 2090-K2CK-D15M connector for Kinetix 2000 drives.)

Figure 14 - Wiring Example for Kinetix 6000, Kinetix 6500/6200 or Kinetix 2000 Drives and LXxxxxxxxHxx1x Linear Motor with a Sin/Cos Encoder



Refer to low profile connector illustration (lower left) for proper grounding and shield termination techniques.




Figure 15 - Wiring Example for Kinetix 6000, Kinetix 6500/6200 or Kinetix 2000 Drives and LXxxxxxxxHxx0x Linear Motor with a TTL Encoder





Figure 16 - Wiring Example for Kinetix 6000, Kinetix 6500/6200 or Kinetix 2000 Drives and LXxxxxxxxHxx0x Linear Motor with a Sin/Cos Encoder







Figure 17 - Wiring Example for Ultra3000 Drive and LX-Series Linear Motor with a TTL Encoder




Refer to low profile connector illustration (lower left) for proper grounding and shield termination techniques.



TTL Encoder
Wire color shown for Renishaw RGH22 linear incremental encoder with its reference mark actuator installed.

Figure 18 - Wiring Example for Ultra3000 Drive and LXxxxxxxxHxx1x Linear Motor with a Sin/Cos Encoder



Refer to low profile connector illustration (lower left) for proper grounding and shield termination techniques.

Ground techniques for feedback cable shield.




Figure 19 - Wiring Example for Ultra3000 Drive and LX-Series Linear Motor with a TTL Encoder







Figure 20 - Wiring Example for Ultra3000 Drive and LXxxxxxxxHxx0x Linear Motor with a Sin/Cos Encoder



Notes:

Sin/Cos Linear Encoder and Kinetix 6000 Drives


Introduction

This appendix guides you through commissioning a linear motor with a Sin/Cos 1V peak-to-peak output linear encoder.

Topic	Page
Kinetix 6000 Drive Feedback Connection	69
Encoder Counting Direction	70
Set Up the Axis Properties	70

Kinetix 6000 Drive Feedback Connection

For robust operation when interfacing your Sin/Cos 1V peak-to-peak differential output linear encoder to a Kinetix 6000 drive, terminate the sine and cosine signals as follows.




For systems where the cable length is less than 10 m (32.8 ft), the encoder power supply from the Kinetix 6000 drive feedback connector should be dropped from its nominal 5.4...5.1V DC with the addition of a Shottky Diode; see the schematic.

Encoder Counting Direction Normally, the encoder signals will output sine-leads-cosine (AM leads BM) when the linear encoder head is moving towards its cable, relative to the encoder scale. SERCOS drives count this in a **negative** direction.

Set Up the Axis Properties Do these steps to install a Sin/Cos linear encoder.


1. From the Motor Feedback tab, enter these parameters values.

Parameter	Value	Comment
Feedback Type	Sin/Cos	–
Cycles	25 per millimeter	For 40 μm pitch encoder scale.
	50 per millimeter	For 20 μm pitch encoder scale.
Interpolation Factor	1024	–




2. From the Drive/Motor tab, enter these parameters values.

Parameter	Value	Comment
Driver Resolution	25600	For 40 μ m pitch encoder scale.
	51200	For 20 μ m pitch encoder scale.
Drive Counts per	Motor millimeter	–



3. From the Conversion tab, enter these parameters values.

Parameter	Value	Comment
Driver Resolution	25600	For 40 μ m pitch encoder scale.
	51200	For 20 μ m pitch encoder scale.



Notes:

A

air gap 16
alignment tool 20
aluminum straight edge 20
**automatic implantable cardioverter
defibrillator (AICD)** 7

B

bumper 10, 17
burn hazard 10

C

carriage 17
coil 15
coil power connector 30
commission
Kinetix 2000 drive 46
Kinetix 6000 drive 46
Ultra3000 drive 51
connector 30
encoder 15, 33
feedback 15, 31
power 15, 30
PTC thermistor 15, 30, 33

D

description
motor 15
design consideration
air gap 16
bumper 17
carriage design
heat sink 17
end of travel bumper 10
linear encoder 17
direction 53

E

encoder
resolution 54
encoder connector 33
encoder sin/cos 69
end of travel
bumpers 10
impact 10
end stop 17

F

feedback connector 31
firmware revision 44
flying leads 35

H

Hall effect module 15
heat sink 17
max temperature 10

I

installation 19
firmware 44
software 44
interconnect diagrams
wiring example notes 59

L

label
identification 8
large impacts 10
linear encoder 17

M

magnet channel 20
magnet track 15
maintenance 18
maximum speed 11
motor
database 44
direction 53
storage 18
mount
multiple motors 40
power cable 30

N

non-magnetic 20

P

performance 17
phase alignment
two motors 40
pinout
coil power 30
encoder 33
feedback 31
power connector 30
PTC thermistor 30, 33
power connector 15, 30
procedure
cleaning magnet track 18
connections 35
install magnet channel 20
power connection 30
verify encoder resolution 54
PTC thermistor connector 30

R

RSLogix software screen

- conversion 50
- drive/motor 46
- motor feedback 47
- units 49

S

safety

- sudden motion 10

safety label

- location of 8

SERCOS Drive 69

setup

- Kinetix 2000 drive 46
- Kinetix 6000 drive 46
- Ultra3000 drive 51

shipping

- air freight restriction 9
- dangerous goods declaration 9
- form 902 instructions 9

shock absorber 17

software

- required version 44

spacing

- two motors 40

storage 18

T

tandem motors 40

temperature

- max heat sink 10

tools 20

torque

- magnet channel 24, 27

V

verify

- direction 53
- resolution 54

W

warning

- air freight restrictions 9
- automatic implantable cardioverter
defibrillator (AICD) 7
- powerful forces 7

wiring 35

wiring diagram 60

- connectorized
 - Sin/Cos encoder 61, 65
 - TTL encoder 60, 64
- flying lead
 - Sin/Cos encoder 63, 66, 67
 - TTL encoder 62

Notes:

Rockwell Automation Support

Rockwell Automation provides technical information on the Web to assist you in using its products.

At <http://www.rockwellautomation.com/support/>, you can find technical manuals, a knowledge base of FAQs, technical and application notes, sample code and links to software service packs, and a MySupport feature that you can customize to make the best use of these tools.

For an additional level of technical phone support for installation, configuration, and troubleshooting, we offer TechConnect support programs. For more information, contact your local distributor or Rockwell Automation representative, or visit <http://www.rockwellautomation.com/support/>.

Installation Assistance

If you experience a problem within the first 24 hours of installation, review the information that is contained in this manual. You can contact Customer Support for initial help in getting your product up and running.

United States or Canada	1.440.646.3434
Outside United States or Canada	Use the Worldwide Locator at http://www.rockwellautomation.com/support/americas/phone_en.html , or contact your local Rockwell Automation representative.

New Product Satisfaction Return

Rockwell Automation tests all of its products to ensure that they are fully operational when shipped from the manufacturing facility. However, if your product is not functioning and needs to be returned, follow these procedures.

United States	Contact your distributor. You must provide a Customer Support case number (call the phone number above to obtain one) to your distributor to complete the return process.
Outside United States	Please contact your local Rockwell Automation representative for the return procedure.

Documentation Feedback

Your comments will help us serve your documentation needs better. If you have any suggestions on how to improve this document, complete this form, publication [RA-DU002](#), available at <http://www.rockwellautomation.com/literature/>.

Rockwell Otomasyon Ticaret A.Ş., Kar Plaza İş Merkezi E Blok Kat:6 34752 İçerenköy, İstanbul, Tel: +90 (216) 5698400

www.rockwellautomation.com

Power, Control and Information Solutions Headquarters

Americas: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444

Europe/Middle East/Africa: Rockwell Automation NV, Pegasus Park, De Kleetlaan 12a, 1831 Diegem, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640

Asia Pacific: Rockwell Automation, Level 14, Core F, Cyberport 3, 100 Cyberport Road, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846