



# Integrated Motion on Sercos and EtherNet/IP Network – Analysis and Comparison

Topic	Page
Hardware	2
Features	2
Topology	3
Communication Module and Drive Configuration	4
Axis Configuration	9
Axis Commissioning	19
Additional Axis Property Equivalents	27
Diagnostics	34
High-level Feature Comparison	36
High-level Safety Feature Comparison	39
Appendix A – Communication Networks and Managed Communication	40
Appendix B – Configuration of the Kinetix 5700 Converter Module	40
Appendix C – Design and Implementation Guide for Using Integrated Motion on an EtherNet/IP Network	40
Appendix D – Drive Parameters Cyclic Read and Write List	43
Appendix E – Available GSV and SSV Data	45
Appendix F – Axis Attributes	52
Appendix G – Axis Exceptions	61
Additional Resources	75

This application technique compares the similarities and differences between these two Integrated Motion systems:

- Systems that use Serial Real-time Communications System (Sercos) interfaces
- Systems that use EtherNet/IP networks

Both comparisons use ControlLogix® controllers.

Topics that are covered include hardware, axis configurations, Get System Variable (GSV), Set System Variable (SSV), and axis exceptions for the two different systems.

## Hardware

This table lists the hardware information for Integrated Motion on Sercos interfaces and EtherNet/IP networks.

Integrated Motion on Sercos Interface	Integrated Motion on the EtherNet/IP Network
<ul style="list-style-type: none"> <li>Sercos II technology</li> <li>1756-L6x, 1756-L7x, GuardLogix®, 1768-L43, and 1768-L45 controllers</li> <li>1756-M03SE, 1756-M08SE, 1756-M16SE, and 1768-M04SE Sercos cards</li> <li>Ultra™ 3000 SE, Kinetix® 2000, Kinetix 6000, Kinetix 6200, and Kinetix 7000 servo drives</li> </ul>	<ul style="list-style-type: none"> <li>EtherNet/IP technology</li> <li>1756-L6x, 1756-L7x, 1756-L8x, 1769-LxxERM, 1769-L3YS, and GuardLogix® controllers</li> <li>1756-EN2T<sup>(1)</sup>, 1756-EN2F, 1756-EN2TR, and 1756-EN3TR Ethernet communication modules</li> <li>Kinetix 6500 servo drive, PowerFlex® 755 AC drive, PowerFlex 527, Kinetix 350, Kinetix 5500, and Kinetix 5700 drives</li> <li>1783-ETAP, 1783-ETAP1F, and 1783-ETAP2F EtherNet/IP taps with embedded switch technology (optional)</li> <li>Stratix 2000™, Stratix 5100™, Stratix 5400™, Stratix 5700™, Stratix 6000™, Stratix 8000™, and Stratix 8300™ switches (and commercially available switches, optional)</li> </ul>

(1) Firmware revision 4.00 or later.



## Features

This table lists features for Integrated Motion on Sercos interfaces and EtherNet/IP networks.

Integrated Motion on Sercos Interface	Integrated Motion on the EtherNet/IP Network
<ul style="list-style-type: none"> <li>Sercos is a controller/drive interface that uses noise-immune, fiber-optic cables.</li> <li>A fiber-optic ring serves as the sole interface between the control and the drive. The fiber-optic ring replaces costly command and feedback wiring, which reduces installation time and the cost of wiring.</li> <li>Kinetix drives provide advanced diagnostics and process reports via the Sercos interface.</li> <li>Wide variety of motion module options for ControlLogix, CompactLogix™, and GuardLogix controllers.</li> <li>Up to 16 axes of motion can be controlled from one motion module.</li> <li>System is fully expandable, with up to 100 axes that are supported per controller.</li> <li>Multiple controllers can be used if additional axes are needed.</li> </ul>	<ul style="list-style-type: none"> <li>EtherNet/IP technology, Integrated Motion on the EtherNet/IP network, and CIP Sync technologies are global standards from ODVA. These standards help to provide device standardization and compatibility.</li> <li>EtherNet/IP technology has an installed base that numbers in the billions of nodes. Compliance with IEEE Ethernet standards provides users with a choice of network interface speeds; for example, 10, 100 Mbps, and 1 Gbps.</li> <li>EtherNet/IP technology is an agile, multidiscipline network that can be used to control, configure, monitor, and do peer interlock for motion, safety, process, and discrete applications; it provides a Connected Enterprise.</li> <li>Multiplexing, a new feature in Integrated Motion on the EtherNet/IP network, allows for the controller to execute up to three effective Coarse Update Periods for a Motion Group. Within the Motion Group, drives can execute at different rates, relative to the needed application performance.</li> <li>The drive multiplex feature is available in Studio 5000® revision 24 and up, and is compatible with Axis CIP Drive and AXIS VIRTUAL data types.</li> <li>Single network architecture integration.</li> <li>High-performance drives, I/O, smart actuators, human machine interface (HMI), programming terminal, and any other EtherNet/IP device providing lower system cost, improved performance, flexibility, and ease-of-use benefits.</li> <li>Extends the benefits and simplicity of Integrated Motion to Kinetix 350, Kinetix 5500, Kinetix 5700, Kinetix 6500, PowerFlex 527, and PowerFlex 755 drives on an EtherNet/IP network.</li> <li>Kinetix and PowerFlex drives can be used on the same network to configure, program, commission, diagnose, and for drive maintenance.</li> <li>Support for any Ethernet topology for maximum flexibility. Embedded switch Device Level Ring (DLR) technology available on Kinetix 5500, Kinetix 5700, Kinetix 6500, PowerFlex 527, and PowerFlex 755 drives. An optional dual-port card is available on PowerFlex 755 drives.</li> </ul>

# Topology





This section lists information on the topologies for Integrated Motion on Sercos and EtherNet/IP network.

Integrated Motion on Sercos Interface	Integrated Motion on the EtherNet/IP Network
<ul style="list-style-type: none"><li>Sercos II technology, 8 MB transmission rate.</li><li>Maximum of 16 drives per Sercos module or ring. Supports multiple Sercos modules per controller.</li><li>Dedicated motion network. Supports only Sercos interface drives.</li><li>Must be configured in ring topology.</li></ul>	<ul style="list-style-type: none"><li>EtherNet/IP technology, 100 MB fast Ethernet.</li><li>Standard unmodified Ethernet and maximum of 128 drives per Ethernet module.</li><li>ControlLogix 5580 controllers offer a 1 GB embedded Ethernet port and support 300 devices in its I/O tree with 256 being drives.</li><li>Any combination of EtherNet/IP devices on a common network: AC and servo drives, distributed I/O, EOI, and any other EtherNet/IP device.</li><li>Coupled with an Ethernet communication module, the ControlLogix 5580 controller supports all Ethernet topologies: star, linear, ring (Device Level Ring or DLR), or hybrid.</li></ul> <p><b>IMPORTANT:</b> A 1756-L7x controller motion group is limited to 100 axes while a ControlLogix 5580 controller motion group can have up to 256 axes. Multiple controllers can control drives on a common Ethernet module.</p> <p><b>IMPORTANT:</b> A standalone ControlLogix 5580 controller supports only linear topology. Other topologies (liner and ring) can be achieved by adding an Ethernet module to the rack.</p>
Ring Topology	Basic Ring Topology
 <p>ControlLogix Controller</p> <p>1756-M08SE Module 1756-M16SE Module</p> <p>Kinetix 6200 Drives</p>	 <p>ControlLogix Controller</p> <p>Device Level Ring (DLR)</p> <p>Kinetix 5700 Drive</p> <p>Point I/O™</p> <p>PowerFlex 527 Drive</p> <p>PanelView™ Plus 7 Performance Terminal</p> <p><b>IMPORTANT:</b> For additional topology examples, see <a href="#">Appendix C – Design and Implementation Guide for Using Integrated Motion on an EtherNet/IP Network on page 40.</a></p>

Communication Module and Drive Configuration

This section compares the communication module and drive configuration for Integrated Motion on Sercos and EtherNet/IP systems.

Communication Module and Drive Configuration Comparison


Integrated Motion on Sercos Interface	Integrated Motion on the EtherNet/IP Network
<div>Select a Sercos Communication Module</div> <div>Select the appropriate Sercos communication module:</div> <div><ul style="list-style-type: none"><li>1756-M03SE = 3 Sercos drives</li><li>1756-M08SE = 8 Sercos drives</li><li>1756-M16SE = 16 Sercos drives</li></ul></div> <div></div>	<div>Select an Ethernet Communication Module</div> <div>Select the appropriate Ethernet communication module:</div> <div><ul style="list-style-type: none"><li>1756-EN2x = Up to 128 EtherNet/IP drives with a maximum of 8 position-configured drives</li><li>1756-EN3x = Up to 128 EtherNet/IP drives</li><li>5580 controller = Up to 256 EtherNet/IP drives</li></ul></div> <div></div>
<div>Configure the Sercos Communication Module</div> <div>Select the appropriate data rate, cycle time, and so on, that matches the Sercos interface. These settings are typically dependent on the number of drives in the network.</div> <div></div>	<div>Configure the Ethernet Communication Module</div> <div>With an Ethernet module, you define Time Sync Connection to Time Sync and Motion to enable CIP Sync time coordination that is required for motion control.</div> <div>With a direct connection from a Kinetix 5700 drive to a ControlLogix 5580 controller embedded Ethernet port, check 'Enable Time Synchronization' and click Apply.</div> <div></div>
	<div>ControlLogix 5580 Embedded Ethernet Controllers</div> <div>The ControlLogix 5580 controllers have an embedded 1 GB Ethernet port available. The controllers do not require a separate Ethernet communication module.</div> <div>IMPORTANT: For additional information on the Ethernet communication module axis limits, see <a href="#">Appendix A – Communication Networks and Managed Communication on page 40</a>.</div>
	<div>IMPORTANT: To configure ControlLogix 5580 controllers, see the ControlLogix 5580 Controllers User Manual, publication <a href="#">1756-UM543</a>.</div>

## Communication Module and Drive Configuration Comparison (Continued)

### Integrated Motion on Sercos Interface

#### Drive Selection


When selecting a Sercos drive, select both the control and power structure.



### Integrated Motion on the EtherNet/IP Network


#### Drive Selection: Control and Power Structure

Compared to the Kinetix 5500 and Kinetix 6500 drives, the Kinetix 5700 drive consists of a power supply/converter and inverter. The power supply is separate from the axis module and is configured in the I/O tree. There is no auto population of the power structure. You can choose the required power supply.




**IMPORTANT:** For complete information on configuration of a Kinetix 5700 drive, see the Kinetix 5700 Servo Drives User Manual, publication [2198-UM002](#).

The power structure is displayed in the module definition.






After you select the power supply, then you select the inverter module.






**IMPORTANT:** Kinetix 5500 and Kinetix 6500 drives have an integrated axis (IAM) power module, which requires the power structure to be specified during configuration.

Communication Module and Drive Configuration Comparison (Continued)

Integrated Motion on Sercos Interface	Integrated Motion on the EtherNet/IP Network
<p><b>Set the Node Address</b></p> <p>Each Sercos drive must have a unique network identifier that is the node address of the drive.</p> 	<p><b>Set the IP Address</b></p> <p>Each EtherNet/IP drive must have a unique network identifier that is the IP address of the drive.</p>  
	<p><b>IMPORTANT:</b> The IP address for the Kinetix 5700 drive can be assigned as Isolated, Static, Dynamic (BOOTP/DHCP), or DHCP Persistence.</p>

## Communication Module and Drive Configuration Comparison (Continued)

Integrated Motion on Sercos Interface			Integrated Motion on the EtherNet/IP Network																
<h3>Digital Inputs</h3> <p>Sercos drives contain up to six digital inputs. Typically the function of these inputs cannot be configured.</p>			<h3>Configurable Digital Inputs</h3> <p>EtherNet/IP drives have configurable digital inputs. The Kinetix 5700 converter module has two configurable inputs, while its axis modules have four configurable inputs.</p>																
<table><tr><th>IOD Pin</th><th>Signal</th><th>Description</th></tr><tr><td>IOD-2</td><td>ENABLE</td><td>Optically isolated, single-ended active high signal. The current load is nominally 10 mA. A 24V DC input is applied to this terminal to enable each axis.</td></tr><tr><td>IOD-5</td><td>HOME</td><td>Optically isolated, single-ended active high signal. The current load is nominally 10 mA. Home switch (normally open contact) inputs for each axis require 24V DC (nominal).</td></tr><tr><td>IOD-15 IOD-17</td><td>REG1 REG2</td><td>Fast registration inputs are required to inform the motor interface to capture the positional information with less than 3 μs of uncertainty. Optically isolated, single-ended active high signal. The current load is nominally 10 mA. A 24V DC input is applied to this terminal to enable each axis.</td></tr><tr><td>IOD-8 IOD-11</td><td>OT+ OT-</td><td>Over-travel detection is available as an optically isolated, single-ended active high signal. The current load is nominally 10 mA per input. The positive/negative limit switch (normally closed contact) inputs for each axis require 24V DC (nominal).</td></tr></table>			IOD Pin	Signal	Description	IOD-2	ENABLE	Optically isolated, single-ended active high signal. The current load is nominally 10 mA. A 24V DC input is applied to this terminal to enable each axis.	IOD-5	HOME	Optically isolated, single-ended active high signal. The current load is nominally 10 mA. Home switch (normally open contact) inputs for each axis require 24V DC (nominal).	IOD-15 IOD-17	REG1 REG2	Fast registration inputs are required to inform the motor interface to capture the positional information with less than 3 μs of uncertainty. Optically isolated, single-ended active high signal. The current load is nominally 10 mA. A 24V DC input is applied to this terminal to enable each axis.	IOD-8 IOD-11	OT+ OT-	Over-travel detection is available as an optically isolated, single-ended active high signal. The current load is nominally 10 mA per input. The positive/negative limit switch (normally closed contact) inputs for each axis require 24V DC (nominal).		
IOD Pin	Signal	Description																	
IOD-2	ENABLE	Optically isolated, single-ended active high signal. The current load is nominally 10 mA. A 24V DC input is applied to this terminal to enable each axis.																	
IOD-5	HOME	Optically isolated, single-ended active high signal. The current load is nominally 10 mA. Home switch (normally open contact) inputs for each axis require 24V DC (nominal).																	
IOD-15 IOD-17	REG1 REG2	Fast registration inputs are required to inform the motor interface to capture the positional information with less than 3 μs of uncertainty. Optically isolated, single-ended active high signal. The current load is nominally 10 mA. A 24V DC input is applied to this terminal to enable each axis.																	
IOD-8 IOD-11	OT+ OT-	Over-travel detection is available as an optically isolated, single-ended active high signal. The current load is nominally 10 mA per input. The positive/negative limit switch (normally closed contact) inputs for each axis require 24V DC (nominal).																	
<h3>Drive Enable Input Checking Example</h3> <p>For a Sercos drive, the Drive Enable Input Checking checkbox is on the Drive/Motor tab of the Axis Properties.</p>			<h3>Drive Enable Input Checking Example</h3> <p>For an EtherNet/IP drive, to disable input checking, make sure that none of the inputs are assigned to enable.</p>																
																			

Communication Module and Drive Configuration Comparison (Continued)

Integrated Motion on Sercos Interface

Hard Travel Limits Example

For a Sercos drive, the Hard Travel Limits checkbox is on the Limits tab of the Axis Properties.

GeneralMotion PlannerUnitsDrive/MotorMotor FeedbackHomingHookupTuneDynamicsGainsOutputLimits

Hard Travel Limits

Soft Travel Limits

Maximum Positive:0.0deg

Maximum Negative:0.0deg

IMPORTANT: The Kinetix 6200 drive is limited to four digital inputs.

IOD Pin	Input	IDN	Type	Default
41	1	P-0-052	INT	Enable
42	2	P-0-053		Home
43	3	P-0-054		Registration 1
44	4	P-0-055		Registration 2

The digital input default settings can be configured by using a Sercos IDN write instruction.

Integrated Motion on the EtherNet/IP Network

Overtravel Limits Example

For an EtherNet/IP drive, to enable the hard travel limits on the Kinetix 5700 or Kinetix 6500 drives, assign the inputs to Positive Overtravel and Negative Overtravel.

Digital Input 1:Enable

Digital Input 2:Home

Digital Input 3:Registration 1

Digital Input 4:Registration 2

Digital Input 1:Enable

Digital Input 2:Home

Digital Input 3:Positive Overtravel

Digital Input 4:Negative Overtravel

IMPORTANT: The following digital inputs can be assigned for the Kinetix 5700 drives.

Unassigned

Unassigned

Enable

Home

Registration 1

Registration 2

Positive Overtravel

Negative Overtravel

Regeneration OK

Bus Capacitor OK




Shunt Thermal Switch OK








# Axis Configuration

This section compares the axis configuration for Integrated Motion on Sercos and EtherNet/IP systems.

## Axis Configuration Comparison

Integrated Motion on Sercos Interface	Integrated Motion on the EtherNet/IP Network
<div><p><b>General</b></p></div>	<div><p><b>General</b></p> </div>

Axis Configuration Comparison (Continued)

Integrated Motion on Sercos Interface	Integrated Motion on the EtherNet/IP Network
<p><b>Axis and Loop Configuration</b></p> <p>For a Sercos axis, the Axis Configuration selects between Servo and Feedback Only operation control.</p> <p>Axis Configuration</p>  <p>To configure the axis for Velocity Servo, Torque Servo, and so on, see Loop Configuration on the Drive/Motor tab.</p> <p>Loop Configuration</p> 	<p><b>Axis and Feedback Configuration</b></p> <p>For the Kinetix 5700 drive, configure the converter module as a CIP drive because it is used for the faults and shutdown mechanism of the inverter.</p> <p>Axis Configuration</p>  <p>Even though the converter module does not spin a motor, an axis must be configured as part of the axis properties for the drive.</p> <p>For an EtherNet/IP axis, the control mode is a combination of the Axis Configuration and Feedback Configurations.</p> <p>Axis Configuration</p>  <p><b>IMPORTANT:</b> The Kinetix 5700 and Kinetix 5500 servo drives support the basic volts/hertz frequency control. Kinetix 6500 and PowerFlex 755 AC drives support all other modes.</p> <p>On the Kinetix 5700 drive, feedback connections are made at the DSL feedback, 2-pin motor feedback (MF) connector, and the 15-pin universal feedback (UFB) connector.</p> <p>Feedback Configuration</p> 

Axis Configuration Comparison (Continued)




Integrated Motion on Sercos Interface	Integrated Motion on the EtherNet/IP Network
<p><b>Drive/Motor</b></p>	<p><b>Motor</b></p>
<p><b>Change the Catalog Number</b></p> <p>For a Sercos axis, the Motor Data Source pull-down selection does not exist. By default, you can only select an available drive that is in the motor catalog database.</p>	<p><b>Motor Data Source Options</b></p>

**Nameplate Datasheet:** Supported third-party motors, or motors that are not included in the motor database. You enter the motor parameters.

**Catalog Number:** Choose supported Allen-Bradley® motors by catalog number. Provides automatic setting of the required parameters.






**Motor NV:** Motor parameters are derived from nonvolatile memory of a smart feedback device that is equipped with a serial interface. Applies to any Hiperface or EnDat feedback device that is preprogrammed with Rockwell Automation formatted motor data. This option is not available for PowerFlex 755 AC drives.

Axis Configuration Comparison (Continued)




Integrated Motion on Sercos Interface	Integrated Motion on the EtherNet/IP Network
<div><p><b>Motor Feedback</b></p><p>For a Sercos axis, the Motor Feedback tab provides a summary of the connected feedback.</p></div>	<div><p><b>Motor Feedback</b></p><p>For an EtherNet/IP axis, the Motor Feedback page provides a summary of the connected feedback device when Catalog Number is selected as a Motor Data Source.</p></div> <p>When Nameplate Datasheet is selected, you can define the motor feedback information.</p> 

**IMPORTANT:** For system features on the Kinetix 5700 drives, see the release notes of your installed firmware.

## Axis Configuration Comparison (Continued)

Integrated Motion on Sercos Interface	Integrated Motion on the EtherNet/IP Network
<p><b>Aux Feedback</b></p> <p>The Aux Feedback page is not accessible unless one of these conditions is true:</p> <ul style="list-style-type: none"> <li>Axis Configuration is set to Feedback Only.</li> <li>Loop Configuration is set to Aux or Dual loop mode.</li> </ul> 	<p><b>Load Feedback</b></p> <p>The Load Feedback page is only visible if the Feedback Configuration is set to Load or Dual Feedback.</p> 
<p>N/A</p> <p><b>IMPORTANT:</b> Each category with an asterisk indicates that a change was made but was not applied. Click Apply or OK to save the changes.</p>	<p><b>Master Feedback</b></p> <p>If the Axis Configuration is set to Feedback Only, the Master Feedback page replaces the Motor and Load Feedback pages.</p> 
<p><b>Conversion Constant</b></p> 	<p><b>Scaling Calculator</b></p> 

Axis Configuration Comparison (Continued)

Integrated Motion on Sercos Interface	Integrated Motion on the EtherNet/IP Network
<p><b>Position Units</b></p> <p>For a Sercos axis, the Position Units are on the Units tab.</p> 	<p><b>Units</b></p> <p>The Scaling units are user-defined and are reflected throughout the Axis Properties.</p> 
<p><b>N/A</b></p> <p>For a Sercos axis, the Transmission Ratio and Actuator entry does not exist. These input values must be directly included in the Conversion Constant and Drive Resolution calculations.</p>	<p><b>Transmission Ratio and Actuator</b></p> <p>The Transmission Ratio and Actuator entry makes it easier to enter application-specific scaling information. For the Actuator, select from Screw, Belt and Pulley, Chain and Sprocket, and Rack and Pinion.</p> 

## Axis Configuration Comparison (Continued)

### Integrated Motion on Sercos Interface

#### Positioning Mode, Drive Resolution, Conversion Constant, and Position Unwind

For a Sercos axis, the Positioning Mode and Unit Scaling/Unwind reside on different tabs.

First, set the Positioning Mode on the Conversion tab.

Positioning Mode: **Rotary**

Next, click Calculate on the Drive/Motor tab.

You can then use the Calculate Position Parameters calculator to calculate the Drive Resolution, Conversion Constant, and Position Unwind.

### Homing

### Integrated Motion on the EtherNet/IP Network

#### Scaling and Travel

For an EtherNet/IP axis, the Travel Mode selections include Unlimited, Limited, or Cyclic. The Cyclic mode is similar to when you select a Sercos Positioning Mode set to Rotary.







**IMPORTANT:** The Scaling can also be set manually without using the Scaling Calculator. On the scaling page, click Parameters to switch between the page and parameter views. On the parameter view, set the Scaling Source to Direct Scaling Factor Entry.

Name	Value	Unit
ActuatorDiameter	1.0	
ActuatorDiameterUnit		Millimeter
ActuatorLead	1.0	
ActuatorLeadUnit		Millimeter/Rev
ActuatorType	Belt and Pulley	
ConversionConstant	1000.0	Motion Counts/deg
LoadType	Linear Actuator	
MotionResolution	360000	Motion Counts/Load Millimeter
MotionScalingConfiguration	Control Scaling	
MotionUnit	Load Millimeter	
PositionScalingDenominator	1.0	Load Millimeter
PositionScalingNumerator	360.0	deg
PositionUnits	deg	
PositionUnwind	360000	Motion Counts/Unwind Cycle
PositionUnwindDenominator	1.0	Unwind Cycles
PositionUnwindNumerator	360.0	deg
ScalingSource	Direct Scaling Factor Entry	
SoftTravelLimitChecking	No	
SoftTravelLimitNegative	0.0	deg

Set the Scaling Source to Direct Scaling Factor Entry to let the Conversion Constant, Motion Resolution, and other scaling parameters be calculated and entered manually.





### Homing

Axis Configuration Comparison (Continued)






Integrated Motion on Sercos Interface	Integrated Motion on the EtherNet/IP Network
<div><p><b>Homing Mode</b></p></div> <p><b>Active:</b> The desired homing sequence is selected by specifying whether a home limit switch or the encoder marker is used for this axis. Active homing sequences always use the trapezoidal velocity profile.</p> <p><b>Passive:</b> Passive homing is most commonly used to calibrate uncontrolled axes, although it can also be used with controlled axes to create a custom homing sequence.</p> <p><b>Absolute:</b> The absolute homing process establishes the true absolute position of the axis by applying the configured Home Position to the reported position of the absolute feedback device.</p> <p><b>IMPORTANT:</b> The only valid Home Sequence for an absolute Homing Mode is immediate.</p>	<div><p><b>Homing Mode</b></p></div> <p><b>IMPORTANT:</b> For an EtherNet/IP axis, if the motor contains an absolute position-capable feedback device, the homing operation automatically sets the absolute position.</p>
<div><p><b>Homing Sequence</b></p></div>	<div><p><b>Homing Sequence</b></p></div> <p><b>IMPORTANT:</b> EtherNet/IP axes currently do not support the home to torque level sequence. This functionality can be implemented via software in your Studio 5000 project.</p> <p>See the <a href="#">Sample Code Library</a>, filename/ID <b>055818</b> – CIP Axis Home To Torque AOI</p>
<div><p><b>Fault Actions</b></p></div> <p>A Sercos axis is limited to nine fault actions.</p>	<div><p><b>Fault Actions</b></p></div> <p>For an EtherNet/IP axis, see <a href="#">Appendix G – Axis Exceptions on page 61</a> for the fault actions referred to as exception conditions. The number of configurable conditions has been expanded.</p>



Axis Configuration Comparison (Continued)

Integrated Motion on Sercos Interface	Integrated Motion on the EtherNet/IP Network
<p><b>Drive Enable Input Fault Example</b></p> <p>For Sercos axis, the Drive Enable Input Fault checkbox is on the Drive/Motor tab. Uncheck this box to ignore this fault.</p>  <p>Otherwise assign the appropriate fault action.</p> 	<p><b>Action – Enable Input Deactivated Example</b></p> <p>For an EtherNet/IP axis, the Enable Input Deactivated actions (including Ignore) are available on the Actions page.</p>  <p>Typically the following actions are available.</p>  <p><b>IMPORTANT:</b> The available actions can vary between exception conditions.</p>



Axis Configuration Comparison (Continued)

Integrated Motion on Sercos Interface	Integrated Motion on the EtherNet/IP Network
<div><p><b>Real-Time Axis Information</b></p></div> <p>For a Sercos axis, you can select two additional real-time attributes, and default Auto Tag Update attributes. The attributes update at the coarse update rate and are read-only.</p>	<div><p><b>Drives Parameters</b></p></div> <p>An EtherNet/IP axis supports up to 10 read parameters and 10 write parameters. These parameters are transferred at the cyclic/coarse rate and are available in the axis structure. For a detailed list of the parameters, see <a href="#">Appendix D – Drive Parameters Cyclic Read and Write List on page 43</a>.</p> <p><b>IMPORTANT:</b> Each parameter that is selected as a cyclic read/write attribute adds overhead to the controller/drive data exchange. You must analyze the trade-off of real-time data on the timing of the axis.</p>
<div><p><b>Update Period and Schedule</b></p><p>To obtain real-time axis Information for both Sercos and EtherNet/IP axes, Auto Tag Update must be enabled. The Auto Tag Update Enable/Disable option has been moved to an SSV instruction in Studio 5000 Logix Designer® application, version 24 or later. The default setting for this feature is Enabled, the same as all previous releases of Logix Designer.</p></div>	<div><p><b>Update Period and Schedule</b></p><p>The Base Update Period is essentially the RPI rate for Ethernet communication between the controller and the motion module, a Unicast connection.</p></div> <p>Integrated Motion on the EtherNet/IP network multiplexing allows for the controller to execute up to three effective update rates for a motion group. Multiplexing also improves EtherNet/IP Integrated Architecture® motion system performance by reducing average Logix controller and EtherNet/IP network utilization.</p> 





# Axis Commissioning

This section compares how to commission the axis for Integrated Motion on Sercos and EtherNet/IP systems.

## Axis Commissioning Comparison

Integrated Motion on Sercos Interface	Integrated Motion on the EtherNet/IP Network
<div><b>Hookup Tests</b> </div>	<div><b>Hookup Tests</b> </div>
<p>The hookup tests interfaces between the Sercos and EtherNet/IP axes are similar.</p> <p>The hookup tests are used to verify the proper connection of the feedback device, and to determine motor and feedback polarity.</p> <p><b>IMPORTANT:</b> The Hookup Tests for both Sercos and EtherNet/IP axes can be executed while the controller is in Program Mode.</p>	<div><b>Commutation Test</b> <p><b>IMPORTANT:</b> Check your firmware release notes for supported features.</p></div>

Axis Commissioning Comparison (Continued)

Integrated Motion on Sercos Interface	Integrated Motion on the EtherNet/IP Network
<div><p><b>Drive Polarity</b></p><p>For a Sercos axis, the Drive Polarity is updated based on the results of the hookup tests. The Drive Polarity setting is on the Hookup tab.</p><p><b>IMPORTANT:</b> The drive polarity for a Sercos axis cannot be manually changed while online with a controller.</p></div>	<div><p><b>Polarity</b></p><p>For an EtherNet/IP axis, the Motion Polarity, Motor Polarity, and Feedback Polarity are updated based on the results of the hookup tests.</p><p><b>IMPORTANT:</b> Use the hookup tests to adjust polarity settings correctly. An incorrect adjustment in the polarity settings can lead to an axis runaway condition.</p></div>
<div><p><b>Tune</b></p></div>	<div><p><b>Autotune</b></p></div>





**Axis Commissioning Comparison (Continued)**

Integrated Motion on Sercos Interface	Integrated Motion on the EtherNet/IP Network																																																	
<div>Tune Settings</div> <div>For a Sercos axis, the Application Type pull-down selection does not exist. Instead, you select the individual tuning parameters that are appropriate for the applications.</div> <div><div>Tune</div><div><div><input type="checkbox"/> Position Error Integrator</div><div><input type="checkbox"/> Velocity Error Integrator</div><div><input type="checkbox"/> Friction Compensation</div><div><input type="checkbox"/> Velocity Feedforward</div><div><input type="checkbox"/> Acceleration Feedforward</div><div><input type="checkbox"/> Torque Offset</div><div><input type="checkbox"/> Output Filter</div></div></div>	<div>Application Type</div> <div>Application Type defines the servo loop tuning parameters that are used. These combinations determine how the gains are calculated, which can eliminate the need to tune the system manually.</div> <div><div>Application Type: Basic</div><div>Custom</div><div>Basic</div><div>Tracking</div><div>Point-to-Point</div><div>Constant Speed</div></div> <table><tr><th>Application Type</th><th>Kpi</th><th>Kvi</th><th>ihold</th><th>Kvff</th><th>Kaff</th><th>TorqLPF</th></tr><tr><td>Custom</td><td>—</td><td>—</td><td>—</td><td>—</td><td>—</td><td>—</td></tr><tr><td>Basic (version 20 and later)</td><td>No</td><td>No</td><td>No</td><td>Yes</td><td>No</td><td>Yes</td></tr><tr><td>Basic (version 19 and earlier)</td><td>No</td><td>No</td><td>No</td><td>No</td><td>No</td><td>—</td></tr><tr><td>Tracking</td><td>No</td><td>Yes</td><td>No</td><td>Yes</td><td>Yes</td><td>Yes</td></tr><tr><td>Point-to-Point</td><td>Yes</td><td>No</td><td>Yes</td><td>No</td><td>No</td><td>Yes</td></tr><tr><td>Constant Speed</td><td>No</td><td>Yes</td><td>No</td><td>Yes</td><td>No</td><td>Yes</td></tr></table> <div><div>Custom:</div><div>Advanced setup. You select specific tuning parameters that are based on the application.</div></div> <div><div>Basic:</div><div>Default setup. Recommended as a starting point for or out-of-the-box configurations.</div></div> <div><div>Tracking:</div><div>Intended for applications that require minimal following error. For example, un/winding, flying shear, and web control applications.</div></div> <div><div>Point-to-Point:</div><div>Intended for applications that require precise position moves with minimal overshoot. For example, pick-n-pace, packaging, and cut-to-length applications.</div></div> <div><div>Constant Speed:</div><div>Intended for applications that require minimal velocity error at steady state speed. For example, conveyor, line shaft, and crank applications.</div></div>	Application Type	Kpi	Kvi	ihold	Kvff	Kaff	TorqLPF	Custom	—	—	—	—	—	—	Basic (version 20 and later)	No	No	No	Yes	No	Yes	Basic (version 19 and earlier)	No	No	No	No	No	—	Tracking	No	Yes	No	Yes	Yes	Yes	Point-to-Point	Yes	No	Yes	No	No	Yes	Constant Speed	No	Yes	No	Yes	No	Yes
Application Type	Kpi	Kvi	ihold	Kvff	Kaff	TorqLPF																																												
Custom	—	—	—	—	—	—																																												
Basic (version 20 and later)	No	No	No	Yes	No	Yes																																												
Basic (version 19 and earlier)	No	No	No	No	No	—																																												
Tracking	No	Yes	No	Yes	Yes	Yes																																												
Point-to-Point	Yes	No	Yes	No	No	Yes																																												
Constant Speed	No	Yes	No	Yes	No	Yes																																												



Axis Commissioning Comparison (Continued)

Integrated Motion on Sercos Interface	Integrated Motion on the EtherNet/IP Network
<div><p><b>Damping Factor</b></p><p>For a Sercos axis, the Loop Response pull-down selection does not exist. Instead you enter the desired damping factor, which impacts the gain calculations.</p><div><div>Travel Limit:36000.0degsg</div><div>Speed:7200.0deg/s</div><div>Torque/Force:100.0% Rated</div><div>Direction:Forward Uni-directional</div><div>Damping Factor:0.8</div></div></div>	<div><p><b>Loop Response</b></p><div><div>Loop Response:Medium</div><div>Load:Low</div><div>Coupling:Medium</div><div>High</div></div><p><b>Low:</b> Damping factor = 1.5 <b>Medium:</b> Damping factor = 1.0 Medium is the default setting. Recommended as a starting point for out-of-the-box configurations. <b>High:</b> Damping factor = 0.8</p><p><b>IMPORTANT:</b> The damping factor is used to calculate the maximum position and velocity servo bandwidth values. In general, the damping factor controls the dynamic response of the drive.</p><p>When the tuning gains are calculated by using a small damping factor, for example 0.8, a step response test tends to demonstrate an under-damped behavior with velocity overshoot.</p><p>However, when the damping factor is increased to 1.0, the step response tends to exhibit little to no overshoot and typically works well for most applications.</p></div>
<div><p><b>N/A</b></p><p>For a Sercos axis, the Load Coupling pull-down selection feature is not supported.</p></div>	<div><p><b>Load Coupling</b></p><div><div>Load Coupling:Rigid</div><div>Rigid</div><div>Customize GCompliant</div></div><p>The Load Coupling automatically corrects the loop gains according to how tightly the system is physically coupled.</p></div>
<div><p><b>Tune Profile</b></p><div><div>Travel Limit:36000.0degsg</div><div>Speed:7200.0deg/s</div><div>Torque/Force:100.0% Rated</div><div>Direction:Forward Uni-directional</div></div><p>For a Sercos axis, you can adjust the tune profile according to the application limitations. The tune profile is used to measure the system inertia. This measurement requires the motor to move the connected load to assess the inertia.</p></div>	<div><p><b>Tune Profile</b></p><div><div><div><input checked="" type="checkbox"/> Measure Inertia using Tune Profile</div><div><div><input checked="" type="radio"/> Motor with Load</div><div><input type="radio"/> Uncoupled Motor</div></div><div><div>Travel Limit:36000.0degsg</div><div>Speed:7200.0deg/s</div><div>Torque:100.0% Rated</div><div>Direction:Forward Uni-directional</div></div></div></div><p>For an EtherNet/IP axis, you can adjust the tune profile, and the tune profile can be used to measure the uncoupled motor inertia separate from the load.</p><p>In cases where the system inertia has been established, the inertia test can also be disabled based on the selection of the Measure Inertia by using Tune Profile checkbox.</p><div><div><input type="checkbox"/> Measure Inertia using Tune Profile</div></div><p>This allows the loop gains to be calculated each time the Perform Tune button is clicked and eliminates the need to re-run the inertia test during successive tuning iterations.</p></div>

Axis Commissioning Comparison (Continued)






Integrated Motion on Sercos Interface	Integrated Motion on the EtherNet/IP Network
<div><p><b>Tune Results</b></p></div> <p>Upon completion of the autotune, a Sercos axis displays the Position Loop Bandwidth and measured Load Inertia Ratio. Click OK to accept the tune results.</p>	<div><p><b>Tune Results</b></p></div> <p>For an EtherNet/IP axis, a more encompassing list of both loop and load parameters are displayed.</p> <p>The '*' next to a parameter indicates the values that are updated. Click Accept Tuned Values to accept these tune results.</p>
<div><p><b>Manual Tuning – Manual Adjustment and Motion Direct Commands</b></p></div> <p>For a Sercos axis, the Manual Adjust interface adjusts only the tuning related parameters.</p>	<div><p><b>Manual Tuning</b></p></div> <p>The Manual Tuning interface consolidates many of the commonly used features that are used during the manual tuning process.</p>

Axis Commissioning Comparison (Continued)







Integrated Motion on Sercos Interface	Integrated Motion on the EtherNet/IP Network
<div><p><b>Motion Direct Commands</b></p></div> <p>For a Sercos axis, you typically launch the Motion Direct Commands for manual control of the drive during the tuning process.</p>	<div><p><b>Motion Generator</b></p></div> <p>As a part of the manual tuning interface, the Motion Generator feature includes direct access to several of the most commonly used motion direct commands. The direct access reduces the need to launch the Motion Direct Commands interface to complete the manual tuning process.</p>



Axis Commissioning Comparison (Continued)

Integrated Motion on Sercos Interface	Integrated Motion on the EtherNet/IP Network
<p><b>Gains</b></p> 	<p><b>Manual Tune – Loop Gains</b></p> 
<p>For a Sercos axis, the gains can only be adjusted individually via the Manual Adjust interface.</p>	<p>The Manual Tuning interface offers two options to adjust the loop gains. Each parameter can be adjusted on an individual basis, or as an entire set of gains that are adjusted proportionally with a parameter.</p> <p>Adjustments to the System Bandwidth or System Damping recalculates the gains accordingly.</p> 
<p><b>Offset</b></p> 	<p><b>Additional Tune</b></p> 
<p>For a Sercos axis, the Manual Adjust interface provides access to the Dynamics, Gains, Output, Limits, and Offset parameters.</p>	<p>The Manual Tuning interface provides access to additional loop and load parameters that are often adjusted during the tuning process.</p>





Axis Commissioning Comparison (Continued)

Integrated Motion on Sercos Interface	Integrated Motion on the EtherNet/IP Network
<div><p><b>Output</b></p></div>	<div><p><b>Load</b></p></div>
<div><p><b>Torque/Force Scaling</b></p></div> <p>The Torque/Force Scaling attribute is used to convert the acceleration of the servo loop into equivalent percentage-rated torque to the motor. This conversion normalizes the units of the servo loops gains so that variations in feedback resolution, drive scaling, motor/load inertia, and mechanical gear ratios do not affect their values.</p>	<div><p><b>System Inertia</b></p></div> <p>For an EtherNet/IP axis, the Torque/Force Scaling is referred as System Inertia.</p>
<div><p><b>Torque/Force Offset</b></p></div> <p>For a Sercos axis, Torque/Force Offset is on the Offset tab.</p>	<div><p><b>Torque Offset</b></p></div>




## Additional Axis Property Equivalents

This section compares the additional axis property equivalents for Integrated Motion on Sercos and EtherNet/IP systems.

### Additional Axis Property Equivalents Comparison

Integrated Motion on Sercos Interface	Integrated Motion on the EtherNet/IP Network
<div><p><b>Torque Control Compensation Features</b></p><p>A number of important compensation features are included in the torque control loop to help overcome physical effects that are typical in many mechanical systems.</p><p><b>IMPORTANT:</b> For complete details on tuning, see the Motion System Tuning Application Technique, publication <a href="#">MOTION-AT005</a>, for both Sercos and Integrated Motion on the EtherNet/IP network.</p><p><b>Offset – Backlash Compensation</b></p></div>	<div><p><b>Backlash Compensation</b></p></div> <p>Use Backlash Compensation to stabilize the control loop for applications with high load-inertia ratios and mechanical backlash.</p>
<div><p><b>Output – Low Pass and Notch Filters</b></p></div>	<div><p><b>Compliance Compensation</b></p></div> <p>A new feature available in Kinetix 5500 and Kinetix 5700 drives is Adaptive Tuning, which includes the tracking notch filter and gain stabilization features. The Adaptive Tuning features operate while the axis runs to mitigate high frequency resonances and help maintain stability during operation.</p> <p><b>IMPORTANT:</b> The Lead-Lag filter in EtherNet/IP axes can be used in the lead configuration to boost velocity or acceleration loop bandwidth. The filter can also be used in the lag configuration to compensate for the frequency gain boost associated with compliant load mechanics.</p>

Additional Axis Property Equivalents Comparison (Continued)

Integrated Motion on Sercos Interface	Integrated Motion on the EtherNet/IP Network
<div>Offset – Friction Compensation</div> <div></div>	<div>Friction Compensation</div> <div></div> <div>Friction Compensation applies a compensating directional torque or force to the motor to overcome the effects of friction in the mechanical system. This compensation helps to minimize the amount of control effort required.</div>
<div>Load Observer</div> <div>Load observer is not available through the Sercos Axis Properties menu. However, load observer can be configured with message instructions.</div>	<div>Load Observer</div> <div></div> <div>The Load Observer feature is a control loop inside the drive that estimates the mechanical load on the motor and compensates for the load. This feature allows the control loops to treat the motor as if it is unloaded and relatively easy to control.</div>

Additional Axis Property Equivalents Comparison (Continued)

Integrated Motion on Sercos Interface	Integrated Motion on the EtherNet/IP Network
---------------------------------------	--

Loop Gains and Limits

The loop gains between a Sercos and EtherNet/IP axis are similar; however, a few notable differences do exist.

Position Gains and Limits

General	Motion Planner	Units	Drive/Motor	Motor Feedback	Aux Feedback	Conv
Homing	Hookup	Tune	Dynamics	Gains	Output	Limits
Position Gains						
Proportional:		151.99413	1/s	Manual Adjust...		
Integral:		0.0	1/ms-s	Set Custom Gains...		
Velocity Gains						
Proportional:		389.105	1/s			
Integral:		0.0	1/ms-s			
Feedforward Gains						
Velocity:		0.0	%			
Acceleration:		0.0	%			
Integrator Hold: Enabled						

General	Motion Planner	Units	Drive/Motor	Motor Feedback
Homing	Hookup	Tune	Dynamics	Gains
<input type="checkbox"/> Hard Travel Limits				
<input type="checkbox"/> Soft Travel Limits				
Maximum Positive:		0.0	deg/s	
Maximum Negative:		0.0	deg/s	
Position Error Tolerance:		335.53926	deg/s	
Position Lock Tolerance:		3.6	deg/s	
Peak Torque/Force Limit:		288.62973	% Rated	
Continuous Torque/Force Limit:		100.0	% Rated	

Position Loop

Categories:	Position Loop
General	
Motor	
Model	
Motor Feedback	
Scaling	
Hookup Tests	
Polarity	
Autotune	
Load	
Backlash	
Compliance	
Friction	
Observer	
Position Loop	
Gains	
Bandwidth:	19.469685 Hertz
Integrator Bandwidth:	0.0 Hertz
Integrator Hold:	Disabled
Velocity Feedforward:	0.0 %
Limits	
Error Tolerance:	490.47003 deg/s
Lock Tolerance:	3.6 deg/s

Additional Axis Property Equivalents Comparison (Continued)

Integrated Motion on Sercos Interface

Velocity Gains and Limits

GeneralMotion PlannerUnitsDrive/MotorMotor FeedbackAux FeedbackConvergingHomingHookupTuneDynamicsGainsOutputLimitsOffsetFault ActionsT

Position Gains

Proportional:151.994131/sIntegral:0.01/ms-s

Manual Adjust...Set Custom Gains...

Velocity Gains

Proportional:389.1051/sIntegral:0.01/ms-s

Integrator Hold:Enabled

Feedforward Gains

Velocity:0.0%Acceleration:0.0%

nerUnitsDrive/MotorMotor FeedbackAux FeedbackConvergingTuneDynamicsGainsOutputLimitsOffsetFault ActionsT

Manual Adjust...Set Custom Limits...

Custom Limits Attributes

Name	Value	Units	Type
VelocityLimitBipolar	30000.0	deg/s	REAL
AccelerationLimitBipolar	11880096.0	deg/s^2	REAL
VelocityLimitPositive	30000.0	deg/s	REAL
VelocityLimitNegative	-30000.0	deg/s	REAL
VelocityThreshold	0.0	deg/s	REAL
VelocityWindow	1.0	deg/s	REAL
VelocityStandstillWindow	1.0	deg/s	REAL
AccelerationLimitPositive	11880096.0	deg/s^2	REAL
AccelerationLimitNegative	-11880096.0	deg/s^2	REAL

CloseCancelHelp

Acceleration Limits

innerUnitsDrive/MotorMotor FeedbackAux FeedbackConvergingTuneDynamicsGainsOutputLimitsOffsetFault ActionsT

Manual Adjust...Set Custom Limits...

Custom Limits Attributes

Name	Value	Units	Type
VelocityThreshold	0.0	deg/s	REAL
VelocityWindow	1.0	deg/s	REAL
VelocityStandstillWindow	1.0	deg/s	REAL
AccelerationLimitPositive	11880096.0	deg/s^2	REAL
AccelerationLimitNegative	-11880096.0	deg/s^2	REAL
TorqueLimitPositive	288.62973	% Rated	REAL
TorqueLimitNegative	-288.62973	% Rated	REAL
TorqueThreshold	0.0	% Rated	REAL

CloseCancelHelp

Integrated Motion on the EtherNet/IP Network

Velocity Loop

Categories:

GeneralMotorModelMotor FeedbackScalingHookup TestsPolarityAutotuneLoadBacklashComplianceFrictionObserverPosition LoopVelocity LoopAcceleration LoopTorque/Current Loop

Velocity Loop

Gains

Bandwidth:77.87874HertzIntegrator Bandwidth:0.0HertzIntegrator Hold:DisabledAcceleration Feedforward:0.0%

Limits

Velocity Limit Positive:60000.0deg/sVelocity Limit Negative:-60000.0deg/sError Tolerance:806.2357deg/sLock Tolerance:300.0deg/s

**IMPORTANT:** For an EtherNet/IP axis, the Bipolar Velocity Limit does not exist. The Velocity Limit Positive and Velocity Limit Negative limits must be set independently.

Acceleration Loop

Categories:





GeneralMotorModelMotor FeedbackScalingHookup TestsPolarityAutotuneLoadBacklashComplianceFrictionObserverPosition LoopVelocity LoopAcceleration Loop

Acceleration Loop

Acceleration Limit:394512.53deg/s^2Deceleration Limit:394512.53deg/s^2




**IMPORTANT:** For an EtherNet/IP axis, the Bipolar Acceleration Limit does not exist. The Acceleration Limit and Deceleration Limit must be set independently.

Additional Axis Property Equivalents Comparison (Continued)

Integrated Motion on Sercos Interface	Integrated Motion on the EtherNet/IP Network
<p><b>Torque Limits</b></p> 	<p><b>Torque/Current Loop</b></p> 
<p><b>IMPORTANT:</b> For a Sercos axis, direct access to the Torque Loop Gain is not available.</p>	
<p><b>Dynamics</b></p> 	<p><b>Planner</b></p> 

For an EtherNet/IP axis, the Dynamics tab is called Planner.

Additional Axis Property Equivalents Comparison (Continued)

Integrated Motion on Sercos Interface	Integrated Motion on the EtherNet/IP Network
<p><b>Motion Planner</b></p>  <p>The Motion Planner is the part of the controller that takes care of position and velocity information for the axes.</p>	<p><b>Motion Planner Parameters</b></p> <p>For an EtherNet/IP axis, the Output Cam Execution Targets and Master Delay Compensation parameters are located under the Planner Parameter Group listing. Click <a href="#">Parameters...</a> to switch between the page and parameter views.</p>  <p>The Program Stop Action is located under the Actions Parameter Group listing.</p>  <p><b>IMPORTANT:</b> Each Parameter Group list can contain more attributes than the associated page. In some instances, attributes listed in the Parameter Group list are not displayed on the associated page.</p>



## Additional Axis Property Equivalents Comparison (Continued)

## Integrated Motion on Sercos Interface

## Set Custom Stop Action

Name	Value	Units	Type
StoppingTorque	288.62973	% Rated	REAL
StoppingTimeLimit	10.0	s	REAL
BrakeEngageDelayTime	0.0	s	REAL
BrakeReleaseDelayTime	0.0	s	REAL
ResistiveBrakeContactDelay	0.0	s	REAL

## Integrated Motion on the EtherNet/IP Network

## Custom Stop Action

Name	Value	Unit
FeedbackDataLossUserLimit	4	Data Packets
FeedbackSignalLossUserLimit	100.0	% FL Voltage Drop
InverterOverloadAction	<none>	
InverterThermalOverloadUserLimit	110.0	% Inverter Rated
MechanicalBrakeControl	Automatic	
MechanicalBrakeEngageDelay	0.0	s
MechanicalBrakeReleaseDelay	0.0	s
MotorOverloadAction	<none>	
MotorThermalOverloadUserLimit	110.0	% Motor Rated
ProgrammedStopMode	Fast Stop	
ResistiveBrakeContactDelay	0.0	s
ShutdownAction	Disable	
StoppingAction	Current Decel & Disable	
StoppingTimeLimit	1.0	s
StoppingTorque	295.2941	% Motor Rated
VelocityStandstillWindow	300.0	degs/s
VelocityThreshold	27000.0	degs/s

For an EtherNet/IP axis, the Custom Stop Action parameters are located under the Action Parameter Group listing.

## Velocity Offset

Parameter	Value	Units
Friction Compensation	0.0	%
Window	0.0	degs
Reversal Offset	0.0	degs
Stabilization Window	0.0	degs
Velocity Offset	0.0	degs/s
Torque/Force Offset	0.0	%

## Velocity Offset

Name	Value	Unit
AccelerationFeedforwardGain	0.0	%
VelocityDroop	0.0	(degs/s)/% Rated
VelocityErrorTolerance	806.2357	degs/s
VelocityErrorToleranceTime	0.01	s
VelocityIntegratorBandwidth	0.0	Hz
VelocityIntegratorHold	Disabled	
VelocityLimitNegative	-60000.0	degs/s
VelocityLimitPositive	60000.0	degs/s
VelocityLockTolerance	300.0	degs/s
VelocityLoopBandwidth	77.87874	Hz
VelocityLowPassFilterBandwidth	0.0	Hz
VelocityNegativeFeedforwardGain	0.0	%
VelocityOffset	0.0	degs/s

For an EtherNet/IP axis, the Velocity Offset parameter is located under the Velocity Loop Parameter Group listing.

## Diagnostics

This section highlights some of the diagnostic capabilities unique to Integrated Motion on the EtherNet/IP networks.

### Axis Structure

The AXIS\_CIP\_DRIVE axis structure is different as compared to the AXIS\_SERVO\_DRIVE axis structure that is the required axis structure for Sercos-based servo drives. Some of the tags match or have similar functions, while additional tags are included in the AXIS\_CIP\_DRIVE axis structure:

- The AXIS\_SERVO\_DRIVE axis structure contains 209 tags.
- The AXIS\_CIP\_DRIVE axis structure contains 468 tags.

One reason for the increase in tags is the increase in the number of faults, and also the addition of alarm tags. For example, there is a series of basic fault bits that now exist under the Axis Fault word.

#### Basic Axis Fault Tags

Name	Value	Force Mask	Style	Data Type
AX_Ethernet	{...}	{...}		AXIS_CIP_DRIVE
AX_EthernetAxisFault	16#0000_0001		Hex	DINT
AX_EthernetPhysicalAxisFault	1		Decimal	BOOL
AX_EthernetModuleFault	0		Decimal	BOOL
AX_EthernetConfigFault	0		Decimal	BOOL
AX_EthernetGroupFault	0		Decimal	BOOL
AX_EthernetMotionFault	0		Decimal	BOOL
AX_EthernetGuardFault	0		Decimal	BOOL
AX_EthernetInitializationFault	0		Decimal	BOOL
AX_EthernetAPRFault	0		Decimal	BOOL

When a fault condition is detected, the associated fault type bit is set. This action provides a high-level view to determine which fault group is active. Also, the fault types are broken down into individual fault and alarm status bits.

#### Fault and Alarm Status Bits


Name	Value	Force Mask	Style	Data Type
AX_EthernetModuleFaults	16#0000_0000		Hex	DINT
AX_EthernetControlSyncFault	0		Decimal	BOOL
AX_EthernetModuleSyncFault	0		Decimal	BOOL
AX_EthernetTimerEventFault	0		Decimal	BOOL
AX_EthernetModuleHardwareFault	0		Decimal	BOOL
AX_EthernetModuleConnFault	0		Decimal	BOOL
AX_EthernetConnFormatFault	0		Decimal	BOOL
AX_EthernetLocalModeFault	0		Decimal	BOOL
AX_EthernetCPUWatchdogFault	0		Decimal	BOOL
AX_EthernetClockJitterFault	0		Decimal	BOOL
AX_EthernetCyclicReadFault	0		Decimal	BOOL
AX_EthernetCyclicWriteFault	0		Decimal	BOOL
AX_EthernetClockSkewFault	0		Decimal	BOOL
AX_EthernetControlConnFault	0		Decimal	BOOL
AX_EthernetControlClockSyncFault	0		Decimal	BOOL
AX_EthernetModuleClockSyncFault	0		Decimal	BOOL
AX_EthernetLogicWatchdogFault	0		Decimal	BOOL
AX_EthernetDuplicateAddressFault	0		Decimal	BOOL
AX_EthernetModuleAlarmStatus	16#0000_0000		Hex	DINT
AX_EthernetControlSyncAlarm	0		Decimal	BOOL
AX_EthernetModuleSyncAlarm	0		Decimal	BOOL
AX_EthernetTimerEventAlarm	0		Decimal	BOOL
AX_EthernetCPUOverloadAlarm	0		Decimal	BOOL
AX_EthernetClockJitterAlarm	0		Decimal	BOOL
AX_EthernetOutOfRangeAlarm	0		Decimal	BOOL
AX_EthernetClockSkewAlarm	0		Decimal	BOOL
AX_EthernetClockSyncAlarm	0		Decimal	BOOL
AX_EthernetNodeAddressAlarm	0		Decimal	BOOL

Faults

Alarms

## Faults and Alarms Log

The Faults and Alarms Log displays the status of the faults and alarms that the controller logs for each individual axis.



The display is read-only except for the ability to clear each of the logs (Faults, Alarms, and Resets) independently. For example, the Alarms log can be cleared while maintaining the Faults and Resets logs. When online, select the Show checkboxes to toggle between show and hide for the specified group of entries, and click Clear Log to clear the selected log.

---





**IMPORTANT** Only the last 25 faults and alarms are displayed.

---





## High-level Feature Comparison

This section compares features of the selected Kinetix drives.





### Kinetix Product Comparison

					
Topics	Details	Kinetix 6000/6200 Drives	Kinetix 6500 Drives	Kinetix 5500 Drives	Kinetix 5700 Drives
Key Features	Key features	<ul style="list-style-type: none"> <li>Common bus for multi-axis applications</li> <li>Sercos topology</li> </ul>	<ul style="list-style-type: none"> <li>Integrated Motion on an EtherNet/IP network</li> <li>Common bus and modular design</li> </ul>	<ul style="list-style-type: none"> <li>Small footprint with optimized density</li> <li>Drive power ratings optimized to match VP low inertia motor family</li> <li>Innovative common AC/DC bus eliminates hardware, reduces installation time, and lowers costs</li> <li>Integrated Motion on an EtherNet/IP network</li> </ul>	<ul style="list-style-type: none"> <li>Small footprint with optimized power density for high axis applications</li> <li>Innovative and quick install DC bus connection eliminates hardware, reduces installation time, and lowers costs. Higher DC bus current capacity than the Kinetix 5500 drives.</li> <li>Integrated Motion on an EtherNet/IP network</li> </ul>
Ratings	AC input voltage	<ul style="list-style-type: none"> <li>195...264V AC, 3-phase</li> <li>324...528V AC, 3-phase</li> </ul>	324...528V AC, 3-phase	<ul style="list-style-type: none"> <li>195...264V AC, single-phase (H003...H015)</li> <li>195...264V AC, 3-phase</li> <li>324...528V AC, 3-phase</li> </ul>	324...528V AC, 3-phase
	Control power input voltage	95...264V rms, single-phase	95...264V rms, single-phase	24V DC	24V DC
	Output power rating (kW) 460V	1.8...22	1.8...22	0.6...14.6	1.6...60
	Converter rating (kW) 460V	6...45 kW	6...45 kW	0.6...14.9	7.0...46
	Continuous output current (A rms)	2.8...34.6	2.8...34.6	1.0...23A	3.5...120 A
	Peak output current (A rms)	7.0...69.2	7.0...69.2	2.5...57.5	8.5A...226 A
	Peak/Continuous ratio	250% BM05-200%	250% BM05-200%	250%	250%
	Ambient temperature limit	0...50 °C (32...122 °F)	0...50 °C (32...122 °F)	0...50 °C (32...122 °F)	0...50 °C (32...122 °F)
	EMC filters	External	External	External	External
	Standards	C-UL, CE, CSA, TÜV, C-Tick, KC	C-UL, CE, CSA, TÜV, C-Tick, KC, ODVA	C-UL, CE, CSA, TÜV, C-Tick, KC, ODVA, OSHA	C-UL, CE, CSA, TÜV, C-Tick, KC, ODVA, OSHA, RoHS
Drive configurations	Bus configurations that are supported	Common bus/shared DC	Common bus/shared DC	<ul style="list-style-type: none"> <li>Standalone/single-axis</li> <li>Shared AC/DC</li> <li>Shared DC</li> <li>Hybrid</li> </ul>	<ul style="list-style-type: none"> <li>Shared AC/DC</li> <li>Shared DC</li> </ul>
Bus-sharing	Maximum number of axes in a bus-sharing group	1...8 axes (power rail dependent)	1...8 axes (power rail dependent)	1...8 axes	>16 axes per group, limited by max cable length or precharge capability
Axis instance	Axis instance support	<ul style="list-style-type: none"> <li>One full axis instance support</li> <li>1/2 axis instance support (feedback only)</li> </ul>	<ul style="list-style-type: none"> <li>One full axis instance support</li> <li>1/2 axis instance support (feedback only)</li> </ul>	One axis instance support	<ul style="list-style-type: none"> <li>Two full axes instance support</li> <li>2-1/2 axes instance support (feedback only)</li> </ul>
Network	Network compatibility	Sercos interface	EtherNet/IP	EtherNet/IP	EtherNet/IP
Controllers	Controller comparability	L4x, L6x, L7x	L2, L36ERM, L7x, L8	L2, L36ERM, L7x, L8	L2, L36ERM, L7x, L8
Programming	RSLogix™ software	RSLogix software Version 17 or later	RSLogix software Version 18 or later	Logix Designer application Version 21 or later	Logix Designer application Version 26 or later

## Kinetix Product Comparison (Continued)

					
Topics	Details	Kinetix 6000/6200 Drives	Kinetix 6500 Drives	Kinetix 5500 Drives	Kinetix 5700 Drives
Dimensions	Height, mm (in.) <sup>(1)</sup>	287 (11.3)	285 (11.2)	170 (6.7)	300 (11.8)
	Width, mm (in.) <sup>(1)</sup>	125 (5.0)	125 (5.0)	50 (2.0)	55 (2.2)
	Depth, mm (in.) <sup>(1)</sup>	249 (9.8)	290 (11.4)	200 (7.9)	200 (7.9)
	Volume, m <sup>3</sup> (ft <sup>3</sup> )	0.089 (3.143)	0.103 (3.637)	0.017 (0.600)	0.033 (1.165)
Safety	Safety rating	<ul style="list-style-type: none"> <li>SIL 3 PLe</li> <li>Safe Torque Off</li> <li>Safe Speed Monitoring (only with K6200)</li> </ul>	<ul style="list-style-type: none"> <li>SIL 3 PLe</li> <li>Safe Torque Off</li> <li>Safe Speed Monitoring</li> </ul>	<ul style="list-style-type: none"> <li>SIL 3, PLe rated network Safe Torque Off with CIP safety</li> <li>SIL 2, PLd rated hardwired Safe Torque Off</li> </ul>	<ul style="list-style-type: none"> <li>SIL 3, PLe rated network Safe Torque Off with CIP safety</li> <li>SIL3, PLe rated hardwired Safe Torque Off</li> </ul>
Digital inputs	Digital input support	<ul style="list-style-type: none"> <li>Four inputs</li> <li>Enable, home, overtravel (+/-)</li> <li>High-speed registration (2/axis)</li> </ul>	<ul style="list-style-type: none"> <li>Four inputs</li> <li>Enable, home, overtravel (+/-)</li> <li>High-speed registration (2/axis)</li> </ul>	<ul style="list-style-type: none"> <li>Two configurable digital inputs</li> <li>Home/Registration 1 (dual function)</li> <li>High-speed registration</li> </ul>	<ul style="list-style-type: none"> <li>Four configurable digital inputs</li> <li>Home/Registration 1</li> <li>Registration 2</li> <li>Over travel</li> <li>Enable/Regen OK</li> </ul>
Motor support	Motor and actuator compatibility	<ul style="list-style-type: none"> <li>MP-Series™ low and medium inertia motors</li> <li>MP-Series food grade, stainless steel motors</li> <li>MP-Series linear stages and MPAR-Series linear actuators</li> <li>LDL-Series™ and LDC-Series™ linear motors</li> <li>RDD-Series™ direct drive motors</li> <li>Kinetix 6000 IDM system</li> </ul>	<ul style="list-style-type: none"> <li>MP-Series low and medium inertia motors</li> <li>MP-Series food grade, stainless steel motors</li> <li>MP-Series linear stages and MPAR-Series linear actuators</li> <li>LDL-Series and LDC-Series linear motors</li> <li>RDD-Series direct drive motors</li> </ul>	<ul style="list-style-type: none"> <li>VP low inertia servo motor with 2198-H2DCK DSL feedback converter kit</li> <li>MP-Series low and medium inertia motors</li> <li>MP-Series food grade, stainless steel motors</li> <li>MP-Series ball screw linear stages and linear actuators</li> <li>3rd-party induction motors</li> </ul>	<ul style="list-style-type: none"> <li>VP low inertia servo motor with 2198-H2DCK DSL feedback converter kit</li> <li>MP-Series low and medium inertia motors</li> <li>MP-Series food grade, stainless steel motors</li> <li>MP-Series ball screw linear stages and linear actuators</li> <li>3rd-party induction motors</li> </ul>
	Cable length (total), m (ft.)	240 (787.4)	240 (787.4)	250 (820.2)	400 (1 312.3) (Max motor cable length per bus power-sharing group)
	Cable length (max/axis), m (ft.)	90 (295.3)	90 (295.3)	50 (164.0)	90 (295.3)
Motor feedback support	Motor feedback	<b>Kinetix 6000 drive</b> <ul style="list-style-type: none"> <li>Stegmann Hiperface</li> <li>Generic TTL Incremental</li> <li>Generic Sine/Cosine Incremental</li> <li>Heidenhain EnDat 2.1 <sup>(2)</sup></li> <li>Heidenhain EnDat 2.2 <sup>(2)</sup></li> <li>Resolver <sup>(3)</sup></li> </ul> <b>Kinetix 6200 drive</b> <ul style="list-style-type: none"> <li>Stegmann Hiperface</li> <li>Generic TTL Incremental</li> <li>Generic Sine/Cosine Incremental</li> <li>Tamagawa 17 bit serial</li> <li>Heidenhain EnDat 2.1</li> <li>Heidenhain EnDat 2.2</li> </ul>	<ul style="list-style-type: none"> <li>Stegmann Hiperface</li> <li>Generic TTL Incremental</li> <li>Generic Sine/Cosine Incremental</li> <li>Tamagawa 17 bit serial</li> <li>Heidenhain EnDat 2.1</li> <li>Heidenhain EnDat 2.2</li> </ul>	<ul style="list-style-type: none"> <li>Stegmann Hiperface DSL</li> <li>Stegmann Hiperface <sup>(4)</sup></li> </ul>	<b>DSL feedback port</b> <ul style="list-style-type: none"> <li>Stegmann Hiperface DSL</li> <li>Stegmann Hiperface <sup>(4)</sup></li> </ul> <b>Universal feedback port</b> <ul style="list-style-type: none"> <li>Stegmann Hiperface</li> <li>Generic TTL Incremental</li> <li>Generic Sine/Cosine Incremental</li> <li>Heidenhain EnDat 2.1</li> <li>Heidenhain EnDat 2.2</li> </ul>
Auxiliary feedback support	Aux feedback	<b>Kinetix 6000 drives</b> <ul style="list-style-type: none"> <li>Stegmann Hiperface</li> <li>Generic TTL Incremental</li> <li>Generic Sine/Cosine Incremental</li> <li>Heidenhain EnDat 2.1(2)</li> <li>Heidenhain EnDat 2.2(2)</li> </ul> <b>Kinetix 6200 drives</b> <ul style="list-style-type: none"> <li>Stegmann Hiperface</li> <li>Generic TTL Incremental</li> <li>Generic Sine/Cosine Incremental</li> <li>Heidenhain EnDat 2.1</li> <li>Heidenhain EnDat 2.2</li> </ul>	<ul style="list-style-type: none"> <li>Stegmann Hiperface</li> <li>Generic TTL Incremental</li> <li>Generic Sine/Cosine Incremental</li> <li>Heidenhain EnDat 2.1</li> <li>Heidenhain EnDat 2.2</li> </ul>	Not applicable	<b>DSL feedback port</b> <ul style="list-style-type: none"> <li>Stegmann Hiperface DSL</li> <li>Stegmann Hiperface(4)</li> </ul> <b>Universal feedback port</b> <ul style="list-style-type: none"> <li>Stegmann Hiperface</li> <li>Generic TTL Incremental</li> <li>Generic Sine/Cosine Incremental</li> <li>Heidenhain EnDat 2.1</li> <li>Heidenhain EnDat 2.2</li> </ul>

**Kinetix Product Comparison (Continued)**

					
Topics	Details	Kinetix 6000/6200 Drives	Kinetix 6500 Drives	Kinetix 5500 Drives	Kinetix 5700 Drives
<b>Motor control</b>	Surface-mounted permanent magnet motor (SPM)	Yes	Yes	Yes	Yes
	Induction motor (IM)	No	No	Yes	Yes
	Control type	No induction motor control	No induction motor control	<ul style="list-style-type: none"> <li>Induction motor control</li> <li>V/Hz</li> <li>Open-loop vector control</li> </ul>	<ul style="list-style-type: none"> <li>Induction motor control</li> <li>V/Hz</li> <li>Open- and closed-loop vector control</li> </ul>
<b>Performance</b>	Position loop update	125 µs	125 µs	125 µs	125 µs
	Velocity loop update	125 µs	125 µs	125 µs	125 µs
	Current loop update	125 µs	125 µs	125 µs	125 µs
	Pulse width modulation (PWM) frequency	<ul style="list-style-type: none"> <li>8 kHz – 01 modules</li> <li>4 kHz – 02 modules</li> </ul>	<ul style="list-style-type: none"> <li>8 kHz – 01 modules</li> <li>4 kHz – 02 modules</li> </ul>	<ul style="list-style-type: none"> <li>8 kHz – H003</li> <li>4 kHz</li> </ul>	4 kHz
	Current loop bandwidth	1300 Hz	1300 Hz	1000 Hz	1000 Hz
	Velocity loop bandwidth	500 Hz	500 Hz	400 Hz	400 Hz
	Dual loop control	Yes	Yes	No	Yes
	Load observer	Yes (with a message [MSG] instruction)	Yes	Yes	Yes
	Tracking notch	No	No	Yes	Yes
<b>Shunting</b>	Resistive brake modules	Yes	Yes	No	No
	Shunt modules	Yes	Yes	No	Yes
	Dynamic brake modules	No	No	No	Yes (through side car or capacitor module)
	External shunt resistors	Yes (through shunt module BSP2)	Yes (through shunt module BSP2)	Yes	Yes
	Shunt capability	Decentralized shunt (every drive has a shunt)	Decentralized shunt (every drive has a shunt)	Decentralized shunt (every drive has a shunt)	Centralized shunt (only power supplies)
<b>Power supplies</b>	Converter capability	<ul style="list-style-type: none"> <li>Shared DC with standalone non-CIP compliant active front end (AFE) (regenerative power supply [RPS] units)</li> <li>Centralized converter</li> <li>No parallel converter capability</li> </ul>	<ul style="list-style-type: none"> <li>Shared DC with standalone non-CIP compliant active front end (AFE) (regenerative power supply [RPS] units)</li> <li>Centralized converter</li> <li>No parallel converter capability</li> </ul>	<ul style="list-style-type: none"> <li>Integral converter in each drive</li> <li>Allows parallel converters for increased kW rating</li> </ul>	<ul style="list-style-type: none"> <li>Shared DC with standalone non-CIP compliant active front end (AFE) (regenerative power supply [RPS] units)</li> <li>CIP-compliant DC-bus power supply power supplies</li> <li>Allows parallel converters for increased kW rating</li> </ul>

(1) Dimensions that are shown are for the smallest frame.





(2) Requires the use of drive firmware revision 1.116 or later and the 2090-K6CK-KENDAT low-profile feedback module for EnDat to Hiperface conversion.

(3) Resolver support only on motor feedback.

(4) Requires the use of drive firmware revision 2.002 or later and the 2198-H2DCK Hiperface to DSL feedback converter kit for Hiperface to DSL conversion.

## High-level Safety Feature Comparison

This section compares the high-level safety features of the selected Kinetix drives.

				
<b>Topics</b>	<b>Kinetix 6000/6200 Drives</b>	<b>Kinetix 6500 Drives</b>	<b>Kinetix 5500 Drives</b>	<b>Kinetix 5700 Drives</b>
<b>Safety type</b>	<p>Hard-wire STO, catalog numbers:</p> <ul style="list-style-type: none"> <li>• 2094-ACxx-Mxx-S</li> <li>• 2094-BCxx-Mxx-S</li> <li>• 2094-AMxx-S</li> <li>• 2094-BMxx-S</li> <li>• 2099-BMxx-S</li> </ul>	<p>Hard-wire advanced safety, catalog numbers:</p> <ul style="list-style-type: none"> <li>• 2094-SE02F-M00-S0</li> <li>• 2094-EN02D-M01-S0</li> </ul>	<p>Hard-wire STO, catalog numbers:</p> <ul style="list-style-type: none"> <li>• 2198-H003-ERS</li> <li>• 2198-H008-ERS</li> <li>• 2198-H015-ERS</li> <li>• 2198-H025-ERS</li> <li>• 2198-H040-ERS</li> <li>• 2198-H070-ERS</li> </ul> <p>Integrated STO, catalog numbers:</p> <ul style="list-style-type: none"> <li>• 2198-H003-ERS2</li> <li>• 2198-H008-ERS2</li> <li>• 2198-H015-ERS2</li> <li>• 2198-H025-ERS2</li> <li>• 2198-H040-ERS2</li> <li>• 2198-H070-ERS2</li> </ul>	<p>Hard-wire STO mode/Integrated STO mode</p> <p>Catalog numbers:</p> <ul style="list-style-type: none"> <li>• 2198-S086-ERS3</li> <li>• 2198-S130-ERS3</li> <li>• 2198-S160-ERS3</li> <li>• 2198-D006-ERS3</li> <li>• 2198-D012-ERS3</li> <li>• 2198-D020-ERS3</li> <li>• 2198-D032-ERS3</li> <li>• 2198-D057-ERS3</li> </ul>
<b>Configuration</b>	None	Web page	AOP/Studio 5000 application	AOP/Studio 5000 application
<b>Safety connection type</b>	Not applicable	Safety internal to drive, only motion	<ul style="list-style-type: none"> <li>• Catalog numbers that end in -ERS, only motion</li> <li>• Catalog numbers that end in -ERS2, motion and safety</li> </ul>	Motion and safety (if network STO)
<b>Reference</b>	See the Kinetix Safe Torque Off Feature Safety Reference Manual, publication <a href="#">GMC-RM002</a> , for connector data and wiring installation.	See the Kinetix 6200 and Kinetix 6500 Safe Torque Off Multi-axis Servo Drives Safety Reference Manual, publication <a href="#">2094-RM002</a> , for installation and wiring, and Safe Torque Off I/O signals.	<p>See the Kinetix 5500 Servo Drives User Manual, publication <a href="#">2198-UM001</a>, for the STO connector pinout, installation, and wiring information.</p> <p>See the 'Kinetix 5500 Safe Torque Off Integrated Safety' chapter for integrated safety drive specifications, configuration of motion and safety connections, direct motion commands, and the STO bypass feature.</p>	<p>See the Kinetix 5700 Servo Drives User Manual, publication <a href="#">2198-UM002</a>, for the STO connector pinout, installation, and wiring information.</p> <p>See the 'Kinetix 5700 Safe Torque Off Function' chapter for integrated safety drive specifications, configuration of motion and safety connections, direct motion commands, and the STO bypass feature.</p>



## Appendix A – Communication Networks and Managed Communication

See the ‘Communication Networks’ and ‘Manage Controller Communication’ chapters of the ControlLogix 5580 Controllers User Manual, publication [1756-UM543](#), for examples of communication networks and connection resources available for ControlLogix® systems.

### EtherNet/IP Network Communication

The EtherNet/IP network offers control, configuration, and data collection services by layering the Common Industrial Protocol (CIP) over the standard Internet protocols, such as TCP/IP and UDP. This combination of accepted standards provides the capability that is required to support information data exchange and control applications.

#### Connection Overview

A Logix5000™ controller provides connection resources whenever communications are established between two devices. Connections are used when the system contains the following conditions or activities:

- I/O modules, communication modules, and adapters are present in the I/O configuration of the user project.
- Produced or consumed tags are configured in the user project.
- Connected messages are executed in the user application.
- External devices, programming terminals, or HMIs communicate with the controller.

See the ControlLogix 5580 Controllers User Manual, publication [1756-UM543](#), for a detailed explanation of each topic.

## Appendix B – Configuration of the Kinetix 5700 Converter Module

For information on how to configure your Kinetix 5700 drive system with a Logix5000™ controller, see ‘Configure and Start the Kinetix 5700 Drive System’ in the Kinetix 5700 Servo Drives User Manual, publication [2198-UM002](#).

## Appendix C – Design and Implementation Guide for Using Integrated Motion on an EtherNet/IP Network

This section is intended to help balance the needs of the application with the cost of the network components. Motion control brings a need for real-time synchronization to the network, but a managed switched with Quality of Service (QoS) and CIP Sync on each machine is not always needed. However, when linking multiple automation cells or machines together, a managed switch with QoS and CIP Sync must be used. Detailed guidelines can be found in the ‘CIP Sync’ and ‘CIP Sync Sequence of Events’ chapters of the Converged Plantwide Ethernet (CPwE) Design and Implementation Guide, publication [ENET-TD001](#).

### Answers to Frequently Asked Questions

How can real-time applications be accomplished over a non-deterministic network like Ethernet?

- Each time-sensitive device has its own internal clock, accurate to the nanosecond level.
- The internal clocks are synchronized and tuned to a master clock over the network once per second.
- This update mechanism is known as CIP Sync and is part of the IEEE 1588-2008 standard for time synchronization.
- CIP Sync is designed to account for real-time latencies in the network and to allow the devices to ride through master clock changes.



How is motion control accomplished over standard Ethernet?

- The clocks in the servo drives are coordinated to the master clock by using CIP Sync.
- A packet of information is sent out to each drive in advance of when it is needed, so the drive can receive it and execute it when required:
  - Think of these packets as meeting invitations with a location and a time that represents the key position and time stamp coordinates for the axis.
  - Like meeting invitations, the drives receive these packets at random times due to network loading. But because they are sent in advance, the axes still arrive in their coordinated positions at the precise time.
- The drive further interpolates its position between these points to improve smoothness.

What could cause these time-sensitive devices to get out of sync and effect motion accuracy?

- Any traffic that interrupts the CIP Sync messages from being delivered accurately, including these items:
  - Unexpected network traffic without proper prioritization.
  - Broadcast traffic without proper prioritization.
  - Loops created using unmanaged switches that could fault the system and stop production.
- However, even these disturbances typically add less inaccuracy than the usual mechanical errors induced by system tuning, backlash, and compliance (which are often greater by an order of magnitude).

How can these disturbances be minimized and any risks mitigated?


- Use managed switches with QoS and CIP Sync where economically feasible.
- Connect the time-sensitive devices that include embedded switches directly to the controller.
- Protect any unmanaged switches that are used in manufacturing cells with managed switches where they tie into the greater network.

## Component Selection Guidelines

General guidelines for devices that include an embedded Ethernet switch:

- Connect these devices directly to the controller without an interposing switch when possible.
- Place any switches without CIP Sync at the end of the line of embedded switch products.
- Use a switch that includes CIP Sync if connected between the controller and time-sensitive devices.
- Connect all other types of traffic to the red arrow points or to the switches as shown in [Embedded Ethernet Switch Connection Example on page 41](#).


### Embedded Ethernet Switch Connection Example



General guidelines for single-port Ethernet products (like Kinetix 350 drives):

- For 1...4 axes, offer a Stratix 2000 unmanaged switch<sup>(1)</sup> if price is a concern.
- For 5...8 axes, offer a Stratix 5700 full managed switch<sup>(1)</sup> if price is a concern.
- Over 8 axes, offer a Stratix 5700 full (with CIP Sync) managed switch.
- Use 1783-ETAP devices for ring topologies with Kinetix 350 drives.

### Single-port Ethernet Connection Example



(1) The application must not require tight coordination between axes or minimal following error when using these switches.

## Appendix D – Drive Parameters Cyclic Read and Write List

This section provides cyclic read and write drive parameters.

### Drive Parameters Cyclic Read and Write List

Sercos Axis (Real-time Axis Info) Cyclic Read Parameters	Kinetix 5700 Drive EtherNet/IP Axis Cyclic Read Parameters	EtherNet/IP Axis Cyclic Write Parameters
PositionCommand	PositionFineCommand	PositionTrim
PositionFeedback	PositionReference	VelocityTrim
AuxPositionFeedback	PositionFeedback1	TorqueTrim
PositionError	PositionError	VelocityFeedforwardGain
PositionIntegratorError	PositionIntegratorOutput	AccelerationFeedforwardGain
VelocityCommand	PositionLoopOutput	PositionLoopBandwidth
VelocityFeedback	VelocityFineCommand	PositionIntegratorBandwidth
VelocityError	VelocityFeedforwardCommand	VelocityLoopBandwidth
VelocityIntegratorError	VelocityReference	VelocityIntegratorBandwidth
AccelerationCommand	VelocityFeedback	LoadObserverBandwidth
AccelerationFeedback	VelocityError	LoadObserverIntegratorBandwidth
MarkerDistance	VelocityIntegratorOutput	TorqueLimitPositive
TorqueCommand	VelocityLoopOutput	TorqueLimitNegative
TorqueFeedback	AccelerationFineCommand	VelocityLowPassFilterBandwidth
PositiveDynamicTorqueLimit	AccelerationFeedforwardCommand	TorqueLowPassFilterBandwidth
NegativeDynamicTorqueLimit	AccelerationReference	SystemInertia=
MotorCapacity	AccelerationFeedback	
DriveCapacity	LoadObserverAccelerationEstimate	
PowerCapacity	LoadObserverTorqueEstimate	
BusRegulatorCapacity	TorqueReference	
MotorElectricalAngle	TorqueReferenceFiltered	
TorqueLimitSource	TorqueReferenceLimited	
DCBusVoltage	CurrentCommand	
	CurrentReference	
	CurrentFeedback	
	CurrentError	
	FluxCurrentReference	
	FluxCurrentFeedback	
	FluxCurrentError	
	OperativeCurrentLimit	
	CurrentLimitSource	
	MotorElectricalAngle	
	OutputFrequency	
	OutputCurrent	
	OutputVoltage	

Drive Parameters Cyclic Read and Write List (Continued)

Sercos Axis (Real-time Axis Info) Cyclic Read Parameters	Kinetix 5700 Drive EtherNet/IP Axis Cyclic Read Parameters	EtherNet/IP Axis Cyclic Write Parameters
	OutputPower	
	DCBusVoltage	
	MotorCapacity	
	InverterCapacity	
	<b>Kinetix 5700 Drive EtherNet/IP <u>Converter</u> Axis Cyclic Read Parameters</b>	
	ConverterOutputCurrent	
	ConverterOutputPower	
	DCBusVoltage	
	ConverterCapacity	
	BusRegulatorCapacity	

## Appendix E – Available GSV and SSV Data

This section provides information for system variables.

### Get System Variable (GSV)

Get System Variable (GSV)	Sercos Axis	EtherNet/IP Axis
Acceleration Feedforward Command		X
Acceleration Command	X	
Acceleration Feedback	X	X
Actual Acceleration		X
Actual Position	X	X
Actual Velocity	X	X
Analog Input 1	X	X
Analog Input 2	X	X
Attribute Error Code	X	X
Attribute Error ID	X	X
Aux Position Feedback	X	
Average Velocity	X	X
Axis Configuration		X
Axis Control Bits	X	
Axis Event Bits	X	X
Axis Fault Bits	X	X
Axis Response Bits	X	
Axis Status Bits	X	X
Axis Features		X
Bus Regulator Capacity	X	X
CIP Axis Faults		X
CIP Axis Faults RA		X
CIP Axis IO Status		X
CIP Axis IO Status RA		X
CIP Axis State		X
CIP Axis Status		X
CIP Axis Status RA		X
CIP Initialization Faults		X
CIP Initialization Faults RA		X
CIP Start Inhibit		X
CIP Start Inhibit RA		X
Command Acceleration	X	X
Command Position	X	X
Command Velocity	X	X
Control Method		X
Current Command		X

**Get System Variable (GSV) (Continued)**

<b>Get System Variable (GSV)</b>	<b>Sercos Axis</b>	<b>EtherNet/IP Axis</b>
DC Bus Voltage	X	X
Drive Capacity	X	
Drive Fault Bits	X	
Drive Status Bits	X	
Drive Warning Bits	X	
Guard Faults	X	X
Guard Status	X	X
Hookup Test Commutation Offset		X
Hookup Test Commutation Polarity		X
Hookup Test Feedback 1 Direction		X
Hookup Test Feedback 2 Direction		X
Hookup Test Status		X
Interpolated Actual Position	X	X
Interpolated Command Position	X	X
Inverter Capacity		X
Marker Distance	X	X
Master Offset	X	X
Module Alarm Bits		X
Module Fault Bits	X	X
Module Status Bits	X	
Motor Capacity	X	X
Motion Alarm Bits		X
Motion Fault Bits		X
Motion Status Bits		X
Motor Electrical Angle	X	X
Motor Test Counter EMF		X
Motor Test Inductance		X
Motor Test Resistance		X
Motor Test Status		X
Motor Unit		X
Negative Dynamic Torque Limit	X	
Output Cam Lock Status	X	X
Output Cam Pending Status	X	X
Output Cam Status	X	X
Output Cam Transition Status	X	X
Output Current		X
Output Power		X
Output Voltage		X
Position Command	X	

**Get System Variable (GSV) (Continued)**

<b>Get System Variable (GSV)</b>	<b>Sercos Axis</b>	<b>EtherNet/IP Axis</b>
Position Error	X	X
Position Feedback	X	X
Position Integrator Error	X	
Position Integrator Output		X
Position Loop Output		X
Position Reference		X
Positive Dynamic Torque Limit	X	
Power Capacity	X	
Registration 1 Negative Edge Position		X
Registration 1 Negative Edge Time		X
Registration 1 Position		X
Registration 1 Positive Edge Position		X
Registration 1 Positive Edge Time		X
Registration 1 Time		X
Registration 2 Negative Edge Position		X
Registration 2 Negative Edge Time		X
Registration 2 Position		X
Registration 2 Positive Edge Position		X
Registration 2 Positive Edge Time		X
Registration 2 Time		X
Registration 1 Position	X	X
Registration 1 Time	X	X
Registration 2 Position	X	X
Registration 2 Time	X	X
Sercos Error Code	X	
Start Actual Position	X	X
Start Command Position	X	X
Start Master Offset	X	X
Strobe Actual Position	X	X
Strobe Command Position	X	X
Strobe Master Offset	X	X
Test Direction Forward	X	
Test Status	X	
Torque Feedback	X	
Torque Limit Source	X	
Torque Reference		X
Torque Reference Filtered		X
Torque Reference Limited		X
Tune Acceleration	X	X

**Get System Variable (GSV) (Continued)**

Get System Variable (GSV)	Sercos Axis	EtherNet/IP Axis
Tune Acceleration Time	X	X
Tune Deceleration	X	X
Tune Deceleration Time	X	X
Tune Inertia	X	
Tune Status		X
Velocity Command	X	
Velocity Error	X	X
Velocity Feedback	X	X
Velocity Feedforward Command		X
Velocity Integrator Error	X	
Velocity Integrator Output		X
Velocity Loop Output		X
Velocity Reference		X
Watch Position	X	X

**Set System Variables (SSV)**

Set System Variables (SSV)	Sercos Axis	EtherNet/IP Axis
Acceleration Feedforward Gain	X	X
Acceleration Limit Bipolar	X	
Acceleration Limit Negative	X	
Acceleration Limit Positive	X	
Average Velocity Time Base	X	X
AxisInfoSelect 1	X	
AxisInfoSelect 2	X	
Axis Type	X	
Backlash Reversal Offset	X	X
Backlash Stabilization Window	X	
Brake Engage Time Delay	X	
Brake Release Time Delay	X	
CIP Axis Alarm Log Reset		X
CIP Axis Fault Log Reset		X
Command Update Delay Offset	X	X
Continuous Torque Limit	X	
Control Mode		X
Conversion Constant	X	X
Damping Factor	X	X
Drive Enable Fault Action	X	
Drive Model Time Constant	X	X
Drive Polarity	X	



**Set System Variables (SSV) (Continued)**

<b>Set System Variables (SSV)</b>	<b>Sercos Axis</b>	<b>EtherNet/IP Axis</b>
Drive Thermal Fault Action	X	
Dynamics Configuration Bits	X	X
Fault Configuration Bits	X	
Feedback Configuration		X
Feedback Mode		X
Feedback Fault Action	X	
Feedback Noise Fault Action	X	
Friction Compensation	X	
Friction Compensation Window	X	
Gain Tuning Configuration Bits		X
Hardware Overtravel Fault Action	X	
Home Configuration bits	X	X
Home Direction	X	X
Home Mode	X	X
Home Offset	X	X
Home Position	X	X
Home Return Speed	X	X
Home Sequence	X	X
Home Speed	X	X
Home Torque Level	X	
Hookup Test Distance		X
Hookup Test Feedback Channel		X
Inhibit Axis	X	X
Integrator Hold Enable	X	
Interpolation Time	X	X
Linear Motor Mass	X	
Load Inertia Ratio	X	X
Load Ratio		X
Master Input Configuration Bits	X	X
Master Position Filter Bandwidth	X	X
Maximum Acceleration	X	X
Maximum Acceleration Jerk	X	X
Maximum Deceleration	X	X
Maximum Deceleration Jerk	X	X
Maximum Negative Travel	X	
Maximum Positive Travel	X	
Maximum Speed		X
Motion Polarity		X
Motion Resolution		X

**Set System Variables (SSV) (Continued)**

<b>Set System Variables (SSV)</b>	<b>Sercos Axis</b>	<b>EtherNet/IP Axis</b>
Motor Inertia	X	
Motor Thermal Fault Action	X	
Output LP Filter Bandwidth	X	
Output Notch Filter Frequency	X	
Position Error Fault Action	X	
Position Error Tolerance	X	X
Position Integrator Bandwidth		X
Position Integrator Control		X
Position Integral Gain	X	
Position Lock Tolerance	X	X
Position Loop Bandwidth		X
Position Proportional Gain	X	
Position Servo Bandwidth		X
Position Trim		X
Position Unwind	X	X
Programmed Stop Mode	X	X
Resistive Brake Contact Delay	X	
Rotary Axis	X	
Rotary Motor Inertia	X	
Scaling Source		X
Servo Loop configuration	X	
Soft Overtravel Fault Action	X	
Soft Travel Limit Checking		X
Soft Travel Limit Negative		X
Soft Travel Limit Positive		X
Stopping Action		X
Stopping Time Limit	X	
Stopping Torque	X	X
System Bandwidth		X
System Damping		X
System Inertia		X
Test Increment	X	
Torque Limit Bipolar	X	
Torque Limit Negative	X	X
Torque Limit Positive	X	X
Torque Offset	X	X
Torque Scaling	X	
Torque Threshold	X	X
Torque Trim		X

**Set System Variables (SSV) (Continued)**

<b>Set System Variables (SSV)</b>	<b>Sercos Axis</b>	<b>EtherNet/IP Axis</b>
Travel Mode		X
Travel Range		
Tune Friction		X
Tune Inertia Mass		X
Tune Load Offset		X
Tuning Configuration Bits	X	
Tuning Direction		X
Tuning Select		X
Tuning Speed	X	X
Tuning Torque	X	X
Tuning Travel Limits	X	X
Velocity Droop	X	X
Velocity Feedforward Gain	X	X
Velocity Integral Gain	X	
Velocity Integrator Bandwidth		X
Velocity Integrator Control		X
Velocity Limit Bipolar	X	
Velocity Limit Negative	X	X
Velocity Limit Positive	X	X
Velocity Loop Bandwidth		X
Velocity Offset	X	X
Velocity Proportional Gain	X	
Velocity Servo Bandwidth	X	X
Velocity Standstill Window	X	X
Velocity Threshold	X	X
Velocity Trim		X
Velocity Window	X	

## Appendix F – Axis Attributes

This section highlights some of the differences in tags between Sercos axes and EtherNet/IP axes. Some tags in a Sercos axis are not applicable to an EtherNet/IP axis, and vice versa. Some tag names changed between Sercos and EtherNet/IP, such as AuxPositionFeedback and PositionFeedback2. See the Integrated Motion on the EtherNet/IP Network Reference Manual, publication [MOTION-RM003](#), for a comprehensive list of EtherNet/IP Axis Attributes.

AXIS_SERVO_DRIVE Sercos Axis	Type	AXIS_CIP_DRIVE EtherNet/IP Axis	Type	Description
N/A	N/A	DirectVelocity ControlStatus	BOOL	When the Direct Velocity Control Status bit is set, the Direct Command Velocity value controls the axis speed. The Motion Drive Start instruction (MDS) sets this bit, and only applies to CIP drive axis types.
N/A	N/A	DirectTorque ControlStatus	BOOL	When the Direct Torque Control Status bit is set, the Command Torque value controls the axis torque. The Motion Drive Start instruction (MDS) sets this bit, and only applies to CIP drive axis types.
N/A	N/A	MotionAlarm Status	DINT	0 = Reserved 1 = SoftTravelLimitPositiveAlarm 2 = SoftTravelLimit NegativeAlarm 3...31 = Reserved
N/A	N/A	SoftTravelLimit PositiveAlarm	BOOL	This exception condition occurs when Soft Travel Checking is enabled and when actual position has exceeded the configured Soft Travel Limit - Positive attribute value in the positive direction. If the Motion Exception Action for this bit is set for Stop Planner, the faulted axis can be moved or jogged back inside the soft travel limits. However, any attempt to move the axis beyond the Soft Travel Limit - Positive value by using a motion instruction results in an instruction error.
N/A	N/A	SoftTravelLimit NegativeAlarm	BOOL	This exception condition occurs when Soft Travel Checking is enabled and when actual position has exceeded the configured Soft Travel Limit - Negative attribute value in the negative direction. If the Motion Exception Action for this bit is set for Stop Planner, the faulted axis can be moved or jogged back inside the soft travel limits. However, any attempt to move the axis beyond the Soft Travel Limit - Negative value by using a motion instruction results in an instruction error.
N/A	N/A	MotionFaultStatus	DINT	0 = Reserved 1 = SoftTravelLimitPositiveFault 2 = SoftTravelLimitNegativeFault 3...31 = Reserved
N/A	N/A	SoftTravelLimit PositiveFault	BOOL	This exception condition occurs when Soft Travel Checking is enabled and when actual position has exceeded the configured Soft Travel Limit - Positive attribute value in the positive direction. If the Motion Exception Action for this bit is set for Stop Planner, the faulted axis can be moved or jogged back inside the soft travel limits. However, any attempt to move the axis beyond the Soft Travel Limit - Positive value by using a motion instruction results in an instruction error.
N/A	N/A	SoftTravelLimit NegativeFault	BOOL	This exception condition occurs when Soft Travel Checking is enabled and when actual position has exceeded the configured Soft Travel Limit - Negative attribute value in the negative direction. If the Motion Exception Action for this bit is set for Stop Planner, the faulted axis can be moved or jogged back inside the soft travel limits. However, any attempt to move the axis beyond the Soft Travel Limit - Negative value by using a motion instruction results in an instruction error.
N/A	N/A	Registration1 PositiveEdgePosition	REAL	Feedback position that is latched on the rising edge of the Registration Input 1.

AXIS_SERVO_DRIVE Sercos Axis	Type	AXIS_CIP_DRIVE EtherNet/IP Axis	Type	Description
N/A	N/A	Registration1 NegativeEdgePosition	REAL	Feedback Position latched on the falling edge of the Registration Input 1.
N/A	N/A	Registration2 PositiveEdgePosition	REAL	Feedback position that is latched on the rising edge of the Registration Input 2.
N/A	N/A	Registration2 NegativeEdgePosition	REAL	Feedback Position latched on the falling edge of the Registration Input 2.
N/A	N/A	Registration1 PositiveEdgeTime	DINT	CST time stamp on the rising edge of the Registration Input 1.
N/A	N/A	Registration1 NegativeEdgeTime	DINT	CST time stamp on the falling edge of the Registration Input 1.
N/A	N/A	Registration2 PositiveEdgeTime	DINT	CST time stamp on the rising edge of the Registration Input 2.
N/A	N/A	Registration2 NegativeEdgeTime	DINT	CST time stamp on the falling edge of the Registration Input 2.
N/A	N/A	DirectCommand Velocity	REAL	<p>The Direct Command Velocity attribute provides tag access to the velocity command for the specified axis. Use this attribute to control the speed of a motor when an associated drive is configured for velocity control mode.</p> <p>For the value of this attribute, to be applied as the velocity command, a Motion Drive Start instruction is executed. The instruction sets the Direct Velocity Control Status bit of the Motion Status Bits attribute.</p> <p>If this bit is not set, the Direct Command Velocity value has no effect on axis motion. Only CIP Drive Axis data types currently support this capability.</p>
PositionCommand	REAL	<i>Equivalent:</i> PositionFine Command	REAL	The Position Fine Command attribute is the output value from the Command Position fine interpolator.
N/A	N/A	PositionReference	REAL	The Position Reference attribute is the command position reference signal into the position loop-summing junction to be compared with a position feedback signal.
PositionFeedback	REAL	PositionFeedback1	REAL	The Position Feedback 1 attribute is the actual position of the encoder.
AuxPosition Feedback	REAL	PositionFeedback2	REAL	The Position Feedback 2 attribute is the actual position of the encoder.
PositionIntegrator Error	REAL	PositionIntegrator Output	REAL	The Position Integrator Output attribute is the output of position integrator that represents the contribution of the position integrator to Position Loop Output.
N/A	N/A	PositionLoop Output	REAL	The Position Loop Output attribute is the output of the position loop forward path that represents the total control effort of the position loop.
VelocityCommand	REAL	<i>Equivalent:</i> VelocityFine Command	REAL	<p>The Velocity Fine Command attribute is the output value from the Command Velocity fine interpolator.</p> <p>When no Command Velocity signal is present when performing position control, this signal can be derived by scaling the Differential Position output value of the Command Position fine interpolator.</p>
N/A	N/A	VelocityFeedforwardCommand	REAL	<p>The Velocity Feedforward Command attribute is a command signal that represents a scaled version of the command velocity profile.</p> <p>This signal is the Velocity Fine Command signal that is scaled by Velocity Feedforward Gain and applied to the output of the position loop.</p>
N/A	N/A	VelocityReference	REAL	Command velocity reference into velocity loop summing junction.
VelocityIntegrator Error	REAL	VelocityIntegrator Output	REAL	Output of velocity integrator that represents the contribution of the velocity integrator to Velocity Loop Output.

AXIS_SERVO_DRIVE Sercos Axis	Type	AXIS_CIP_DRIVE EtherNet/IP Axis	Type	Description
N/A	N/A	VelocityLoop Output	REAL	Output of velocity forward path that represents the total control effort of the velocity loop.
N/A	N/A	AccelerationFine Command	REAL	The Acceleration Fine Command attribute is the output value from the Command Acceleration fine interpolator. When no Command Acceleration signal is present when performing position or velocity control, this signal can be derived by scaling the Differential Velocity output value of the Command Velocity fine interpolator. If no Command Velocity signal is present, the Interpolated Command Acceleration signal can be derived by scaling the second Differential Position output value of the Command Position fine interpolator.
N/A	N/A	Acceleration FeedforwardCommand	REAL	The Acceleration Feedforward Command attribute is a signal that represents a scaled version of the command acceleration profile. This signal is the Acceleration Fine Command signal that is scaled by Acceleration Feedforward Gain and applied to the output of the velocity loop.
N/A	N/A	Acceleration Reference	REAL	Command velocity reference into velocity loop summing junction.
N/A	N/A	LoadObserver AccelerationEstimate	REAL	Output of the Load Observer that, when the Load Observer block is enabled, is applied to the acceleration reference-summing junction. In the Load Observer configuration, this signal compensates for disturbances to the load relative to an ideal load model. When the Load Observer is configured to operate in Acceleration Feedback Only mode, this signal is the estimated acceleration feedback signal that is used to close the acceleration loop. When the Load Observer is disabled, this signal is 0.
N/A	N/A	LoadObserver TorqueEstimate	REAL	Product of the Load Observer Acceleration Estimate signal and the current System Inertia value, Kj. In the Load Observer configuration, this signal represents the estimated torque disturbances to the load relative to an ideal load model. When the Load Observer is configured to operate in Acceleration Feedback Only mode, this signal is an estimate of the applied motor torque. When the Load Observer is disabled, this signal is 0.
N/A	N/A	CommandTorque	REAL	Command torque output from Fine Command Generator (if active) into torque input summing junction when configured for torque control.
N/A	N/A	TorqueReference	REAL	Commanded torque reference input signal before torque filter section that represents the sum of the Torque Command and Torque Trim signal inputs.
N/A	N/A	TorqueReference Filtered	REAL	Commanded torque reference input signal after torque filter section.
N/A	N/A	TorqueReference Limited	REAL	Commanded torque reference input signal after torque limiter section.
TorqueCommand	REAL	<i>Equivalent:</i> CurrentReference	REAL	Current reference signal, Iq, into the torque-producing current loop-summing junction.
N/A	N/A	CurrentCommand	REAL	Represents the instantaneous commanded torque-producing current signal, Iq, before passing through the Current Vector Limiter. The attribute is tied directly to the output of torque reference path after the 1/Kt scaling that represents the torque effort to be applied to the torque-producing Iq current loop of the drive. The nominal value for 1/Kt is 1 based on 100% rated torque that is produced by 100% rated current.
TorqueFeedback	REAL	<i>Equivalent:</i> CurrentFeedback	REAL	Actual torque current that is applied to the axis based on current sensor feedback (% Motor Rated).
N/A	N/A	CurrentError	REAL	Error between commanded and actual current that is the output of the torque-producing, q-axis, current loop.

AXIS_SERVO_DRIVE Sercos Axis	Type	AXIS_CIP_DRIVE EtherNet/IP Axis	Type	Description
N/A	N/A	FluxCurrent Reference	REAL	Command current reference, Id, into the flux-producing current loop-summing junction.
N/A	N/A	FluxCurrent Feedback	REAL	Actual flux current that is applied to the axis based on current sensor feedback.
N/A	N/A	FluxCurrentError	REAL	Error between commanded and actual current that is the output of the flux-producing, d-axis, current loop summing junction.
N/A	N/A	OperativeCurrent Limit	REAL	Represents the operative current limit that is based on multiple limit sources.
TorqueLimit Source	DINT	<i>Equivalent:</i> CurrentLimit Source	DINT	Represents the operative source of a current limit if a current limit condition occurs.
N/A	N/A	SlipCompensation	REAL	Indicates the actual amount of slip compensation currently being applied.
N/A	N/A	OutputFrequency	REAL	The Output Frequency attribute is the time averaged output frequency that is applied to motor. Frequency value is in terms of electrical cycles.
N/A	N/A	OutputCurrent	REAL	The Output Current attribute is the total time averaged output current applied to motor.
N/A	N/A	OutputVoltage	REAL	The Output Voltage attribute is the total time averaged phase-to-phase output voltage that is applied to motor.
N/A	N/A	OutputPower	REAL	The Output Power attribute is the total time averaged output power of the motor. This value is based on the product of the Torque Reference signal and the Velocity Feedback.
DriveCapacity	REAL	<i>Equivalent:</i> InverterCapacity	REAL	The Inverter Capacity attribute is the real-time estimate of the continuous rated inverter thermal capacity that is used during operation that is based on the inverter thermal model. A value of 100% indicates that the inverter is being used at 100% of rated capacity as determined by the continuous current rating of the inverter.
PowerCapacity	REAL	<i>Equivalent:</i> Converter Capacity	REAL	The Converter Capacity attribute is the real-time estimate of the continuous rated converter thermal capacity that is used during operation that is based on the converter thermal model. A value of 100% indicates that the converter is being used at 100% of rated capacity as determined by the continuous current rating of the converter.
N/A	N/A	DigitalInputs	DINT	The Digital Inputs attribute is a 32-bit word with bits assigned by the vendor to general-purpose digital inputs.
N/A	N/A	PositionTrim	REAL	The Position Trim attribute is an additional position command added to the Position Command to generate the Position Reference signal into the position loop-summing junction.
VelocityOffset	REAL	<i>Equivalent:</i> VelocityTrim	REAL	Additional velocity command added to the velocity loop-summing junction.
Acceleration Command	REAL	<i>Equivalent:</i> AccelerationTrim	REAL	Additional acceleration command added to the acceleration loop-summing junction.
TorqueOffset	REAL	<i>Equivalent:</i> TorqueTrim	REAL	Additional torque command added to the torque input summing junction.
N/A	N/A	VelocityFeed forwardGain	REAL	The Velocity Feedforward Gain attribute multiplies the Velocity Feedforward Command signal to form the Velocity Feedforward Command that is applied to the velocity loop-summing junction.
N/A	N/A	Acceleration FeedforwardGain	REAL	The Acceleration Feedforward Gain attribute is a value that multiplies the Acceleration Fine Command signal to form the Acceleration Feedforward Command that is applied acceleration loop summing junction.

<b>AXIS_SERVO_DRIVE</b> Sercos Axis	<b>Type</b>	<b>AXIS_CIP_DRIVE</b> EtherNet/IP Axis	<b>Type</b>	<b>Description</b>
N/A	N/A	PositionLoop Bandwidth	REAL	The Position Loop Bandwidth attribute determines the proportional gain, Kpp, of the position loop that multiplies the Position Error signal. This value represents the unity gain bandwidth of the position loop beyond which the position loop is ineffective.
N/A	N/A	PositionIntegrator Bandwidth	REAL	The Position Integrator Bandwidth attribute determines the position loop integral gain, Kpi, which together with the Kpp, multiplies the integrated Position Error signal. This value represents the bandwidth of the position integrator beyond which the integrator is ineffective. A value of 0 for this attribute disables the integrator.
N/A	N/A	VelocityLoop Bandwidth	REAL	The Velocity Loop Bandwidth attribute is a value that determines the proportional gain, Kvp, of the velocity loop that multiplies the Velocity Error signal. This value represents the unity gain bandwidth of the velocity loop.
N/A	N/A	VelocityIntegrator Bandwidth	REAL	The Velocity Integrator Bandwidth attribute determines the velocity loop integral gain, Kvi, which together with the Kvp, multiplies the integrated Velocity Error signal. This value represents the bandwidth of the velocity integrator beyond which the integrator is ineffective. A value of 0 for this attribute disables the integrator.
N/A	N/A	LoadObserver Bandwidth	REAL	The Load Observer Bandwidth attribute determines the proportional gain, Kop, of the load observer. This value represents the unity gain bandwidth of the load observer.
N/A	N/A	LoadObserver IntegratorBandwidth	REAL	The Load Observer Integrator Bandwidth attribute determines the load observer integral gain, Koi, which together with the Kop, multiplies the integrated error signal within the observer. This value represents the bandwidth of the integrator beyond which the integrator is ineffective. A value of 0 for this attribute disables the integrator.
N/A	N/A	TorqueLimit Positive	REAL	This positive value determines the maximum positive torque that can be applied to the motor. If the device attempts to exceed this value, the torque command is clamped to this value.
N/A	N/A	TorqueLimit Negative	REAL	This negative value determines the most negative torque value that can be applied to the motor. If the device attempts to apply a more negative torque than this limit, the torque command is clamped to this value.
N/A	N/A	VelocityLowPass FilterBandwidth	REAL	The Velocity Low Pass Filter Bandwidth attribute controls the bandwidth of the Low Pass Filter applied to the Velocity Error signal. The recommended implementation is a two-pole IIR filter. A value of 0 for this attribute disables this feature.
N/A	N/A	TorqueLowPass FilterBandwidth	REAL	Break frequency for the second order low pass filter that is applied to torque reference signal.
N/A	N/A	SystemInertia	REAL	Torque or force scaling gain value that converts commanded acceleration into equivalent rated torque/force. Properly set, this value represents the total system inertia or mass.
N/A	N/A	Current Disturbance	REAL	Injected current command that produces torque that is used to excite the motor as part of Frequency Analysis service.
N/A	N/A	DigitalOutputs	DINT	The Digital Outputs attribute is a 32-bit word with bits assigned by the vendor to general-purpose digital outputs.
N/A	N/A	AnalogOutput1	REAL	The Analog Output 1 attribute is a general-purpose analog output 1 level.
N/A	N/A	AnalogOutput2	REAL	The Analog Output 1 attribute is a general-purpose analog output 2 level.
MarkerDistance	REAL	N/A	N/A	Marker Distance in Position Units.



AXIS_SERVO_DRIVE Sercos Axis	Type	AXIS_CIP_DRIVE EtherNet/IP Axis	Type	Description																																																																																											
PosDynamicTorqueLimit	REAL	N/A	N/A	The currently operative maximum positive torque/current limits magnitude. It is the lowest value of all torque/current limits in the drive at a given time, including: amplifier peak limit, motor peak limit, user current limit, amplifier thermal limit, and motor thermal limit.																																																																																											
NegDynamicTorqueLimit	REAL	N/A	N/A	The currently operative negative positive torque/current limits magnitude. It is the lowest value of all torque/current limits in the drive at a given time, including: amplifier peak limit, motor peak limit, user current limit, amplifier thermal limit, and motor thermal limit.																																																																																											
DriveStatus	DINT	N/A	N/A	The status bits for your servo drive.																																																																																											
				Bit	No.	Data Type	Description	- no tag -	00	DINT	Servo Action Status	- no tag -	01	DINT	Drive Enable Status	- no tag -	02	DINT	Axis Shutdown Status	ProcessStatus	03	DINT	Process Status	Reserved	04, 05	N/A	Reserved	HomeInputStatus	06	DINT	Home Input Status	Reg1InputStatus	07	DINT	Registration 1 Input Status	Reg2InputStatus	08	DINT	Registration 12Input Status	PosOvertravelInputStatus	09	DINT	Positive Overtravel Input Status	NegOvertravelInputStatus	10	DINT	Negative Overtravel Input Status	EnableInputStatus	11	DINT	Enable Input Status	AccelLimitStatus	12	DINT	Accel Limit Status	AbsoluteReferenceStatus	13	DINT	Absolute Reference Status	Reserved	14, 15	N/A	Reserved	VelocityLockStatus	16	DINT	Velocity Lock Status	VelocityStandstillStatus	17	DINT	Velocity Standstill Status	VelocityThresholdStatus	18	DINT	Velocity Threshold Status	TorqueThresholdStatus	19	DINT	Torque Threshold Status	TorqueLimitStatus	20	DINT	Torque Limit Status	VelocityLimitStatus	21	DINT	Velocity Limit Status	PosLockStatus	22	DINT	Position Lock Status	Reserved	23...31	N/A	Reserved
				Bit	No.	Data Type	Description																																																																																								
				- no tag -	00	DINT	Servo Action Status																																																																																								
				- no tag -	01	DINT	Drive Enable Status																																																																																								
				- no tag -	02	DINT	Axis Shutdown Status																																																																																								
				ProcessStatus	03	DINT	Process Status																																																																																								
				Reserved	04, 05	N/A	Reserved																																																																																								
				HomeInputStatus	06	DINT	Home Input Status																																																																																								
				Reg1InputStatus	07	DINT	Registration 1 Input Status																																																																																								
				Reg2InputStatus	08	DINT	Registration 12Input Status																																																																																								
				PosOvertravelInputStatus	09	DINT	Positive Overtravel Input Status																																																																																								
				NegOvertravelInputStatus	10	DINT	Negative Overtravel Input Status																																																																																								
				EnableInputStatus	11	DINT	Enable Input Status																																																																																								
				AccelLimitStatus	12	DINT	Accel Limit Status																																																																																								
				AbsoluteReferenceStatus	13	DINT	Absolute Reference Status																																																																																								
				Reserved	14, 15	N/A	Reserved																																																																																								
				VelocityLockStatus	16	DINT	Velocity Lock Status																																																																																								
				VelocityStandstillStatus	17	DINT	Velocity Standstill Status																																																																																								
				VelocityThresholdStatus	18	DINT	Velocity Threshold Status																																																																																								
				TorqueThresholdStatus	19	DINT	Torque Threshold Status																																																																																								
				TorqueLimitStatus	20	DINT	Torque Limit Status																																																																																								
				VelocityLimitStatus	21	DINT	Velocity Limit Status																																																																																								
PosLockStatus	22	DINT	Position Lock Status																																																																																												
Reserved	23...31	N/A	Reserved																																																																																												
ProcessStatus	BOOL	N/A	N/A	Process Status																																																																																											
BusReadyStatus	BOOL	N/A	N/A	Bus Ready Status																																																																																											
AbsoluteReferenceStatus	BOOL	N/A	N/A	Absolute Reference Status																																																																																											
SafeOffModeActiveStatus	BOOL	N/A	N/A	Safe-off Mode Active Status																																																																																											

<b>AXIS_SERVO_DRIVE Sercos Axis</b>	<b>Type</b>	<b>AXIS_CIP_DRIVE EtherNet/IP Axis</b>	<b>Type</b>	<b>Description</b>
PowerLimitStatus	BOOL	N/A	N/A	Power Limit Status
LowVelocityThresholdStatus	BOOL	N/A	N/A	Low Velocity Threshold Status
HighVelocityThresholdStatus	BOOL	N/A	N/A	High Velocity Threshold Status
N/A	N/A	CIPAxisState	INT	Bitmap: 0 = Initializing 1 = Pre-Charge 2 = Stopped 3 = Starting 4 = Running 5 = Testing 6 = Stopping 7 = Aborting 8 = Faulted 9 = Start Inhibited 10 = Shutdown 11 = Axis Inhibited 12 = Not Grouped 13 = No Module 14...255 = Reserved
N/A	N/A	CIPAxisStatus	DINT	Bitmap: 0 = Local Control 1 = Alarm 2 = DC Bus Up 3 = Power Structure Enabled 4 = Motor Flux Up 5 = Tracking Command 6 = Position Lock 7 = Velocity Lock 8 = Velocity Standstill 9 = Velocity Threshold 10 = Velocity Limit 11 = Acceleration Limit 12 = Deceleration Limit 13 = Torque Threshold 14 = Torque Limit 15 = Current Limit 16 = Thermal Limit 17 = Feedback Integrity 18 = Shutdown 19 = In Process 20...31 = Reserved
N/A	N/A	LocalControlStatus	BOOL	This bit is set if axis is taking command reference and services from local interface instead of the remote (Integrated Motion on the EtherNet/IP network) interface.
N/A	N/A	AlarmStatus	BOOL	This bit is set if the axis has detected one or more exception conditions that are configured to generate an alarm.
N/A	N/A	DCBusUpStatus	BOOL	This bit is set if DC Bus has charged up to an operational voltage level.
N/A	N/A	PowerStructureEnabledStatus	BOOL	This bit is set if the axis amplifier is energized and capable to generate motor flux and torque.
N/A	N/A	MotorFluxUpStatus	BOOL	This bit is set if motor flux for an induction motor has reached an operational level.

<b>AXIS_SERVO_DRIVE Sercos Axis</b>	<b>Type</b>	<b>AXIS_CIP_DRIVE EtherNet/IP Axis</b>	<b>Type</b>	<b>Description</b>
N/A	N/A	Tracking CommandStatus	BOOL	This bit is set if the axis control structure is now actively tracking the command reference from motion planner.
AccelLimitStatus	BOOL	AccelerationLimit Status	BOOL	This bit is set if the acceleration reference signal is being limited by the Acceleration Limiter.
N/A	N/A	DecelerationLimit Status	BOOL	This bit is set if the acceleration reference signal is being limited by the Deceleration Limiter.
N/A	N/A	CurrentLimit Status	BOOL	This bit is set if the command current, Iq, is being limited by the Current Vector Limiter.
N/A	N/A	ThermalLimit Status	BOOL	This bit is set if Current Vector Limit condition of the axis is being limited by any of the Thermal Models of the axis.
N/A	N/A	FeedbackIntegrity Status	BOOL	<p>This bit, when set, indicates that the feedback device is accurately reflecting changes to axis position. Also, there have been no conditions detected that would compromise the quality of the feedback position value. The bit is set at power-up after the feedback device passes any power-up self-test required.</p> <p>If Feedback Integrity is cleared, the Axis Homed Status attribute is also cleared. This clearing prevents Soft Overtravel from checking if during operation a feedback exception occurs that could affect the fidelity of axis position, the bit is immediately cleared. The bit remains clear until the drive executes a fault reset, or you power cycle the drive.</p> <p>The drive generates Fault Resets, or the resets can be initiated by the controller via motion instructions.</p> <p>The Feedback Integrity bit behavior applies to both absolute and incremental feedback device operation.</p>
N/A	N/A	CIPShutdown Status	BOOL	This bit is set when the axis is in the shutdown state or in the faulted state but would transition to the shutdown state if the faults were cleared.
N/A	N/A	InProcessStatus	BOOL	This bit is set for the duration of an active process. An example of active process is an operation that is initiated by a Run Motor Test, Run Hookup Test, or Run Inertia Test request service.
N/A	N/A	CIPAxisStatusRA	DINT	0...31 = Reserved
N/A	N/A	CIPAxisIOStatus	DINT	Bitmap: 0 = Regenerative Power Input Status 1...31 = Reserved
Reg1InputStatus	BOOL	Registration1Input Status	BOOL	Registration 1 Input Status
Reg2InputStatus	BOOL	Registration2Input Status	BOOL	Registration 2 Input Status
PosOvertravel InputStatus	BOOL	PositiveOvertravel InputStatus	BOOL	Positive Overtravel Input Status
NegOvertravel InputStatus	BOOL	Negative OvertravelInputStatus	BOOL	Negative Overtravel Input Status
N/A	N/A	Feedback1 ThermostatStatus	BOOL	Feedback 1 Thermostat Status
N/A	N/A	ResistiveBrake OutputStatus	BOOL	Resistive Brake Output Status
N/A	N/A	MechanicalBrake OutputStatus	BOOL	Mechanical Brake Output Status
N/A	N/A	CIPAxisIOStatus RA	DINT	0...31 = Reserved
N/A	N/A	Regenerative PowerInputStatus	BOOL	This bit represents the logical state of the Regenerative Power Input

AXIS_SERVO_DRIVE Sercos Axis	Type	AXIS_CIP_DRIVE EtherNet/IP Axis	Type	Description
N/A	N/A	CIPStartInhibits	INT	Bitmap: 1 = Axis Enable Input 2 = Motor Not Configured 3 = Feedback Not Configured 4...15 = Reserved
N/A	N/A	AxisEnableInput Inhibit	BOOL	Axis Enable Input is not active.
N/A	N/A	MotorNot ConfiguredInhibit	BOOL	The associated motor has not been configured for use.
N/A	N/A	FeedbackNot ConfiguredInhibit	BOOL	The associated feedback device has not been configured.
N/A	N/A	CIPStartInhibits RA	INT	Bitmap: 1 = Volts Hertz Curve Definition Inhibit 2 = Motor Feedback Required Inhibit 3 = Speed Limit Configuration Inhibit 4 = Torque Prove Configuration Inhibit 5 = Safe Torque Off Inhibit 6 = Safety Reset Required Inhibit 8...15 = Reserved
N/A	N/A	VoltsHertzCurve DefinitionInhibit	BOOL	Conflict exists in the V/Hz curve definition.
N/A	N/A	MotorFeedback RequiredInhibit	BOOL	Cannot run using the selected motor control mode with Primary Feedback or Alternate Feedback set as open loop.
N/A	N/A	SpeedLimit ConfigurationInhibit	BOOL	Speed Ref Limit Conflict, either Minimum Forward Speed Limit exceeds Maximum Forward Speed Limit, or Minimum Reverse Speed Limit exceeds Maximum Reverse Speed Limit.
N/A	N/A	TorqueProve ConfigurationInhibit	BOOL	When Torque Prove Config is enabled, Control Mode, Feedback Mode, Motor Feedback Type, and Motor Option Configuration are properly set.
N/A	N/A	Safe Torque Off Inhibit	BOOL	The safety function has disabled the power structure.
N/A	N/A	SafetyReset RequiredInhibit	BOOL	Toggle the safety reset input before the safety board allows motion again.
N/A	N/A	SafetyNot ConfiguredInhibit	BOOL	The embedded safety function of the drive has not been configured.

## Appendix G – Axis Exceptions

This section highlights some of the differences in axis exceptions between Sercos axes and EtherNet/IP axes. Some exceptions in a Sercos axis are not applicable to an EtherNet/IP axis, and vice versa. See the Integrated Motion on the EtherNet/IP Network Reference Manual, publication [MOTION-RM003](#), for a comprehensive list of EtherNet/IP Axis Attributes.

### Axis Exceptions

AXIS_SERVO_DRIVE	AXIS_CIP_DRIVE	Type	Description
N/A	MotionFault	BOOL	If the Motion Fault bit is set, it indicates that there is one or more fault conditions have occurred related to the Motion Planner function. The specific fault conditions can then be determined through access to the Motion Fault attribute of the associated axis.
<i>Equivalent:</i> GuardFaultExists	GuardFault	BOOL	If the Guard Fault bit is set, it indicates that there is one or more fault conditions that have occurred related to the GuardMotion™ safety function. The specific fault conditions can then be determined through access to the Guard Motion attribute of the associated axis. Guard Faults are only applicable if the drive device is equipped with Guard Safety functionality.
N/A	InitializationFault	BOOL	The Initialization Fault bit is set when initialization of an Integrated Motion on the EtherNet/IP network drive fails for any reason. Specific information concerning the Initialization Fault is found in the standard CIP Initialization attribute, or manufacturer-specific CIP Initialization Fault – RA, and CIP Initialization Fault – manufacturer attributes associated with the CIP Drive axis data types.
N/A	APRFault	BOOL	The APR (Absolute Position Recovery) Fault bit is set when during axis configuration the system is not able to recover the absolute position of the axis. Specific information concerning the APR Fault is found in the standard APR Fault attribute, or manufacturer-specific APR Fault – RA, and APR Fault – manufacturer attributes associated with the CIP Drive axis data types.
N/A	MotionAlarmStatus	DINT	These two attributes collect the fault and alarm exception conditions that are associated with the Motion Planner. When the controller detects one of the listed excepted conditions, the condition is indicated as a Fault or Alarm according to the associated Motion Exception Action attribute value.  In general, Alarms are considered warnings by the control system while Faults result in some form of action to stop the axis.
N/A	SoftTravelLimitPositiveAlarm	BOOL	This exception condition occurs when Soft Travel Checking is enabled and when actual position has exceeded the configured Soft Travel Limit - Positive attribute value in the positive direction. If the Motion Exception Action for this bit is set for Stop Planner, the faulted axis can be moved or jogged back inside the soft travel limits.  However, any attempt to move the axis beyond the Soft Travel Limit - Positive value by using a motion instruction results in an instruction error. As soon as the axis is moved back within the specified soft travel limits, the corresponding Soft Travel Limit - Positive fault bit is automatically cleared.  However the soft travel fault persists through any attempt to clear it while the axis position is still beyond the Soft Travel Limit - Positive value with the axis enabled.
N/A	SoftTravelLimitNegativeAlarm	BOOL	This exception condition occurs when Soft Travel Checking is enabled and when actual position has exceeded the configured Soft Travel Limit - Negative attribute value in the negative direction. If the Motion Exception Action for this bit is set for Stop Planner, the faulted axis can be moved or jogged back inside the soft travel limits.  However, any attempt to move the axis beyond the Soft Travel Limit - Negative value by using a motion instruction results in an instruction error. As soon as the axis is moved back within the specified soft travel limits, the corresponding Soft Travel Limit - Negative fault bit is automatically cleared.  However the soft travel fault persists through any attempt to clear it while the axis position is still beyond the Soft Travel Limit - Negative value with the axis enabled.

**Axis Exceptions (Continued)**

<b>AXIS_SERVO_DRIVE</b>	<b>AXIS_CIP_DRIVE</b>	<b>Type</b>	<b>Description</b>
N/A	MotionFaultStatus	DINT	These two attributes collect the fault and alarm exception conditions that are associated with the Motion Planner. When the controller detects one of the listed exception conditions, the condition is indicated as a Fault or Alarm according to the associated Motion Exception Action attribute value. In general, Alarms are considered warnings by the control system while Faults result in some form of action to stop the axis.
<i>Equivalent:</i> PosSoftOvertravel Fault	SoftTravelLimitPositiveFault	BOOL	This exception condition occurs when Soft Travel Checking is enabled and when actual position has exceeded the configured Soft Travel Limit - Positive attribute value in the positive direction. If the Motion Exception Action for this bit is set for Stop Planner, the faulted axis can be moved or jogged back inside the soft travel limits. However, any attempt to move the axis beyond the Soft Travel Limit - Positive value by using a motion instruction results in an instruction error. As soon as the axis is moved back within the specified soft travel limits, the corresponding Soft Travel Limit - Positive fault bit is automatically cleared. However the soft travel fault persists through any attempt to clear it while the axis position is still beyond the Soft Travel Limit - Positive value with the axis enabled.
<i>Equivalent:</i> NegSoftOvertravel Fault	SoftTravelLimitNegativeFault	BOOL	This exception condition occurs when Soft Travel Checking is enabled and when actual position has exceeded the configured Soft Travel Limit - Negative attribute value in the negative direction. If the Motion Exception Action for this bit is set for Stop Planner, the faulted axis can be moved or jogged back inside the soft travel limits. However, any attempt to move the axis beyond the Soft Travel Limit - Negative value by using a motion instruction results in an instruction error. As soon as the axis is moved back within the specified soft travel limits, the corresponding Soft Travel Limit - Negative fault bit is automatically cleared. However the soft travel fault persists through any attempt to clear it while the axis position is still beyond the Soft Travel Limit - Negative value with axis enabled.
ModuleFaults	ModuleFaults	DINT	This bit field is a roll-up of module scoped fault conditions that can include synchronization faults that are detected on either side of the Integrated Motion on the EtherNet/IP network connection. All defined Node Fault Codes are mapped into bits in this attribute.
ControlSyncFault	ControlSyncFault	BOOL	If this bit is set, the controller lost communication with the motion module and missed several position updates in a row. The controller can miss up to four position updates. After that, the Control Sync Fault bit is set. The motion module can fault later or can already be faulted. For a consumed axis, this bit means that communication is lost with the producing controller. This bit clears when communication is re-established.
SERCOSRingFault	N/A	BOOL	If this bit is set, there is a problem on the Sercos ring; that is, the light has been broken or a drive has been powered down.
N/A	ModuleConnFault	BOOL	The Module Connection Fault bit indicates that the CIP Motion drive to controller connection from the controller has timed out.
N/A	ConnFormatFault	BOOL	This fault code indicates that an error has occurred in the data format between the controller and the device, for example, a Format Revision mismatch.
N/A	LocalModeFault	BOOL	The Local Mode Fault is set when the controller is locked in Local Mode operation.
N/A	CPUWatchdogFault	BOOL	The Processor Watchdog Fault code indicates that the processor that is associated with the device node has experienced an excessive overload condition that has tripped the associated processor watchdog mechanism.
N/A	ClockJitterFault	BOOL	The Clock Jitter Fault bit is set when there is excessive clock jitter between the controller and the motion device.
N/A	CyclicReadFault	BOOL	The Cyclic Read Fault is set when the controller detects a runtime error that is associated with the Cyclic Read mechanism.
N/A	CyclicWriteFault	BOOL	The Cyclic Write Fault is set when the controller detects a runtime error that is associated with the Cyclic Write mechanism.

**Axis Exceptions (Continued)**

<b>AXIS_SERVO_DRIVE</b>	<b>AXIS_CIP_DRIVE</b>	<b>Type</b>	<b>Description</b>
N/A	ClockSkewFault	BOOL	The Clock Skew Fault bit indicates that the motion device has detected significant difference between the System Time of the device and the System Time of the controller. The difference prevents the device from switching to synchronous operation after a time-out period.
N/A	ControlConnFault	BOOL	The Control Connection Loss fault bit indicates that the Integrated Motion on the EtherNet/IP network C-to-D connection from the controller has timed out.
N/A	ClockSyncFault	BOOL	The Clock Sync Fault bit indicates that the local clock of the motion device has lost synchronization with the master clock for an extended period of time (40 . . . 60 seconds) during synchronous operation. This fault condition is an indication that the local IEEE 1588 clock has lost synchronization with the master and is not able to resynchronize within the allotted timeout (40 . . . 60 seconds).
N/A	LogicWatchdogFault	BOOL	The Logic Watchdog Fault bit indicates that an auxiliary logic component, for example, FPGA, or ASIC, associated with the device node has experienced an excessive overload condition that has tripped the associated logic watchdog mechanism.
N/A	DuplicateAddressFault	BOOL	The Duplicate Address Fault bit indicates that a motion device node has been detected on the network that uses the same Node Address as this device node. For Ethernet, this address would be the IP address of the device.
N/A	ModuleAlarmStatus	DINT	This bit field is a roll-up of module scoped alarm conditions that can include synchronization alarms that are detected on either side of the Integrated Motion on the EtherNet/IP network connection. All defined Node Alarm Codes are mapped into bits in this attribute.
N/A	ControlSyncAlarm	BOOL	If this bit is set, the controller lost communication with the motion module and missed several position updates in a row. The controller can miss up to four position updates. After that, the Control Sync Fault bit is set. The motion module can fault later or can already be faulted. For a consumed axis, this bit means that communication is lost with the producing controller. This bit clears when communication is re-established.
N/A	ModuleSyncAlarm	BOOL	If this bit is set, the motion module lost communication with the controller and missed several position updates in a row. The motion module can miss up to four position updates. After that, the motion module shuts down. This bit clears when communication is re-established.
N/A	TimerEventAlarm	BOOL	If this bit is set, the motion module has a problem with its timer event that synchronizes the servo loop of the module to the master time base of the chassis (that is, Coordinated System Time). To clear this bit, reconfigure the motion module.
N/A	ProcessorOverloadAlarm	BOOL	The Processor Overload Alarm bit indicates that the host processor associated with motion device is experiencing overload conditions that can lead to a fault.
N/A	ClockJitterAlarm	BOOL	The Clock Jitter Alarm bit indicates that the Sync Variance has exceeded the Sync Threshold while the motion device is running in Sync Mode.
N/A	OutOfRangeAlarm	BOOL	The Out of Range Alarm bit is set when the drive determines that a Cyclic Write attribute value is out of range.
N/A	ClockSkewAlarm	BOOL	The Clock Skew Alarm bit indicates that the motion device has detected significant difference between the System Time of the device and the System Time of the controller. The difference prevents the device from switching to synchronous operation.
AxisFault	AxisFault		A fault exists on an axis.

**Axis Exceptions (Continued)**

<b>AXIS_SERVO_DRIVE</b>	<b>AXIS_CIP_DRIVE</b>	<b>Type</b>	<b>Description</b>
PosHardOvertravel Fault	<i>Equivalent:</i> HardwareOvertravelPositive Fault	BOOL	<p>Set if the axis moves beyond the current position limits as established by hardware overtravel limit switches mounted on the equipment. This fault can only occur when the drive is in the enabled state and the Hard Overtravel Checking bit is set in the Fault Configuration Bits attribute. If the Hard Overtravel Fault Action is set for Stop Command, the faulted axis can be moved or jogged back inside the soft overtravel limits.</p> <p>However, any attempt to move the axis beyond the hard overtravel limit switch by using a motion instruction results in an instruction error. To recover from this fault, the axis must be moved back within normal operation limits of the equipment and the limit switch closed. This fault condition is latched and requires execution of a Motion Axis Fault Reset (MAFR) or Motion Axis Shutdown Reset (MASR) instruction to clear.</p> <p>Any attempt to clear the fault while the overtravel limit switch is still open and the drive is enabled is unsuccessful.</p>
MotFeedbackFault	<i>Equivalent:</i> FeedbackSignalLossFLFault	BOOL	<p>Set for the A Quad B feedback device when:</p> <ul style="list-style-type: none"> <li>The differential electrical signals for one or more of the feedback channels (for example, A+ and A-, B+ and B-, or Z+ and Z-) are at the same level (both high or both low). Under normal operation, the differential signals are always at opposite levels. The most common cause of this situation is a broken wire between the feedback transducer and the servo module or drive.</li> <li>Loss of feedback 'power' or feedback 'common' electrical connection between the servo module or drive and the feedback device. The controller latches this fault. Use a Motion Axis Fault Reset (MAFR) or Motion Axis Shutdown Reset (MASR) instruction to clear the fault.</li> </ul>
MotFeedback NoiseFault	<i>Equivalent:</i> FeedbackSignalNoiseFLFault	BOOL	<p>Set when there is noise on the signal lines of the feedback device. For example, simultaneous transitions of the feedback A and B channels of an A Quad B are referred to generally as feedback noise.</p> <p>Feedback noise is caused by loss of quadrature in the feedback device, or radiated common-mode noise signals that the feedback device wiring picks up. You can see both of these noises on an oscilloscope.</p> <p>To troubleshoot the loss of channel quadrature, look for these things:</p> <ul style="list-style-type: none"> <li>Physical misalignment of the feedback transducer components.</li> <li>Excessive capacitance (or other delays) on the encoder signals.</li> </ul> <p>Proper grounding and shielding usually cures radiated noise problems. The controller latches this fault. Use a Motion Axis Fault Reset (MAFR) or Motion Axis Shutdown Reset (MASR) instruction to clear the fault.</p>
AuxFeedbackFault	N/A	BOOL	<p>Set for an auxiliary feedback source when:</p> <ul style="list-style-type: none"> <li>The differential electrical signals for one or more of the feedback channels (for example, A+ and A-, B+ and B-, or Z+ and Z-) are at the same level (both high or both low). Under normal operation, the differential signals are always at opposite levels. The most common cause of this situation is a broken wire between the feedback transducer and the servo module or drive.</li> <li>Loss of feedback 'power' or feedback 'common' electrical connection between the servo module or drive and the feedback device. The controller latches this fault. Use a Motion Axis Fault Reset (MAFR) or Motion Axis Shutdown Reset (MASR) instruction to clear the fault.</li> </ul>
AuxFeedbackNoise Fault	N/A	BOOL	<p>Set when there is noise on the signal lines of the feedback device. For example, simultaneous transitions of the feedback A and B channels of an A Quad B are referred to generally as feedback noise.</p> <p>Feedback noise (shown below) is most often caused by loss of quadrature in the feedback device itself or radiated common-mode noise signals being picked up by the feedback device wiring. You can see both of these on an oscilloscope.</p> <p>To troubleshoot the loss of channel quadrature, look for these things:</p> <ul style="list-style-type: none"> <li>Physical misalignment of the feedback transducer components.</li> <li>Excessive capacitance (or other delays) on the encoder signals.</li> </ul> <p>Proper grounding and shielding usually cures radiated noise problems. The controller latches this fault. Use a Motion Axis Fault Reset (MAFR) or Motion Axis Shutdown Reset (MASR) instruction to clear the fault.</p>



**Axis Exceptions (Continued)**

<b>AXIS_SERVO_DRIVE</b>	<b>AXIS_CIP_DRIVE</b>	<b>Type</b>	<b>Description</b>
DriveEnableInput Fault	<i>Equivalent:</i> EnableInputDeactivatedFault	BOOL	<p>This fault would be declared if either one of two possible conditions occur:</p> <ol style="list-style-type: none"> <li>1. If an attempt is made to enable the axis (typically via MSO or MAH instruction) while the Drive Enable Input is inactive.</li> <li>2. If the Drive Enable Input transitions from active to inactive while the axis is enabled. This fault can only occur when the Drive Enable Input Fault Handling bit is set in the Fault Configuration Bits attribute.</li> </ol> <p>If the Drive Enable Input Fault Action is set for Stop Command and the axis is stopped because of a Drive Enable Input Fault, the faulted axis cannot be moved until the fault is cleared. Any attempt to move the axis in the faulted state by using a motion instruction results in an instruction error.</p> <p>If the Drive Enable Fault Action setting is Status Only or Stop Command and an attempt is made to enable the axis (typically via MSO or MAH instruction) while the Drive Enable Input is active, the axis enables in the faulted state indicating a Drive Enable Input Fault. When the Drive Enable Fault Action setting is Stop Command, instructions that both enable the axis and initiate motion (MAH, MRAT, MAHD) abort the motion process leaving the instruction with both the IP and PC bits clear. This fault condition is latched and requires execution of an explicit MAFR (Motion Axis Fault Reset) or MASR (Motion Axis Shutdown Reset) instruction to clear.</p> <p>Any attempt to clear the fault while the drive enable input is still inactive and the drive is enabled is unsuccessful. However, the drive enable input fault may be cleared with the drive enable input inactive if the drive is disabled.</p> <p>If the Drive Enable Input Checking bit is clear, then the state of the Drive Enable Input is irrelevant so no fault would be declared in any of the above conditions.</p>
CommonBusFault	<i>Equivalent:</i> DCCCommonBusFault	BOOL	The drive shuts down if you give it 3-phase power while it is configured for Common Bus Follower mode. If that happens, this bit turns on.
PreCharge OverloadFault	<i>Equivalent:</i> ConverterPreCharge OverloadFLFault	BOOL	The pre-charge resistor of the drive gets too hot if you cycle 3-phase power too many times. If that happens, this bit turns on.
GuardFaultExists	<i>Equivalent:</i> GuardFault	BOOL	If the Guard Fault bit is set, it indicates that one or more fault conditions have occurred related to the embedded Guard Motion safety function of the drive. The specific fault conditions can then be determined through access to the Guard Fault attribute of the associated axis. Guard Faults are applicable only if the drive device is equipped with hardwired guard safety functionality.
GroundShortFault	<i>Equivalent:</i> ConverterGroundCurrentFL Fault	BOOL	When the drive detects an imbalance in the DC bus supply current, the Ground Short Fault bit is set, indicating that current is flowing through an improper ground connection.
DriveHardFault	N/A	BOOL	Set when the drive detects a serious hardware fault. NOTE: The Axis_CIP_Drive structure provides detailed fault, alarm, and inhibit tags to assist you to diagnose a failure.
OverSpeedFault	<i>Equivalent:</i> MotorOverspeedFLFault	BOOL	Set when the speed of the axis as determined from the feedback has exceeded the over speed limit, which is typically set to 150% of configured velocity limit for the motor.
OverloadFault	N/A	BOOL	When the load limit of the motor/drive is first exceeded, the Overload warning bit is set. If the condition persists, the Overload fault is set. Often this bit is tied into the IT limit of the drive. NOTE: The Axis_CIP_Drive structure provides independent overload tags for all components of the servo system instead of consolidating them into one tag.
DriveOvertemp Fault	N/A	BOOL	Set when the temperature of the drive exceeds the drive shutdown temperature. NOTE: The Axis_CIP_Drive structure provides specific fault and alarm tags for the converter, inverter, and bus regulator to provide more detailed information than this single tag.
MotorOvertemp Fault	<i>Equivalent:</i> MotorOvertemperatureFLFault	BOOL	Set when the temperature of the motor exceeds the motor shutdown temperature.
DriveCoolingFault	N/A	BOOL	Set when the ambient temperature surrounding the control circuitry of the drive temperature exceeds the drive ambient shutdown temperature.

**Axis Exceptions (Continued)**

AXIS_SERVO_DRIVE	AXIS_CIP_DRIVE	Type	Description
DriveControl VoltageFault	<i>Equivalent:</i> ModuleVoltageMismatchFault	BOOL	Set when the power supply voltages associated with the drive circuitry fall outside of acceptable limits.
FeedbackFault	<i>Equivalent:</i> FeedbackDeviceFault	BOOL	Set when one of the feedback sources that are associated with the drive axis has a problem that prevents the drive from receiving accurate or reliable position information from the feedback device. Set when one of the feedback sources for the axis cannot send accurate or reliable position information because there is a problem. For AXIS_SERVO axis, possible problems are: <ul style="list-style-type: none"> <li>The differential electrical signals for one or more of the feedback channels (for example, A+ and A-, B+ and B-, or Z+ and Z-) are at the same level (both high or both low). Under normal operation, the differential signals are always at opposite levels. The most common cause of this situation is a broken wire between the feedback transducer and the servo module or drive.</li> <li>Loss of feedback power or common electrical connection between the servo module or drive and the feedback device.</li> </ul> The controller latches this fault. Use a Motion Axis Fault Reset (MAFR) or Motion Axis Shutdown Reset (MASR) instruction to clear the fault.
CommutationFault	<i>Equivalent:</i> MotorCommutationFault	BOOL	Set when the commutation feedback source that is associated with the drive axis has a problem that prevents the drive from receiving accurate or reliable motor shaft information to perform commutation.
DriveOvercurrent Fault	<i>Equivalent:</i> InverterOvercurrentFault	BOOL	Set when drive output current exceeds the predefined operating limits for the drive. NOTE: As output current is the domain specifically of the inverter, the Axis_CIP_Drive structure indicates it as such rather than the generic drive label.
DriveOvervoltage Fault	<i>Equivalent:</i> BusOvervoltageFLFault	BOOL	Set when drive DC bus voltage exceeds the predefined operating limits for the bus. NOTE: The Axis_CIP_Drive structure clearly indicates that this fault is specifically representing the DC bus voltage rather than the inverter or converter voltage.
DriveUndervoltage Fault	<i>Equivalent:</i> BusUndervoltageFLFault	BOOL	Set when drive DC bus voltage is below the predefined operating limits for the bus. NOTE: The Axis_CIP_Drive structure clearly indicates that this fault is specifically representing the DC bus voltage rather than the inverter or converter voltage.
PowerPhaseLoss Fault	<i>Equivalent:</i> ConverterACSinglePhaseLoss Fault	BOOL	Set when the drive detects that one or more of the three power line phases is lost from the 3-phase power inputs. NOTE: The Axis_CIP_Drive structure indicates that this fault is specifically representing the input power rather than the output power.
PositionErrorFault	<i>Equivalent:</i> ExcessivePositionErrorFault	BOOL	Set when the axis position error exceeds the Position Error Tolerance. This fault can only occur when the drive is in the enabled state. The controller latches this fault. Use a Motion Axis Fault Reset (MAFR) or Motion Axis Shutdown Reset (MASR) instruction to clear the fault.
SercosFault	N/A	BOOL	Set when either a requested Sercos procedure fails to execute properly or the associated drive node has detected a Sercos communication fault. NOTE: The Axis_CIP_Drive structure contains similar faults and alarms to describe the health of the Ethernet communications link, but there is no need for a Sercos fault indication.
<i>Equivalent:</i> OverSpeedFault	MotorOverspeedFLFault	BOOL	Motor speed has exceeded its maximum limit given by the Motor Overspeed Factory Limit attribute associated with the motor type.
N/A	MotorOverspeedULFault	BOOL	Motor speed has exceeded the user-defined speed limit given by Motor Overspeed User Limit.
<i>Equivalent:</i> MotorOvertemp Fault	MotorOvertemperatureFLFault	BOOL	Motor temperature has exceeded its factory set temperature limit given by Motor Overtemperature Factory Limit, or the integral motor thermal switch has tripped.
N/A	MotorOvertemperatureULFault	BOOL	Motor temperature has exceeded the user-defined temperature limit given by Motor Overtemperature User Limit.
N/A	MotorThermalOverloadFLFault	BOOL	Motor thermal model has exceeded its factory set thermal capacity limit given by Motor Thermal Overload Factory Limit.

**Axis Exceptions (Continued)**

<b>AXIS_SERVO_DRIVE</b>	<b>AXIS_CIP_DRIVE</b>	<b>Type</b>	<b>Description</b>
N/A	MotorThermalOverloadULFault	BOOL	Motor thermal model has exceeded its user-defined thermal capacity given by Motor Thermal Overload User Limit.
<i>Equivalent:</i> DriveOvercurrent Fault	InverterOvercurrentFault	BOOL	Inverter current has exceeded the factory set peak or instantaneous current limit.
N/A	InverterOvertemperatureFL Fault	BOOL	Inverter temperature has exceeded its factory set temperature limit given by Inverter Overtemperature Factory Limit.
N/A	InverterOvertemperatureUL Fault	BOOL	Inverter temperature has exceeded the user-defined temperature limit given by Inverter Overtemperature User Limit.
N/A	InverterThermalOverloadFL Fault	BOOL	Inverter thermal model has exceeded its factory set thermal capacity limit given by Inverter Thermal Overload Factory Limit.
N/A	InverterThermalOverloadUL Fault	BOOL	Inverter thermal model has exceeded its user-defined thermal capacity given by Inverter Thermal Overload User Limit.
<i>Equivalent:</i> GroundShortFault	ConverterGroundCurrentFL Fault	BOOL	Ground Current has exceeded its factory set current limit by Converter Ground Current Factory Limit.
N/A	ConverterGroundCurrentUL Fault	BOOL	Ground Current has exceeded user-defined limit given by Converter Ground Current User Limit.
N/A	ConverterOvertemperatureFL Fault	BOOL	Converter temperature has exceeded its factory set temperature limit given by Converter Overtemperature Factory Limit.
N/A	ConverterOvertemperature ULFault	BOOL	Converter temperature has exceeded the user-defined temperature limit given by Converter Overtemperature User Limit.
N/A	ConverterThermalOverloadFL Fault	BOOL	Converter thermal model has exceeded its factory set thermal capacity limit given by Converter Thermal Overload Factory Limit.
N/A	ConverterThermalOverloadUL Fault	BOOL	Converter thermal model has exceeded its user-defined thermal capacity given by Converter Thermal Overload User Limit.
N/A	ConverterACPowerLossFault	BOOL	Multiple AC phases have been lost on the AC line to the converter.
<i>Equivalent:</i> PowerPhaseLoss Fault	ConverterACSinglePhaseLoss Fault	BOOL	One AC phase was lost on the AC line to the converter.
N/A	ConverterACPhaseShortFault	BOOL	A short has been detected between an AC phase and another AC phase or ground.
N/A	ConverterPreChargeFault	BOOL	A problem has been detected in the Converter's Pre-Charge circuitry preventing the DC Bus from charging to an acceptable voltage level.
N/A	BusRegulatorOvertemperatureFLFault	BOOL	Bus Regulator temperature has exceeded its factory set temperature limit given by Bus Regulator Overtemperature Factory Limit.
N/A	BusRegulatorOvertemperatureULFault	BOOL	Bus Regulator temperature has exceeded the user-defined temperature limit given by Bus Regulator Overtemperature User Limit.
N/A	BusRegulatorFault	BOOL	The bus regulator (shunt) module in a multi-axis system has failed.
<i>Equivalent:</i> DriveUndervoltageFault	BusUndervoltageFLFault	BOOL	DC Bus voltage level is below the factory set limit given by Bus Undervoltage Factory Limit.
N/A	BusUndervoltageULFault	BOOL	DC Bus voltage level is below user-defined limit given by Bus Undervoltage User Limit.
<i>Equivalent:</i> Drive OvervoltageFault	BusOvervoltageFLFault	BOOL	DC Bus voltage level is above the factory set limit given by Bus Overvoltage Factory Limit.
N/A	BusOvervoltageULFault	BOOL	DC Bus voltage level is above user-defined limit given by Bus Overvoltage User Limit.
N/A	BusPowerLossFault	BOOL	DC Bus voltage level is below the Bus Power Loss Threshold for more than the timeout period-specified Bus Power Loss Time value.

**Axis Exceptions (Continued)**

<b>AXIS_SERVO_DRIVE</b>	<b>AXIS_CIP_DRIVE</b>	<b>Type</b>	<b>Description</b>
N/A	BusPowerBlownFuseFault	BOOL	DC Bus power loss due to blown fuse.
<i>Equivalent:</i> MotFeedbackNoiseFault	FeedbackSignalNoiseFLFault	BOOL	Noise induced A/B channel state changes (illegal states) from a feedback device were detected by the drive. Specifically, the number of these noise events that have occurred on this channel has exceeded the Feedback Noise Factory Limit. The offending feedback channel number is encoded in the associated Fault/Alarm Sub Code.
N/A	FeedbackSignalNoiseULFault	BOOL	Noise induced A/B channel state changes (illegal states) from a feedback device were detected on a feedback channel. Specifically, the number of these noise events that have occurred on this channel has exceeded the Feedback Noise User Limit. The offending feedback channel number is encoded in the associated Fault/Alarm Sub Code.
<i>Equivalent:</i> MotFeedbackFault)	FeedbackSignalLossFLFault	BOOL	One or more A/B channel signals from a feedback device are open, shorted, missing, or severely attenuated. Specifically, the detected voltage levels of the signals are below the Feedback Loss Factory Limit. The offending feedback channel number is encoded in the associated Fault/Alarm Sub Code.
N/A	FeedbackSignalLossULFault	BOOL	One or more A/B channel signals from a feedback device are open, shorted, missing, or severely attenuated. Specifically, the detected voltage levels of the signals are below the Feedback Loss User Limit. The offending feedback channel number is encoded in the associated Fault/Alarm Sub Code.
N/A	FeedbackDataLossFLFault	BOOL	The number of consecutive missed or corrupted serial data packets over the serial data channel from a feedback device has exceeded the Feedback Data Loss Factory Limit. The offending feedback channel number is encoded in the associated Fault/Alarm Sub Code.
N/A	FeedbackDataLossULFault	BOOL	The number of consecutive missed or corrupted serial data packets over the serial data channel from a feedback device has exceeded the Feedback Data Loss User Limit. The offending feedback channel number is encoded in the associated Fault/Alarm Sub Code.
<i>Equivalent:</i> FeedbackFault	FeedbackDeviceFault	BOOL	The feedback device has detected an internal error.
<i>Equivalent:</i> PosHardOvertravelFault	HardwareOvertravelPositiveFault	BOOL	Axis moved beyond the physical travel limits in the positive direction and activated the Positive Overtravel limit switch.
<i>Equivalent:</i> NegHardOvertravelFault	HardwareOvertravelNegativeFault	BOOL	Axis moved beyond the physical travel limits in the negative direction and activated the Negative Overtravel limit switch.
<i>Equivalent:</i> PositionErrorFault	ExcessivePositionErrorFault	BOOL	The Position Error value of the position control loop has exceeded the configured value for Position Error Tolerance.
N/A	ExcessiveVelocityErrorFault	BOOL	The Velocity Error value of the velocity control loop has exceeded the configured value for Velocity Error Tolerance.
N/A	OvertorqueLimitFault	BOOL	Motor torque has risen above user-defined maximum torque level given by Overtorque Limit.
N/A	UndertorqueLimitFault	BOOL	Motor torque has dropped below user-defined minimum torque level given by Undertorque Limit.
N/A	IllegalControlModeFault	BOOL	Controller has specified an unsupported Control Mode or Feedback Mode
<i>Equivalent:</i> DriveEnableInputFault	EnableInputDeactivatedFault	BOOL	Enable has been deactivated while the axis is in Running state.
N/A	ControllerInitiatedFault	BOOL	Exception generated specifically by controller.
N/A	ExternalInputFault	BOOL	Exception generated by external input to device.

**Axis Exceptions (Continued)**

AXIS_SERVO_DRIVE	AXIS_CIP_DRIVE	Type	Description
N/A	CIPAxisFaultsRA	LINT	A bit map that represents the state of all manufacturer-specific runtime faults. Fault bits when set are latched until a fault reset occurs. A fault reset clears the runtime fault bits, but the bits set again immediately if the underlying exception condition is still present. Any exceptions whose Axis Exception Action is configured to ignore or report as alarms do not appear in this attribute.
N/A	CommutationStartupFault	BOOL	The self-sensing commutation startup algorithm failed.
N/A	MotorVoltageMismatchFault	BOOL	The motor voltage is incompatible with the applied drive voltage.
N/A	FeedbackFilterNoiseFault	BOOL	Excessive levels of noise have been detected by the digital feedback filter.
N/A	FeedbackBatteryLossFault	BOOL	The battery voltage on a battery-backed motor encoder is low enough such that absolute position is not longer available.
N/A	FeedbackBatteryLowFault	BOOL	The battery voltage on a battery-backed motor encoder is below a caution level.
N/A	FeedbackIncrementalCountErrorFault	BOOL	The periodic check of the incremental encoder position against the absolute encoder position or Hall edges indicates they are out of tolerance.
N/A	ControlModuleOvertemperatureFLFault	BOOL	Kinetix drives: The control module temperature has exceeded its limit. PowerFlex 755 drives: The temperature sensor on the Main Control Board detected excessive heat.
N/A	ControlModuleOvertemperatureULFault	BOOL	The control module temperature has exceeded a user-defined limit given by Control Module Overtemperature User Limit. Factory limit due to excessive power cycling.
<i>Equivalent: PreCharge OverloadFault</i>	ConverterPreChargeOverloadFLFault	BOOL	Converter estimates that the pre-charge circuit has exceeded its limit.
N/A	ConverterPreChargeOverloadULFault	BOOL	Converter estimates that the pre-charge circuit has exceeded its user-defined limit given by Converter Pre-charge Overload User Limit due to excessive power cycling.
N/A	ExcessiveCurrentFeedbackOffsetFault	BOOL	Current in one or more phases has been lost or remains below a preset level.
N/A	RegenerativePowerSupplyFault	BOOL	The hardware Regeneration OK input was deactivated while the drive was enabled.
N/A	PWMFrequencyReducedFault	BOOL	Carrier Frequency foldback due to excessive Junction Temperature.
N/A	CurrentLimitReducedFault	BOOL	Current Limit reduced due to excessive Junction Temperature or due to Overload Protection.
N/A	TorqueProveFault	BOOL	Actual feedback indicates error in torque proving.
N/A	DecelOverrideFault	BOOL	The drive is not following a commanded deceleration because it is attempting to limit bus voltage.
N/A	PreventativeMaintenanceFault	BOOL	Component has reached lifetime limit.
N/A	MotorTestFault	BOOL	Motor Test procedure has failed.
N/A	HardwareConfigurationFault	BOOL	Error related to the tracking of optional hardware installation.
N/A	FirmwareChangeFault	BOOL	Errors or forced configuration changes relating to firmware update.
<i>Equivalent: CommonBusFault</i>	DCCommonBusFault	BOOL	Error has been detected related to Common Bus operation.
N/A	RuntimeErrorFault	BOOL	Runtime Assertions detected.
N/A	BackplaneCommunicationErrorFault	BOOL	Error in communicating over the modular backplane.
N/A	SafetyModuleCommunicationErrorFault	BOOL	Error in communicating to the Safety module.
N/A	ProductSpecificFault	BOOL	Product Specific (exotic) exceptions by Sub Code.

**Axis Exceptions (Continued)**

AXIS_SERVO_DRIVE	AXIS_CIP_DRIVE	Type	Description
N/A	CIPAxisAlarms	LINT	A bit map that represents the current state of all standard alarm conditions. The bit map is identical to that of the Std. CIP Axis Exceptions attribute. Only exception conditions whose Axis Exception Action is configured to report as an alarm appear in this attribute, and will not be reported in the CIP Axis Faults attribute. Alarm bits when set are not latched and will clear as soon as the underlying exception condition is corrected.
N/A	MotorCommutationAlarm	BOOL	Permanent magnet motor commutation problem detected. Example would be an illegal state "111" or "000" for UVW commutation signals, S1, S2, and S3.
N/A	MotorOverspeedFLAlarm	BOOL	Motor speed has exceeded its maximum limit given by the Motor Overspeed Factory Limit attribute associated with the motor type.
N/A	MotorOverspeedULAlarm	BOOL	Motor speed has exceeded the user-defined speed limit given by Motor Overspeed User Limit.
N/A	MotorOvertemperatureFLAlarm	BOOL	Motor temperature has exceeded its factory set temperature limit given by Motor Overtemperature Factory Limit, or the integral motor thermal switch has tripped.
N/A	MotorOvertemperatureULAlarm	BOOL	Motor temperature has exceeded the user-defined temperature limit given by Motor Overtemperature User Limit.
N/A	MotorThermalOverloadFLAlarm	BOOL	Motor thermal model has exceeded its factory set thermal capacity limit given by Motor Thermal Overload Factory Limit.
N/A	MotorThermalOverloadULAlarm	BOOL	Motor thermal model has exceeded its user-defined thermal capacity given by Motor Thermal Overload User Limit.
N/A	InverterOvercurrentAlarm	BOOL	Inverter current has exceeded the factory set peak or instantaneous current limit.
N/A	InverterOvertemperatureFLAlarm	BOOL	Inverter temperature has exceeded its factory set temperature limit given by Inverter Overtemperature Factory Limit.
N/A	InverterOvertemperatureULAlarm	BOOL	Inverter temperature has exceeded the user-defined temperature limit given by Inverter Overtemperature User Limit.
N/A	InverterThermalOverloadFLAlarm	BOOL	Inverter thermal model has exceeded its factory set thermal capacity limit given by Inverter Thermal Overload Factory Limit.
N/A	InverterThermalOverloadULAlarm	BOOL	Inverter thermal model has exceeded its user-defined thermal capacity given by Inverter Thermal Overload User Limit.
N/A	ConverterGroundCurrentFLAlarm	BOOL	Ground Current has exceeded its factory set current limit given by Converter Ground Current Factory Limit.
N/A	ConverterGroundCurrentULAlarm	BOOL	Ground Current has exceeded user-defined limit given by Converter Ground Current User Limit.
N/A	ConverterOvertemperatureFLAlarm	BOOL	Converter temperature has exceeded its factory set temperature limit given by Converter Overtemperature Factory Limit.
N/A	ConverterOvertemperatureULAlarm	BOOL	Converter temperature has exceeded the user-defined temperature limit given by Converter Overtemperature User Limit.
N/A	ConverterThermalOverloadFLAlarm	BOOL	Converter thermal model has exceeded its factory set thermal capacity limit given by Converter Thermal Overload Factory Limit.
N/A	ConverterThermalOverloadULAlarm	BOOL	Converter thermal model has exceeded its user-defined thermal capacity given by Converter Thermal Overload User Limit.
N/A	ConverterACPowerLossAlarm	BOOL	Multiple AC phases have been lost on the AC line to the converter.
N/A	ConverterACSinglePhaseLossAlarm	BOOL	One AC phase has been lost on the AC line to the converter.
N/A	ConverterACPhaseShortAlarm	BOOL	A short has been detected between an AC phase and another AC phase or ground.
N/A	ConverterPreChargeAlarm	BOOL	A problem has been detected in the Converter's Pre-Charge circuitry preventing the DC Bus from charging to an acceptable voltage level.

**Axis Exceptions (Continued)**

<b>AXIS_SERVO_DRIVE</b>	<b>AXIS_CIP_DRIVE</b>	<b>Type</b>	<b>Description</b>
N/A	BusRegulatorOvertemperatureFLAlarm	BOOL	Bus Regulator temperature has exceeded its factory set temperature limit given by Bus Regulator Overtemperature Factory Limit.
N/A	BusRegulatorOvertemperatureULAlarm	BOOL	Bus Regulator temperature has exceeded the user-defined temperature limit given by Bus Regulator Overtemperature User Limit.
N/A	BusRegulatorThermalOverloadFLAlarm	BOOL	Bus Regulator thermal model has exceeded its factory set thermal capacity limit given by Bus Regulator Thermal Overload Factory Limit.
N/A	BusRegulatorThermalOverloadULAlarm	BOOL	Bus Regulator thermal model has exceeded its user-defined thermal capacity given by Bus Regulator Thermal Overload User Limit.
N/A	BusRegulatorAlarm	BOOL	The bus regulator (shunt) module in a multi-axis system has failed.
N/A	BusUndervoltageFLAlarm	BOOL	DC Bus voltage level is below the factory set limit given by Bus Undervoltage Factory Limit.
N/A	BusUndervoltageULAlarm	BOOL	DC Bus voltage level is below user-defined limit given by Bus Undervoltage User Limit.
N/A	BusOvervoltageFLAlarm	BOOL	DC Bus voltage level is above the factory set limit given by Bus Overvoltage Factory Limit.
N/A	BusOvervoltageULAlarm	BOOL	DC Bus voltage level is above user-defined limit given by Bus Overvoltage User Limit.
N/A	BusPowerLossAlarm	BOOL	DC Bus voltage level is below the Bus Power Loss Threshold for more than the timeout period-specified Bus Power Loss Time value.
N/A	BusPowerBlownFuseAlarm	BOOL	DC Bus power loss due to blown fuse.
N/A	FeedbackSignalNoiseFLAlarm	BOOL	Noise induced A/B channel state changes (illegal states) from a feedback device were detected by the drive. Specifically, the number of these noise events that have occurred on this channel has exceeded the Feedback Noise Factory Limit. The offending feedback channel number is encoded in the associated Fault/Alarm Sub Code.
N/A	FeedbackSignalNoiseULAlarm	BOOL	Noise induced A/B channel state changes (illegal states) from a feedback device were detected on a feedback channel. Specifically, the number of these noise events that have occurred on this channel has exceeded the Feedback Noise User Limit. The offending feedback channel number is encoded in the associated Fault/Alarm Sub Code.
N/A	FeedbackSignalLossFLAlarm	BOOL	One or more A/B channel signals from a feedback device are open, shorted, missing, or severely attenuated. Specifically, the detected voltage levels of the signals are below the Feedback Loss Factory Limit. The offending feedback channel number is encoded in the associated Fault/Alarm Sub Code.
N/A	FeedbackSignalLossULAlarm	BOOL	One or more A/B channel signals from a feedback device are open, shorted, missing, or severely attenuated. Specifically, the detected voltage levels of the signals are below the Feedback Loss User Limit. The offending feedback channel number is encoded in the associated Fault/Alarm Sub Code.
N/A	FeedbackDataLossFLAlarm	BOOL	The number of consecutive missed or corrupted serial data packets over the serial data channel from a feedback device has exceeded the Feedback Data Loss Factory Limit. The offending feedback channel number is encoded in the associated Fault/Alarm Sub Code.
N/A	FeedbackDataLossULAlarm	BOOL	The number of consecutive missed or corrupted serial data packets over the serial data channel from a feedback device has exceeded the Feedback Data Loss User Limit. The offending feedback channel number is encoded in the associated Fault/Alarm Sub Code.
N/A	FeedbackDeviceAlarm	BOOL	The feedback device has detected an internal error.
N/A	HardwareOvertravelPositiveAlarm	BOOL	Axis moved beyond the physical travel limits in the positive direction and activated the Positive Overtravel limit switch.
N/A	HardwareOvertravelNegativeAlarm	BOOL	Axis moved beyond the physical travel limits in the negative direction and activated the Negative Overtravel limit switch.
N/A	ExcessivePositionErrorAlarm	BOOL	The Position Error value of the position control loop has exceeded the configured value for Position Error Tolerance.

**Axis Exceptions (Continued)**

<b>AXIS_SERVO_DRIVE</b>	<b>AXIS_CIP_DRIVE</b>	<b>Type</b>	<b>Description</b>
N/A	ExcessiveVelocityErrorAlarm	BOOL	The Velocity Error value of the velocity control loop has exceeded the configured value for Velocity Error Tolerance.
N/A	OvertorqueLimitAlarm	BOOL	Motor torque has risen above user-defined maximum torque level given by Overtorque Limit.
N/A	UndertorqueLimitAlarm	BOOL	Motor torque has dropped below user-defined minimum torque level given by Undertorque Limit.
N/A	IllegalControlModeAlarm	BOOL	Controller has specified an unsupported Control Mode or Feedback Mode.
N/A	EnableInputDeactivatedAlarm	BOOL	Enable has been deactivated while the axis is in Running state.
N/A	ControllerInitiatedAlarm	BOOL	Exception generated specifically by controller.
N/A	ExternalInputAlarm	BOOL	Exception generated by external input to device.
N/A	CIPAxisAlarmsRA	LINT	A bit map that represents the current state of all manufacturer-specific alarm conditions. Only exception conditions whose Axis Exception Action is configured to report as an alarm appear in this attribute, and will not be reported in the CIP Axis Faults attribute. Alarm bits when set are not latched and will clear as soon as the underlying exception condition is corrected.
N/A	CommutationStartupAlarm	BOOL	The self-sensing commutation startup algorithm failed.
N/A	MotorVoltageMismatchAlarm	BOOL	The motor voltage is incompatible with the applied drive voltage.
N/A	FeedbackFilterNoiseAlarm	BOOL	Excessive levels of noise have been detected by the digital feedback filter.
N/A	FeedbackBatteryLossAlarm	BOOL	The battery voltage on a battery-backed motor encoder is low enough such that absolute position is not longer available.
N/A	FeedbackBatteryLowAlarm	BOOL	The battery voltage on a battery-backed motor encoder is below a caution level.
N/A	FeedbackIncrementalCount ErrorAlarm	BOOL	The periodic check of the incremental encoder position against the absolute encoder position or Hall edges indicates they are out of tolerance.
N/A	ControlModuleOvertemperature FLAlarm	BOOL	Kinetix: The control module temperature has exceeded its limit. PF755: The temperature sensor on the Main Control Board detected excessive heat.
N/A	ControlModuleOvertemperature ULAlarm	BOOL	The control module temperature has exceeded a user-defined limit given by Control Module Overtemperature User Limit.
N/A	ConverterPreChargeOverload FLAlarm	BOOL	Converter estimates that the pre-charge circuit has exceeded its factory limit due to excessive power cycling.
N/A	ConverterPreChargeOverload ULAlarm	BOOL	Converter estimates that the pre-charge circuit has exceeded its user-defined limit given by Converter Pre-charge Overload User Limit due to excessive power cycling.
N/A	ExcessiveCurrentFeedback OffsetAlarm	BOOL	Current in one or more phases has been lost or remains below a preset level.
N/A	RegenerativePowerSupplyAlarm	BOOL	The hardware Regeneration OK input was deactivated while the drive was enabled.
N/A	PWMFrequencyReducedAlarm	BOOL	Carrier Frequency foldback due to excessive Junction Temperature.
N/A	CurrentLimitReducedAlarm	BOOL	Current Limit reduced due to excessive Junction Temperature or due to Overload Protection.
N/A	TorqueProveAlarm	BOOL	Actual feedback indicates error in torque proving.
N/A	DecelOverrideAlarm	BOOL	The drive is not following a commanded deceleration because it is attempting to limit bus voltage.
N/A	PreventativeMaintenanceAlarm	BOOL	Component has reached lifetime limit.
N/A	MotorTestAlarm	BOOL	Motor Test procedure has failed.
N/A	HardwareConfigurationAlarm	BOOL	Error related to the tracking of optional hardware installation.
N/A	FirmwareChangeAlarm	BOOL	Errors or forced configuration changes relating to firmware update.
N/A	DCCCommonBusAlarm	BOOL	Error has been detected related to Common Bus operation.



**Axis Exceptions (Continued)**

<b>AXIS_SERVO_DRIVE</b>	<b>AXIS_CIP_DRIVE</b>	<b>Type</b>	<b>Description</b>
N/A	RuntimeErrorAlarm	BOOL	Runtime Assertions detected.
N/A	BackplaneCommunicationErrorAlarm	BOOL	Error in communicating over the modular backplane.
N/A	SafetyModuleCommunicationErrorAlarm	BOOL	Error in communicating to the Safety module.
N/A	ProductSpecificAlarm	BOOL	Product Specific (exotic) exceptions by Sub Code.
N/A	CIPInitializationFaults	DINT	A bit map that represents the state of all standard initialization faults. These faults prevent any motion, and do not have configurable fault actions. Examples of initialization faults are corrupted memory data, calibration errors, firmware startup problems, or an invalid configuration attribute value. Initialization faults cannot be cleared with a Fault Reset service, although a power-cycle provides a new attempt at initialization.
N/A	BootBlockChecksumFault	BOOL	Checksum or CRC error for Boot Block of Integrated Motion on the EtherNet/IP network device detected as part of self-test.
N/A	MainBlockChecksumFault	BOOL	Checksum or CRC error for Main Block of Integrated Motion on the EtherNet/IP network device detected as part of self-test.
N/A	NonvolatileMemoryChecksumFault	BOOL	Checksum or CRC error for NV Memory of Integrated Motion on the EtherNet/IP network device detected as part of self-test.
N/A	CIPInitializationFaultsRA	DINT	A bit map that represents the state of all Rockwell Automation specific initialization faults. These faults prevent any motion, and do not have configurable fault actions. Examples of initialization faults are corrupted memory data, calibration errors, firmware startup problems, or an invalid configuration attribute value. Initialization faults cannot be cleared with a Fault Reset service, although a power-cycle provides a new attempt at initialization.
N/A	FeedbackDataCorruptionFault	BOOL	Smart Encoder Data Corruption detected.
N/A	FeedbackDataRangeFault	BOOL	Data within a motor data blob is out of range.
N/A	FeedbackCommunicationStartupFault	BOOL	Communications with a smart encoder could not be established.
N/A	FeedbackAbsoluteOverspeedFault	BOOL	Excessive speed was detected in the battery-backed encoder while power was off.
N/A	FeedbackAbsolutePowerOffTravelFault	BOOL	The power-off travel range of the battery-backed encoder has been exceeded.
N/A	FeedbackAbsoluteStartupSpeedFault	BOOL	The absolute encoder was not able to accurately determine the position after power-up due to speed greater than 100 RPM.
N/A	CommutationOffsetUninitializedFault	BOOL	The commutation offset stored in a third-party motor has not been initialized.
N/A	InvalidFPGAImageFault	BOOL	The FPGA image is incompatible with hardware operation.
N/A	InvalidBoardSupportPackageFault	BOOL	The board support package is incompatible with hardware operation.
N/A	InvalidSafetyFirmwareFault	BOOL	The safety firmware is not compatible with the drive firmware, or the main safety firmware is missing.
N/A	PowerBoardFault	BOOL	Power Board checksum error.
N/A	IllegalOptionCardFault	BOOL	The Main Control Board has detected an illegal option installed in the port.
N/A	OptionStorageChecksumFault	BOOL	Option data storage checksum failed.
<i>Equivalent:</i> DriveControlVoltageFault	ModuleVoltageMismatchFault	BOOL	IAM detects a voltage rating mismatch on the modular backplane.
N/A	UnknownModuleFault	BOOL	Unknown module is detected on the modular backplane.
N/A	FactoryConfigurationErrorFault	BOOL	Factory Configuration Data is missing or invalid.

**Axis Exceptions (Continued)**

<b>AXIS_SERVO_DRIVE</b>	<b>AXIS_CIP_DRIVE</b>	<b>Type</b>	<b>Description</b>
N/A	IllegalAddressFault	BOOL	AM Node Address is out of range (>254).
N/A	SeriesMismatchFault	BOOL	Sercos AMs have been detected by the CIP IAM.
N/A	OpenSlotFault	BOOL	IAM detects an open slot on the modular backplane.
N/A	CIPStartInhibits	INT	A bit map that specifies the current state of all standard conditions that inhibits starting of the axis.
N/A	AxisEnableInputInhibit	BOOL	Axis Enable Input is not active.
N/A	MotorNotConfiguredInhibit	BOOL	The associated motor has not been configured for use.
N/A	FeedbackNotConfiguredInhibit	BOOL	The associated feedback device has not been configured for use.
N/A	CIPStartInhibitsRA	INT	A bit map that specifies the current state of all Rockwell Automation specific conditions that inhibits starting of the axis.
N/A	VoltsHertzCurveDefinition Inhibit	BOOL	Conflict exists in the V/Hz curve definition.
N/A	MotorFeedbackRequiredInhibit	BOOL	Can't run using the selected motor control mode with Primary Feedback or Alternate Feedback set as open loop.
N/A	SpeedLimitConfiguration Inhibit	BOOL	Speed Ref Limit Conflict, either Minimum Forward Speed Limit exceeds Maximum Forward Speed Limit, or Minimum Reverse Speed Limit exceeds Maximum Reverse Speed Limit.
N/A	TorqueProveConfiguration Inhibit	BOOL	When Torque Prove Config is enabled, Control Mode, Feedback Mode, Motor Feedback Type, and Motor Option Configuration must be properly set.
N/A	SafeTorqueOffInhibit	BOOL	The safety function has disabled the power structure.
N/A	SafetyResetRequiredInhibit	BOOL	The safety reset input needs to be toggled before the safety board will allow motion again.
N/A	SafetyNotConfiguredInhibit	BOOL	The embedded safety function of the drive has not been configured.

## Additional Resources

These documents contain additional information concerning related products from Rockwell Automation.

Resource	Description
Kinetix 6200 and Kinetix 6500 Modular Multi-axis Servo Drives User Manual, publication <a href="#">2094-UM002</a>	Provides detailed information about the Kinetix 6200 and Kinetix 6500 drives.
Kinetix 6200 and Kinetix 6500 Safe Speed Monitoring Multi-axis Servo Drives Safety Reference Manual, publication <a href="#">2094-RM001</a>	Information on how to wire, configure, and troubleshoot the safe-speed features of your Kinetix 6200 and Kinetix 6500 drives.
Integrated Motion on the EtherNet/IP Network: Configuration and Startup User Manual, publication <a href="#">MOTION-UM003</a>	Information on how to configure and troubleshoot your ControlLogix and CompactLogix EtherNet/IP network modules.
Kinetix Motion Control Selection Guide, publication <a href="#">GMC-SG001</a>	Overview of Kinetix servo drives, motors, actuators, and motion accessories that are designed to help make initial decisions for the motion control products that are best suited for your system requirements.
Integrated Motion on the EtherNet/IP: 8 Axis Basic Linear/Ring Drawing, publication <a href="#">IASIMP-QR020</a>	Provides an example of an integrated motion on EtherNet/IP 8 axis basic linear/ring network.
Integrated Motion on the EtherNet/IP Network Reference Manual, publication <a href="#">MOTION-RM003</a>	Provides a programmer with details about the AXIS_CIP_DRIVE motion control axis attributes and the Logix Designer application Control Modes.
ControlLogix 5580 Controllers User Manual, publication <a href="#">1756-UM543</a>	Provides detailed information about the ControlLogix 5580 controllers.
Kinetix 5700 Servo Drives User Manual, publication <a href="#">2198-UM002</a>	Provides detailed information about the Kinetix 5700 servo drives.
Motion System Tuning Application Technique, publication <a href="#">MOTION-AT005</a>	Provides detailed information about tuning motion systems.
Industrial Automation Wiring and Grounding Guidelines, publication <a href="#">1770-4.1</a>	Provides general guidelines for installing a Rockwell Automation industrial system.
Product Certifications website, <a href="http://www.rockwellautomation.com/global/certification/overview.page">http://www.rockwellautomation.com/global/certification/overview.page</a>	Provides declarations of conformity, certificates, and other certification details.

You can view or download publications at <http://www.rockwellautomation.com/global/literature-library/overview.page>. To order paper copies of technical documentation, contact your local Allen-Bradley distributor or Rockwell Automation sales representative.

## Rockwell Automation Support

Use the following resources to access support information.

<b>Technical Support Center</b>	Knowledgebase Articles, How-to Videos, FAQs, Chat, User Forums, and Product Notification Updates.	<a href="http://www.rockwellautomation.com/knowledgebase">www.rockwellautomation.com/knowledgebase</a>
<b>Local Technical Support Phone Numbers</b>	Locate the phone number for your country.	<a href="http://www.rockwellautomation.com/global/support/get-support-now.page">www.rockwellautomation.com/global/support/get-support-now.page</a>
<b>Direct Dial Codes</b>	Find the Direct Dial Code for your product. Use the code to route your call directly to a technical support engineer.	<a href="http://www.rockwellautomation.com/global/support/direct-dial.page">www.rockwellautomation.com/global/support/direct-dial.page</a>
<b>Literature Library</b>	Installation Instructions, Manuals, Brochures, and Technical Data.	<a href="http://www.rockwellautomation.com/literature">www.rockwellautomation.com/literature</a>
<b>Product Compatibility and Download Center (PCDC)</b>	Get help determining how products interact, check features and capabilities, and find associated firmware.	<a href="http://www.rockwellautomation.com/global/support/pcdc.page">www.rockwellautomation.com/global/support/pcdc.page</a>

## Documentation Feedback

Your comments will help us serve your documentation needs better. If you have any suggestions on how to improve this document, complete the How Are We Doing? form at [http://literature.rockwellautomation.com/idc/groups/literature/documents/du/ra-du002\\_-en-e.pdf](http://literature.rockwellautomation.com/idc/groups/literature/documents/du/ra-du002_-en-e.pdf).

Rockwell Automation maintains current product environmental information on its website at <http://www.rockwellautomation.com/rockwellautomation/about-us/sustainability-ethics/product-environmental-compliance.page>.

Allen-Bradley, ArmorBlock, CompactLogix, ControlLogix, GuardLogix, GuardMotion, Integrated Architecture, Kinetix, LDC-Series, LDL-Series, LISTEN. THINK. SOLVE, Logix5000, MP-Series, POINT I/O, PowerFlex, RDD-Series, Rockwell Automation, Rockwell Software, RSLogix, Stratix 2000, Stratix 5100, Stratix 5400, Stratix 5700, Stratix 6000, Stratix 8000, Stratix 8300, Studio 5000, Studio 5000 Logix Designer, and Ultra are trademarks of Rockwell Automation, Inc. Trademarks not belonging to Rockwell Automation are property of their respective companies.

Rockwell Otomasyon Ticaret A.Ş., Kar Plaza İş Merkezi E Blok Kat:6 34752 İçerenköy, İstanbul, Tel: +90 (216) 5698400

**[www.rockwellautomation.com](http://www.rockwellautomation.com)**

### Power, Control and Information Solutions Headquarters

Americas: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444

Europe/Middle East/Africa: Rockwell Automation NV, Pegasus Park, De Kleetlaan 12a, 1831 Diegem, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640

Asia Pacific: Rockwell Automation, Level 14, Core F, Cyberport 3, 100 Cyberport Road, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846