

Installation Instructions

FLEX I/O Remote I/O Adapter Modules

Cat. No. 1794-ASB and 1794-ASBK Series E;
1794-ASB2, Series D

(Modules with a K in the last position of the catalog number are conformally coated to meet noxious gas requirements of ISA/ANSI-71.040 1985 Class G3 Environment.)

IMPORTANT Do not use these adapters (1794-ASB and 1794-ASBK Series E; 1794-ASB2, Series D) with the Classic PLC-5/15 or PLC-5/25 processors. Improper operation of the remote I/O can result.

Important User Information



Solid state equipment has operational characteristics differing from those of electromechanical equipment. Safety Guidelines for the Application, Installation and Maintenance of Solid State Controls (Publication [SGI-1.1](#) available from your local Rockwell Automation sales office or online at <http://www.literature.rockwellautomation.com>) describes some important differences between solid state equipment and hard-wired electromechanical devices. Because of this difference, and also because of the wide variety of uses for solid state equipment, all persons responsible for applying this equipment must satisfy themselves that each intended application of this equipment is acceptable.

In no event will Rockwell Automation, Inc. be responsible or liable for indirect or consequential damages resulting from the use or application of this equipment. The examples and diagrams in this manual are included solely for illustrative purposes. Because of the many variables and requirements associated with any particular installation, Rockwell Automation, Inc. cannot assume responsibility or liability for actual use based on the examples and diagrams.

No patent liability is assumed by Rockwell Automation, Inc. with respect to use of information, circuits, equipment, or software described in this manual.

Reproduction of the contents of this manual, in whole or in part, without written permission of Rockwell Automation, Inc., is prohibited.

Throughout this manual we use notes to make you aware of safety considerations.

WARNING 	Identifies information about practices or circumstances that can cause an explosion in a hazardous environment, which may lead to personal injury or death, property damage, or economic loss.
IMPORTANT	Identifies information that is critical for successful application and understanding of the product.
ATTENTION 	Identifies information about practices or circumstances that can lead to personal injury or death, property damage, or economic loss. Attentions help you: <ul style="list-style-type: none"> • identify a hazard • avoid a hazard • recognize the consequence

ATTENTION Environment and Enclosure



This equipment is intended for use in a Pollution Degree 2 industrial environment, in overvoltage Category II applications (as defined in IEC 60664-1), at altitudes up to 2000 m (6562 ft) without derating.

This equipment is considered Group 1, Class A industrial equipment according to IEC/CISPR 11. Without appropriate precautions, there may be difficulties with electromagnetic compatibility in residential and other environments due to conducted and radiated disturbances.

This equipment is supplied as open-type equipment. It must be mounted within an enclosure that is suitably designed for those specific environmental conditions that will be present and appropriately designed to prevent personal injury resulting from accessibility to live parts. The enclosure must have suitable flame-retardant properties to prevent or minimize the spread of flame, complying with a flame spread rating of 5VA, V2, V1, V0 (or equivalent) if non-metallic. The interior of the enclosure must be accessible only by the use of a tool.

Subsequent sections of this publication may contain additional information regarding specific enclosure type ratings that are required to comply with certain product safety certifications.

In addition to this publication, see:

- Industrial Automation Wiring and Grounding Guidelines, Rockwell Automation publication [1770-4.1](#), or additional installation requirements.
- NEMA Standard 250 and IEC 60529, as applicable, for explanations of the degrees of protection provided by different types of enclosure.

ATTENTION Preventing Electrostatic Discharge



This equipment is sensitive to electrostatic discharge, which can cause internal damage and affect normal operation. Follow these guidelines when you handle this equipment:

- Touch a grounded object to discharge potential static.
- Wear an approved grounding wriststrap.
- Do not touch connectors or pins on component boards.
- Do not touch circuit components inside the equipment.
- Use a static-safe workstation, if available.
- Store the equipment in appropriate static-safe packaging when not in use.

ATTENTION Power wiring must be less than 10 m (33 ft) in length.



ATTENTION FLEX I/O is grounded through the DIN rail to chassis ground. Use zinc plated yellow-chromate steel DIN rail to assure proper grounding. The use of other DIN rail materials (for example, aluminum or plastic) that can corrode, oxidize, or are poor conductors, can result in improper or intermittent grounding. Secure DIN rail to mounting surface approximately every 200 mm (7.8 in.) and use end-anchors appropriately.

ATTENTION Do not remove or replace an adapter module while power is applied. Interruption of the backplane can result in unintentional operation or machine motion.



ATTENTION To reduce susceptibility to noise, power analog modules and digital modules from separate power supplies.



European Hazardous Location Approval

The following modules are European Zone 2 approved: 1794-ASB and 1794-ASBK Series E; 1794-ASB2, Series D

European Zone 2 Certification (The following applies when the product bears the Ex Marking)

This equipment is intended for use in potentially explosive atmospheres as defined by European Union Directive 94/9/EC and has been found to comply with the Essential Health and Safety Requirements relating to the design and construction of Category 3 equipment intended for use in Zone 2 potentially explosive atmospheres, given in Annex II to this Directive.

Compliance with the Essential Health and Safety Requirements has been assured by compliance with EN 60079-15 and EN 60079-0.

WARNING Observe the following additional Zone 2 certification requirements:



- This equipment is not resistant to sunlight or other sources of UV radiation.
- This equipment must be installed in an enclosure providing at least IP54 protection when applied in Zone 2 environments.
- This equipment shall be used within its specified ratings defined by Rockwell Automation.
- Provision shall be made to prevent the rated voltage from being exceeded by transient disturbances of more than 40% when applied in Zone 2 environments.
- Secure any external connections that mate to this equipment by using screws, sliding latches, threaded connectors, or other means provided with this product.
- Do not disconnect equipment unless power has been removed or the area is known to be nonhazardous.


North American Hazardous Location Approval

The following modules are North American Hazardous Location approved: 1794-ASB and 1794-ASBK Series E; 1794-ASB2, Series D.

<p>The following information applies when operating this equipment in hazardous locations:</p> <p>Products marked "CL I, DIV 2, GP A, B, C, D" are suitable for use in Class I Division 2 Groups A, B, C, D, Hazardous Locations and nonhazardous locations only. Each product is supplied with markings on the rating nameplate indicating the hazardous location temperature code. When combining products within a system, the most adverse temperature code (lowest "T" number) may be used to help determine the overall temperature code of the system. Combinations of equipment in your system are subject to investigation by the local Authority Having Jurisdiction at the time of installation.</p>	<p>Informations sur l'utilisation de cet équipement en environnements dangereux:</p> <p>Les produits marqués "CL I, DIV 2, GP A, B, C, D" ne conviennent qu'à une utilisation en environnements de Classe I Division 2 Groupes A, B, C, D dangereux et non dangereux. Chaque produit est livré avec des marquages sur sa plaque d'identification qui indiquent le code de température pour les environnements dangereux. Lorsque plusieurs produits sont combinés dans un système, le code de température le plus défavorable (code de température le plus faible) peut être utilisé pour déterminer le code de température global du système. Les combinaisons d'équipements dans le système sont sujettes à inspection par les autorités locales qualifiées au moment de l'installation.</p>
<p>WARNING</p> <p>EXPLOSION HAZARD</p> <ul style="list-style-type: none"> Do not disconnect equipment unless power has been removed or the area is known to be nonhazardous. Do not disconnect connections to this equipment unless power has been removed or the area is known to be nonhazardous. Secure any external connections that mate to this equipment by using screws, sliding latches, threaded connectors, or other means provided with this product. Substitution of components may impair suitability for Class I, Division 2. If this product contains batteries, they must only be changed in an area known to be nonhazardous. 	<p>AVERTISSEMENT</p> <p>RISQUE D'EXPLOSION</p> <ul style="list-style-type: none"> Couper le courant ou s'assurer que l'environnement est classé non dangereux avant de débrancher l'équipement. Couper le courant ou s'assurer que l'environnement est classé non dangereux avant de débrancher les connecteurs. Fixer tous les connecteurs externes reliés à cet équipement à l'aide de vis, loquets coulissants, connecteurs filetés ou autres moyens fournis avec ce produit. La substitution de composants peut rendre cet équipement inadapté à une utilisation en environnement de Classe I, Division 2. S'assurer que l'environnement est classé non dangereux avant de changer les piles.

Remote I/O Adapter 1794-ASB/E, 1794-ASBK/E, 1794-ASB2/D

These adapters are shipped configured for standard addressing mode. In Standard Addressing Mode, the 1794-ASB(K) series E adapter can be used as a replacement for 1794-ASB series A and B remote I/O adapters, and the 1794-ASB2 series D can be used for a replacement for 1794-ASB2 series A 2-slot remote I/O adapters.




Component Identification			
1	Remote I/O Adapter Module	6	Remote I/O cable connector
2	Indicators	7	+V DC connections
3	Communication reset button (PRL)	8	-V common connections
4	Access door to switches S1 and S2	9	FlexBus connector
5	Switches S1 and S2 (behind door)		

WARNING If you insert or remove the module while backplane power is on, an electrical arc can occur. This could cause an explosion in hazardous location installations. Be sure that power is removed or the area is nonhazardous before proceeding.



Installing Your Adapter Module



WARNING If you connect or disconnect the communications cable with power applied to this module or any device on the network, an electrical arc can occur. This could cause an explosion in hazardous location installations. Be sure that power is removed or the area is nonhazardous before proceeding.



WARNING For Class I Division 2 applications, use only Class I Division 2 listed or recognized accessories and modules approved for used within the 1794 platform.



ATTENTION During mounting of all devices, be sure that all debris (metal chips, wire strands, etc.) is kept from falling into the module. Debris that falls into the module could cause damage on power up.



Mount on a DIN rail before installing the Terminal Base Units

- Hook the lip on the rear of the adapter onto the top of the DIN rail, and rotate the adapter module onto the rail.
- Press the adapter module down onto the DIN rail until flush. Locking tab C will snap into position and lock the adapter module to the DIN rail.
- If the adapter module does not lock in place, use a screwdriver or similar device to move the locking tab down while pressing the adapter module flush onto the DIN rail, and release the locking tab to lock the adapter module in place. If necessary, push up on the locking tab to lock.
- Connect the adapter wiring as shown under "Wiring" later in this document.

Mount or Replace the Adapter on an Existing System

- Remove the RIO plug-in connector from the front of the adapter.
- Disconnect any wiring jumpered to the adjacent terminal base.
- Open the module latching mechanism and remove the module from the base unit to which the adapter will be attached.
- Push the FlexBus connector toward the right side of the terminal base to unplug the backplane connection. (When fully retracted, you will see a raised dot on the connector).
- Release the adapter locking tab and remove the adapter module.


- Before installing the new adapter, notice the notch on the right rear of the adapter. This notch accepts the hook on the terminal base unit. The notch is open at the bottom. The hook and adjacent connection point keep the terminal base and the adapter tight together, reducing the possibility of a break in communication over the backplane.



- Complete the adapter mounting as shown below.

Push down and in at the same time to lock the adapter to the DIN rail.

When the adapter is locked onto the DIN rail, gently push the FlexBus connector into the adapter to complete the backplane



- If the adapter module does not lock in place, use a screwdriver or similar device to move the locking tab down while pressing the adapter module flush onto the DIN rail, and release the locking tab to lock the adapter module in place. If necessary, push up on the locking tab to lock.
- Reinstall the module in the adjacent terminal base unit.


ATTENTION Do not wire more than 2 conductors on any single terminal.



Connect the Wiring

- Connect the remote I/O cable to the removable remote I/O connector.

Connect	To terminal
Blue Wire - RIO	1
Shield Wire - RIO	SH
Clear Wire - RIO	2



WARNING If you connect or disconnect wiring while the field-side power is on, an electrical arc can occur. This could cause an explosion in hazardous location installations. Be sure that power is removed or the area is nonhazardous before proceeding.




- Connect +V DC power to the left side of the lower connector, terminal **A**.
- Connect -V common to the left side of the upper connector, terminal **B**.

- Connections C and D are used to pass +V DC power (D) and -V common (C) to the next module in the series (if required).

ATTENTION If this is the last adapter, you must terminate the remote I/O link here. Use a terminating resistor connected across terminals 1 and 2. Refer to your processor manual for information on the size of the resistor.



Set the Addressing Mode Switches



WARNING When you change switch settings while power is on, an electrical arc can occur. This could cause an explosion in hazardous location installations. Be sure that power is removed or the area is nonhazardous before proceeding.



ATTENTION Some switches on this adapter differ from the switches on previous versions. Make certain that you identify each switch before setting.



- Lift the hinged switch cover on the front of the adapter to expose the switches.
- Set the switches as shown below.
- Cycle power to the adapter after setting the switches.

8 and 16-point Mode Switch Settings

When using this addressing mode	And	Mode Switch 2 S1-1	Mode Switch 1 S2-5	Mode Switch 0 S2-8
Standard (as shipped)	8 and/or 16-point modules	See note 1	ON	ON
Compact	8-point modules	OFF	ON	OFF
	16-point modules	ON	ON	OFF
Complementary	See complementary table below.			
Primary Chassis	8-point modules	OFF	OFF	ON
Complementary Chassis		ON	OFF	ON
Complementary	See complementary table below.			
Primary Chassis	16-point modules	OFF	OFF	OFF
Complementary Chassis		ON	OFF	OFF

- In Standard mode, this switch retains its function as switch position 1 of rack addressing. In standard mode, the module is functionally interchangeable with 1794-ASB series A or B adapters.
- In compact mode, 32-point modules appear as 8 or 16-point modules.
- When programming block transfers, address analog modules as module 0 if switch S1-1 is on; module 1 if switch S1-1 is off.


32-point Mode Switch Settings

When using this addressing mode	And	Mode Switch 0 S2-8	Mode Switch 1 S2-5	Mode Switch 2 S1-1	Mode Switch 3 S2-3	Mode Switch 4 S2-4
Standard - 32	8, 16 and/or 32-point modules	ON	ON	See note 1	OFF	OFF
Complementary - 32						

32-point Mode Switch Settings

When using this addressing mode	And	Mode Switch 0 S2-8	Mode Switch 1 S2-5	Mode Switch 2 S1-1	Mode Switch 3 S2-3	Mode Switch 4 S2-4
Primary Chassis	8, 16 and/or 32-point modules	OFF	OFF	OFF	OFF	OFF
Complementary Chassis		OFF	OFF	ON	OFF	OFF

- In Standard – 32 mode, any module in the chassis occupies 32 input points and 32 output points in the input/output data table.
- In Complementary – 32 mode, any module in the chassis occupies 32 input points or 32 output points in the input/output data table. If using 8 or 16-point modules, unused points in the data table are zeroed out.



First I/O Group ¹⁾ (see Important)			I/O Rack Number
S1-8	S1-7	I/O Group	S1-6...S1-1
ON	ON	0 (1st)	Refer to addressing mode tables.
OFF	ON	2 (2nd)	
ON	OFF	4 (3rd)	
OFF	OFF	6 (4th)	
IMPORTANT		¹⁾ In 32-point mode, starting quarter must be 0 (S1-8 and S1-7 on).	

S2-8	Mode Switch 0
Refer to mode selection switches, above.	

S2-7	Hold Inputs	S2-6	Rack Fault Select
ON	Hold inputs	ON	Disabled (default)
OFF	Reset inputs	OFF	Enabled

S2-5	Mode Switch 1
Refer to mode selection switches, above.	

Communication Rate (32-point Mode Select)			Processor Restart Lockout		Hold Last State	
S2-4	S2-3	Bits/s	S2-2		S2-1	
ON	ON	57.6k	ON	Restart	ON	Reset Outputs
OFF	ON	115.2k	OFF	Locked out	OFF	Hold Last State
ON	OFF	230.4k				
OFF	OFF	Auto Baud	Use only with 32-point modules. ¹⁾ These switches used to put the adapter in 32-point mode and perform autobaud.			

¹⁾ Cycle power to the adapter or push the RESET button when the baud rate is changed in the scanner.

I/O Rack Number Switch Settings

Rack Number				S1 Switch Position					
1747-SN	PLC-5	PLC-5/25	PLC-3	6	5	4	3	2	1
Rack 0	Not Valid	Rack 0	Rack 0	ON	ON	ON	ON	ON	ON
Rack 1	Rack 1	Rack 1	Rack 1	OFF	ON	ON	ON	ON	ON
Rack 2	Rack 2	Rack 2	Rack 2	ON	OFF	ON	ON	ON	ON
Rack 3	Rack 3	Rack 3	Rack 3	OFF	OFF	ON	ON	ON	ON
Rack 4	Rack 4	Rack 4	Rack 4	ON	ON	OFF	ON	ON	ON
Rack 5	Rack 5	Rack 5	Rack 5	OFF	ON	OFF	ON	ON	ON
Rack 6	Rack 6	Rack 6	Rack 6	ON	OFF	OFF	ON	ON	ON
Rack 7	Rack 7	Rack 7	Rack 7	OFF	OFF	OFF	ON	ON	ON
Rack 10	Rack 10	Rack 10	Rack 10	ON	ON	ON	OFF	ON	ON
Rack 11	Rack 11	Rack 11	Rack 11	OFF	ON	ON	OFF	ON	ON
Rack 12	Rack 12	Rack 12	Rack 12	ON	OFF	ON	OFF	ON	ON
Rack 13	Rack 13	Rack 13	Rack 13	OFF	OFF	ON	OFF	ON	ON
Rack 14	Rack 14	Rack 14	Rack 14	ON	ON	OFF	OFF	ON	ON
Rack 15	Rack 15	Rack 15	Rack 15	OFF	ON	OFF	OFF	ON	ON
Rack 16	Rack 16	Rack 16	Rack 16	ON	OFF	OFF	OFF	ON	ON
Rack 17	Rack 17	Rack 17	Rack 17	OFF	OFF	OFF	OFF	ON	ON
Rack 20	Rack 20	Rack 20	Rack 20	ON	ON	ON	ON	OFF	ON
Rack 21	Rack 21	Rack 21	Rack 21	OFF	ON	ON	ON	OFF	ON
Rack 22	Rack 22	Rack 22	Rack 22	ON	OFF	ON	ON	OFF	ON
Rack 23	Rack 23	Rack 23	Rack 23	OFF	OFF	ON	ON	OFF	ON
Rack 24	Rack 24	Rack 24	Rack 24	ON	ON	ON	ON	OFF	ON
Rack 25	Rack 25	Rack 25	Rack 25	OFF	ON	OFF	ON	OFF	ON
Rack 26	Rack 26	Rack 26	Rack 26	ON	OFF	OFF	ON	OFF	ON
Rack 27	Rack 27	Rack 27	Rack 27	OFF	OFF	OFF	ON	OFF	ON
Rack 30	Rack 30	Rack 30	Rack 30	ON	ON	ON	OFF	OFF	ON
Rack 31	Rack 31	Rack 31	Rack 31	OFF	ON	ON	OFF	OFF	ON
Rack 32	Rack 32	Rack 32	Rack 32	ON	ON	ON	OFF	OFF	ON
Rack 33	Rack 33	Rack 33	Rack 33	OFF	OFF	ON	OFF	OFF	ON
Rack 34	Rack 34	Rack 34	Rack 34	ON	ON	OFF	OFF	OFF	ON
Rack 35	Rack 35	Rack 35	Rack 35	OFF	ON	OFF	OFF	OFF	ON
Rack 36	Rack 36	Rack 36	Rack 36	ON	OFF	OFF	OFF	OFF	ON
Rack 37	Rack 37	Rack 37	Rack 37	OFF	OFF	OFF	OFF	OFF	ON
Rack 40				ON	ON	ON	ON	ON	OFF
Rack 41				OFF	ON	ON	ON	ON	OFF
Rack 42				ON	OFF	ON	ON	ON	OFF
Rack 43				OFF	OFF	ON	ON	ON	OFF
Rack 44				ON	ON	OFF	ON	ON	OFF
Rack 45				OFF	ON	OFF	ON	ON	OFF
Rack 46				ON	OFF	OFF	ON	ON	OFF
Rack 47				OFF	OFF	OFF	ON	ON	OFF
Rack 50				ON	ON	ON	OFF	ON	OFF
Rack 51				OFF	ON	ON	OFF	ON	OFF
Rack 52				ON	OFF	ON	OFF	ON	OFF
Rack 53				OFF	OFF	ON	OFF	ON	OFF
Rack 54				ON	ON	ON	OFF	ON	OFF
Rack 55				OFF	ON	OFF	OFF	ON	OFF
Rack 56				ON	OFF	OFF	OFF	ON	OFF
Rack 57				OFF	OFF	OFF	OFF	ON	OFF
Rack 60				ON	ON	ON	ON	OFF	OFF
Rack 61				OFF	ON	ON	ON	OFF	OFF
Rack 62				ON	OFF	ON	ON	OFF	OFF
Rack 63				OFF	OFF	ON	ON	OFF	OFF
Rack 64				ON	ON	OFF	ON	OFF	OFF
Rack 65				OFF	ON	OFF	ON	OFF	OFF
Rack 66				ON	OFF	OFF	ON	OFF	OFF
Rack 67				OFF	OFF	OFF	ON	OFF	OFF
Rack 70				ON	ON	ON	OFF	OFF	OFF
Rack 71				OFF	ON	ON	OFF	OFF	OFF
Rack 72				ON	OFF	ON	OFF	OFF	OFF
Rack 73				OFF	OFF	ON	OFF	OFF	OFF
Rack 74				ON	ON	OFF	OFF	OFF	OFF
Rack 75				OFF	ON	OFF	OFF	OFF	OFF
Rack 76				ON	OFF	OFF	OFF	OFF	OFF
Not Valid				OFF	OFF	OFF	OFF	OFF	OFF

See note 1 - Rack addresses 40...76 are available only in Standard Mode

Rack address 77 is an illegal configuration.
 PLC-5/11 processors can scan rack 03.
 PLC-5/15 and PLC-5/20 processors can scan racks 01...03.
 PLC-5/25 and PLC-5/30 processors can scan racks 01...07.
 PLC-5/40 and PLC-5/40L processors can scan racks 01...17.
 PLC-5/60 and PLC-5/60L processors can scan racks 01...27.
 PLC-5/80 processors can scan racks 01...27.
 PLC-5/250 processors can scan racks 00...37.
 Note 1 – Rack switch 1-1 is used to set a mode in this adapter. As a result, rack addresses from 40...76 are only available in Standard mode.

Complementary I/O Rack Number Switch Settings for PLC-5 Processors

(refer to your processor documentation for all other processors)

Primary Rack

Rack Number		S1 Switch Position					
1747-SN	PLC-5	6	5	4	3	2	1
Rack 0	Not Valid	ON	ON	ON	ON	ON	OFF
Rack 1	Rack 1	OFF	ON	ON	ON	ON	OFF
Rack 2	Rack 2	ON	OFF	ON	ON	ON	OFF
Rack 3	Rack 3	OFF	OFF	ON	ON	ON	OFF
	Rack 4	ON	ON	OFF	ON	ON	OFF
	Rack 5	OFF	ON	OFF	ON	ON	OFF
	Rack 6	ON	OFF	OFF	ON	ON	OFF
	Rack 7	OFF	OFF	OFF	ON	ON	OFF

Complementary Rack

Rack Number		S1 Switch Position					
1747-SN	PLC-5	6	5	4	3	2	1
Rack 0	Not Valid	ON	ON	ON	OFF	ON	ON
Rack 1	Rack 1	OFF	ON	ON	OFF	ON	ON
Rack 2	Rack 2	ON	OFF	ON	OFF	ON	ON
Rack 3	Rack 3	OFF	OFF	ON	OFF	ON	ON
	Rack 4	ON	ON	OFF	OFF	ON	ON
	Rack 5	OFF	ON	OFF	OFF	ON	ON
	Rack 6	ON	OFF	OFF	OFF	ON	ON
	Rack 7	OFF	OFF	OFF	OFF	ON	ON

Specifications

Specifications – 1794-ASB/E, 1794-ASBK/E, and 1794-ASB2/D		
	1794-ASB/E, 1794-ASBK/E	1794-ASB2/D
I/O capacity	8 modules	2 modules
Power supply	Power supply must be capable of providing a turn-on inrush surge current of 23 A (at 24V DC) for 2 ms for each adapter connected to the power supply.	
Input voltage range	19.2V...31.2 V DC, 450 mA	
Output voltage	5V DC, 640 mA	
Communication rate	57.6 Kbps 115.2 Kbps 230.4 Kbps	
Indicators	Power – green; Adapter active – green; Adapter fault – red; Local fault – red	
Dimensions (H x W x D)	87 x 69 x 69 mm 3.4 x 2.7 x 2.7 inches	
Isolation voltage	50V (continuous), Basic Insulation Type Type tested at 750V DC for 60 s, power to system, power to RIO, and RIO to system	
Current draw	330 mA at 24V DC; 450 mA max	
Power dissipation, max	4.6 W	
Thermal dissipation, max	1.7 BTU/hr @ 31.2V DC	
Enclosure type rating	None (open-style)	
Wire size	Power and RIO connections: Single wire connection: 0.33... 2.5 mm ² (22...12 AWG) solid or stranded copper wire rated at 75 °C (167 °F) or greater 1.2 mm (3/64 in.) insulation max Double wire connection: 0.33... 1.3 mm ² (22...16 AWG) solid or stranded (not intermixed) copper wire rated at 75 °C (167 °F) or greater 1.2 mm (3/64 in.) insulation max	
Wire category ⁽¹⁾	3 – on power ports 2 – on communications ports	
Terminal screw torque	0.8 Nm (7 lb-in.)	
Remote I/O cable	Belden 9463 or equivalent	
Remote I/O connector plug	Part number 942029-03	
North American temp code	T4A	
IEC temp code	T4	


⁽¹⁾ Use this Conductor Category information for planning conductor routing. Refer to Industrial Automation Wiring and Grounding Guidelines, publication [1770-4.1](#).

Environmental Conditions	
Temperature, operating	IEC 60068-2-1 (Test Ad, Operating Cold), IEC 60068-2-2 (Test Bd, Operating Dry Heat), IEC 60068-2-14 (Test Nb, Operating Thermal Shock): 0...55 °C (32...131 °F)
Temperature, surrounding air, max	55 °C (131 °F)
Temperature, nonoperating	IEC 60068-2-1 (Test Ab, Un-packaged Non-operating Cold), IEC 60068-2-2 (Test Bb, Un-packaged Non-operating Dry Heat), IEC 60068-2-14 (Test Na, Un-packaged Non-operating Thermal Shock): -40...85 °C (-40...185 °F)
Relative humidity	IEC 60068-2-30 (Test Db, Un-packaged Damp Heat): 5...95% non-condensing
Vibration	IEC60068-2-6 (Test Fc, Operating): 5 g @ 10...500 Hz
Shock, operating	IEC60068-2-27 (Test Ea, Unpackaged shock): 30 g
Shock, nonoperating	IEC60068-2-27 (Test Ea, Unpackaged shock): 50 g
Emissions	CISPR 11: Group 1, Class A (with appropriate enclosure)
ESD immunity	IEC 61000-4-2: 8 kV air discharges
Radiated RF immunity	IEC 61000-4-3: 10 V/m with 1 kHz sine-wave 80%AM from 80...2000 MHz 10 V/m with 200 Hz 50% Pulse 100%AM at 900 MHz 10 V/m with 200 Hz 50% Pulse 100%AM at 1890 MHz 3 V/m with 1 kHz sine-wave 80%AM from 2000...2700 MHz
EFT/B immunity	IEC 61000-4-4: ±2 kV at 5 kHz on power ports ±2 kV at 5 kHz on communications ports
Surge Transient Immunity	IEC 61000-4-5: ±2 kV line-earth(CM) on communications ports
Conducted RF Immunity	IEC 61000-4-6: 10 Vrms with 1 kHz sine-wave 80%AM from 150 kHz...80 MHz

Certifications (when product is marked) ⁽¹⁾	
c-UL-us	UL Listed Industrial Control Equipment, certified for US and Canada. See UL File E65584. UL Listed for Class I, Division 2 Group A,B,C,D Hazardous Locations, certified for U.S. and Canada. See UL File E194810.
CSA	CSA Certified Process Control Equipment. See CSA File LR54689C. CSA Certified Process Control Equipment for Class I, Division 2 Group A,B,C,D Hazardous Locations. See CSA File LR69960C.
CE	European Union 2004/108/EC EMC Directive, compliant with: EN 61326-1; Meas./Control/Lab., Industrial Requirements EN 61000-6-2; Industrial Immunity EN 61000-6-4; Industrial Emissions EN 61131-2; Programmable Controllers (Clause 8, Zone A & B)
C-Tick	Australian Radiocommunications Act, compliant with: AS/NZS CISPR 11; Industrial Emissions
Ex	European Union 94/9/EC ATEX Directive, compliant with: EN 60079-15; Potentially Explosive Atmospheres, Protection "n" EN 60079-0; General Requirements II 3 G Ex nA IIC T4 X
Publications	Installation Instructions 1794-IN098 ; User Manual 1794-UM009

⁽¹⁾ See the Product Certification link at www.ab.com for Declarations of Conformity, Certificates, and other certification details.

Mounting Dimensions



A = Mounting hole dimensions for optional mounting kit

B = DIN rail

C = Secure DIN rail approximately every 200 mm

Rockwell Otomasyon Ticaret A.Ş., Kar Plaza İş Merkezi E Blok Kat:6 34752 İçerenköy, İstanbul, Tel: +90 (216) 5698400

www.rockwellautomation.com

Power, Control and Information Solutions Headquarters

Americas: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444

Europe/Middle East/Africa: Rockwell Automation, Vorstlaan/Boulevard du Souverain 36, 1170 Brussels, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640

Asia Pacific: Rockwell Automation, Level 14, Core F, Cyberport 3, 100 Cyberport Road, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846

Publication 1794-IN098E-EN-P - January 2011

Supersedes Publication 1794-IN098D-EN-P- March 2005

Copyright © 2011 Rockwell Automation, Inc. All rights reserved.