

Product Information

Original Instructions



PowerFlex 4 Adjustable Frequency AC Drive

Catalog Number 22A

- ATTENTION:**
- Before installing, configuring, operating, or maintaining this product, read this document and the documents that are listed in the Additional Resources section for installing, configuring, or operating equipment. Users should familiarize themselves with installation and wiring instructions in addition to requirements of all applicable codes, laws, and standards.
 - Installation, adjustments, putting into service, use, assembly, disassembly, and maintenance shall be carried out by suitably trained personnel in accordance with applicable code of practice.
 - If this equipment is used in a manner that is not specified by the manufacturer, the protection that is provided by the equipment may be impaired.
 - Solid-state equipment has operational characteristics that differ from those of electromechanical equipment. Safety Guidelines for the Application, Installation, and Maintenance of Solid-state Control, publication SGI-11, available from your local Rockwell Automation sales office or online at rok.auto/literature describes some important differences between solid-state equipment and hard-wired electromechanical devices.

ATTENTION: Do not install, configure, operate or maintain this product until you have read the product documentation and the documents in the Additional Resources section for installing, configuring, operating or maintaining equipment. To get the product documentation go to rok.auto/literature or contact your local sales office or Rockwell Automation representative.

ATTENTION: Ne pas installer, configurer, exploiter ou maintenir ce produit tant que vous n'avez pas lu sa documentation et les documents de la rubrique Documents connexes pour l'installation, la configuration, l'exploitation et la maintenance de l'équipement. Pour obtenir de la documentation, rendez-vous sur le site rok.auto/literature ou contactez votre agence commerciale Rockwell Automation locale ou son représentant.

ACHTUNG: Für die Installation, Konfiguration, den Betrieb und die Wartung dieses Produkt lesen Sie sich bitte zunächst die Produktdokumentation sowie die Dokumente im Abschnitt "Weitere Informationen" durch. Die entsprechende Produktdokumentation finden Sie unter rok.auto/literature oder kontaktieren Sie Ihr lokales Vertriebsbüro bzw. einen Rockwell Automation-Mitarbeiter.

ATENCIÓN: No instale, configure, opere ni mantenga este producto hasta que haya leído la documentación del producto y los documentos en la sección Recursos adicionales para la instalación, configuración, operación o mantenimiento de equipo. Para conseguir la documentación, diríjase a rok.auto/literature o póngase en contacto con su oficina regional de ventas o representante de Rockwell Automation.

ATENÇÃO: Não instale, configure, opere ou mantenha este produto até que você leia a documentação do produto e os documentos na seção Recursos adicionais para a instalação, configuração, operação ou manutenção do equipamento. Para conseguir a documentação, visite rok.auto/literature ou entre em contato com seu escritório de vendas regional ou representante da Rockwell Automation.

ATTENZIONE: Non installare, configurare, attivare o riparare questo prodotto senza avere prima letto la relativa documentazione nonché i documenti indicati nella sezione Ulteriori Risorse riguardanti l'installazione, la configurazione, l'attivazione o la riparazione dell'apparecchiatura. Per la documentazione sul prodotto visitare il sito rok.auto/literature o contattare l'ufficio vendite o il rappresentante Rockwell Automation di zona.

注意: 製品の資料および追加資料に記載の装置の取付け、構成、操作、または保守に関する資料をお読みになるまでは、この製品の資料、構成、操作、または保守を行わないでください。製品の資料を入手するには、Web サイト: rok.auto/literature を 방문 해주거나 해당 지역의 로크웰 오토메이션 대리점으로 문의하십시오.

注意: 若未阅读产品文档以及“其它资源”小节中提及的有关安装、配置、运行或维护设备的相关文档，请勿安装、配置、运行或维护本产品。请访问 rok.auto/literature 或联系您当地的销售办事处或罗克韦尔自动化代表，以获取产品文档。

注意: 在您完整閱讀本產品相關文件及其他關於安裝、配置、操作或維護設備等資料之前，請勿安裝、配置、操作或維護此產品。您可到下列網站下載所有產品相關文件 rok.auto/literature，或聯繫洛克威爾自動化工場辦公處。

ВНИМАНИЕ: Не устанавливайте, не конфигурируйте, не запускайте в эксплуатацию и не поддерживайте работу продукта до прочтения технической документации по продукту и документации в разделе Дополнительные материалы для инсталлирования, конфигурирования, запуска в эксплуатацию и поддержки работы продукта. Чтобы ознакомиться с документацией по продукту, перейдите по ссылке rok.auto/literature или свяжитесь с локальным офисом продаж или представителем Rockwell Automation.

UWAGA: Nie instaluj i nie uruchamij tego urządzenia dopóki nie zapoznasz się z instrukcją użytkownika produktu. Aby uzyskać dokumentację produktu przejdź do strony internetowej rok.auto/literature lub skontaktuj się z lokalnym biurem sprzedaży lub przedstawicielstwem firmy Rockwell Automation.

OPROZORNENIE: Neprovádějte instalaci, konfiguraci, provoz ani údržbu, pokud jste dosud nepřečetli dokumentaci k produktu a dokumenty obsažené v sekci Doplňující informace pro instalaci, konfiguraci, provoz a údržbu. Tuto dokumentaci můžete získat na rok.auto/literature nebo od obchodního zástupce společnosti Rockwell Automation.

Summary of Changes

This publication contains new or updated information. Changes throughout this revision are marked by change bars, as shown to the left of this paragraph.

Mounting Considerations


- Mount the drive upright on a flat, vertical, and level surface.

Min. Panel Thickness	Screw Size	Screw Torque	DIN Rail
1.9 mm (0.0747 in.)	M4 (#8...32)	1.56...1.96 N-m (14...17 lb-in)	35 mm

- Protect the cooling fan by avoiding dust or metallic particles.
- Do not expose to a corrosive atmosphere.
- Protect from moisture and direct sunlight.

Minimum Mounting Clearances

Vertical mounting is shown. If mounting horizontally, apply the same clearances plus 50 mm (2.0 in.) clearance from the top and bottom of the enclosure to allow for proper airflow.



Ambient Operating Temperatures

Ambient Temperature		Enclosure Rating	Minimum Mounting Clearances
Minimum	Maximum		
-10 °C (14 °F)	40 °C (104 °F)	IP20/Open Type	Use Mounting Option A
		IP30/NEMA 1/UL Type 1 ⁽¹⁾	Use Mounting Option B
	50 °C (122 °F)	IP20/Open Type	

(1) Rating requires installation of the PowerFlex® 40P IP30/NEMA 1/UL Type 1 option kit.

Drive Dimensions


PowerFlex 4 Panel Mount Drives

Flange Mount drives are also available. See the PowerFlex 4 User Manual for more information. Ratings are in kW and (HP).

Frame	1-Phase 120V AC	1-Phase 240V AC No Brake	1-Phase 240V AC	3-Phase 240V AC	3-Phase 480V AC
A	0.2 (0.25) 0.37 (0.5)	0.2 (0.25) 0.37 (0.5) 0.75 (1.0)	0.2 (0.25) 0.37 (0.5) 0.75 (1.0)	0.2 (0.25) 0.37 (0.5) 0.75 (1.0) 1.5 (2.0)	0.37 (0.5) 0.75 (1.0) 1.5 (2.0)
B	0.75 (1.0) 1.1 (1.5)	1.5 (2.0) 2.2 (3.0)	1.5 (2.0)	2.2 (3.0) 3.7 (5.0)	2.2 (3.0) 3.7 (5.0)

PowerFlex 4 AC Drive

Dimensions are in mm and (in.). Weights are in kg and (lb).




Frame	A	B ⁽¹⁾	C	D	E ⁽²⁾	F	G	Ship Weight
A	80 (3.15)	185 (7.28)	136 (5.35)	67 (2.64)	152 (5.98)	59.3 (2.33)	140 (5.51)	1.4 (3.1)
B	100 (3.94)	213 (8.39)	136 (5.35)	87 (3.43)	180 (7.09)	87.4 (3.44)	168 (6.61)	2.2 (4.9)

(1) Overall height of drive with IP30/NEMA 1/UL Type 1 option kit installed.

(2) Overall height of standard IP20/Open Type drive.

IP30/NEMA 1/UL Type 1 Option Kit



Fuses and Circuit Breakers

See the PowerFlex 4 Adjustable Frequency AC Drive User Manual for fuses and circuit breakers for non-UL applications.

Fuses and Circuit Breakers - UL 61800-5-1 Applications

Catalog No.	Output Ratings		Input Ratings		Branch Circuit Protection		Power Dissipation		
	kW	HP	Voltage Range	Amps	Fuses	IP20 Open Watts			
100...120V AC (±10%) - 1-Phase Input, 0...230V 3-Phase Output									
22A-V1P5N104	0.2	0.25	1.5	90...126	0.75	6.0	10 140M-C2E-C10 140MT-C3E-C10	1855	32
22A-V2P3N104	0.4	0.5	2.3	90...126	1.15	9.0	15 140M-C2E-C16 140MT-C3E-C16	1855	40
22A-V4P5N104	0.75	1.0	4.5	90...126	2.25	18.0	30 140M-D8E-C20 140MT-D9E-C20	1855	55
22A-V6P0N104	1.1	1.5	6.0	90...126	3.0	24.0	40 140M-F8E-C32	1855	80
200...240V AC (±10%) - 1-Phase Input⁽¹⁾, 0...230V 3-Phase Output, NO BRAKE									
22A-A1P4N103	0.2	0.25	1.4	180...265	0.7	3.2	6 140M-C2E-B40 140MT-C3E-B40	1855	32
22A-A2P1N103	0.4	0.5	2.1	180...265	1.05	5.3	10 140M-C2E-B63 140MT-C3E-B63	1855	40
22A-A3P6N103	0.75	1.0	3.6	180...265	1.8	9.2	15 140M-C2E-C16 140MT-C3E-C16	1855	55
22A-A6P8N103	1.5	2.0	6.8	180...265	3.4	14.2	25 140M-C2E-C16 140MT-C3E-C16	1855	85
22A-A6P8N103	2.2	3.0	9.6	180...265	4.8	19.6	30 140M-D8E-C25 140MT-D9E-C25	1855	125
200...240V AC (±10%) - 3-Phase Input, 0...230V 3-Phase Output									
22A-A1P5N104	0.2	0.25	1.5	180...265	0.75	5.0	10 140M-C2E-B63 140MT-C3E-B63	1855	32
22A-A2P3N104	0.4	0.5	2.3	180...265	1.15	6.0	10 140M-C2E-B63 140MT-C3E-B63	1855	40
22A-A2P3N104	0.75	1.0	4.5	180...265	2.25	10.0	15 140M-C2E-C16 140MT-C3E-C16	1855	55
22A-A8P0N104	1.5	2.0	8.0	180...265	4.0	18.0	30 140M-D8E-C20 140MT-D9E-C20	1855	85
200...240V AC (±10%) - 3-Phase Input, 0...230V 3-Phase Output									
22A-B1P5N104	0.2	0.25	1.5	180...265	0.75	1.8	3 140M-C2E-B25 140MT-C3E-B25	1855	32
22A-B2P3N104	0.4	0.5	2.3	180...265	1.15	2.5	6 140M-C2E-B40 140MT-C3E-B40	1855	40
22A-B4P5N104	0.75	1.0	4.5	180...265	2.25	5.2	10 140M-C2E-C10 140MT-C3E-C10	1855	55
22A-B8P0N104	1.5	2.0	8.0	180...265	4.0	9.5	15 140M-C2E-C16 140MT-C3E-C16	1855	85
22A-B012N104	2.2	3.0	12.0	180...265	5.5	15.5	25 140M-C2E-C16 140MT-C3E-C16	1855	125
22A-B017N104	3.7	5.0	17.5	180...265	8.6	21.0	30 140M-F8E-C25	1855	180
380...480V AC (±10%) - 3-Phase Input, 0...460V 3-Phase Output									
22A-D1P4N104	0.4	0.5	1.4	340...528	1.4	1.8	3 140M-C2E-B25 140MT-C3E-B25	1855	32
22A-D2P3N104	0.75	1.0	2.3	340...528	2.3	3.2	6 140M-C2E-B40 140MT-C3E-B40	1855	50
22A-D4P0N104	1.5	2.0	4.0	340...528	4.0	5.7	10 140M-C2E-B63 140MT-C3E-B63	1855	70
22A-D6P0N104	2.2	3.0	6.0	340...528	5.9	7.5	15 140M-C2E-C10 140MT-C3E-C10	1855	100
22A-D8P7N104	4.0	5.0	8.7	340...528	8.6	9.0	15 140M-C2E-C16 140MT-C3E-C16	1855	150

(1) 200...240V AC - 1-Phase drives are also available with an integral EMC filter. Catalog suffix changes from N103 to N113 and N104 to N114.

(2) The AIC ratings of the Bulletin 140M/MT devices can vary. See publication [140-TD005](http://rok.auto/literature) or [140M-TD002](http://rok.auto/literature).

(3) Bulletin 140M/MT devices with adjustable current range must have the current trip set to the minimum range that the device does not trip.

(4) Manual Self-Protected (Type E) Combination Motor Controller, UL Listed for 208V Wye or Delta, 240V Wye or Delta, 480V V/277 or 600V V/347. Not UL Listed for use on 480V or 600V Delta/Delta, corner ground, or high-resistance ground systems.

(5) When using a Manual Self-Protected (Type E) Combination Motor Controller, the drive must be installed in a ventilated or non-ventilated enclosure with the minimum volume specified in this column. Application specific thermal considerations may require a larger enclosure.


Wiring

See the PowerFlex 4 Adjustable Frequency AC Drive User Manual for instructions on how to wire the power terminals and control terminals.

Power Wiring

Power Wire Rating	Recommended Copper Wire
Unshielded 600V 75 °C (167 °F) THHN/THWN	15 Mils insulated, dry location
Shielded 600V 75 °C or 90 °C (167 °F or 194 °F) RHH/RHW-2	Belden 29501-29507 or equivalent
Shielded Tray rated 600V 75 °C or 90 °C (167 °F or 194 °F) RHH/RHW-2	Shawflex 2ACD/3ACD or equivalent

Power Terminal Block



IMPORTANT Terminal screws may become loose during shipment. Verify that all terminal screws are tightened to the recommended torque before you apply power to the drive.


Power Terminal Block Specifications

Frame	Maximum Wire Size ⁽¹⁾	Minimum Wire Size ⁽¹⁾	Torque
A	3.3 mm ² (12 AWG)	0.8 mm ² (18 AWG)	17...22 N-m (16...19 lb-in)
B	5.3 mm ² (10 AWG)	1.3 mm ² (16 AWG)	

(1) Maximum/minimum sizes that the terminal block accepts. These are not recommendations.

Control Terminal Block

Control I/O Wiring Block Diagram




	30V DC	125V AC	240V AC	P036 [Start Source]	Stop	I/O Terminal 01 Stop
Resistive	3.0 A	3.0 A	3.0 A	Keypad	Per P037	Coast
Inductive	0.5 A	0.5 A	0.5 A	3-wire	Per P037	Per P037
				2-wire	Per P037	Coast
				RS485 Port	Per P037	Coast

IMPORTANT - I/O Terminal 01 is always a coast to stop input except when P036 [Start Source] is set to "3-Wire", "2-W Lvl Sens" or "Momt FWD/REV" control. In three wire control, I/O Terminal 01 is controlled by P037 [Stop Mode]. All other stop sources are controlled by P037 [Stop Mode].

- The drive is shipped with a jumper installed between I/O Terminals 01 and 11. Remove this jumper when using I/O Terminal 01 as a stop or enable input.

- (2) Two wire control shown. For three wire control, use a momentary input on I/O Terminal 02 to command a start. Use a maintained input for I/O Terminal 03 to change direction.
- (3) Only one analog frequency source may be connected at a time. If more than one reference is connected at the same time, an undetermined frequency reference will result.

General Grounding Requirements




IMPORTANT The MOV to ground jumper must be removed if the drive is installed on an ungrounded (IT mains) or resistive grounded distribution system. Tighten screw after jumper removal.

Prepare For Drive Startup

ATTENTION: Power must be applied to the drive to perform the following startup procedures. Some of the voltages present are at incoming line potential. To avoid electric shock hazard or damage to equipment, only qualified service personnel should perform the following procedure. Thoroughly read and understand the procedure before beginning. If an event does not occur while performing this procedure, **Do Not Proceed. Remove All Power** including user supplied control voltages. User supplied voltages may exist even when main AC power is not applied to the drive. Correct the malfunction before continuing.

Integral Keypad



No.	LED (Color)	No.	LED (Color)
1	Run/Direction Status (Red) Note: A flashing LED indicates that the drive has been commanded to change direction. Indicates actual motor direction while decelerating to zero.	4	Program Status (Red)
2	Alphanumeric Display (Red)	5	Fault Status (Red)
3	Displayed Units (Red)	6	Pot Status (Green)
		7	Start Key Status (Green)

No.	Key	Name	No.	Key	Name
8		Escape	9		Potentiometer
		Select			Start
		Up Arrow/ Down Arrow			Reverse
		Enter			Stop

Smart Start-Up with Program Group Parameters

The PowerFlex 40P is designed so that start up is simple and efficient. The Program Group contains the most commonly used parameters.

= Stop drive before changing this parameter.

No.	Parameter	Min/Max	Display/Options	Default
P031	[Motor NP Volts] Set to the motor nameplate rated volts.	20/Drive Rated Volts	1V AC	Based on Drive Rating
P032	[Motor NP Hertz] Set to the motor nameplate rated frequency.	15/500 Hz	1 Hz	60 Hz
P033	[Motor OL Current] Set to the maximum allowable motor current.	0.0/Drive Rated Amps x 2	0.1 A	Based on Drive Rating
P034	[Minimum Freq] Sets the lowest frequency the drive will output continuously.	0.00/500.0 Hz	0.1 Hz	0.0 Hz
P035	[Maximum Freq] Sets the highest frequency the drive will output.	0.00/500.0 Hz	0.1 Hz	60.0 Hz
P036	[Start Source] Sets the control scheme used to start the drive.	0/5	0 = "Keypad" ⁽¹⁾ 1 = "3-Wire" 2 = "2-Wire" 3 = "2-W Lvl Sens" 4 = "2-W Hi Speed" 5 = "Comm Port"	5
P037	[Stop Mode] Active stop mode for all stop sources [e.g. keypad, run forward (I/O Terminal O2), run reverse (I/O Terminal O3), RS485 port] except as noted below. Important: I/O Terminal O1 is always a coast to stop input except when P036 [Start Source] is set for "3-Wire" control. When in three wire control, I/O Terminal O1 is controlled by P037 [Stop Mode].	0/7	0 = "Ramp, CF" ⁽¹⁾ 1 = "Coast, CF" ⁽¹⁾ 2 = "DC Brake, CF" ⁽¹⁾ 3 = "DCBrkAuto,CF" ⁽¹⁾ 4 = "Ramp" 5 = "Coast" 6 = "DC Brake" 7 = "DC BrakeAuto"	0
P038	[Speed Reference] Sets the source of the speed reference to the drive. Important: When A051 or A052 [Digital Inx Sel] is set to option 2, 4, 5, 6, 13 or 14 and the digital input is active, A051, A052, A053 or A054 will override the speed reference commanded by this parameter. Refer to Chapter 1 of the PowerFlex 40P User Manual for details.	0/5	0 = "Drive Pot" 1 = "InternalFreq" 2 = "0-10V Input" 3 = "4-20mA Input" 4 = "Preset Freq" 5 = "Comm Port"	0 1 (IP66, Type 4X)
P039	[Accel Time 1] Sets the rate of accel for all speed increases.	0.0/600.0 s	0.1 s	10.0 s
P040	[Decel Time 1] Sets the rate of decel for all speed decreases.	0.1/600.0 s	0.1 s	10.0 s
P041	[Reset To Defaults] Resets all parameter values to factory defaults.	0/1	0 = "Ready/Idle" 1 = "Factory Rset"	0
P043	[Motor OL Ret] Enables/disables the Motor Overload Retention function.	0/1	0 = "Disabled" 1 = "Enabled"	0

Fault Codes

To clear a fault, press the Stop key, cycle power or set A100 [Fault Clear] to 1 or 2.

Fault Code Descriptions

No.	Fault	Description
F2	Auxiliary Input ⁽¹⁾	Check remote wiring.
F3	Power Loss	Monitor the incoming AC line for low voltage or line power interruption.
F4	UnderVoltage ⁽¹⁾	Monitor the incoming AC line for low voltage or line power interruption.
F5	OverVoltage ⁽¹⁾	Monitor the AC line for high line voltage or transient conditions. Bus overvoltage can also be caused by motor regeneration. Extend the decel time or install dynamic brake option.
F6	Motor Stalled ⁽¹⁾	Increase [Accel Time x] or reduce load so drive output current does not exceed the current set by parameter A089 [Current Limit].
F7	Motor Overload ⁽¹⁾	An excessive motor load exists. Reduce load so drive output current does not exceed the current set by parameter P033 [Motor OL Current]. Verify A084 [Boost Select] setting.
F8	Heatsink OvrTemp ⁽¹⁾	Check for blocked or dirty heat sink fins. Verify that ambient temperature has not exceeded 40 °C (104 °F) for IP 30/NEMA 1/UL Type 1 installations or 50 °C (122 ° F) for Open type installations. Check fan.
F12	HW OverCurrent	Check programming. Check for excess load, improper DC boost setting, DC brake volts set too high or other causes of excess current.
F13	Ground Fault	Check the motor and external wiring to the drive output terminals for a grounded condition.
F33	Auto Rstrt Tries	Correct the cause of the fault and manually clear.
F38	Phase U to Gnd	Check the wiring between the drive and motor.
F39	Phase V to Gnd	Check motor for grounded phase. Replace drive if fault cannot be cleared.
F40	Phase W to Gnd	
F41	Phase UV Short	Check the motor and drive output terminal wiring for a shorted condition.
F42	Phase UW Short	Replace drive if fault cannot be cleared.
F43	Phase VW Short	
F48	Params Defaulted	The drive was commanded to write default values to EEPROM. Clear the fault or cycle power to the drive. Program the drive parameters as needed.
F63	SW OverCurrent ⁽¹⁾	Check load requirements and A098 [SW Current Trip] setting.
F64	Drive Overload	Reduce load or extend Accel Time.
F70	Power Unit	Cycle power. Replace drive if fault cannot be cleared.
F71	Net Loss	The communication network has faulted. Cycle power. Check communications cabling. Check network adapter setting. Check external network status.
F81	Comm Loss	If adapter was not intentionally disconnected, check wiring to the port. Replace wiring, port expander, adapters or complete drive as required. Check connection. An adapter was intentionally disconnected. Turn off using A105 [Comm Loss Action]. Connecting I/O Terminal O4 to ground may improve noise immunity.
F100	Parameter Checksum	Restore factory defaults.
F122	I/O Board Fail	Cycle power. Replace drive if fault cannot be cleared.

⁽¹⁾ Auto-Reset/Run type fault. Configure with parameters A092 and A093.

Specifications

Agency Certifications

	Listed to UL508C and CSA C22.2 No. 14		Australian Radiocommunications Act, compliant with: EN 61800-3
	Marked for all applicable European Directives EMC Directive: 2014/30/EU; EN 61800-3 LV Directive: 2014/35/EU; EN 61800-5-1		KCC-REM-RAA-22A
	EMC Regulations: 2016 No. 1091; EN 61800-3 LV Regulations: 2016 No. 1101; EN 61800-5-1		

Input/Output Ratings

Output frequency: 0...240 Hz (Programmable)
Efficiency: 97.5% (Typical)

Control Inputs

Digital control inputs	Analog control inputs
Input current: 6 mA	4...20 mA Analog; 250 kΩ input impedance
SRC (Source) mode: 18...24V = ON 0...6V = OFF	0...10V DC Analog; 100 kΩ input impedance External Pot: 1...10 kΩ, 2 W min
SNK (Sink) mode: 0...6V = ON 18...24V = OFF	

Control Output (Programmable Output, form C relay)

Resistive rating: 3.0 A @ 30V DC, 125V AC and 240V AC
Inductive rating: 0.5 A @ 30V DC, 125V AC and 240V AC

Fuses and Circuit Breakers

Recommended Fuse Type: UL Class J, T, or Type BS88; 600V (550V) or equivalent
Recommended Circuit Breakers: HMCP or Bulletin 140U or equivalent.

Protective Features

Motor Protection:
I²t overload protection - 150% for 60 s, 200% for 3 s (Provides Class 10 protection)
Overcurrent: 200% hardware limit, 300% instantaneous fault

Over Voltage:
100...120V AC Input - Trip occurs @ 405V DC bus voltage (equivalent to 150V AC incoming line)
200...240V AC Input - Trip occurs @ 405V DC bus voltage (equivalent to 290V AC incoming line)
380...460V AC Input - Trip occurs @ 810V DC bus voltage (equivalent to 575V AC incoming line)

Under Voltage:
100...120V AC Input - Trip occurs @ 210V DC bus voltage (equivalent to 75V AC incoming line)
200...240V AC Input - Trip occurs @ 210V DC bus voltage (equivalent to 150V AC incoming line)
380...460V AC Input - Trip occurs @ 390V DC bus voltage (equivalent to 275V AC incoming line)

Control Ride-through: Minimum ride-through is 0.5 s - typical value 2 s

Faultless Power Ride-through: 100 ms

Dynamic Braking

Internal brake IGBT included with all ratings except No Brake versions. See Appendix B of the PowerFlex 4 User Manual for DB resistor ordering information.

Additional Resources

These documents contain additional information concerning related products from Rockwell Automation. You can view or download publications at rok.auto/literature.

Resource	Description
PowerFlex 4 User Manual, FRN, publication 22A-UM001	Provides detailed information on the parameters and specifications of the PowerFlex 4 drives.
AC Drive Installation Considerations, publication DRIVES-IN003	Provides additional information that is needed to install PowerFlex AC drives properly.
Wiring and Grounding for Pulse Width Modulated (PWM) AC Drives, publication DRIVES-IN001	Provides basic information that is needed to wire and ground PWM AC drives properly.
Industrial Automation Wiring and Grounding, publication 1770-4.1	Provides general guidelines for installing a Rockwell Automation industrial system.
PowerFlex AC Drive Performance Specifications per Ecodesign Regulation (EU) 2019/1781, publication PFLX-1D003	Provides specifications per Ecodesign Regulation (EU) 2019/1781 and UK SI 2021 No. 745, including efficiency class.
Product Certifications website, rok.auto/certifications	Provides declarations of conformity, certificates, and other certification details.

Rockwell Automation Support

Use these resources to access support information.

Technical Support Center	Find help with how-to videos, FAQs, chat, user forums, and product notification updates.	rok.auto/support
Local Technical Support Phone Numbers	Locate the telephone number for your country.	rok.auto/phonesupport
Technical Documentation Center	Quickly access and download technical specifications, installation instructions, and user manuals.	rok.auto/techdocs
Literature Library	Find installation instructions, manuals, brochures, and technical data publications.	rok.auto/literature
Product Compatibility and Download Center (PCDC)	Download firmware, associated files (such as AOP, EDS, and DTM), and access product release notes.	rok.auto/pcdc

Documentation Feedback

Your comments help us serve your documentation needs better. If you have any suggestions on how to improve our content, complete the form at rok.auto/docfeedback.

Waste Electrical and Electronic Equipment (WEEE)



At the end of life, this equipment should be collected separately from any unsorted municipal waste.

Rockwell Automation maintains current product environmental compliance information on its website at rok.auto/pec.

Connect with us.

rockwellautomation.com

expanding human possibility[®]

AMERICAS: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000

EUROPE/MIDDLE EAST/AFRICA: Rockwell Automation NV, Pegasus Park, De Kleetlaan 12a, 1831 Diegem, Belgium, Tel: (32) 2663 0600

ASIA PACIFIC: Rockwell Automation SEA Pte Ltd, 2 Corporation Road, #04-05, Main Lobby, Corporation Place, Singapore 618494, Tel: (65) 6510 6608

UNITED KINGDOM: Rockwell Automation Ltd., Pitfield, Kiln Farm, Milton Keynes, MK11 3DR, United Kingdom, Tel: (44)(1908) 838-800

Allen-Bradley, expanding human possibility, FactoryTalk, PowerFlex, Rockwell Automation, and TechConnect are trademarks of Rockwell Automation, Inc. Trademarks not belonging to Rockwell Automation are property of their respective companies.

Publication 22A-PC001E-EN-P - February 2024 | Supersedes Publication 22A-PC001D-EN-P - March 2016
Copyright © 2024 Rockwell Automation, Inc. All rights reserved. Printed in China.



PF4
5011610513