


Integral Keypad



Menu	Parameter Group and Description
d	Display Group (View Only) Consists of commonly viewed drive operating conditions.
P	Basic Display Group Consists of most commonly used programmable functions.
A	Advanced Program Group Consists of remaining programmable functions.
F	Fault Designator Consists of list of codes for specific fault conditions. Displayed only when fault is present.

No.	LED (Color)	No.	LED (Color)		
1	Run/Direction Status (Red) Note: A flashing LED indicates that the drive has been commanded to change direction. Indicates actual motor direction while decelerating to zero.	4	Program Status (Red)		
2	Alphanumeric Display (Red)	5	Fault Status (Red)		
3	Displayed Units (Red)	6	Pot Status (Green)		
		7	Start Key Status (Green)		
No.	Key	Name	No.	Key	Name
8		Escape	9		Potentiometer
		Select			Start
		Up Arrow/ Down Arrow			Reverse
		Enter			Stop

Smart Start-Up with Program Group Parameters

The PowerFlex 40P is designed so that start up is simple and efficient. The Program Group contains the most commonly used parameters.

= Stop drive before changing this parameter.

No.	Parameter	Min/Max	Display/Options	Default
P031	[Motor NP Volts] Set to the motor nameplate rated volts.	20/Drive Rated Volts	1V AC	Based on Drive Rating
P032	[Motor NP Hertz] Set to the motor nameplate rated frequency.	15/500 Hz	1 Hz	60 Hz
P033	[Motor OL Current] Set to the maximum allowable motor current.	0.0/Drive Rated Amps x 2	0.1 A	Based on Drive Rating
P034	[Minimum Freq] Sets the lowest frequency the drive will output continuously.	0.00/500.0 Hz	0.1 Hz	0.0 Hz
P035	[Maximum Freq] Sets the highest frequency the drive will output.	0.00/500.0 Hz	0.1 Hz	60.0 Hz
P036	[Start Source] Sets the control scheme used to start the drive.	0/5	0 = "Keypad" ⁽¹⁾ 1 = "3-Wire" 2 = "2-Wire" 3 = "2-W Lvl Sens" 4 = "2-W Hi Speed" 5 = "Comm Port"	5
P037	[Stop Mode] Active stop mode for all stop sources [e.g. keypad, run forward (I/O Terminal O2), run reverse (I/O Terminal O3), RS485 port] except as noted below. Important: I/O Terminal O1 is always a coast to stop input except when P036 [Start Source] is set for "3-Wire" control. When in three wire control, I/O Terminal O1 is controlled by P037 [Stop Mode].	0/7	0 = "Ramp, CF" ⁽¹⁾ 1 = "Coast, CF" ⁽¹⁾ 2 = "DC Brake, CF" ⁽¹⁾ 3 = "DCBrkAuto,CF" ⁽¹⁾ 4 = "Ramp" 5 = "Coast" 6 = "DC Brake" 7 = "DC BrakeAuto"	0
P038	[Speed Reference] Sets the source of the speed reference to the drive. Important: When A051 or A052 [Digital Inx Sel] is set to option 2, 4, 5, 6, 13 or 14 and the digital input is active, A051, A052, A053 or A054 will override the speed reference commanded by this parameter. Refer to Chapter 1 of the PowerFlex 40P User Manual for details.	0/5	0 = "Drive Pot" 1 = "InternalFreq" 2 = "0-10V Input" 3 = "4-20mA Input" 4 = "Preset Freq" 5 = "Comm Port"	0 1 (IP66, Type 4X)
P039	[Accel Time 1] Sets the rate of accel for all speed increases.	0.0/600.0 s	0.1 s	10.0 s
P040	[Decel Time 1] Sets the rate of decel for all speed decreases.	0.1/600.0 s	0.1 s	10.0 s
P041	[Reset To Defaults] Resets all parameter values to factory defaults.	0/1	0 = "Ready/Idle" 1 = "Factory Rset"	0
P043	[Motor OL Ret] Enables/disables the Motor Overload Retention function.	0/1	0 = "Disabled" 1 = "Enabled"	0

Fault Codes

To clear a fault, press the Stop key, cycle power or set A100 [Fault Clear] to 1 or 2.

Fault Code Descriptions

No.	Fault	Description
F2	Auxiliary Input ⁽¹⁾	Check remote wiring.
F3	Power Loss	Monitor the incoming AC line for low voltage or line power interruption.
F4	UnderVoltage ⁽¹⁾	Monitor the incoming AC line for low voltage or line power interruption.
F5	OverVoltage ⁽¹⁾	Monitor the AC line for high line voltage or transient conditions. Bus overvoltage can also be caused by motor regeneration. Extend the decel time or install dynamic brake option.
F6	Motor Stalled ⁽¹⁾	Increase [Accel Time x] or reduce load so drive output current does not exceed the current set by parameter A089 [Current Limit].
F7	Motor Overload ⁽¹⁾	An excessive motor load exists. Reduce load so drive output current does not exceed the current set by parameter P033 [Motor OL Current]. Verify A084 [Boost Select] setting.
F8	Heatsink OvrTemp ⁽¹⁾	Check for blocked or dirty heat sink fins. Verify that ambient temperature has not exceeded 40 °C (104 °F) for IP 30/NEMA 1/UL Type 1 installations or 50 °C (122 ° F) for Open type installations. Check fan.
F12	HW OverCurrent	Check programming. Check for excess load, improper DC boost setting, DC brake volts set too high or other causes of excess current.
F13	Ground Fault	Check the motor and external wiring to the drive output terminals for a grounded condition.
F33	Auto Rstrt Tries	Correct the cause of the fault and manually clear.
F38	Phase U to Gnd	Check the wiring between the drive and motor.
F39	Phase V to Gnd	Check motor for grounded phase. Replace drive if fault cannot be cleared.
F40	Phase W to Gnd	
F41	Phase UV Short	Check the motor and drive output terminal wiring for a shorted condition.
F42	Phase UW Short	Replace drive if fault cannot be cleared.
F43	Phase VW Short	
F48	Params Defaulted	The drive was commanded to write default values to EEPROM. Clear the fault or cycle power to the drive. Program the drive parameters as needed.
F63	SW OverCurrent ⁽¹⁾	Check load requirements and A098 [SW Current Trip] setting.
F64	Drive Overload	Reduce load or extend Accel Time.
F70	Power Unit	Cycle power. Replace drive if fault cannot be cleared.
F71	Net Loss	The communication network has faulted. Cycle power. Check communications cabling. Check network adapter setting. Check external network status.
F81	Comm Loss	If adapter was not intentionally disconnected, check wiring to the port. Replace wiring, port expander, adapters or complete drive as required. Check connection. An adapter was intentionally disconnected. Turn off using A105 [Comm Loss Action]. Connecting I/O Terminal O4 to ground may improve noise immunity.
F100	Parameter Checksum	Restore factory defaults.
F122	I/O Board Fail	Cycle power. Replace drive if fault cannot be cleared.

⁽¹⁾ Auto-Reset/Run type fault. Configure with parameters A092 and A093.

Specifications

Agency Certifications

	Listed to UL508C and CSA C22.2 No. 14		Australian Radiocommunications Act, compliant with: EN 61800-3
	Marked for all applicable European Directives EMC Directive: 2014/30/EU; EN 61800-3 LV Directive: 2014/35/EU; EN 61800-5-1		KCC-REM-RAA-22A
	EMC Regulations: 2016 No. 1091; EN 61800-3 LV Regulations: 2016 No. 1101; EN 61800-5-1		

Input/Output Ratings

Output frequency: 0...240 Hz (Programmable)

Efficiency: 97.5% (Typical)

Control Inputs

Digital control inputs

Input current: 6 mA

SRC (Source) mode:
1B...24V = ON
0...6V = OFF

SNK (Sink) mode:
0...6V = ON
1B...24V = OFF

Analog control inputs

4...20 mA Analog; 250 Ω input impedance

0...10V DC Analog; 100 kΩ input impedance

External Pot: 1...10 kΩ, 2 W min

Control Output (Programmable Output, form C relay)

Resistive rating: 3.0 A @ 30V DC, 125V AC and 240V AC

Inductive rating: 0.5 A @ 30V DC, 125V AC and 240V AC

Fuses and Circuit Breakers

Recommended Fuse Type: UL Class J, T, or Type BS88; 600V (550V) or equivalent

Recommended Circuit Breakers: HMCP or Bulletin 140U or equivalent.

Protective Features

Motor Protection:

1^{1/2} overload protection - 150% for 60 s, 200% for 3 s (Provides Class 10 protection)

Overcurrent: 200% hardware limit, 300% instantaneous fault

Over Voltage:

100...120V AC Input - Trip occurs @ 405V DC bus voltage (equivalent to 150V AC incoming line)

200...240V AC Input - Trip occurs @ 405V DC bus voltage (equivalent to 290V AC incoming line)

380...480V AC Input - Trip occurs @ 810V DC bus voltage (equivalent to 575V AC incoming line)

Under Voltage:

100...120V AC Input - Trip occurs @ 210V DC bus voltage (equivalent to 75V AC incoming line)

200...240V AC Input - Trip occurs @ 210V DC bus voltage (equivalent to 150V AC incoming line)

380...480V AC Input - Trip occurs @ 390V DC bus voltage (equivalent to 275V AC incoming line)

Control Ride-through: Minimum ride-through is 0.5 s - typical value 2 s

Faultless Power Ride-through: 100 ms

Dynamic Braking

Internal brake IGBT included with all ratings except No Brake versions. See Appendix B of the PowerFlex 4 User Manual for DB resistor ordering information.

Additional Resources

These documents contain additional information concerning related products from Rockwell Automation. You can view or download publications at rok.auto/literature.

Resource	Description
PowerFlex 4 User Manual, FRN, publication 22A-UM001	Provides detailed information on the parameters and specifications of the PowerFlex 4 drives.
AC Drive Installation Considerations, publication DRIVES-IN003	Provides additional information that is needed to install PowerFlex AC drives properly.
Wiring and Grounding for Pulse Width Modulated (PWM) AC Drives, publication DRIVES-IN001	Provides basic information that is needed to wire and ground PWM AC drives properly.
Industrial Automation Wiring and Grounding, publication 1770-4.1	Provides general guidelines for installing a Rockwell Automation industrial system.
PowerFlex AC Drive Performance Specifications per Ecodesign Regulation (EU) 2019/1781, publication PFLX-1D003	Provides specifications per Ecodesign Regulation (EU) 2019/1781 and UK SI 2021 No. 745, including efficiency class.
Product Certifications website, rok.auto/certifications	Provides declarations of conformity, certificates, and other certification details.

Rockwell Automation Support

Use these resources to access support information.

Technical Support Center	Find help with how-to videos, FAQs, chat, user forums, and product notification updates.	rok.auto/support
Local Technical Support Phone Numbers	Locate the telephone number for your country.	rok.auto/phonesupport
Technical Documentation Center	Quickly access and download technical specifications, installation instructions, and user manuals.	rok.auto/techdocs
Literature Library	Find installation instructions, manuals, brochures, and technical data publications.	rok.auto/literature
Product Compatibility and Download Center (PCDC)	Download firmware, associated files (such as AOP, EDS, and DTM), and access product release notes.	rok.auto/pcdc

Documentation Feedback

Your comments help us serve your documentation needs better. If you have any suggestions on how to improve our content, complete the form at rok.auto/docfeedback.

Waste Electrical and Electronic Equipment (WEEE)



At the end of life, this equipment should be collected separately from any unsorted municipal waste.

Rockwell Automation maintains current product environmental compliance information on its website at rok.auto/pec.

Connect with us.

rockwellautomation.com

expanding human possibility®

AMERICAS: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000

EUROPE/MIDDLE EAST/AFRICA: Rockwell Automation NV, Pegasus Park, De Kleetlaan 12a, 1831 Diegem, Belgium, Tel: (32) 2663 0600

ASIA PACIFIC: Rockwell Automation SEA Pte Ltd, 2 Corporation Road, #04-05, Main Lobby, Corporation Place, Singapore 618494, Tel: (65) 6510 6608

UNITED KINGDOM: Rockwell Automation Ltd., Pitfield, Kiln Farm, Milton Keynes, MK11 3DR, United Kingdom, Tel: (44)(1908) 838-800

Allen-Bradley, expanding human possibility, FactoryTalk, PowerFlex, Rockwell Automation, and TechConnect are trademarks of Rockwell Automation, Inc. Trademarks not belonging to Rockwell Automation are property of their respective companies.

Publication 22A-PC001E-EN-P - February 2024 | Supersedes Publication 22A-PC001D-EN-P - March 2016
Copyright © 2024 Rockwell Automation, Inc. All rights reserved. Printed in China.



PF4
5011610513