


Energy Assessment and Monitoring Methods System Configuration and Wiring Energy Data Collector Configuration FactoryTalk EnergyMetrix Configuration and Maintenance Local HMI Integration



Important User Information

Read this document and the documents listed in the additional resources section about installation, configuration, and operation of this equipment before you install, configure, operate, or maintain this product. Users are required to familiarize themselves with installation and wiring instructions in addition to requirements of all applicable codes, laws, and standards.

Activities including installation, adjustments, putting into service, use, assembly, disassembly, and maintenance are required to be carried out by suitably trained personnel in accordance with applicable code of practice.

If this equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.

In no event will Rockwell Automation, Inc. be responsible or liable for indirect or consequential damages resulting from the use or application of this equipment.

The examples and diagrams in this manual are included solely for illustrative purposes. Because of the many variables and requirements associated with any particular installation, Rockwell Automation, Inc. cannot assume responsibility or liability for actual use based on the examples and diagrams.

No patent liability is assumed by Rockwell Automation, Inc. with respect to use of information, circuits, equipment, or software described in this manual.

Reproduction of the contents of this manual, in whole or in part, without written permission of Rockwell Automation, Inc., is prohibited.

Throughout this manual, when necessary, we use notes to make you aware of safety considerations.



WARNING: Identifies information about practices or circumstances that can cause an explosion in a hazardous environment, which may lead to personal injury or death, property damage, or economic loss.



ATTENTION: Identifies information about practices or circumstances that can lead to personal injury or death, property damage, or economic loss. Attentions help you identify a hazard, avoid a hazard, and recognize the consequence.

IMPORTANT

Identifies information that is critical for successful application and understanding of the product.

Labels may also be on or inside the equipment to provide specific precautions.



SHOCK HAZARD: Labels may be on or inside the equipment, for example, a drive or motor, to alert people that dangerous voltage may be present.



BURN HAZARD: Labels may be on or inside the equipment, for example, a drive or motor, to alert people that surfaces may reach dangerous temperatures.



ARC FLASH HAZARD: Labels may be on or inside the equipment, for example, a motor control center, to alert people to potential Arc Flash. Arc Flash will cause severe injury or death. Wear proper Personal Protective Equipment (PPE). Follow ALL Regulatory requirements for safe work practices and for Personal Protective Equipment (PPE).

Follow this path to complete your energy management application.

Chapter 1

Energy Assessment and Monitoring Methods

4. Compressed Air System


Two Gardner Denver 480V-750cdm 150 hp air compressors operate around the clock 7 days per week at full line pressure even if the plant is in a down condition on week ends or holidays. Several cost savings alternatives are possible:

4.1. Recommendation: Reduce line pressure when plant is in down condition to minimum pressure required by non-operating devices (safety systems etc. assume 80-85 psi).

a. Savings \$3,896 per year.

b. Calculations (to operate 2 compressors 3 shift-6days-50wks/yr)
 $900\text{hp} \times 1\text{hp} \times 1\text{hr} \times 3\text{shifts} \times 12\text{days} \times 50\text{wks} \times (0.08\text{ \$}/\text{kwh} / 36\text{ \$}/\text{kwh}) = \$345/\text{hr-yr}$
 $\$345/\text{hr-yr} \times 150\text{hp} = \$51,750/\text{compressor-yr}$
 $\$51,750 \times 2\text{ compressors} = \$103,500/\text{yr}$
 $\$103,500 / 300\text{ days/yr} = \$345/\text{day}$

Given every 7 lb reduction in pressure (Psi) reduces energy required by 4%
 Operating pressure: 107 psi - target pressure 80 psi=27psi reduction
 $27\text{psi} / 7\text{ lb factor} = 3$
 $3 \times 4\% \text{ reduction factor} = 12\% \text{ total saving in energy}$
 $12\% \times \$345/\text{day} = \$42/\text{day savings at } 80\text{ psi}$



Chapter 3

Energy Data Collector Configuration

Energy_Gas_Digital

Energy_Gas_Digital	Boiler_House_Gas
Inp_Pulse	Local:1:1.Data:0
Set_Meter_Pulse_Factor	1.5
Set_Calc_Interval	1
Set_High_Flow	500
Set_Critical_Flow	750
Val_Total_Gas	0.0
Val_Gas_Per_Calc_Interval	0.0

Chapter 4

FactoryTalk EnergyMetrix Software Installation

FactoryTalk® EnergyMetrix™ Configuration and Maintenance

Chapter 5 - Groups and Security Setup


Chapter 6 - Device Setup

Chapter 7 - Meter and Tag Setup

Chapter 8 - Alarm Setup

Chapter 9 - Reports and Charts

Chapter 10 - Maintenance



Chapter 11

FactoryTalk View ME Energy Faceplates

Efficient Plant 1 - Boiler House

Device	State	Value 1	Value 2	Value 3	Value 4
Gas Main	ACTIVE	5905.000	103.000	0.000	0.000
Boiler House Gas	ACTIVE	7554.000	385.000	0.000	0.000
Propane	HIGH FLOW	4323.000	4.000	0.000	0.000
Fuel Oil	ACTIVE	2162.000	5.000	0.000	0.000
Boiler House Electric	ACTIVE	0.000	0.000	0.000	0.000

11:32:28 AM Tuesday, September 29, 2009

Chapter 12

Demand Control

Demand Control Status

Load	State	Load	State	Predicted KWH Demand	Demand Control
1	D	9	D	150	ON
2	D	10	D		
3	D	11	D		
4	D	12	D		
5	D	13	D		
6	D	14	D		
7	INT	15	D		
8	D	16	D		

Present Billing KWH Demand: 0

Demand KWH Setpoint: 100

22:43:59 1/9/2012

Chapter 13

Time of Day Control

Load Configuration

Load	Load Description	Start Time	Stop Time
1	Load 1 Production	07:00	23:00

TOD Control: TOD Control

Copy Day: Paste Day

Save Day Changes: Undo Day Changes: Reset Day to Default

Sun Mon Tue Wed Thu Fri Sat Hol

Holidays Enabled

11:44:33 2/16/2011

Notes:

	Preface	
	About This Publication.....	13
	Conventions.....	14
	Software Requirements.....	14
	Studio 5000 Environment.....	15
	Additional Resources.....	16
	Chapter 1	
Energy Assessment and Monitoring Methods	Introduction.....	17
	Review These Steps.....	17
	Determine Business Goals.....	18
	Plant Walk-Through.....	18
	Energy Assessment.....	19
	Business Case for Energy Monitoring.....	23
	Monitoring Methods.....	24
	Chapter 2	
System Configuration and Wiring	Introduction.....	29
	Before You Begin.....	29
	What You Need.....	29
	Follow These Steps.....	30
	List Energy Data Points.....	31
	Identify Existing Energy Distribution Layouts and Metering.....	33
	Create Metering Layout and Name Data Collection Hardware.....	36
	Create Energy Panel Layout and Wiring Drawings.....	48
	Select Monitoring Software.....	52
	License Options.....	52
	Server Requirements.....	53
	Client Requirements.....	54
	Chapter 3	
Energy Data Collector Configuration	Introduction.....	55
	Before You Begin.....	55
	What You Need.....	55
	Follow These Steps.....	56
	Configure a PowerMonitor 3000 Device.....	57
	Configure a PowerMonitor 1000 Device.....	62
	Configure a PowerMonitor Wireless 250 Device.....	67
	PC Receiver Connection.....	67
	Configure a PowerMonitor 500 Device.....	68
	Configure with the Display.....	68
	Access the Programming Menu.....	69
	Configure Communication Parameters.....	69
	Configure Basic Device Parameters.....	70
	Configure Advanced Parameters.....	70
	Configure the Date and Time.....	71

	Configure a PowerMonitor 5000 Device	72
	Setup Using the Web Interface.....	72
	Obtaining Access to the Configuration Pages	72
	How to Set Up the PowerMonitor 5000 Unit.....	73
	Configure a CompactLogix Controller	78
FactoryTalk EnergyMetrix Software Installation	Chapter 4	
	Introduction	91
	Before You Begin	91
	What You Need	91
	Follow These Steps	92
	Contents of Installation DVD	93
	Server Requirements	93
	Server Software Requirements for Installing FactoryTalk EnergyMetrix.....	93
	Hardware Requirements	93
	Client Requirements.....	94
	Installation (64-bit).....	95
	Configure Windows 2008 Server.....	95
	Install SQL Server 2008 R2.....	96
	Enable 32-bit Applications	98
	Install FactoryTalk EnergyMetrix Software Version 2.0	98
	Installation (32-bit).....	99
	Pre-installation Checks.....	99
	Installation	100
	Activate FactoryTalk EnergyMetrix Software	102
	How to Activate Your Software.....	103
FactoryTalk EnergyMetrix Groups and Security Setup	Chapter 5	
	Introduction	105
	Before You Begin	105
	What You Need	105
	Follow These Steps	106
	Creating Domains and Groups	107
	Configuring Security.....	113
FactoryTalk EnergyMetrix Software Device Setup	Chapter 6	
	Introduction	119
	Before You Begin	119
	What You Need	119
	Follow These Steps	120
	Overview of Devices	121
	Configure Communication Drivers	122
	Configure a PowerMonitor Device.....	126
	Copy Devices	128

	Configure a CompactLogix Device	130
	Configure OPC Server Device	132
	Chapter 7	
FactoryTalk EnergyMetrix Software Meter and Tag Setup	Introduction.....	133
	Before You Begin.....	133
	What You Need	133
	Follow These Steps.....	134
	Creating Electric Meters for PowerMonitor Devices	134
	Creating Energy Meters for PowerMonitor Status Inputs.....	140
	Creating Energy Meters for CompactLogix Devices	145
	Creating Energy Meters for OPC Server Device	150
	Sharing and Moving Meters.....	153
	Chapter 8	
FactoryTalk EnergyMetrix Software Alarm Setup	Introduction.....	159
	Before You Begin.....	159
	What You Need	159
	Follow These Steps.....	160
	Overview of Alarms	161
	Configure an Analog Alarm.....	161
	Configure a Digital Alarm	164
	View and Edit Alarm Setups	169
	Configure Communication Alarms.....	169
	Configure Email Alarm Subscriptions.....	170
	Configure SMTP Server	171
	View Active Alarms and Alarm Log.....	172
	Chapter 9	
FactoryTalk EnergyMetrix Software Reports and Charts	Introduction.....	173
	What You Need	173
	Follow These Steps.....	174
	Standard Reports.....	175
	Consumption Report.....	176
	Demand Analysis Report	180
	Billing Report.....	182
	Cost Allocation Report.....	187
	Power Quality Report	192
	Standard Charts.....	194
	Chapter 10	
FactoryTalk EnergyMetrix Software and PowerMonitor Device Maintenance	Introduction.....	199
	Before You Begin.....	199
	What You Need	199
	Follow These Steps.....	200

Set Up Database Maintenance	201
Automatic Data Repopulation	204
Devices that Support ADR	204
Monitor Health of Data Logging	206
Using the Windows Event Viewer	207
Running System Configuration Reports	208
System Updates and Upgrades	209

Chapter 11

FactoryTalk View ME Energy Faceplates

Introduction	213
Before You Begin	214
What You Need	214
Follow These Steps	215
Configure PowerMonitor 1000 Faceplates	217
Configure ME PowerMonitor 500 Faceplates	229
Configure RSLogix5000 for the PowerMonitor 500 Unit Faceplate	230
Configure FactoryTalk View ME for the PowerMonitor 500 Unit Faceplate	233
Configure PowerMonitor 5000 Unit Faceplates	238
Configure RSLogix5000 for the PowerMonitor 5000 Unit Faceplate	239
Configure FactoryTalk View ME for the PowerMonitor 5000 Unit Faceplate	243
Configure ME PowerFlex Drives Faceplates	248
Configure RSLogix5000 for the PowerFlex Drive Faceplate	249
Configure FactoryTalk View ME for the PowerFlex Drive Unit Faceplate	261
Configure ME E3PLUS Faceplates	265
DeviceNet to EtherNet/IP Network Setup	265
Configure RSLogix5000 for the E3 Plus Faceplate	268
Configure FactoryTalk View ME for the E3 Plus Module Faceplate	276
Configure ME E300 Faceplate	280
Configure RSLogix5000 for the E300 Module Faceplate	281
Configure FactoryTalk View ME for the E3 Plus Module Faceplate	287
Configure ME SMC-50 Controller Faceplates	292
Configure RSLogix5000 for the SMC-50 Controller Faceplate ..	292
Configure FactoryTalk View ME for the SMC-50 Controller Faceplate	301
Configure ME CIP Motion Drive Faceplates	306
System Compatibility	306
General Setup	306
Configure Studio 5000 Logix Designer Application for the Kinetix Drive Faceplate	307

CIP Motion Energy Faceplate Overview.....	315
Configure Device Logic for Equipment Status and Alarm	
History Faceplates.....	317
Configure Equipment Status Faceplate.....	338
Configure Alarm History Faceplate.....	347
Create a Runtime Application File.....	354
Transfer Runtime File to PanelView Plus Terminal	356
Run Application on PanelView Plus Terminal.....	357

Chapter 12

Demand Control

Introduction.....	359
Before You Begin.....	359
What You Need	359
Follow These Steps.....	360
Control Hardware Selection and Wiring.....	360
List Load Outputs and Inputs	360
Create Control Panel Layout and Wiring.....	361
Logic Integration.....	362
Configure Controller, Network, and I/O.....	362
Import and Configure Demand Control Program.....	364
Configure Load Inputs and Outputs	366
Configure PowerMonitor Messages	367
Configure Password	368
Save the Project File	368
HMI Integration.....	369
Add Demand Faceplate to FactoryTalk View ME Application ..	369
Create a Display Navigation Button.....	369
Configure Alarms	370
Configure Communication	372
System Commissioning.....	373
Install System Hardware	373
Download RSLogix5000 Project.....	374
Configure and Download FactoryTalk Project to	
PanelView Plus Terminal	375
Demand Control Configuration.....	377
System Application Guide	380
Faceplate Operation Overview.....	380
Demand Controller Tags	389

Chapter 13

Time of Day Control

Introduction.....	393
Before You Begin.....	393
What You Need	393
Follow These Steps.....	394
Control Hardware Selection and Wiring.....	394

List Load Outputs and Inputs.....	394
Create Control Panel Layout and Wiring.....	395
Logic Integration.....	396
Configure Controller, Network, and I/O.....	396
Import and Configure Time of Day Program.....	398
Configure Load Inputs and Outputs.....	399
Configure Alarms.....	401
Save the Project File.....	401
HMI Integration.....	402
Add TOD Faceplate to FactoryTalk View ME Application.....	402
Configure Alarms.....	402
Configure Communication.....	404
System Commissioning.....	405
Install System Hardware.....	405
Download RSLogix5000 Project File.....	405
Configure and Download FactoryTalk Project to PanelView Plus Terminal.....	407
System Startup and Test.....	409
System Application Guide.....	415
Faceplate Operation Overview.....	415

Appendix A

Custom Meter Types.....	423
-------------------------	-----

Appendix B

Custom Units and Value Types	Verify Base Units.....	425
	Create Base Units.....	426
	Verify Units.....	427
	Create Units.....	427
	Verify Value Types.....	429
	Create Value Types.....	429

Appendix C

Energy Electric Add-On Instructions	CompactLogix Digital Input Logic.....	431
	PowerMonitor Digital Status Input Logic.....	432
	CompactLogix Analog Input Logic.....	433
	Demand Calculation Logic.....	434
	Equipment Status Faceplate Logic.....	436
	Alarm History Faceplate Logic.....	437

Appendix D

Digital and Analog Energy Add-On Instructions	CompactLogix Digital Input Logic.....	439
	PowerMonitor Digital Status Input Logic.....	440
	CompactLogix Analog Input Logic.....	441
	Equipment Status Faceplate Logic.....	443

Alarm History Faceplate Logic	444
-------------------------------------	-----

Appendix E

Update Add-on Profiles

Update the E3PLUS Add-On Profiles	447
Update the SMC-50 Add-On Profiles	448
Update the PowerFlex Add-On Profiles	449
Update the E300 Add-On Profiles	450

Notes:

About This Publication

This quick start is designed to provide a framework for developing an energy management monitoring, analysis, and control application for your facility. Each section guides you through the tasks you need to plan, configure, program, and use your Rockwell Automation™ energy data collection and control devices and analysis software. An example application, named Efficient Industries Plant 1, is referenced throughout this quick start to guide you through these tasks.

To help in the design and installation of your system, application files and other information is provided on the Energy Management Accelerator Toolkit CD, publication IASIMP-SP014. The CD provides an energy data worksheet, layout and wiring drawings, data collection and control logic, and more. With these tools and the built-in best-practices design, you can focus on the design of your system and not on design overhead tasks.

IMPORTANT Before using this quick start and the CD, read the Terms and Conditions on the CD.

The beginning of each chapter contains the following information. Read these sections carefully before you begin work in each chapter.

- **Before You Begin** - This section lists the steps that must be completed and decisions that must be made before starting that chapter. The chapters in this quick start do not have to be completed in the order in which they appear, but this section defines the minimum amount of preparation that is required before completing the current chapter.
- **What You Need** - This section lists the tools that are required to complete the steps in the current chapter. This includes, but is not limited to, hardware and software.
- **Follow These Steps** - This illustrates the steps in the current chapter and identifies which steps are required to complete the examples.

Conventions

The manual uses the following conventions.

Convention	Meaning	Example
Click	Click the left mouse button once to initiate an action. (Assumes cursor is positioned on object or selection.)	Click Browse.
Double-click	To initiate an action, click the left mouse button twice in quick succession while the cursor is positioned on object or selection.	Double-click the application icon.
Right-click	To initiate an action, click the right mouse button once while the cursor is positioned on object or selection.	Right-click the Ethernet port.
Drag and drop	Click and hold the left mouse button on an object, move the cursor to where you want to move the object, and release the mouse button.	Drag and drop a task into the blank plan.
Choose	Choose an option from a list of options.	From the Tools menu, choose Internet Options.
Select	Click to highlight an item.	Select the Devices folder.
Check or uncheck	Click to activate or deactivate a checkbox.	Check Enable device.
>	Shows nested menu selections as menu name followed by menu selection.	Choose File > New > Document.
Expand	Click the + to the left of a given item /folder to show its contents.	Expand the Main Task.

Software Requirements

You need the following software to use this toolkit.

Rockwell Automation Software	Version	Required For
Studio 5000™ Logix Designer application	21.00 or later	Power and energy management applications
RSLogix™ 5000 <ul style="list-style-type: none"> ControlFlash BOOTP/DHCP utility RSLinX® Classic 	17.00 or later	
FactoryTalk View Studio for Machine Edition <ul style="list-style-type: none"> FactoryTalk Services RSLinX Enterprise RSLinX Classic 	5.0 or later	PanelView™ Plus terminals
FactoryTalk® EnergyMetrix™ CD, cat. no. 9307-FTEMMENE	2.0 or later	FactoryTalk EnergyMetrix software
Energy Management Accelerator Toolkit CD	IASIMP-SP014	CAD files, wiring diagrams, application files, and other support information

Studio 5000 Environment

The Studio 5000 Engineering and Design Environment combines engineering and design elements into a common environment. The first element in the Studio 5000 environment is the Logix Designer application. The Logix Designer application is the rebranding of RSLogix 5000 software and continues to be the product to program Logix5000™ controllers for discrete, process, batch, motion, safety, and drive-based solutions.



The Studio 5000 environment is the foundation for the future of Rockwell Automation engineering design tools and capabilities. It is the one place for design engineers to develop all the elements of their control system.

Additional Resources

These documents contain additional information concerning related products from Rockwell Automation.

Resource	Description
PowerMonitor 1000 Unit Installation Instructions, publication 1408-IN001	Provides information on installing, wiring, connecting, applying power and configuring the PowerMonitor™ 1000 unit.
PowerMonitor 1000 Unit User Manual, publication 1408-UM001	Provides information on setting up communication with the PowerMonitor 1000 unit by using other applications and controllers.
PowerMonitor 3000 Master Module installation instructions, publication 1404-IN007	Provides information on selecting an enclosure, installing, and wiring the PowerMonitor 3000 master module.
Bulletin 1404 PowerMonitor 3000 Display Module installation instructions, 1404-IN005	Provides information on installing and wiring the PowerMonitor 3000 display module.
Bulletin 1404 PowerMonitor 3000 Unit User Manual, publication 1404-UM001	Provides information on setting up communication with the PowerMonitor 3000 master module, firmware version 3.0 or later, by using other applications and controllers.
Bulletin 1404 PowerMonitor 3000 Unit User Manual, publication 1404-UM001D-EN-P	Provides information on setting up communication with the PowerMonitor 3000 master module, prior to firmware version 3.0, by using other applications and controllers.
Bulletin 1404 Series B Ethernet Communication Release Note, publication 1404-RN008	Provides information on using the PowerMonitor 3000 module with EtherNet/IP communication.
PowerMonitor Wireless 250 Monitor User Manual, publication 1425-UM001	Provides information on installing, wiring and setting up communication with the PowerMonitor Wireless 250 unit.
PowerMonitor 500 Unit User Manual, publication 1420-UM001	Provides information on installing, wiring and setting up communication with the PowerMonitor 500 unit.
PowerMonitor 5000 Unit User Manual, publication 1426-UM001A	Provides information on installing, wiring and setting up communication with the PowerMonitor 5000 unit.
FactoryTalk EnergyMetrix User Manual, publication FTEM-UM002	Provides information on how to use FactoryTalk EnergyMetrix, a modular, scalable, web-enabled, client/server energy information and management application.
Power and Energy Management Solutions Product Overview, publication EMSE00-BR017	Provides an overview of the Rockwell Automation suite of energy management services and solutions, including hardware and software, for monitoring, analyzing, controlling, and optimizing energy systems.
Power and Energy Management Solutions Selection Guide, publication 1400-SG001	Provides information on selecting energy management services and solutions, including hardware and power management software.
Logix Common Procedures Programming Manual, publication 1756-PM001	Provides information on programming Logix 5000™ controllers, including managing project files, organizing tags, programming and testing routines, and handling faults
Industrial Automation Wiring and Grounding Guidelines, publication 1770-4.1	Provides general guidelines for installing a Rockwell Automation industrial system.
Product Certifications website, http://www.ab.com	Provides declarations of conformity, certificates, and other certification details.
http://www.rockwellautomation.com/solutions/integratedarchitecture/	Provides information on integrated architecture tools and resources including accelerator toolkits.
Rockwell Automation Configuration and Selection Tools, available at http://www.rockwellautomation.com/en/e-tools/	These online tools install on your personal computer so that you can quickly access information on our products. <ul style="list-style-type: none"> • CrossWorks • Industrial Computer Selector • Operator Interface Selection Tool • Programmable Controller Family Selector

You can view or download publications at <http://www.rockwellautomation.com/literature/>. To order paper copies of technical documentation, contact your local Allen-Bradley distributor or Rockwell Automation sales representative.

Energy Assessment and Monitoring Methods


Introduction

This chapter introduces the fundamentals of creating an energy management plan that will help you to:

- determine your business goals.
- perform a plant walk-through.
- perform an energy assessment.
- understand the business case for energy monitoring.
- review the monitoring methods available when applying Rockwell Automation energy management hardware and software products.

Review These Steps

Review these concepts to create an energy management plan for your facility.



Determine Business Goals

Business today has changed and it added a color - green. Not only do you need to meet your business and production goals, but global dynamics are forcing you to pursue energy reductions. Many companies can help reduce energy consumption at their manufacturing facilities when a plan is implemented.

Determining your business goals is the first step in understanding and developing the scope of your energy and power management application. Your business goals may include:

- Energy cost reduction
- Operating equipment efficiency
- Usage based cost accounting
- Downtime reduction through power quality monitoring
- Sustainable production initiatives
- Driving energy cost accountability to the energy user
- Identifying and justifying energy cost savings projects

Plant Walk-Through

After determining your business goals, conduct a walk-through of your plant or campus. This will help you to identify the largest energy consumption uses and events.

To maximize the efficiency of the walk-through, gather pertinent facility documentation that is available.

- Facility one line diagrams for electricity, gas, water, steam, air, and other fuels
- Production equipment layout
- Electric power equipment list
- Other energy equipment documentation including boilers, air compressors, HVAC equipment, and process cooling equipment
- Energy meters and monitoring equipment

Plant walk-through steps include:

1. Listing large energy consuming equipment and processes.
2. Listing typical time of use or duty cycle.
3. Listing operational or production dependencies.
4. Identifying applications using variable speed drives.
5. Reviewing operation of air compressors, boilers, and chillers

Energy Assessment

The assessment process is a detailed analysis of the data collected during the walk-through. Identifying opportunities for energy savings and developing the return on investment for these projects is critical. Energy assessments should identify not only opportunities, but savings, project costs, and payback calculations. Projects should also be categorized as awareness or behavior changes, minor cost, and capital. This approach will help prioritize the steps in the energy savings plan.

Collect and Analyze Utility Bills and Rate Schedules

An important part of the energy assessment is to collect and analyze your current utility rate schedules and bills. This typically includes electric, natural gas, water, and sewer. Other fuels consumed may include fuel oil, propane, or steam. Understanding your bill is crucial in executing an appropriate energy management plan to maximize your energy savings investment.

Energy rate schedules from your local utilities can include, but are not limited to, line item charges such as:

- **Demand Charges** - A variable monthly or yearly charge for the highest amount of energy consumed over a fixed period, typically 15 minutes. This charge can contribute significantly to overall energy costs.
- **Energy Charge** - A variable monthly charge for the total energy that is consumed. This charge typically includes on-peak and off-peak rates, contracted minimums, alternative charges, ratchet demand penalties, or other special terms.

Here is an example of an electric bill and electric rate schedule. You can see that time-of-use and on-peak demand needs can significantly increase your overall energy costs.

Sample Electric Bill



Electric Billing Period: 06/05/07 to 07/04/07		42 Heating Degree Days	173 Cooling Degree Days
10am to 10pm			
Actual Reading on 07/04/07			13994
Actual Reading on 06/05/07			13779
Meter Multiplier 4800			
Total Consumption			1,033,829 kWhrs
Total On-Peak Consumption			413,729 kWhrs
Total Off-Peak Consumption			620,100 kWhrs
Actual On-Peak Demand		06/07/07@13:45	2770.500 kw
Actual Off-Peak Demand		06/18/07@08:30	2676.400 kw
Actual Reactive Demand		06/07/07@13:45	1537.900 kvar
Total Usage Period : 06/05/07 to 07/04/07			
Current Period Power Factor			0.935 kw
Billed On-Peak Demand		9,594.800 * (1 - 5(.935 - .85)) =	9187.000 kw
Customer Demand 07/06/06 - 08/03/06			9774.400 kw
Total Consumption		4,690,135	
Total On-Peak Consumption		1,902,680	
Total Off-Peak Consumption		2,787,455	
Electric Charges Period : 06/05/07 to 07/04/07			
General Primary Service - CP1 29 Days			
Customer Demand Charge > 12470 and < 138000	9,774.4 kw @	\$0.760000	\$7,428.54
On-Peak Demand Charge > 12470 and < 138000	9,187.0 kw @	\$10.380000	\$95,361.06
Facilities	29 days @	\$17.260270	\$500.55
Non-taxable Customer Charge			\$200.00
On-Peak Energy > 12470 and < 138000	1,902,680 kWh @	\$0.081270	\$154,577.20
Off-Peak Energy > 12470 and < 138000	2,787,455 kWh @	\$0.033050	\$92,125.39
Subtotal			\$312,192.74
Sales Tax @ 5.60% (15.0% Exempt) (prorated) On Charges Of \$311,992.74			\$14,650.85
Total Amount			\$327,043.59

Sample Rate Schedules

RATE

Facilities Charge, including one meter \$1.52877 per day

Demand Charges

On-Peak Demand

Per kW of measured on-peak demand \$11.20500

For monthly on-peak hours of use less than 100, the monthly on-peak demand charge of \$11.20500 per kW will be reduced by \$0.06723 times the difference between 100 and the monthly on-peak hours of use. Monthly on-peak hours of use is the on-peak energy usage divided by the measured on-peak demand.

In the case of customers who have received an embedded credit, the minimum on-peak demand charge shall be established by contract.

Customer Maximum Demand

Per kW of measured demand \$1.75700

For Determination of Demand, see Sheet No. 43

Energy Charge, per kWh

On-Peak Energy (a)	\$0.07342
Off-Peak Energy (b)	\$0.05366

- (a) General Secondary on-peak energy usage is the energy in kilowatt hours delivered between 9:00 a.m. and 9:00 p.m., prevailing time, Monday through Friday, excluding those days designated as legal holidays for New Year's Day, Memorial Day, Independence Day, Labor Day, Thanksgiving Day and Christmas Day.
- (b) General Secondary off-peak energy usage is the energy in kilowatt hours delivered during all hours other than on-peak hours.

Sample Energy Assessment

Here is an example of a compressed air plant system assessment.

Sample Energy Assessment Document

4. Compressed Air System

Two Gardner Denver 480v- 750scfm-150 hp air compressors operate around the clock 7 days per week at full line pressure even if the plant is in a down condition on week ends or holidays. Several cost savings alternatives are possible.

4.1. Recommendation: Reduce line pressure when plant is in down condition to minimum Pressure required by non operating devices (safety systems etc...assume 80-85 psi) .

a. Savings \$3,696 per year.

b. Calculations (to operate 2 compressors 3 shift- 6days-50wks yr)
 $\$60/\text{yr-hp-shift} \times 3 \text{ shifts/yr} \times 1.2 \text{ days/oper wk} \times (.08 \text{ \$/kw} / .05 \text{ \$/kw}) = \$345/\text{hp-yr}$
 $\$345/\text{hp-yr} \times 150 \text{ hp} = \$51,750/\text{compressor-yr}$
 $\$51,750 \times 2 \text{ compressors} = \$103,500/\text{yr}$
 $\$103,500 / 300 \text{ days/yr} = \$345/\text{day}$

Given every 7 lb reduction in pressure (Psi) reduces energy required by 4%

Operating pressure 107 psi - target pressure 80 psi=27psi reduction
 27psi / 7 lb factor = 3
 3 X 4% reduction factor = 12% total saving in energy
 12% X \$345/day=\$42/day savings at 80 psi

88 down days/yr X \$42/day=**\$3,696 /yr**

4.2. Recommendation: Reduce Line pressure during operational periods from 107 to 85-90 psi.(assume form fill machines require minimum of 85 psi)

a. Savings:\$12,041

b. Calculations
 107 psi – 85 psi=22 psi
 22psi / 7 lb factor = 3.14
 3.14 X 4% reduction factor= 12.6% energy savings
 12.6% X \$345/day X 277 production days=**\$12,041/yr**

4.3. Recommendation: Isolate devices that must stay on over week end & holidays. Feed with smaller dedicated compressor. Assume 1- 25 hp compressor

a. Savings: \$22,770

b. Calculations
 88 days that large compressor is down (see above)= 24% of time
 24% X \$103,500/yr= \$24,840
 Less cost to operate small compressor =25hp/300hp=8.3%
 8.3% \$103,500 X 24%=\$2,070
= \$22,770/yr

4.4. Recommendation: Increase air leak detection program from 1 time per year to 3 times per year to sustain gains. Utilize ultrasonic tools to provide most reliable results.

a. Savings: estimated at \$10,700/yr.

b. Calculations

Opening dia.	1/64	1/32	1/16	1/8	total
air escaping at each leak (cfm)	.5 cfm	1.5 cfm	6.5 cfm	26 cfm	
annual kwh(6.5day/wk 24 hr day X 50 wk/yr)		647	1940	8405	33620
annual cost/leak (@.08 \$/kwh)		\$51	\$155	\$672	\$2,689
					\$3,567
assume 12leaks/yr in uniform dist. = 12 / 4 X \$3,567			\$10,701		

4.5. Recommendation: Improve metering and recording of data on air compressor system. Complete program to install instruments and trend charts to track air consumption and peak usage. To further reduce air use and improve the overall efficiency of the existing compressors correlate spikes in demand with activities at the bag house, scales, silos, and waste treatment plant. All are major air users and have multiple devices pulsing at full line pressure. Further study may show installation of an air buffer tank or added storage tanks may reduce peak loads and therefore reduce overall load and cycling of the compressors.

How Rockwell Can Help

Rockwell Automation has a team of engineers that are experienced in conducting energy assessments for energy sources including, but not limited to, electricity, gas, water, air, and steam.

To help you identify energy cost savings opportunities, Rockwell Automation can perform a general energy assessment that will help you create a sustainable plan. If the scope of your needs is more extensive, a comprehensive assessment can be performed to best fit your requirements.

Rockwell Automation Energy Assessment Options

Energy Assessment Option	General 2 to 3 Days ⁽¹⁾	Comprehensive 2 to 3 Weeks ⁽²⁾
Utility usage review	•	•
Energy saving project identification	•	•
Operations analysis of savings opportunities	•	•
Utility usage review		•
Detailed energy usage analysis		•
Rates and tariffs analysis		•
Detailed quotations for sustainability projects		•
Prioritization of projects		•

(1) Request a 1400-AUD services quote from your local Rockwell Automation distributor or the Rockwell Automation custom support and maintenance team.

(2) Request 1400-ATT services quote from your local Rockwell Automation distributor or the Rockwell Automation custom support and maintenance team.

To view a sample assessment, refer to the Energy and Utilities Site Assessment document in the Support Information section on the Energy Management Accelerator Toolkit CD.

Business Case for Energy Monitoring

Energy monitoring makes energy usage data visible so that it is included in the planning and execution of a business strategy along with other management information. Because utility bills can be a significant portion of business expense, it is important to understand how energy is used. Implementing a monitoring plan will help your business set goals for energy reduction that will translate into cost savings.

Typical energy users evolve through a number of energy awareness phases.

Ignorance is Expensive

In the first phase, energy is not considered a significant expense or important management information. Operations uses energy and accounts payable pays for it. Management begins to notice the higher costs and sets goals for energy reduction. If operation managers are not aware of the energy cost of their operations, energy savings will not be captured.

Metering the Envelope

In the second phase, energy monitoring is installed on the plant main feeds. Electricity, natural gas, water, and other feeds are recorded. The investment is relatively low. The monitoring system generates shadow bills to verify the utility billing. Major users of energy are identified. The relationship between operating schedules and plant demand becomes clearer. A few energy saving opportunities are identified and cost savings generated. However, monitoring only the entire plant has limitations addressed in the next phase.

Submetering the Processes

In this phase, submeters are installed on process lines and utility equipment such as air, compressors, and boilers. This phase requires a higher level of investment but provides a more detailed view of energy usage. Reports run daily or weekly provide a direct line of sight to the impact of operations decisions. Energy use can be correlated with key production indicators to identify peak producers and opportunities for improvement. Operations can be benchmarked within a plant or across an enterprise. More cost-saving opportunities are identified. Historical data is used to accurately forecast energy use, providing the basis for negotiating more favorable rates from energy providers. The same data is used in justifying capital projects to improve efficiency and further reduce energy usage, cost, and waste. Energy accountability grows.

Controlling Energy Use and Demand

The volume and accuracy of energy use information gathered in the preceding phases is useful in determining the next steps. Perhaps an automated demand control system would be effective in increasing energy efficiency and sustainability. Opportunities for heat recovery and onsite generation may be identified. Potential trouble spots might be avoided that would minimize unnecessary downtime.


Monitoring Methods

Rockwell Automation power monitors and controllers collect data from your plant floor that can be used by FactoryTalk EnergyMetrix software for monitoring and analysis.

FactoryTalk EnergyMetrix software provides monitoring and reporting tools to help you understand usage patterns, optimize processes, and reduce utility costs in your organization. You can use these tools to monitor electrical loads, consumption, power quality, analyze demand, and generate billing and cost allocation reports.

Load Profiling

Load profiling is a method where electrical loads are monitored or profiled. Load profiling helps to identify peak demands so that you can reschedule loads accordingly to reduce energy costs.



Consumption Reporting

Consumption reporting typically monitors periodic utility usage, production, or other key performance indicators, and assists with the early detection of production/equipment problems such as leaks, inefficiencies, and production problems.

Demand Analysis

Demand analysis monitors the electrical demand of plant areas so that you can make energy saving production scheduling or demand control decisions.

Consumption Report

8/31/2009 12:00 AM to 9/1/2009 12:00 AM

Time Zone: (GMT-06:00) Central Time (US & Canada)

Air (ID 22)

Air Usage (cf)	
Air Flow _Meter	1,441
Total(s):	1,441

Electricity (ID 23)

Electric	Real Energy Net (kWh)		Reactive Energy Net (kVARh)	
Electric Main _Meter	23,910		7,076	
Total(s):	23,910		7,076	

Fuels (ID 24)

Fuel Oil Usage (Gal)	
Fuel Oil _Meter	0
Total(s):	0

Electrical Demand Analysis

7/1/2009 12:00 AM to 8/1/2009 12:00 AM

Time Zone: (GMT-06:00) Central Time (US & Canada)

kW

Peak Demand Summary

Boiler House _Meter	665.5 kW	9.2%	7/22/2009 1:30:00 PM
Power House _Meter	352.0 kW	4.9%	7/22/2009 1:30:00 PM
Production 1 _Meter	1,787.9 kW	24.7%	7/22/2009 1:30:00 PM
Production 2 _Meter	1,224.6 kW	16.9%	7/22/2009 1:30:00 PM
Shipping/Receiving _Meter	3,222.4 kW	44.4%	7/22/2009 1:30:00 PM
Total	7,252.3 kW	100.0%	

Worst Case Peak Demand Analysis

Boiler House _Meter	732.0 kW	9.8%	7/29/2009 10:15:00 AM
Power House _Meter	388.2 kW	5.2%	7/15/2009 10:30:00 AM
Production 1 _Meter	1,851.8 kW	24.8%	7/1/2009 3:45:00 PM
Production 2 _Meter	1,250.4 kW	16.8%	7/8/2009 11:45:00 AM
Shipping/Receiving _Meter	3,236.0 kW	43.4%	7/7/2009 4:00:00 PM
Total	7,458.3 kW	100.0%	

Shadow Billing

Shadow billing generates a replication of a monthly bill from your energy provider for comparative billing analysis and potential energy cost recovery.

Cost Allocation

Cost allocation monitoring lets you allocate energy costs based on actual usage that is based on production area submetering rather than other measurements such as square footage allocation. Effective cost allocation helps drive energy accountabilities to the user.

Electric Billing Report

8/1/2009 12:00 AM to 9/1/2009 12:00 AM

Time Zone: (GMT-06:00) Central Time (US & Canada)

Rate Schedule: WE General Primary Service TOU Cp1

Total Charge: \$175,405.72

Fixed Charges

Description	Quantity	Rate	Charge
Facilities Charge	1.0	525	\$525.00
Subtotal:			\$525.00

Demand Charges

Description	Quantity	Rate	Charge
Demand, On-peak	7,400.7 kW	8.72	\$64,533.81
Demand, Customer Maximum	7,815.1 kW	0.76	\$5,939.46
Subtotal:			\$70,473.27

Energy Charges

Description	Quantity	Rate	Charge
Energy, On-peak	1,585,749.1 kWh	0.03459	\$54,851.06
Energy, Off-peak	1,877,882.2 kWh	0.02152	\$40,412.02
Subtotal:			\$95,263.08

Taxes and Fees

Description	Quantity	Rate	Charge
Sales Tax	168,261.4	0.055	\$9,144.37
Subtotal:			\$9,144.37

	A	B	C	D	E	F
1	Report name:	Electric Cost Allocation Report				
2	Starting date/time:	8/1/2009 0:00				
3	Ending date/time:	9/1/2009 0:00				
4	Time zone:	(GMT-06:00) Central Time (US & Canada)				
5	Rate schedule:	Electric Cost Allocation				
6	Total charge:	\$89,204.20				
7						
8		Real Energy Charge (kWh)		Subtotals		
9	Data Center	\$11,947.60		\$11,947.60		
10	Production 1	\$26,717.20		\$26,717.20		
11	Production 2	\$17,784.00		\$17,784.00		
12	Shipping/Receiving	\$32,755.40		\$32,755.40		
13						
14	Subtotals	\$89,204.20		\$89,204.20		
15						


Power Quality

Power quality monitoring lets you capture power quality events or conditions that could cause a production shutdown like voltage sags, swells, and brownouts.

Electric Main Power Quality Report

9/1/2009 12:00 AM to 10/1/2009 12:00 AM

Time Zone: (GMT-06:00) Central Time (US & Canada)



Notes:

System Configuration and Wiring

Introduction

In this chapter, you will do the following:

- List energy data points based on your business goals and energy monitoring plan.
- Identify your existing energy meters and distribution systems.
- Select data collection hardware and create a meter layout.
- Create panel layouts and wiring for your data collection hardware.
- Select required software.

To help you with system configuration, an industrial plant example, named Efficient Industries Plant 1, is referenced in this and subsequent chapters.

Before You Begin

Complete an energy assessment and review monitoring methods in [Chapter 1](#).

What You Need


- Personal computer with internet access for downloading software and files
- AutoCAD program to open the .dwg files or Adobe Acrobat Reader software to open.pdf files

TIP Use AutoCAD Electrical to take advantage of advanced features.

- Energy Management Accelerator Toolkit CD, publication IASIMP-SP014, or visit the Integrated Architecture Tools and Resources website at <http://www.ab.com/go/iatools> to download toolkit files
- Power and Energy Management section of the Industrial Controls catalog, available at <http://www.ab.com/catalogs/>
- Microsoft Excel software

Follow These Steps

Follow this path to layout your energy panel and wiring, and select monitoring software.



List Energy Data Points

You will now review your business goals and energy monitoring plan, then enter your data points in the Energy Data Worksheet.

Review Business Goals and Energy Monitoring Plan

1. Review the business goals that you created in Chapter 1.

The Efficient Industries Plant 1 example, referenced throughout this quick start, is a mid-sized plant with two production areas. These are the business goals of the example plant:

- Reduce electrical energy demand charges
- Improve electrical energy efficiency through power quality monitoring
- Reduce fuels and steam energy usage by running boilers in accordance with production demand schedules
- Reduce air compressor energy use
- Provide energy cost allocation to production areas, shipping and receiving, and the data center

2. Review your monitoring plan based on the initial energy assessment findings.


These are the monitoring goals of the Efficient Industries Plant 1 example:

- Monitor electrical main power quality
- Track electrical consumption of production 1, production 2, shipping/receiving, boiler house, and data center
- Monitor gas main, boiler house gas, fuel oil, and propane fuel usage
- Monitor steam, air, and water flow

Enter Energy Data Points in Energy Data Worksheet

Enter your energy data points in the Energy Data Worksheet. The procedure demonstrates how to enter data points using the Efficient Industries Plant 1 example.

1. Browse to the System Layout and Wiring folder on the Energy Management Accelerator Toolkit CD image.



2. Right-click Energy Data Worksheet and open the file.

When opening the spreadsheet, select Enable Macros.

Name	Size	Type	Date Modified
CompactLogix		File Folder	11/5/2009 10:04 AM
PM1000		File Folder	11/5/2009 10:04 AM
PM3000		File Folder	11/5/2009 10:04 AM
Energy Data Worksheet	53 KB	Microsoft Excel Wor...	11/3/2009 7:55 AM

3. Click the Energy Point tab in the worksheet and enter an energy type and name for the first energy data point in your system.

- a. Select a cell in the Energy Type column and click the pull-down list icon.

- b. Choose an Energy Type.

For the Efficient Energy Plant 1 example, choose Electricity.

Microsoft Excel - Energy Data Worksheet

Energy Point Listing		
Energy Type	Energy Data Point Name	
Electricity		
Natural Gas		
Fuel Oil		
Propane		
Steam		
Air		
Water		

- c. Select a cell in the Name column and enter a name for the energy data point.

For the Efficient Energy Plant 1 example, Electric Main is entered as the first Electricity data point.

Energy Point Listing	
Energy Type	Energy Data Point Name
Electricity	Electric Main

4. Repeat step 3 for each data point with the same energy type selected in step 2.

For the Efficient Energy Plant 1 example, the Electricity energy point listing should look like this.

Energy Point Listing	
Energy Type	Energy Data Point Name
Electricity	Electric Main
Electricity	Boiler House
Electricity	Power House
Electricity	Production 1
Electricity	Production 2
Electricity	Shipping/Receiving/DC
Electricity	Data Center

5. Repeat steps 3 and 4 for the remaining energy types in your system.

For the Efficient Energy Plant 1 example, the completed energy point listing should look like this.


Energy Point Listing	
Energy Type	Energy Data Point Name
Electricity	Electric Main
Electricity	Boiler House
Electricity	Power House
Electricity	Production 1
Electricity	Production 2
Electricity	Shipping/Receiving/DC
Electricity	Data Center
Natural Gas	Gas Main
Natural Gas	Boiler House Gas
Fuel Oil	Fuel Oil
Propane	Propane
Steam	Steam Flow
Air	Air Flow
Water	Water Main

Identify Existing Energy Distribution Layouts and Metering

Follow these steps to help identify your existing energy distribution and metering systems.


1. Gather existing electrical distribution single line drawings and label electricity data point substations and distribution points.

Efficient Industries Plant 1 Example - Electrical Single Line Drawing Example




2. Gather or create the electrical distribution plant layout.

Efficient Industries Plant 1 Example- Electrical Distribution Layout



3. Gather or create other energy distribution plant layouts.

Efficient Industries Plant 1 Example - Other Energy Distribution Plant Layouts



Create Metering Layout and Name Data Collection Hardware

In this section, you will create a metering layout, then select and name your data collection hardware using the Energy Data Worksheet. The information entered in the worksheet will be used later in the FactoryTalk EnergyMetrix software configuration chapters.


Create a Metering Layout and Select Data Collection Device Classes

Follow these steps to create a metering layout of your energy data collection devices.


1. Add PowerMonitors to your Electrical Distribution Layout drawing based on the electricity energy data points listed in the Energy Data Worksheet.

For the Efficient Industries Plant 1 example, these devices are added to the drawing:

- One PowerMonitor 3000 for the Electric Main to monitor power quality
- Five PowerMonitor 1000 devices to monitor electric consumption and demand for various plant departments, as listed in the Energy Data Worksheet



2. Browse to the System Layout and Wiring folder on your Energy Management Accelerator Toolkit CD image and open the Energy Data Worksheet.



3. Click the FactoryTalk EnergyMetrix tab and select a Device Class for each PowerMonitor added to the layout.

The device classes will be used in later chapters when configuring devices in FactoryTalk EnergyMetrix software and also determine the energy meter tag names.

- a. Select a cell in the Device Class column and click the pull-down list icon.
- b. Choose the appropriate PowerMonitor device class for each data point based on the Device Class Selection table.

Energy Type	Energy Data Point Name	Group Name	Device Class	Device Cat. No.
Electricity	Electric Main			
Electricity	Boiler House			
Electricity	Power House			
Electricity	Production 1			
Electricity	Production 2			
Electricity	Shipping/Receiving/DC			
Electricity	Data Center			

Device Class Selection

Device Class	Energy Data Point Metering Requirements
PowerMonitor 1000 on EtherNet/IP	Select this device class for: <ul style="list-style-type: none"> electricity data points requiring only consumption and demand monitoring. other energy data points in close proximity to a PowerMonitor 1000 device that can provide a digital contact output, for example, an existing utility meter with a pulse contact output. A maximum of two energy status inputs are provided on the PowerMonitor 1000 device.
PowerMonitor 3000 on EtherNet/IP	Select this device class for: <ul style="list-style-type: none"> electricity data points requiring consumption, demand, and power quality monitoring. other energy data points in close proximity to a PowerMonitor 3000 device that can provide a digital contact output, for example, an existing utility meter with a pulse contact output. A maximum of two energy status inputs are provided on the PowerMonitor 3000 device.
PowerMonitor W250	Select this device class for: electricity data points requiring consumption monitoring in a wireless communication network
PowerMonitor 500 on Serial	Select this device class for: electricity data points requiring consumption monitoring
PowerMonitor 500 on EtherNet/IP	Select this device class for: <ul style="list-style-type: none"> electricity data points requiring consumption monitoring can also be used for demand monitoring
PowerMonitor 5000 on Ethernet/IP	Select this device class for: <ul style="list-style-type: none"> electricity data points requiring consumption, demand, and power quality monitoring. other energy data points in close proximity to a PowerMonitor 5000 device that can provide a digital contact output, for example, an existing utility meter with a pulse contact output. A maximum of four energy status inputs are provided on the PowerMonitor 5000 device.

For the Efficient Industries Plant 1 example, the electricity energy data point listing would look like this.

Energy Type	Energy Data Point Name	Group Name	Device Class	Device Cat. No.	Device Name	Meter Name
Electricity	Electric Main		Powermonitor 3000 on EtherNet/IP			Electric Main Meter
Electricity	Boiler House		Powermonitor 1000 on EtherNet/IP			Boiler House Meter
Electricity	Power House		Powermonitor 1000 on EtherNet/IP			Power House Meter
Electricity	Production 1		Powermonitor 1000 on EtherNet/IP			Production 1 Meter
Electricity	Production 2		Powermonitor 1000 on EtherNet/IP			Production 2 Meter
Electricity	Shipping/Receiving/DC		Powermonitor 1000 on EtherNet/IP			Shipping/Receiving/DC Meter

4. Identify other digital energy data points in close proximity that you can connect to the status inputs of the PowerMonitors.

For the Efficient Industries Plant 1 example, the air flow digital pulse meter is near the Production 2 electrical substation so it can connect to the PowerMonitor 1000 named Production 2.

5. Select a Device Class and Meter Type on the FactoryTalk EnergyMetrix tab of the Energy Data Worksheet for the PowerMonitor status inputs identified in step 4.
 - a. Select the appropriate PowerMonitor Device Class.
 - b. Select PM Status Input for the Meter Type.

For the Efficient Industries Plant 1 example, the entries for the air flow data point would look like this.


Energy Type	Energy Data Point Name	Group Name	Device Class	Device Cat. No.	Device Name	Meter Name	Meter Type
Electricity	Electric Main		Powermonitor 3000 on EtherNet/IP			Electric Main Meter	
Electricity	Boiler House		Powermonitor 1000 on EtherNet/IP			Boiler House Meter	
Electricity	Power House		Powermonitor 1000 on EtherNet/IP			Power House Meter	
Electricity	Production 1		Powermonitor 1000 on EtherNet/IP			Production 1 Meter	
Electricity	Production 2		Powermonitor 1000 on EtherNet/IP			Production 2 Meter	
Electricity	Shipping/Receiving/DC		Powermonitor 1000 on EtherNet/IP			Shipping/Receiving/DC Meter	
Electricity	Data Center					Data Center Meter	
Natural Gas	Gas Main					Gas Main Meter	
Natural Gas	Boiler House Gas					Boiler House Gas Meter	
Fuel Oil	Fuel Oil					Fuel Oil Meter	
Propane	Propane					Propane Meter	
Steam	Steam Flow					Steam Flow Meter	
Air	Air Flow		Powermonitor 1000 on EtherNet/IP			Air Flow Meter	PM Status Input
Water	Water Main					Water Main Meter	



6. Identify other small groups (<3) of digital energy points in close proximity that can be collected by the digital status inputs of the PowerMonitor 1000 device.

This is a lower cost alternative to a CompactLogix™ controller with a few digital inputs.

For the Efficient Industries Plant 1 example, the gas main and water main digital meters are somewhat isolated in the corner of the production area near MCC 2. A PowerMonitor 1000 named MCC 2 is added to capture these two digital meter inputs.



7. Select a Device Class and Meter Type on the FactoryTalk EnergyMetrix tab of the Energy Data Worksheet for the PowerMonitor status inputs identified in step 6.
- a. Select a PowerMonitor 1000 Device Class.
 - b. Select PM Status Input for the Meter Type.


For the Efficient Industries Plant 1 example, the entries for the gas main and water main data points would look like this.

Energy Type	Energy Data Point Name	Group Name	Device Class	Device Cat. No.	Device Name	Meter Name	Meter Type
Electricity	Electric Main		Powermonitor 3000 on EtherNet/IP			Electric Main Meter	
Electricity	Boiler House		Powermonitor 1000 on EtherNet/IP			Boiler House Meter	
Electricity	Power House		Powermonitor 1000 on EtherNet/IP			Power House Meter	
Electricity	Production 1		Powermonitor 1000 on EtherNet/IP			Production 1 Meter	
Electricity	Production 2		Powermonitor 1000 on EtherNet/IP			Production 2 Meter	
Electricity	Shipping/Receiving/DC		Powermonitor 1000 on EtherNet/IP			Shipping/Receiving/DC Meter	
Electricity	Data Center					Data Center Meter	
Natural Gas	Gas Main		Powermonitor 1000 on EtherNet/IP			Gas Main Meter	
Natural Gas	Boiler House Gas					Boiler House Gas Meter	PM Status Input
Fuel Oil	Fuel Oil					Fuel Oil Meter	
Propane	Propane					Propane Meter	
Steam	Steam Flow					Steam Flow Meter	
Air	Air Flow		Powermonitor 1000 on EtherNet/IP			Air Flow Meter	
Water	Water Main		Powermonitor 1000 on EtherNet/IP			Water Main Meter	PM Status Input

8. Identify other larger groups of digital and analog energy data points in close proximity that can connect to an L23 CompactLogix controller data collection device.

The L23 CompactLogix controller can collect up to 16 digital inputs and 4 analog inputs.

For the Efficient Industries Plant 1 example, the remaining digital and analog energy data points are in the Boiler House so a CompactLogix controller is added to the metering layout.




- 9. Select a Device Class and Meter Type on the FactoryTalk EnergyMetrix tab of the Energy Data Worksheet for the digital and analog energy inputs identified in step 8.
 - a. Select ControlLogix® on Ethernet for the Device Class.
 - b. Select L2x Input for the Meter Type.

For the Efficient Industries Plant 1 example, the entries for the CompactLogix digital and analog energy data points would look like this.

Energy Type	Energy Data Point Name	Group Name	Device Class	Device Cat. No.	Device Name	Meter Name	Meter Type
Electricity	Electric Main		Powermonitor 3000 on EtherNet/IP			Electric Main Meter	
Electricity	Boiler House		Powermonitor 1000 on EtherNet/IP			Boiler House Meter	
Electricity	Power House		Powermonitor 1000 on EtherNet/IP			Power House Meter	
Electricity	Production 1		Powermonitor 1000 on EtherNet/IP			Production 1 Meter	
Electricity	Production 2		Powermonitor 1000 on EtherNet/IP			Production 2 Meter	
Electricity	Shipping/Receiving/DC		Powermonitor 1000 on EtherNet/IP			Shipping/Receiving/DC Meter	
Electricity	Data Center					Data Center Meter	
Natural Gas	Gas Main		Powermonitor 1000 on EtherNet/IP			Gas Main Meter	PM Status Input
Natural Gas	Boiler House Gas		ControlLogix on Ethernet			Boiler House Gas Meter	
Fuel Oil	Fuel Oil		ControlLogix on Ethernet			Fuel Oil Meter	L2x Input
Propane	Propane		ControlLogix on Ethernet			Propane Meter	L2x Input
Steam	Steam Flow		ControlLogix on Ethernet			Steam Flow Meter	L2x Input
Air	Air Flow		Powermonitor 1000 on EtherNet/IP			Air Flow Meter	PM Status Input
Water	Water Main		Powermonitor 1000 on EtherNet/IP			Water Main Meter	PM Status Input

- 10. Identify and list any energy data points to be collected from an OPC server.

For the Efficient Industries Plant 1 example, Data Center energy consumption will be collected by an OPC server in the office area. The personal computer for the FactoryTalk EnergyMetrix server is also in this location. All energy data collection devices and the FactoryTalk EnergyMetrix server are connected to an EtherNet/IP network.



11. Select a Device Class and Meter Type on the FactoryTalk EnergyMetric tab of the Energy Data Worksheet for the OPC server data point identified in step 10.
- a. Select OPC Server on Ethernet for the Device Class.
 - b. Select OPC for the Meter Type.


For the Efficient Industries Plant 1 example, the entry for the OPC server data point would look like this.

Energy Type	Energy Data Point Name	Group Name	Device Class	Device Cat. No.	Device Name	Meter Name	Meter Type
Electricity	Electric Main		Powermonitor 3000 on EtherNet/IP			Electric Main Meter	
Electricity	Boiler House		Powermonitor 1000 on EtherNet/IP			Boiler House Meter	
Electricity	Power House		Powermonitor 1000 on EtherNet/IP			Power House Meter	
Electricity	Production 1		Powermonitor 1000 on EtherNet/IP			Production 1 Meter	
Electricity	Production 2		Powermonitor 1000 on EtherNet/IP			Production 2 Meter	
Electricity	Shipping/Receiving/DC		Powermonitor 1000 on EtherNet/IP			Shipping/Receiving/DC Meter	
Electricity	Data Center		OPC Server on Ethernet			Data Center Meter	OPC
Natural Gas	Gas Main		Powermonitor 1000 on EtherNet/IP			Gas Main Meter	PM Status Input
Natural Gas	Boiler House Gas		ControlLogix on Ethernet			Boiler House Gas Meter	
Fuel Oil	Fuel Oil		ControlLogix on Ethernet			Fuel Oil Meter	L2x Input
Propane	Propane		ControlLogix on Ethernet			Propane Meter	L2x Input
Steam	Steam Flow		ControlLogix on Ethernet			Steam Flow Meter	L2x Input
Air	Air Flow		Powermonitor 1000 on EtherNet/IP			Air Flow Meter	
Water	Water Main		Powermonitor 1000 on EtherNet/IP			Water Main Meter	PM Status Input

Select Data Collection Hardware

Follow these steps to select your data collection hardware.

1. Browse to the System Layout and Wiring folder on the Energy Management Accelerator Toolkit CD image and open the Energy Data Worksheet.
2. Click the FactoryTalk EnergyMetrix tab then choose or enter energy device catalog numbers.
 - a. Select a cell in the Cat. No. column and click the pull-down list icon.
 - b. Choose the appropriate Cat. No. for each data point based on the PowerMonitor and CompactLogix Device Selection table.



To use a nonstandard energy device, select the blank at the bottom of the list and enter the catalog number.

Device	Cat. No.	Description	Communication
PowerMonitor 1000 on Ethernet	1408-EM1A-ENT	Provides kWh data, energy log, and status log only.	Ethernet
	1408-EM2A-ENT	Provides kWh, kVARh, kVAHh data, demand and projected demand values plus energy min/max, load factor, and status log.	
	1408-EM3A-ENT ⁽²⁾	Provides same parameters as catalog number 1408-EM2A-ENT plus separate voltage, current, frequency, and power factor parameters.	
PowerMonitor 3000 on Ethernet	1404-M505x-ENT ⁽³⁾	Provides full consumption and demand value parameters, ten configurable setpoints, %THD, and K-factor harmonic analysis.	Ethernet
	1404-M605x-ENT ⁽²⁾⁽³⁾	Provides same parameters as catalog number 1404-M505x-ENT plus waveform capture capability, and 41st order harmonic analysis.	
	1404-M805x-ENT ⁽³⁾	Provides same parameters as catalog number 1404-M605x-ENT plus transient detection and capture, and 63rd order harmonic analysis.	
PowerMonitor W250	1425-D1002-MOD	PowerMonitor Wireless, 100A, 300V Delta	Serial or Ethernet (using a serial to Ethernet gateway).
	1425-D1002-MOD-480	PowerMonitor Wireless, 100A, 480V Delta	
	1425-W1003-MOD	PowerMonitor Wireless, 100A, 300V Wye	
	1425-D2002-MOD	PowerMonitor Wireless, 200A, 300V Delta	
	1425-W2003-MOD	PowerMonitor Wireless, 200A, 300V Wye	
	1425-D5002-MOD	PowerMonitor Wireless, 500A, 300V Delta	
	1425-D5002-MOD-480	PowerMonitor Wireless, 500A, 480V Delta	
	1425-W5003-MOD	PowerMonitor Wireless, 500A, 300V Wye	
	1425-D10002-MOD	PowerMonitor Wireless, 1000A, 300V Delta	
	1425-W10003-MOD	PowerMonitor Wireless, 1000A, 300V Wye	
	1425-D20002-MOD	PowerMonitor Wireless, 2000A, 300V Delta	
	1425-D20002-MOD-480	PowerMonitor Wireless, 2000A, 480V Delta	
	1425-W20003-MOD	PowerMonitor Wireless, 2000A, 300V Wye	

Device	Cat. No.	Description	Communication
PowerMonitor 500 ⁽¹⁾	1420-Vy	Power Meter Indicator	No Comm
	1420-VyP	Power Meter - Pulse (digital) Output	
	1420-VyA	Power Meter - Analog Output	
	1420-Vy-ENT	EtherNet/IP Power Meter	Ethernet
	1420-VyP-ENT	EtherNet/IP Power Meter - Pulse (digital) Output	
	1420-VyA-ENT	EtherNet/IP Power Meter - Analog Output	
	1420-Vy-485	Serial Power Meter	Serial
	1420-VyP-485	Serial Power Meter - Pulse (digital) Output	
	1420-VyA-485	Serial Power Meter - Analog Output	
PowerMonitor 5000	1426-M5E	Power Quality Meter	Ethernet
	1426-M5E-ENT	Power Quality Meter with 2nd Ethernet Port	
	1426-M5E-CNT	Power Quality Meter with ControlNet Port	
	1426-M5E-DNET	Power Quality Meter with DeviceNet Port	
CompactLogix L23 Controllers	1769-L23E-QB1B	Provides 16 DC inputs/16 DC outputs	Ethernet
	1769-L23E-QBFC1B	Provides 16 DC inputs/16 DC outputs plus: 4 analog inputs 2 analog outputs 4 high speed counters	

(1) The y in the catalog number designates device voltage, where 1 = 240V ACV-LL/120V ACV-LN/208V ACV-LL and 2 = 400V ACV-LN and 690V ACV-LL.

(2) Preferred devices for use with this toolkit.

(3) The x in the catalog number designates device power, where A=120/240 VAC and B= 24 VDC.

For the Efficient Industries Plant 1 example, the catalog numbers for the data collection devices would look like this.

Energy Type	Energy Data Point Name	Group Name	Device Class	Device Cat. No.	Device Name	Meter Name	Meter Type
Electricity	Electric Main		Powermonitor 3000 on EtherNet/IP	1404-M605x-ENT		Electric Main Meter	
Electricity	Boiler House		Powermonitor 1000 on EtherNet/IP	1408-EM3A-ENT		Boiler House Meter	
Electricity	Power House		Powermonitor 1000 on EtherNet/IP	1408-EM3A-ENT		Power House Meter	
Electricity	Production 1		Powermonitor 1000 on EtherNet/IP	1408-EM3A-ENT		Production 1 Meter	
Electricity	Production 2		Powermonitor 1000 on EtherNet/IP	1408-EM3A-ENT		Production 2 Meter	
Electricity	Shipping/Receiving/DC		Powermonitor 1000 on EtherNet/IP	1408-EM3A-ENT		Shipping/Receiving/DC Meter	
Electricity	Data Center		OPC Server on Ethernet			Data Center Meter	OPC
Natural Gas	Gas Main		Powermonitor 1000 on EtherNet/IP	1408-EM2A-ENT		Gas Main Meter	PM Status Input
Natural Gas	Boiler House Gas		ControlLogix on Ethernet	1769-L23E-QBFC1B		Boiler House Gas Meter	L2x Input
Fuel Oil	Fuel Oil		ControlLogix on Ethernet	1769-L23E-QBFC1B		Fuel Oil Meter	L2x Input
Propane	Propane		ControlLogix on Ethernet	1769-L23E-QBFC1B		Propane Meter	L2x Input
Steam	Steam Flow		ControlLogix on Ethernet	1769-L23E-QBFC1B		Steam Flow Meter	L2x Input
Air	Air Flow		Powermonitor 1000 on EtherNet/IP	1408-EM3A-ENT		Air Flow Meter	PM Status Input
Water	Water Main		Powermonitor 1000 on EtherNet/IP	1408-EM2A-ENT		Water Main Meter	PM Status Input

Name Data Collection Hardware

Follow these steps to create or select device names, meter types, and meter tag names for each energy data point. These names will be used later in the FactoryTalk EnergyMetrix software configuration chapters.

1. Click the FactoryTalk EnergyMetrix tab on the Energy Data Worksheet.
2. Enter a device name for each energy data point.

TIP It is recommended that you name the device with the same name as the energy data point when possible. If a device collects multiple energy data points, use a name related to the most significant data point or unique location.

For the Efficient Industries Plant 1 example, the device names for the first six PowerMonitor devices and the data center are the same as the energy data point names.

Energy Type	Energy Data Point Name	Group Name	Device Class	Device Cat. No.	Device Name	Meter Name	Meter Type
Electricity	Electric Main		Powermonitor 3000 on EtherNet/IP	1404-M605x-ENT	Electric Main	Electric Main Meter	
Electricity	Boiler House		Powermonitor 1000 on EtherNet/IP	1408-EM3A-ENT	Boiler House	Boiler House Meter	
Electricity	Power House		Powermonitor 1000 on EtherNet/IP	1408-EM3A-ENT	Power House	Power House Meter	
Electricity	Production 1		Powermonitor 1000 on EtherNet/IP	1408-EM3A-ENT	Production 1	Production 1 Meter	
Electricity	Production 2		Powermonitor 1000 on EtherNet/IP	1408-EM3A-ENT	Production 2	Production 2 Meter	
Electricity	Shipping/Receiving/DC		Powermonitor 1000 on EtherNet/IP	1408-EM3A-ENT	Shipping/Receiving/DC	Shipping/Receiving/DC Meter	
Electricity	Data Center		OPC Server on Ethernet		Data Center	Data Center Meter	OPC
Natural Gas	Gas Main		Powermonitor 1000 on EtherNet/IP	1408-EM2A-ENT		Gas Main Meter	PM Status Input
Natural Gas	Boiler House Gas		ControlLogix on Ethernet	1769-L23E-QBFC1B		Boiler House Gas Meter	L2x Input
Fuel Oil	Fuel Oil		ControlLogix on Ethernet	1769-L23E-QBFC1B		Fuel Oil Meter	L2x Input
Propane	Propane		ControlLogix on Ethernet	1769-L23E-QBFC1B		Propane Meter	L2x Input
Steam	Steam Flow		ControlLogix on Ethernet	1769-L23E-QBFC1B		Steam Flow Meter	L2x Input
Air	Air Flow		Powermonitor 1000 on EtherNet/IP	1408-EM3A-ENT		Air Flow Meter	PM Status Input
Water	Water Main		Powermonitor 1000 on EtherNet/IP	1408-EM2A-ENT		Water Main Meter	PM Status Input

For the Efficient Industries Plant 1 example, the PowerMonitor 1000 device named MCC 2 collects two energy data points, the Gas Main and the Water Main. The CompactLogix device collecting one digital and three analog inputs is named L2x.

Energy Type	Energy Data Point Name	Group Name	Device Class	Device Cat. No.	Device Name	Meter Name	Meter Type
Electricity	Electric Main		Powermonitor 3000 on EtherNet/IP	1404-M605x-ENT	Electric Main	Electric Main Meter	
Electricity	Boiler House		Powermonitor 1000 on EtherNet/IP	1408-EM3A-ENT	Boiler House	Boiler House Meter	
Electricity	Power House		Powermonitor 1000 on EtherNet/IP	1408-EM3A-ENT	Power House	Power House Meter	
Electricity	Production 1		Powermonitor 1000 on EtherNet/IP	1408-EM3A-ENT	Production 1	Production 1 Meter	
Electricity	Production 2		Powermonitor 1000 on EtherNet/IP	1408-EM3A-ENT	Production 2	Production 2 Meter	
Electricity	Shipping/Receiving/DC		Powermonitor 1000 on EtherNet/IP	1408-EM3A-ENT	Shipping/Receiving/DC	Shipping/Receiving/DC Meter	
Electricity	Data Center		OPC Server on Ethernet		Data Center	Data Center Meter	OPC
Natural Gas	Gas Main		Powermonitor 1000 on EtherNet/IP	1408-EM2A-ENT	MCC 2	Gas Main Meter	PM Status Input
Natural Gas	Boiler House Gas		ControlLogix on Ethernet	1769-L23E-QBFC1B	L2x	Boiler House Gas Meter	L2x Input
Fuel Oil	Fuel Oil		ControlLogix on Ethernet	1769-L23E-QBFC1B	L2x	Fuel Oil Meter	L2x Input
Propane	Propane		ControlLogix on Ethernet	1769-L23E-QBFC1B	L2x	Propane Meter	L2x Input
Steam	Steam Flow		ControlLogix on Ethernet	1769-L23E-QBFC1B	L2x	Steam Flow Meter	L2x Input
Air	Air Flow		Powermonitor 1000 on EtherNet/IP	1408-EM3A-ENT	Production 2	Air Flow Meter	PM Status Input
Water	Water Main		Powermonitor 1000 on EtherNet/IP	1408-EM2A-ENT	MCC 2	Water Main Meter	PM Status Input

3. Review meter names.

The meter names are autopopulated in the worksheet based on energy data point names.

4. Choose Electric as the Meter Type for all the PowerMonitor devices.

5. Select or enter meter tag names for each data point based on the Energy Type and Meter Type shown in the table.

Energy Type	Meter Type	Meter Tag Names
Electricity	Electric	Real Energy Net Reactive Energy Net Reactive Power Demand
	PM Status Input	Real Energy Net ⁽¹⁾
	L2x Input	
	OPC	
Natural Gas	PM Status Input	Natural Gas Usage ⁽¹⁾
	L2x Input	
	OPC	
Fuel Oil	PM Status Input	Fuel Oil Usage ⁽¹⁾
	L2x Input	
	OPC	
Propane	PM Status Input	Propane Usage ⁽¹⁾
	L2x Input	
	OPC	
Steam	PM Status Input	Propane Usage ⁽¹⁾
	L2x Input	
	OPC	
Air	PM Status Input	Air Usage ⁽¹⁾
	L2x Input	
	OPC	
Water	PM Status Input	Water Usage ⁽¹⁾
	L2x Input	
	OPC	

(1) If there is only one energy data point of a particular energy type then select the meter tag name listed in the table. If there is more than one energy data point with the same energy type then select a blank meter name and type [EnergyDataPointName] [EnergyType] Usage, for example, Boiler House Natural Gas Usage.

For the Efficient Industries Plant 1 example, the meter type and meter tag name listing would look like this.

Energy Type	Energy Data Point Name	Group Name	Device Class	Device Cat. No.	Device Name	Meter Name	Meter Type	Meter Tag Name
Electricity	Electric Main		Powermonitor 3000 on EtherNet/IP	1404-M605x-ENT	Electric Main	Electric Main Meter	Electrnc	Real Energy Net Reactive Energy Net Reactive Power
Electricity	Boiler House		Powermonitor 1000 on EtherNet/IP	1408-EM3A-ENT	Boiler House	Boiler House Meter	Electric	Real Energy Net Reactive Energy Net Reactive Power
Electricity	Power House		Powermonitor 1000 on EtherNet/IP	1408-EM3A-ENT	Power House	Power House Meter	Electric	Real Energy Net Reactive Energy Net Reactive Power
Electricity	Production 1		Powermonitor 1000 on EtherNet/IP	1408-EM3A-ENT	Production 1	Production 1 Meter	Electric	Real Energy Net Reactive Energy Net Reactive Power
Electricity	Production 2		Powermonitor 1000 on EtherNet/IP	1408-EM3A-ENT	Production 2	Production 2 Meter	Electric	Real Energy Net Reactive Energy Net Reactive Power
Electricity	Shipping/Receiving/DC		Powermonitor 1000 on EtherNet/IP	1408-EM3A-ENT	Shipping/Receiving/D C	Shipping/Receiving/DC Meter	Electric	Real Energy Net Reactive Energy Net Reactive Power
Electricity	Data Center		OPC Server on Ethernet		Data Center	Data Center Meter	OPC	Real Energy Net
Natural Gas	Gas Main		Powermonitor 1000 on EtherNet/IP	1408-EM2A-ENT	MCC 2	Gas Main Meter	PM Status Input	Natural Gas Usage
Natural Gas	Boiler House Gas		ControlLogix on Ethernet	1769-L23E-QBFC1B	L2x	Boiler House Gas Meter	L2x Input	Boiler House Natural Gas Usage
Fuel Oil	Fuel Oil		ControlLogix on Ethernet	1769-L23E-QBFC1B	L2x	Fuel Oil Meter	L2x Input	Fuel Oil Usage
Propane	Propane		ControlLogix on Ethernet	1769-L23E-QBFC1B	L2x	Propane Meter	L2x Input	Propane Usage
Steam	Steam Flow		ControlLogix on Ethernet	1769-L23E-QBFC1B	L2x	Steam Flow Meter	L2x Input	Steam Usage
Air	Air Flow		Powermonitor 1000 on EtherNet/IP	1408-EM3A-ENT	Production 2	Air Flow Meter	PM Status Input	Air Usage
Water	Water Main		Powermonitor 1000 on EtherNet/IP	1408-EM2A-ENT	MCC 2	Water Main Meter	PM Status Input	Water Usage

Assign CompactLogix Input Addresses

Follow these steps to assign CompactLogix hardware input addresses and corresponding PLC-5[®] mapped tags to the energy data points.

1. Click the CompactLogix tab on the Energy Data Worksheet.
2. Enter an L2x address for each energy data point that is connected to a CompactLogix controller.
 - a. Select a cell in the L2x column and click the pull-down list icon.
 - b. Choose the L2x digital hardware address to which the energy data point is wired.

Digital Input addresses are Local:1:I.Data.0 through Local:1:I.Data.15.

Analog Input addresses are Local:3:I.CH0 through Local:3:I.CH3.

Group Name	Device Name	Meter Name	Meter Type	Meter Tag Name	AOI Name	L2x Input Address
	L2x	Boiler House Gas	L2x Input	Boiler House Natural Gas Usage	Boiler_House_Gas	
	L2x	Fuel Oil Meter	L2x Input	Fuel Oil Usage	Fuel_Oil	Local:H.Data0
	L2x	Propane Meter	L2x Input	Propane Usage	Propane	Local:H.Data1
	L2x	Steam Flow Meter	L2x Input	Steam Usage	Steam_Flow	Local:H.Data2
						Local:H.Data3
						Local:H.Data4
						Local:H.Data5
						Local:H.Data6
						Local:H.Data7

- TIP** It is recommended that you assign consecutive PLC-5 addresses in a single file to simplify mapping. Refer to [page 86](#) for details on mapped PLC-5 addresses.

For the Efficient Industries Plant 1 example, the Compactlogix and PLC-5 address assignments would look similar to this.

Device Name	Meter Name	Meter Type	Meter Tag Name	AOI Name	L2x Input Address	L2x EnergyTotals Address	PLC 5 Address
L2x	Boiler House Gas	L2x Input	Boiler House Natural Gas Usage	Boiler_House_Gas	Local:1:1.Data0	L2x_EnergyTotals[0]	F10:0
L2x	Fuel Oil Meter	L2x Input	Fuel Oil Usage	Fuel_Oil	Local:3:1.Ch0Data	L2x_EnergyTotals[1]	F10:1
L2x	Propane Meter	L2x Input	Propane Usage	Propane	Local:3:1.Ch1Data	L2x_EnergyTotals[2]	F10:2
L2x	Steam Flow Meter	L2x Input	Steam Usage	Steam_Flow	Local:3:1.Ch2Data	L2x_EnergyTotals[3]	F10:3

Create Energy Panel Layout and Wiring Drawings


The toolkit provides energy data collector panel layout and wiring drawings in DWG, DXF, and PDF file formats to help you plan the layout of your energy system. The files are organized by device (CompactLogix, PM1000, PM3000, PMW250, PM500, and PM5000). The drawings include power and control wiring.

If you do not have CAD software, use the pdf files to build your system drawings.

Use CAD Drawings from Toolkit

Follow these steps to access the AutoCAD drawings for each device in your Energy Data Worksheet.

1. Browse to and open the System Layout and Wiring folder on the Energy Management Accelerator Toolkit CD image.
2. Navigate to the desired files based on your device and file format (DXF, DWG, or PDF).



3. Add the required files to your project or copy them to your project folder.


The drawings were created using AutoCAD Electrical. The project files are included in the DWG folder. The path references in the project file are the default AutoCAD Electrical installation path.

Panel Layout Drawings

The AutoCAD Electrical project includes several panel-layout drawings for the PowerMonitor 1000, PowerMonitor 3000, and CompactLogix data collector devices. Choose an appropriate drawing as a starting point. Add or remove components as needed.

This example shows an energy panel layout with a PowerMonitor 3000 device.

Sample PowerMonitor 3000 Layout



Sample Bill of Material


ITEM	QTY	DESCRIPTION	MFG	CATALOG
01	1	CONCEPT WALL-MOUNT ENCLOSURE	HOFFMAN	CSD20248
02	1	24" X 20" SUBPAN	HOFFMAN	CP2420
03	A/R	1X4 GRAY SLOT WIRE DUCT	PANDUIT	FIX4LG6
04	1	PANEL GROUND LUG #8AWG	ILSCO	TA-2
05	1	2 POLE FUSE BLOCK - CLASS CC	AB	1492-FB2C30-L
06	1	1 POLE FUSE BLOCK - CLASS CC	AB	1492-FB1C30-L
07	A/R	RAIL, DIN MTG, 25MM, 1M	AB	199-DR1
08	6	END ANCHOR	AB	1492-EAJ35
09	6	SCREW CONNECTION TERMINAL BLOCK; 1492-J	AB	1492-J4
10	1	END BARRIER; 1492-J	AB	1492-EBJ3
11	4	GROUP MARKER CARRIER	AB	1492-GM35
12	2	1AMP CIRCUIT BREAKER	AB	1492-SP1D010
13	1	PS, COMPACT, 30 W, 24-28V	AB	1606-XLP30E
14	1	INDUSTRIAL, COPPER TO FIBER MEDIA CONVERTER 10-/100-MBPS	BLACKBOX	LIC022A
16	1	POWER MONITOR 3000, 120V/240VAC 50/60HZ OR 125-250VDC	AB	1404-MB05A-ENT
17	1	POWERMONITOR 3000, DISPLAY MODULE, WITH 3 METER CABLE	AB	1404-DM
18	1	SHORTING BLOCK, 8 POSITION	FLEX-CORE	IKU8SC
19	1	GROUNDING BAR SYSTEM, 9 POS	SQUARE-D	PK9GTA
20	1	3 POLE FUSE BLOCK - CLASS CC	AB	1492-FB3C30-L

Wiring Drawings

The AutoCAD electrical project includes a variety of electrical power wiring configurations for PowerMonitor 1000 and PowerMonitor 3000 devices plus power and control wiring drawings for the CompactLogix L23E controller.

This drawing shows PowerMonitor 3000 device wiring for a 480V, 4-wire WYE direct system.

PowerMonitor 3000 Device Wiring



Access Other Allen-Bradley CAD Drawings

Follow these steps to download other Allen-Bradley® product CAD drawings.

1. Open your browser and go to <http://ab.com/e-tools>.

The Configuration and Selection Tools webpage opens.

Configuration & Selection Tools

- > Product Selection
 - Overview
 - + Get the Product Selection Toolbox
- System Configuration
- Product Drawings
- Integrated Architecture Tools
- + Get Support Now

Resources

- Product Directory
- Product Certification
- Product Cross Reference
- Literature Library

CONFIGURATION & SELECTION TOOLS

Rockwell Automation offers a powerful range of product selection and system configuration tools to assist you to choose and apply our products. There are tools available on-line and for you to install on your personal computer so that you can quickly access information on our products while in the office or on the go.

Product Selection | System Configuration | Product Drawings

- **Build/Validate A Catalog Number** – Build, Verify and Get Information and CAD Drawings for Products

To verify a catalog number, acquire drawings and product information enter the complete number (including dashes) below.

Catalog Number:

You can also browse our [product directory](#) for additional product information or to configure a part.

NOTE: You must be [logged in](#) to correctly view Canadian dollar results.

TIP If you know the complete catalog number of your Allen-Bradley product, you can enter it here and click Submit. However, you need a complete catalog number string to get the configuration results.

2. If you don't know the complete catalog number, click product directory to browse the configured Rockwell Automation products.
3. Click Rockwell Automation and follow the prompts.

Select and Configure Products

Rockwell Automation/Allen-Bradley Product Catalog

- [Rockwell Automation](#)
- [Services](#)
- [Encompass Partner Library](#)

Select Monitoring Software

Use these tables to select the FactoryTalk EnergyMetrix software appropriate for your application requirements. Every FactoryTalk EnergyMetrix system must include a Manager license of 8, 64, or 1000 meters.

License Options

FactoryTalk EnergyMetrix software is a scalable, modular software application. Its components and capabilities are determined by the licenses purchased and installed by the user. Licenses are installed by means of FactoryTalk Activation.

The table below shows the component type and, if applicable, the number of meters supported. There is no limit on the number of users. It is the customer's responsibility to observe the requirements of software licenses.

The Manager license is required for use of the software, and includes 10 meters which can be any combination of RSLinx software and 3rd-party OPC meters. Additional meter licenses can be purchased in 10-, 50, 100- and 500- meter sets. The FTEMOPC 3rd-party OPC option enables 3rd-party OPC connectivity to all licensed meters.

If you are upgrading from an existing installation of FactoryTalk EnergyMetrix software, your existing licenses are supported, including existing meter counts.

IMPORTANT FactoryTalk EnergyMetrix software only supports FactoryTalk Activation. If you plan to upgrade from an installation of FactoryTalk EnergyMetrix that uses EVRSI Master Disk activation, please contact Rockwell Automation customer service to convert to FT Activation.

Component Type	Maximum Meter Count
FTEM Manager, includes 10 RSLinx or OPC meters	10
FTEM10 10-meter option, RSLinx	10
FTEM50 50-meter option, RSLinx	50
FTEM100 100-meter option, RSLinx	100
FTEM500 500-meter option, RSLinx	500
FTEMOPC 3rd-party OPC client for all licensed meters	N/A
FTEMRT Real Time option	N/A
FTEMRPT ReportsPlus option	N/A
FTEMCHT ChartsPlus option	N/A
Microsoft SQL Server bundle - 1 client license option	N/A
Microsoft SQL Server bundle - processor license option	N/A

Contact your Rockwell Automation representative for information on the meter and option packages listed above.

Server Requirements

We recommend, but do not require, that you install FactoryTalk EnergyMetrix software on a dedicated server with a local installation of Microsoft SQL Server.

Server Software Requirements for Installing FactoryTalk EnergyMetrix Software

- Windows 2003 Server or Windows 2008 Server, Application Server role. For 64-bit operating systems, RSLinx Classic software version 2.57 CPR9 SR3 or later must be installed. Windows 2000 Server is not supported.
- Microsoft SQL Server 2005 or 2008, installed with mixed-mode authentication (Windows and SQL). TCP/IP access must be enabled. A system administrator SQL login must be used for the FactoryTalk EnergyMetrix installation.
- You must have machine administrator privileges to install FactoryTalk EnergyMetrix software.

Hardware Requirements

These are the hardware requirements that you need to use FactoryTalk EnergyMetrix software.

Definitions

The following rules of thumb are offered as a starting point for determining server sizing for FactoryTalk EnergyMetrix. Other factors will affect the required size of a server. A higher number of tags being logged, a faster log rate, a larger number of users, and a larger number of reports being run will require a more powerful server than the guidelines specify. These are the server guidelines:

- A low-end server has up to 8 meters and logs up to 40 meter tags at a minimum 15 minute log rate.
- A mid-range server has up to 64 meters and logs up to 320 meter tags at a minimum 15 minute log rate.
- A high-end server has more than 64 meters and logs more than 500 meter tags at a minimum 15 minute log rate.

Database Size Guidelines

FactoryTalk EnergyMetrix writes 16 bytes of data to the database for each meter tag logged. Over time, the database can grow to become quite large. Some examples include the following:

- A low-end server, logging 40 meter tags at 15 minute intervals, will grow the database at a rate of 2.56 KB per hour or 22 MB per year.
- A mid-level server, logging 320 meter tags at 15 minute intervals, will grow the database at a rate of 20.5 KB per hour, or 180 MB per year.
- A high-end server, logging 1000 meter tags at 15 minute intervals, will grow the database at a rate of 240 KB per hour, or 2.1 GB per year.

Consider these guidelines when determining hard disk requirements for a server as well as database maintenance schedules.

Recommendations

These are general guidelines. FactoryTalk EnergyMetrix software is capable of running on a variety of hardware platforms. The main scalability issue is related to processing of logged data (for example, report generation, trending). CPU speed, number of CPUs, RAM, and RAID 5 for the database files are the main scalability factors (in that order). All hardware platforms require the following:

- Processor, RAM and hard drive as noted below
- DVD drive
- One or more Ethernet network ports
- Internet access
- Monitor, keyboard, pointing device (mouse)
- Low-end Server
 - Single 2 GHz Pentium 4
 - 1...2 GB RAM
 - 80 GB hard disk
- Mid-range Server
 - 2 or 4 CPU 2 GHz Pentium 4 or better
 - 2...4 GB RAM
 - 160 GB hard disk (with separate disks for operating system and log files and RAID 5 for main database files preferred)
- High-end Server
 - High-end server requirements are very dependent upon the user's application requirements. Please contact Rockwell Automation for assistance in specifying hardware for a high-end server.

Client Requirements

The following are the client requirements for compatibility with FactoryTalk EnergyMetrix software:

- Microsoft Windows XP Professional, Vista Professional, Windows 7 (Windows 2000 is not supported) operating system.
- Internet Explorer 7, 8, or 9 web browser.
- Adobe Acrobat Reader 7.0 software or later is required to view reports.
- Microsoft .NET Framework 3.5 SP1 is required to use RT and Charts Plus options. .NET Framework 3.5 SP1 is included on the installation DVD or can be downloaded at no charge from Microsoft.

Your client workstation must also be permitted Intranet, Internet or dial-in access to the FactoryTalk EnergyMetrix server. Contact your IT support personnel for assistance.

TIP Your browser should be set to check for newer versions of stored pages automatically, not every visit to the page.

Energy Data Collector Configuration

Introduction

In this chapter, you configure data collector devices for your energy management application. This can include PowerMonitor W250, 500, 1000, 3000, or 5000 devices and CompactLogix controllers.

PowerMonitor devices typically gather electrical energy data through connections to electrical distribution systems. In addition, PowerMonitor devices can connect to digital pulse outputs from gas, water, and other types of energy meters.

The CompactLogix controller collects energy data from digital or analog outputs of meters and transmitters for a variety of energy sources such as water, air, gas, steam, electric, and fuel. The controller also provides an interface to HMI devices providing energy data and device status to the plant floor.

Before You Begin







- Determine business goals, complete energy assessment, and determine monitoring methods ([Chapter 1](#)).
- Select hardware and wire devices ([Chapter 2](#)).

What You Need

- Supporting hardware identified in the Energy Data Worksheet for your system, which includes:
 - PowerMonitor 1000 device
 - PowerMonitor 3000 master module and display module
 - PowerMonitor W250 device
 - PowerMonitor 500 device
 - PowerMonitor 5000 device
 - CompactLogix controller
- RSLogix 5000 software, version 17 or later or Studio 5000 Logix Designer application, version 21.00 or later
- Energy Management Accelerator Toolkit, publication IASIMP-SP014 or visit the Integrated Architecture Tools and Resources website at <http://www.ab.com/go/iatools>
- Product manuals:
 - Bulletin 1404 PowerMonitor 3000 Unit User Manual, publication [1404-UM001](#)
 - PowerMonitor 3000 Installation Instructions, publication [1404-IN007](#)
 - PowerMonitor 1000 Unit User Manual, publication [1408-UM001](#)
 - PowerMonitor 1000 Unit Installation Instructions, publication [1408-IN001](#)
 - PowerMonitor W250 Unit User Manual, publication [1425-UM001](#)
 - PowerMonitor 500 Unit User Manual, publication [1420-UM001](#)
 - PowerMonitor 5000 Unit User Manual, publication [1426-UM001](#)
 - Logix Common Procedures Programming Manual, publication [1756-PM001](#)

Follow These Steps

Follow these paths to configure the PowerMonitor devices and CompactLogix controllers in your energy system.




Configure a PowerMonitor 3000 Device

This section shows you how to configure PowerMonitor 3000 device settings by using the PowerMonitor 3000 display module. Certain settings are needed for the power monitor to meter accurately, communicate correctly, and work with FactoryTalk EnergyMetrix software properly. These settings include network configuration, wiring, PT and CT ratios, nominal system voltage, demand settings, and the date/time. Your application may require additional configuration.

TIP Network configuration is provided for the PowerMonitor 3000 on Ethernet device. For other communication options, refer to the PowerMonitor 3000 Unit User Manual, publication [1408-UM001](#).

The PowerMonitor 3000 display module has four keys on its front bezel that are used to navigate menus and select parameters within the module. The phase indicators, L1, L2, L3, N, show which phase, or phases, are being displayed. The phase indicators also indicate Program mode by flashing.



Navigation to Menu Items

Mode	Escape Key	Up Arrow Key	Down Arrow Key	Enter Key
Display	Returns to parent menu.	Steps back to the previous parameter/menu in the list.	Steps forward to the next parameter/menu in the list.	Steps into a submenu or sets as default screen.
Program	Returns to parent menu.	Steps back to the previous parameter/menu in the list.	Steps forward to the next parameter/menu in the list.	Steps into a submenu, selects the parameter to be modified, or changes to Edit mode.
Edit	Cancels changes to a parameter, restores the existing value, and returns to Program mode.	Increments the parameter/menu value.	Decrements the parameter value.	Saves the parameter change to the master module and returns to Program mode.

Configure the Ethernet IP Address

Follow these steps to configure the Ethernet IP address of the PowerMonitor 3000 module.

The default IP address is 192.168.254.xxx, where xxx is the unit's id.

TIP Before starting the procedure, make sure the PowerMonitor 3000 display module is connected to the PowerMonitor 3000 device and control power is on.

1. Press the Down Arrow key to select PROG mode.

2. Press the Enter key to access Edit mode.

You should see PASS.? and four flashing zeroes, 0000, on the display.

3. Press the Up and Down arrow keys to select the four-digit password and press the Enter key.

The default password is 0000.

TIP You can press and hold the Up Arrow or Down Arrow key for a few seconds to increase the rate the value increments or decrements.

4. Press the Down arrow key to select CONFIGURATION, then press the Enter key.

5. Press the Down Arrow key until you see OPTIONAL COMM, then press the Enter key.

You should see IP ADDR. BYTE 1 on the display.

The syntax of the IP address is four bytes connected by decimal points: aaa.bbb.ccc.ddd. Each byte has a value in the range 0...255.

6. Press the Enter key to access the parameter value for editing.

TIP When editing a parameter, the phase indicators at the right of the display module are solid and the parameter flashes. After pressing the Enter key to store the new value, the phase indicators flash and the parameter turns solid.

7. Press the Up Arrow or Down Arrow key to select the desired value.

8. Press the Enter key to write the new value to the PowerMonitor 3000 master module.

9. Press the Down Arrow key to select the next IP address byte.

10. Repeat steps 6...9 to edit the remaining IP address byte values.

11. Repeat steps 6...10 to configure the Subnet Mask and Gateway IP addresses as required.

12. Press the Escape key twice to return to the Configuration menu.

Configure Basic Device Parameters

Follow these steps to configure wiring, PT and CT ratios, and nominal system voltage for the PowerMonitor 3000 device. The [Basic Device Configuration Parameters](#) table on [page 59](#) provides a list of basic device configuration parameters and example settings.

1. Press the Enter key from the PROG.>CONFIGURATION menu.

The BASIC configuration menu is displayed.

2. Press the Enter key to select the WIRING CONFIG. menu.
3. Press the Enter key to access Edit mode.
4. Press the Down Arrow key to select the desired wiring mode parameter.
5. Press the Enter key to write the new value to the PowerMonitor 3000 master module and return to the WIRING CONFIG menu.
6. Repeat steps 4 and 5 to set the PT Secondary, CT Primary, CT Secondary, and Nominal System Voltage (M6 and M8 models only) parameters.

The I4 Primary and I4 Secondary parameters are used for neutral metering only.

7. Press the Escape key to return to the Configuration menu.

Basic Device Configuration Parameters

Parameter	Range	Default	Example Settings
Wiring	0 = Delta 3 CT 1 = Delta 2 CT 2 = Direct Delta 3 CT 3 = Direct Delta 2 CT 4 = Open Delta 3 CT 5 = Open Delta 2 CT 6 = Wye 7 = Single Phase 8 = Demo	6 = Wye	Wye
PT Primary	1...10,000,000	480	480 (Volts)
PT Secondary	1...600	480	480 (Volts)
CT Primary	1...10,000,000	5	600 (Amps)
CT Secondary	1...5	5	5 (Amps)
I4 Primary	1...10,000,000	5	
I4 Secondary	1...5	5	
Nominal System Voltage (M6 and M8 only)	1...10,000,000	480	277 (Volts) ⁽¹⁾

(1) This value is typically line-to-neutral voltage for Wye systems and line-to-line voltage for Delta systems.

Configure Advanced Device Parameters

The [Advanced Device Configuration Parameters](#) table on [page 61](#) provides a list of advanced parameters and values you can set for the PowerMonitor 3000 device. Most applications use the default values for demand period length, number of demand periods, and forced demand delay.

Follow these basic steps to configure demand parameters and the date/time.

1. Press the Enter key from the PROG.>CONFIGURATION menu.
The BASIC configuration menu is displayed.
2. Press the Down Arrow key to select the ADVANCED menu, then press the Enter key.
3. Press the Down Arrow key to select the desired advanced parameter.
4. Press the Enter key to access Edit mode.
5. Press the Up and Down Arrow keys to change the value.
6. Press the Enter key to write the new value to the PowerMonitor 3000 master module and set the display module back to Program mode.
7. Repeat steps 3...6 to set other advanced parameters.
8. Press the Escape key to return to desired menus.

Advanced Device Configuration Parameters

Parameter	Range	Default	Example Settings
New Password	-1...9999	0000	0000
Demand Period Length	-99...99 min	15	15
Number of Demand Periods	1...15	1	1
Forced Demand Delay	0...900 s	10	10
Predicted Demand Type	Instantaneous 1st Order 2nd Order	Instantaneous	
KYZ Control Source	0 = None 1 = Wh Forward 2 = Wh Reverse 3 = VARh Forward 4 = VARh Reverse 5 = Vah 6 = Ah 7 = Setpoint 8 = Comms	7 = Setpoint	
KYZ Pulse Output Scale	1...30000	10	
KYZ Pulse Output Width	0, 40...2000	0	
Relay Control Source	Same as KYZ	7 = Setpoint	
Relay Pulse Output Scale	1...30000	10	
Relay Pulse Output Width	0, 40...2000	100	
RMS Resolution	Nominal / High	High ⁽²⁾	
RMS Averaging	On / Off	On	
Frequency Averaging	On / Off	On	
Date Format	MM/DD/YYYY DD/MM/YYYY	MM/DD/YYYY	
Date: Year	1998...2097	1998	
Date: Month	1...12	1	
Date: Day	1...31	1	
Time: Hour	0...23	0	
Time: Minutes	0...59	0	
Time: Seconds	0...59	0	
Default relay state on comms loss	0 = Last state/resume 1 = Last state/freeze 2 = De-energize/resume 3 = De-energize/freeze	0	
Default KYZ state on comms loss		0	
Wdog action	0 = Halt 1 = Continue	0 = Halt	
Display Module Scroll Speed	Fast / Slow	Fast	
Energy counter rollover point	4...15 digits	15	
Metering Result Set (M8 only ⁽¹⁾)	0 = All results 1 = Transducer mode 2 = Energy meter mode	0 = All results	

(1) Metering result set parameter may only be configured by using communication.

(2) Factory default for RMS Resolution is Nominal for the M4 and High for the M5, M6, and M8.

Configure a PowerMonitor 1000 Device

This section shows you how to configure parameters of a PowerMonitor 1000 device by using its internal Display and Configuration web page. Certain settings are needed for the PowerMonitor to meter accurately, communicate correctly, and work with FactoryTalk EnergyMetrix software properly. You will set the network configuration, voltage mode, PT and CT ratios, demand values, and the date and time. Your application may require additional configuration.


TIP Network configuration is provided for the PowerMonitor 1000 on Ethernet device. For other communication options, refer to the PowerMonitor 1000 Unit Installation Instructions, publication [1408-IN001](#)

Follow these steps to configure PowerMonitor 1000 device parameters.

1. Launch the Internet browser on your computer.
2. In the Address field, type the IP address of your PowerMonitor 1000 device.
The default IP address is 192.168.254.xxx, where xxx is the unit's id. The default address simplifies the task of making the initial connection to the unit from a personal computer.




TIP You can check the IP address of the PowerMonitor 1000 device from its display or by using RSLink Classic software and configuring an EtherNet/IP driver.



Configure the Ethernet IP Address

Follow these steps to configure the Ethernet IP address of a PowerMonitor 1000 device.

1. Choose Configure Options> Communication>Ethernet Communications to access the Ethernet Configuration page.



- Enter the default password of 0 or another valid password to access Edit mode.

TIP The password appears as asterisks (*). If you don't know the password, call Rockwell Automation technical support for assistance.

- Enter appropriate values in the IP Address Byte fields.

For the [Efficient Industries Plant 1](#) example, the IP address is 10.10.10.1 for the first PowerMonitor 1000 device.

- Enter the Subnet Mask and Gateway IP addresses as required.
- Click Submit to send the parameter changes to the PowerMonitor 1000 device.

TIP You will lose communication to the PowerMonitor device. You must enter the new IP address in the Address field of your web browser to re-establish communication with the device.

- Browse to the new IP address from your web browser.

The IP address is shown on the default LCD display screen.

Ethernet Configuration		
Element	Item Name	Value
0	Password Range 0 to 9999	<input type="text"/>
1	IP Address Byte a (aaa.xxx.xxx.xxx) Range 0 to 255	<input type="text"/>
2	IP Address Byte b (xxx.bbb.xxx.xxx) Range 0 to 255	<input type="text"/>
3	IP Address Byte c (xxx.xxx.ccc.xxx) Range 0 to 255	<input type="text"/>
4	IP Address Byte d (xxx.xxx.xxx.ddd) Range 0 to 255	<input type="text"/>
5	Subnet Mask Byte a Range 0 to 255	<input type="text"/>
6	Subnet Mask Byte b Range 0 to 255	<input type="text"/>
7	Subnet Mask Byte c Range 0 to 255	<input type="text"/>

Configure Analog Inputs

Follow these steps to configure the voltage mode, PT ratios, and CT ratios for the PowerMonitor 1000 device. The [Analog Input Setup Parameters](#) table on [page 64](#) shows the analog input parameters and example settings.

- Choose Configure Options>Analog Input to display the Analog Input Configuration page.

Power and Energy Management Solutions
Meeting the Changing Demands for Power and Energy Management
Powermonitor 1000 Display and Configuration

Allen-Bradley
Display and Configuration Menu

- Home
- Display Metering Information
- Display Status
- Execute Commands
- Configure Options
- Analog Number Breakdown
- Go To ab.com

- Analog Input
- Date and Time
- Advanced
- User Configurable Table
- Communication

Element	Item Name	Value
0	Password Range 0 to 9999	<input type="text"/>
1	Voltage Mode 0 = Direct Delta 1 = Open Delta 2 = Wye 3 = Single Phase 4 = Demo 5 = 1PT1CT-LL 6 = 1PT1CT-LN	<input type="text"/>
2	PT Primary Range 1 to 50000	<input type="text"/>
3	PT Secondary Range 1 to 600	<input type="text"/>
4	CT Primary Range 5 to 50000	<input type="text"/>
5	System PF Setting 0 = Leading -97 to +99	<input type="text"/>

2. Enter the default password of 0 or another valid password to access Edit mode.

TIP The password appears as asterisks (*). If you don't know the password, call Rockwell Automation technical support for assistance.

3. Enter the value of the Voltage Mode you are using.
4. Set elements 2, 3, and 4 to configure the PT and CT parameters.
5. Click Submit to send the parameter changes to the PowerMonitor 1000 device.

Analog Input Configuration		
Element	Item Name	Value
0	Password Range 0 to 9999	<input type="text" value="0"/>
1	Voltage Mode 0 = Direct Delta 1 = Open Delta 2 = Wye 3 = Single Phase 4 = Demo 5 = 1PT1CT-LL 6 = 1PT1CT-LN	<input type="text" value="2"/>
2	PT Primary Range 1 to 50000	<input type="text" value="480"/>
3	PT Secondary Range 1 to 600	<input type="text" value="480"/>
4	CT Primary Range 5 to 50000	<input type="text" value="600"/>

Analog Input Setup Parameters

Parameter	Range	Default	Example Settings
Password	0...9999	0	0
Voltage Mode	0...6 0 = Direct Delta 1 = Open Delta 2 = Wye 3 = Single Phase 4 = Demo, simulated results 5 = 1PT1CT-LL 6 = 1PT1CT-LN	2	2
PT Primary	1.0... 50,000	480	480
PT Secondary	5.00... 50,000	480	480
CT Primary	5.00... 50,000	5	600
System PF Setting	0 = Lead (-97...89) 1 = High (-85...98) 2 = Low (-52...-95)	2 = Low	2

Configure Advanced Device Parameters

Follow these steps to configure advanced demand parameters for the PowerMonitor 1000 device. These settings include demand source, demand period length, and the number of demand periods to average for the demand calculation. The [Advanced Device Configuration Parameters](#) table on [page 65](#) shows the demand parameters and example settings.

1. Choose Configure Options>Advanced to access the Advanced Configuration page.

Element	Item Name	Value
0	Password Range 0 to 9999	0
14	Demand Source 0 = Internal Timer 1 = Status Input 2 2 = Controller Command 3 = Ethernet Broadcast	0
15	Demand Period Length (minutes) Range 0 to 99	15
16	Number of Demand Periods Range 1 to 15	1

2. Enter the default password of 0 or another valid password to access Edit mode.

TIP The password appears as asterisks (*). If you don't know the password, call Rockwell Automation technical support for assistance.

3. Set appropriate values for the demand parameters (elements 14, 15, and 16).

For this example, accept the default parameters as shown.

4. Click Submit to send the parameter changes to the PowerMonitor 1000 device.

Advanced Device Configuration Parameters

Parameter	Range	Default	Example Settings
Password	0...9999	0	0
Demand Source	0...3 0 = Internal Timer 1 = Status Input 2 2 = Controller Command 3 = Ethernet Demand Broadcast	0	0
Demand Period Length	0...99 min	15 min	15
Number of Demand Periods	1...15	1	1
Forced Demand Sync Delay	0... 90 s	10	
Demand Broadcast Master Select	0...1	0	
Broadcast Port Number (Ethernet Setup)	300... 400	300	

Configure the Date and Time

Follow these steps to configure the date and time for the PowerMonitor 1000 device. The [Date and Time Setup Parameters](#) table on [page 66](#) shows the date and time parameters, and example settings

1. Choose Configure Options>Date and Time to access the Date and Time Configuration page.

Element	Item Name	Value
0	Password Range 0 to 9999	0
1	New Password Range 0 to 9999	0
2	Metering Result Averaging OFF = 0 ON = 1	1
3	Log Status Input Changes NO = 0 YES = 1	0

2. Enter the default password of 0 or another valid password to access Edit mode.

TIP The password appears as asterisks (*).
If you don't know the password, call Rockwell Automation technical support for assistance.

3. Configure the date and time parameters accordingly.
4. Click Submit to send the parameter changes to the PowerMonitor 1000 device.

Date and Time Configuration		
Element	Item Name	Value
0	Password Range 0 to 9999	0
1	Date: Year Range 2001 to 2100	2009
2	Date: Month Range 1 to 12	8
3	Date: Day Range 1 to 31	31
4	Time: Hour Range 0 to 23	7
5	Time: Minute Range 0 to 59	44
6	Time: Seconds Range 0 to 59	39
7	Time: Hundredths Range 0 to 99	46

Submit Refresh

Date and Time Setup Parameters

Parameter	Range	Default	Example Settings
Password	0...9999	0	0
Date: Year	2001...2100	2005	
Date:Month	1...12	1	
Date:Day	1...31	0	
Time:Hour	0...23	0	
Time:Minute	0...59	0	
Time:Seconds	0...59	0	
Time:Hundreths	0...59	0	

Configure a PowerMonitor Wireless 250 Device

The PowerMonitor Wireless 250 monitors are factory configured. Each PowerMonitor Wireless 250 device is assigned a Group ID and Device ID in the factory. These should not be modified except under exceptional circumstances. One such circumstance would be operating two or more independent PowerMonitor W250 networks in such close proximity that RF interference with each other occurs. Please contact Rockwell Automation support services for more information or if assistance is required.

The PC Receiver can be configured for RS-232 or RS-485 data port use.

PC Receiver Connection

This section describes the RS-232 and RS-485 connections.

RS-232 Data Port Use and Configuration

DB-9 style connector: RS-232 Data Port connector with standard DCE connections for transmit data, receive data, RTS input, and CTS output.


The PC Receiver is factory configured with the following parameters:

- Communication Rate - 115,200
- Data Bits - 8
- Parity - None
- Stop Bits - 1

PC Receiver RS-485 Data Port Use and Configuration

The RS-485 mode of the PC Receiver requires special wiring for the DB9 connection. In order to activate the RS-485 mode, please connect the data port as follows.

PC Receiver RS-485 Wiring Diagram



As soon as power is applied to the PC Receiver unit, the PC Receiver unit chooses the serial mode, RS-232 or RS-485, according to the DB9 wiring. This mode remains until the PC Receiver is power cycled (just removing the DB9 connector does not change the serial mode).

RS-485 mode is available on the PC Receiver unit with the date code 10267 or later with firmware revision (or later) 1.5.15 (100 and 200 node) or 1.7.5.15 (10 node). Upgrade of an older PC Receiver (before date code 10267) is not possible, as it is a different hardware revision.

RS-485 mode sets the device Modbus address to 247. The address cannot be changed. Only point-to-point communication is supported.

Refer to the PowerMonitor Wireless 250 Monitor User Manual, publication [1425-UM001](#), for more information on installing and commissioning your wireless network.

Configure a PowerMonitor 500 Device


This section shows you how to configure parameters of a PowerMonitor 500 device by using its front panel display. Certain settings are needed for the power monitor to meter accurately, communicate correctly, and work with FactoryTalk EnergyMetrix software properly. You set the communication parameters, system type, PT and CT ratios, demand values, and the date and time. Your application may require additional configuration.

Configure with the Display

The PowerMonitor 500 unit provides menu-based configuration (programming) using its front panel display. The programming menus let you select parameters to edit, select digits within parameters, and increase or decrease the value of each digit.

During the Programming mode, the instrument provides this information.

1. Indicates Programming mode.
2. Identifies the programming menu number.
Refer to the programming flow chart.
3. Indicates parameter currently being edited.
4. Cursor identifies the digit currently being edited.
5. Allowable range of selected parameter.




Use the Up and Down arrow (7) to increase and decrease the digit indicated by the cursor (4). To set another digit, move the cursor to the desired digit by using Escape (6). Each button press shifts the cursor (4) one digit to the left.

When the cursor is beneath the last digit on the left, a further press of Escape (6) lets you change the decimal point and the multiplier (9) (k or M). The blinking 'dP' (decimal point) text (10) indicates this capability.


To modify the decimal point position and the multiplier, use the Up and Down arrow button (7) to select the desired value.

To store the new programmed value, press Enter (7). To cancel the change in programming and restore the previous values of the parameter, press Escape (6) for at least 2 seconds.



Follow these steps to configure PowerMonitor 500 device parameters.

Access the Programming Menu

1. Press and hold Enter  for at least 2 seconds to access the programming menu.
2. Enter the default password of 0 (or another valid password).
3. Press Enter to access programming mode.

Configure Communication Parameters

1. Press the Up Arrow until you reach the RS232-485 or Ethernet menu.
2. Press Enter to select the menu item.
3. Press the Up and Down arrows to scroll through the communication parameters.


The Serial communication parameters are listed in this table.

Parameter	Range	Default
Address	1...247	1
Communication Rate	9600, 19200, 38400, 115200	9600
Parity	None/odd/even	none

The Ethernet communication parameters are listed in this table.

Parameter	Range	Default
IP Address	www.xxx.yyy.zzz	N/A
Subnet	www.xxx.yyy.zzz	N/A
Gateway	www.xxx.yyy.zzz	N/A
TCP IP Port	1...9999	502
ACD	Yes or No	No

4. To change a parameter:
 - a. Press Enter to select a menu item.
 - b. Press the Up and Down arrows to change the value.
 - c. When the desired value is displayed, press Enter to confirm your selection.

5. Press Esc  to return to the main menu.

Configure Basic Device Parameters

1. From the main programming menu, use the Up and Down Arrows to scroll through the programming menu and view the configuration for the basic device parameters.

Parameter	Range	Default
System	1P, 2P, 3P, 3P.n, 3P.1, 3P.2	3P.n
CT Ratio	1.0...9999	1.0
PT Ratio	1.0...9999	1.0

2. To change a parameter:
 - a. Press Enter to select a menu item.
 - b. Press the Up and Down arrows to change the value.
 - c. When the desired value is displayed, press Enter to confirm your selection.
3. Press Esc to return to the main menu.

Configure Advanced Parameters

Follow these steps to configure the advanced parameters for the PowerMonitor 500 device. These settings include the demand calculation mode, interval time, and synchronization mode.

1. From the main programming menu, use the Up and Down Arrows to scroll through the programming menu.
2. Select a menu item by pressing Enter.

These are the Demand configuration parameters.

Parameter ⁽¹⁾	Range	Default
Type	FIXED AVG/DMD SLIDE	FIXED
Time	01, 05, 10, 15, 20, 30	15
Sync	OFF/CLOCK	OFF

(1) Additional advanced parameters, such as alarms, outputs, and digital filtering are also available for configuration. Refer to the PowerMonitor 500 Unit User Manual, publication [1420-UM001](#), for detailed information.

3. To change a parameter:
 - a. Press Enter to select a menu item.
 - b. Press the Up and Down arrows to change the value.
 - c. When the desired value is displayed, press Enter to confirm your selection.
4. Press Esc to return to the main menu.

Configure the Date and Time

Follow these steps to configure the date and time for the PowerMonitor 500 device.

1. From the main programming menu, use the Up and Down Arrows to scroll through the programming menu.
2. Select the Clock menu item by pressing Enter.

These are the Clock configuration parameters.

Parameter	Range	Default
FORMAT	EU/USA	EU
YEAR	2009...2099	2009
MONTH	1...12	1
DAY	1...31	1
HOUR	0...23	0
MINUTE	0...59	0
SECOND	0...59	0

3. To change a parameter:
 - a. Press Enter to select a menu item.
 - b. Press the Up and Down arrows to change the value.
 - c. When the desired value is displayed, press Enter to confirm your selection.
 - d. Press Esc to return to the main menu.

Configure a PowerMonitor 5000 Device


This section shows you how to configure parameters of a PowerMonitor 5000 device by using the Web interface. Certain settings are needed for the power monitor to meter accurately, communicate correctly, and work with FactoryTalk EnergyMetrix software properly. You will set the basic metering, native Ethernet communication, date and time, and initial security configuration. Your application may require additional configuration.

Setup Using the Web Interface

For initial setup, connect a personal computer to the PowerMonitor 5000 unit by using a USB cable. Initial setup is usually performed by using the USB Web interface, and initial security setup can only be performed by using the USB Web interface.

Refer to the PowerMonitor 5000 USB Driver Installation and Configuration instructions, publication [1426-IN001](#) for more information on installing the USB communication drivers.

Open Internet Explorer and browse to <http://192.168.169.3>. The PowerMonitor 5000 home page will display in your browser as shown below. The home page displays general information about the PowerMonitor 5000 unit. You can navigate by clicking folders and pages from the tree on the left.



Initial setup by using the USB Web interface should include at least the following configuration steps:

- Basic Metering - this aligns the power monitor metering functionality with the properties of the circuit to which it connects
- Native Ethernet Network Communication - this permits access to the unit for data monitoring and setup through an Ethernet network
- Date and Time - this sets the unit's internal clock so that time stamps in logged data are correct
- Security (if desired) - enabling and configuring security will guard against unauthorized changes to the power monitor configuration

Once initial setup has been completed, including configuration of the Ethernet IP address, you can also access the Web interface from a computer connected through a network to the PowerMonitor 5000 unit's native Ethernet port. Open Internet Explorer and browse to the IP address of the unit.

Obtaining Access to the Configuration Pages

The PowerMonitor 5000 unit initially has security disabled by default. If your power monitor's security is disabled, you can continue setting up the unit without logging in.

If Security is Enabled

If security is enabled, the web page header displays 'Logged in as:' and a Log in link.



If security is enabled, you will need to log in as an administrator to configure setup parameters. If not logged in as an administrator, you will be able to view, but not change, configuration parameters. If you need to log in, click the Log in link.


The USB connection has a special administrator account. Follow these steps to log in with this account.

1. Type in the user name usbadmin.
2. Type in the password usbadmin.
3. Click Log In.

A dialog box reports the result.

To log in from the network Web interface, select a previously configured administrator account user name and password. The PowerMonitor 5000 unit does not permit logging in with the USB administrator login from the network.

You will remain logged in until you log out or until 30 minutes have passed since configuration changes have been applied.



How to Set Up the PowerMonitor 5000 Unit

From any power monitor web page, click the Configuration folder. A list of available configuration pages is displayed in the tree. The steps for entering, editing and applying configuration parameters are similar for each configuration page.

The configuration pages contain text boxes for entering parameter values, pull-down menus for selecting enumerated parameter values, and an Apply Changes button for committing changes to the power monitor. The power monitor checks that parameter values are within their valid range before applying them. A dialog box appears to report the success or reason for failure of an attempt to apply new parameters.




Basic Metering Setup

We will begin with configuring the basic metering parameters. Click the Metering_Basic page under the open Configuration folder. The page opens. You can select other configuration pages by clicking the desired page in the tree, or by clicking the corresponding tab in the page.

This page displays the existing basic metering configuration of the power monitor, including the metering mode, PT (VT) and CT ratios, nominal voltage and frequency, and demand. To change the basic metering setup, enter the desired values into the text boxes, scroll down, and click Apply Changes. A dialog box appears to report the result of the setup change.

EXAMPLE This Metering_Basic page illustrates the setup for a 480V, 3-phase system with 1000:5 current transformer (CT) ratios on all phases and the neutral.



Native Ethernet Communication Setup

Click the Configuration folder and select the CommunicationsNative page. The PowerMonitor 5000 unit is set up by default to obtain an IP address automatically from a DHCP (Dynamic Host Configuration Protocol) server. If your power monitor is on a network served by a DHCP server, and the power monitor is connected to the network, it has probably already been assigned an IP address.

We recommend that each power monitor be assigned a static, or fixed, IP address, since DHCP addresses can change from time to time, resulting in loss of communication with client applications. Obtain a fixed IP address, subnet mask, default gateway, and other network setup parameters from your network administrator. Another option can be to set up the power monitor as a reserved client in the DHCP server.

EXAMPLE This example explains how to change from a DHCP-assigned to a static IP address.

The initial network configuration is shown below. The IP address assigned is 192.168.200.8. The network administrator has provided a range of static IP addresses in the same subnet, beginning with 192.168.200.100. In this case, the default gateway and DNS servers remain the same for static or DHCP-obtained addresses (verify if this is true in your case with your network administrator).

The screenshot shows the 'CommunicationsNative' tab in the PowerMonitor 5000 configuration interface. The 'IP_Address_Obtain' dropdown is set to 'DHCP'. The IP address fields are configured as follows:

Field	Value
IP_Address_A	192
IP_Address_B	168
IP_Address_C	200
IP_Address_D	8
Subnet_Mask_A	255
Subnet_Mask_B	255
Subnet_Mask_C	255
Subnet_Mask_D	0
Gateway_Address_A	192
Gateway_Address_B	168
Gateway_Address_C	200
Gateway_Address_D	1
DNS_Enable	Disable

To change to the new address, from the IP_Address_Obtain pull-down menu choose Static, type in the new IP address, and click Apply Changes.

The screenshot shows the 'CommunicationsNative' tab after the configuration change. The 'IP_Address_Obtain' dropdown is now set to 'Static'. The IP address fields are configured as follows:

Field	Value
IP_Address_A	192
IP_Address_B	168
IP_Address_C	200
IP_Address_D	101
Subnet_Mask_A	255
Subnet_Mask_B	255
Subnet_Mask_C	255
Subnet_Mask_D	0
Gateway_Address_A	192
Gateway_Address_B	168
Gateway_Address_C	200
Gateway_Address_D	1

IMPORTANT You can change the network configuration from the USB or network web pages. If you change the IP address from the network Web interface, you will then need to browse to the new IP address to re-establish communication.



Set Up Date and Time

Click the Configuration folder and select the DateTime page. Enter the year, month, day, hour, and minute into the corresponding input fields and click Apply Changes. If your power monitor has been set up for time synchronization with either a SNTP or IEEE 1588 PTP server, the time may already be set.


Set-up Initial Security

If you choose to enable security on the power monitor, you must perform the initial security setup by using the USB Web interface.

1. In the USB web page, select the Security folder and then the Security page.
2. From the Security Defaults pull-down menu, choose Enable Security.
3. Accept the prompt regarding enabling security and accept the prompt to reload the web pages.
4. Log in with user name usbadmin and password usbadmin.
5. Accept the prompt that the login was successful.
6. To add a network administrator, click AddNew.
7. Enter a username and password for a network administrator.



The username and password can be any string up to 32 characters in length. This example sets a username of admin with a password of admin. Make a note of the new network administrator login for future use and keep it in a secure location.



8. While still connected to the USB port, log out from the usbadmin account.

Only one admin type account is permitted to be active at a time.


Now that the network administrator user has been created, you can continue setting up the PowerMonitor 5000 unit by connecting through the native EtherNet/IP port and using the network Web interface. This includes the ability to configure additional users, administrators, and application security accounts.

Test Security

To test the network administrator login, follow these steps.

1. Browse to the network address of the PowerMonitor 5000 unit.
2. Click Log in from the page header and enter the user name and password just created and click Log In.

Note that only the USB Web interface can be used to enable, disable, or reset security. If security accounts are lost or forgotten, you will need to connect to the USB Web interface and log in with the usbadmin account to create new network security accounts.



Setting Up Remaining Functions of the PowerMonitor 5000 Unit

The remaining functions are set up in the same way as the examples discussed in this section. For additional details on configuring the PowerMonitor 5000 unit refer to the PowerMonitor 5000 Unit user manual, publication [1426-UM001](#).

Optionally, the PowerMonitor 5000 device can be configured using the FactoryTalk EnergyMetrix software. Refer to the FactoryTalk EnergyMetrix software user manual, publication [FTEM-UM002](#), for details.

Configure a CompactLogix Controller

In this section, you set up a CompactLogix™ controller as a FactoryTalk EnergyMetrix data collector, and interface to local HMI faceplates. You configure controller properties, digital and analog energy inputs, and energy Add-On Instructions for each controller in your system.

Refer to the CompactLogix tab in the Energy Data Worksheet created in [Chapter 2](#) for CompactLogix and PLC-5® address assignments.

Create a Project and Set Up Controller Properties

1. Open RSLogix 5000 software to create a new project.


2. Choose your first controller and choose revision 17, or later.

For this example, a CompactLogix 1769-L23E-QBFC1 is selected as a cost-effective solution supporting digital and analog energy inputs, and Ethernet communication.

3. Enter the name of the controller from your Energy Data Worksheet.

For this example, L2x is entered.

4. Click OK.




5. Right-click the Ethernet Port and choose Properties.

For this example, choose the LocalENB port.

6. Enter a unique IP address for your controller and click OK.


For this example, 10.10.10.7 is entered.



Import Energy Add-On Instructions

You will now import preconfigured Energy Add-On Instructions to support the digital and analog energy inputs listed on the CompactLogix tab of your Energy Data Worksheet. These Add-On Instructions provide energy data calculations and HMI interface logic for the energy inputs. Refer to [Appendix C](#) and [Appendix D](#) for detailed logic information.

1. Navigate to and right-click the Add-On Instructions folder.
2. Choose Import Add-On Instruction.



3. Browse to the Energy Input Logic folder on your Energy Management Accelerator Toolkit CD image.




4. Select the Analog or Digital folder and browse to the desired energy input file.


Choose a digital input file for meters with a pulse output representing consumption. Select an analog input file for meters with an analog output representing flow rate.

The example shows a gas meter digital input selected.


5. Click Import.



- Click OK from the Import Configuration dialog box to continue the Add-On Instruction import.




- Verify the imported file appears under Add-On Instructions.



- Repeat steps 1...7 to import other required Add-On Instruction files for your project.


For the [Efficient Industries Plant 1](#) example, the Add-On Instructions list would look similar to this.



Configure CompactLogix Energy Inputs


You are now ready to program each digital and analog energy input listed on the CompactLogix tab of your Energy Data Worksheet and assign energy tags and factors.

- Open your program routine and create a new rung.




2. Click the Add-On tab in the instruction toolbar.
3. Click an Energy Add-On Instruction icon to add the instruction to your rung.


For this example, the Energy_Gas_Digital Add-On Instruction is selected.



4. Click in the energy tag name field and enter a tag name.
For this example, Boiler_House_Gas is entered.
5. Right-click the energy tag name just entered and choose the New “Tag_Name” from the list.



6. Click OK to accept the default setup for the new Add-On Instruction tag.




7. Double-click the input parameter field, then click the pull-down menu icon to display the input controller tags.

Refer to the CompactLogix tab of the Energy Data Worksheet for the local I/O digital or analog input address.

8. Navigate to the desired digital or analog input tag.

This example shows Local:1:I.Data.


9. For digital input tags:
 - a. Click the tag pull-down menu icon to display a table of data bits.
 - b. Click the bit associated with the hardware terminal wired to your digital input.




For analog input tags:

- a. Click the tag pull-down menu icon to display the channel tags.
- b. Double-click the channel data tag associated with the hardware terminal wired to your analog energy input.

The analog input channels must also be enabled.




- c. Double-click Analog I/O under IO Configuration to launch the module properties and enable the channels that will be used.



10. Assign energy input calculation and scaling factor tag values based on the Energy Add-On Instruction Factor table definitions on [page 84](#).

One table provides factor definitions for electric inputs and one for all other energy inputs.

This example shows values that need to be set for the Energy_Gas_Digital Add-On Instruction.



The screenshot shows a configuration window titled "Energy_Gas_Digital". It contains a table with two columns: the first column lists configuration parameters, and the second column lists their values. Four arrows point to the rows for "Set_Meter_Pulse_Factor", "Set_Calc_Interval", "Set_High_Flow", and "Set_Critical_Flow".

Energy_Gas_Digital	
Energy_Gas_Digital	Boiler_House_Gas ...
Inp_Pulse	Local: 1:I.Data.0
	0
Set_Meter_Pulse_Factor	1.5
Set_Calc_Interval	1
Set_High_Flow	500
Set_Critical_Flow	750
Val_Total_Gas	0.0
Val_Gas_Per_Calc_Interval	0.0

TIP

For additional information on how these energy factors affect calculations, refer to [Appendix C, Energy Electric Add-On Instructions](#) and [Appendix D, Digital and Analog Energy Add-On Instructions](#).

Energy Add-On Instruction Factors for Electric Inputs

Energy Factor Tag	Description
Set_Meter_Pulse_Factor	The kWh value used to scale the input pulses. The value 1.5 represents 1.5 kWh per pulse.
Set_Demand_Interval	The value, in minutes, used to calculate the End of Demand Interval (EOI). This value is used only if the Val_End_of_Demand_Type is 2.
Set_Demand_Delay	The time value used to reset the end of interval after the Set_Demand_Interval value has been exceeded without a utility contact or master end of demand contact closure. The value must be in the range of 0...90 seconds.
Set_End_of_Demand_Interval_Type	The value that defines how the End of Demand Interval (EOI) is triggered. 1 = A local digital input connected to an electric utility meter EOI contact (Inp_End_of_Demand_UTILITY_Contact). 2 = An internal PLC timer (Demand_Interval_PLC_Timer) that is typically used when an electric utility meter EOI contact is not available. 3 = A master command input (CMD_Master_End_Of_Demand_Interval) typically from a central controller that is used to synchronize multiple electric meter EOIs.
Set_High_Demand	When the demand (kW) value exceeds the Set_High_Demand, the High Demand Fault is set.
Set_Critical_Demand	When the demand (kW) value exceeds the Set_Critical_Demand, the High Critical Fault is set.


Energy Add-On Instruction Factors for Gas, Propane, Fuel Oil, Steam, Air and Water Inputs

Energy Factor Tag	Definitions										
Set_Meter_Pulse_Factor ⁽¹⁾	<p>The consumption value of each input pulse.</p> <table border="1"> <thead> <tr> <th>Energy Add-On Instruction</th><th>Default Consumption Unit</th></tr> </thead> <tbody> <tr> <td>Air</td><td>cf (cubic feet)</td></tr> <tr> <td>Fuel Oil, Propane, Water</td><td>gallons</td></tr> <tr> <td>Gas</td><td>therms</td></tr> <tr> <td>Steam</td><td>lbs (pounds)</td></tr> </tbody> </table> <p>For example, a value of 1.5 for the Energy_Gas_Digital Add-On Instruction, represents 1.5 therms per pulse.</p>	Energy Add-On Instruction	Default Consumption Unit	Air	cf (cubic feet)	Fuel Oil, Propane, Water	gallons	Gas	therms	Steam	lbs (pounds)
Energy Add-On Instruction	Default Consumption Unit										
Air	cf (cubic feet)										
Fuel Oil, Propane, Water	gallons										
Gas	therms										
Steam	lbs (pounds)										
Set_Calc_Interval	<p>The time interval, in minutes, used to calculate the average energy flow.</p> <p>For example, an interval value of 5 will calculate the average energy flow every 5 minutes.</p>										
Set_High_Flow	<p>When the flow rate value exceeds the Set_High_Flow value, the High Flow Fault is set.</p> <table border="1"> <thead> <tr> <th>Energy Add-On Instruction</th><th>Default Flow Rate Unit</th></tr> </thead> <tbody> <tr> <td>Air</td><td>cfm (cubic feet per min)</td></tr> <tr> <td>Fuel Oil, Propane, Water</td><td>gpm (gallons per min)</td></tr> <tr> <td>Gas</td><td>therms/hr</td></tr> <tr> <td>Steam</td><td>lbs/hr</td></tr> </tbody> </table> <p><u>Example 1:</u> A value of 500 will set the High Flow Fault in the Energy_Gas_Digital Add-On Instruction when the gas flow rate exceeds 500 therms/hr. <u>Example 2:</u> A value of 500 will set the High Flow Fault in the Energy_Air_Analog Add-On Instruction when the air flow rate exceeds 500 cfm.</p>	Energy Add-On Instruction	Default Flow Rate Unit	Air	cfm (cubic feet per min)	Fuel Oil, Propane, Water	gpm (gallons per min)	Gas	therms/hr	Steam	lbs/hr
Energy Add-On Instruction	Default Flow Rate Unit										
Air	cfm (cubic feet per min)										
Fuel Oil, Propane, Water	gpm (gallons per min)										
Gas	therms/hr										
Steam	lbs/hr										
Set_Critical_Flow	<p>When the flow rate value exceeds the Set_Critical_Flow value, the Critical Flow Fault is set.</p> <table border="1"> <thead> <tr> <th>Energy Add-On Instruction</th><th>Default Flow Rate Unit</th></tr> </thead> <tbody> <tr> <td>Air</td><td>cfm (cubic feet per min)</td></tr> <tr> <td>Fuel Oil, Propane, Water</td><td>gpm (gallons per min)</td></tr> <tr> <td>Gas</td><td>therms/hr</td></tr> <tr> <td>Steam</td><td>lbs/hr</td></tr> </tbody> </table> <p><u>Example 1:</u> A value of 750 will set the Critical Flow Fault in the Energy_Gas_Digital Add-On Instruction when the gas flow rate exceeds 750 therms/hr. <u>Example 2:</u> A value of 750 will set the Critical Flow Fault in the Energy_Air_Analog Add-On Instruction when the air flow rate exceeds 750 cfm.</p>	Energy Add-On Instruction	Default Flow Rate Unit	Air	cfm (cubic feet per min)	Fuel Oil, Propane, Water	gpm (gallons per min)	Gas	therms/hr	Steam	lbs/hr
Energy Add-On Instruction	Default Flow Rate Unit										
Air	cfm (cubic feet per min)										
Fuel Oil, Propane, Water	gpm (gallons per min)										
Gas	therms/hr										
Steam	lbs/hr										

(1) The Set_Meter_Pulse_Factor applies only to Energy_xxx_Digital Add-On Instructions. Analog inputs must be scaled to represent flow by using the engineering units in the table.

11. Repeat steps 1...10 to program other digital and analog energy inputs in your project.

For the [Efficient Industries Plant 1](#) example, the completed energy input logic would look similar to this.



Map Energy Add-On Instruction Tags to PLC-5 Addresses

After programming the CompactLogix energy Add-On Instructions, you must map the total energy tags (*AOIName.Val_Total_xxx*) to PLC-5 type addresses (*Fxx:xx*) that FactoryTalk EnergyMetrix software can read. You will create a MOV instruction for each CompactLogix energy Add-On Instruction to move its total to a tag within an array named *ControllerName_EnergyTotals*. You will then map that array to the PLC-5 file F10.

TIP Tag mapping must be done in Offline mode.

Refer to the CompactLogix tab of the Energy Data Worksheet for the CompactLogix EnergyTotal and PLC-5 tags that must be mapped.


The worksheet below shows the tags to be mapped for the Efficient Industries Plant 1 example.

Device Name	Meter Name	Meter Type	Meter Tag Name	AOI Name	L2x Input Address	L2x EnergyTotals Address	PLC 5 Address
L2x	Boiler House Gas	L2x Input	Boiler House Natural Gas Usage	Boiler_House_Gas	Local:1:I.Data.0	L2x_EnergyTotals[0]	F10:0
L2x	Fuel Oil Meter	L2x Input	Fuel Oil Usage	Fuel_Oil	Local:3:I.Ch0Data	L2x_EnergyTotals[1]	F10:1
L2x	Propane Meter	L2x Input	Propane Usage	Propane	Local:3:I.Ch1Data	L2x_EnergyTotals[2]	F10:2
L2x	Steam Flow Meter	L2x Input	Steam Usage	Steam_Flow	Local:3:I.Ch2Data	L2x_EnergyTotals[3]	F10:3


Follow these steps to map the total energy Add-On Instruction tags to PLC-5 type addresses.

1. Open your program routine and create a new rung.

For this example, a new rung is added after the Energy Add-On Instruction rung.



2. Add the MOV instruction to your rung by clicking the Move/Logical tab in the Instruction toolbar, then clicking the MOV instruction icon.




3. Choose the source tag, Val_Total_xxx, from your energy Add-On Instruction.

For this example, Boiler_House_Gas.Val_Total_Gas is selected.

4. Enter a name for the new controller-scoped destination tag in the format: *ControllerName_EnergyTotals*.


For this example, enter L2x_EnergyTotals.

5. Right-click the destination tag just entered and choose New 'TagName' to create the controller tag.




6. Configure the new tag.

- a. Choose Real for the Data Type with an array size at least equal to the number of controller total energy tags to be mapped.
- b. Choose Float for the Style.
- c. Click OK to save the configuration.




7. Double-click the Dest tag assignment in the MOV instruction and reassign the Dest tag to a unique *ControllerName_EnergyTotals* array element in the CompactLogix tab of the Energy Data worksheet.

This example shows the instruction used to move Boiler_House_Gas.Val_Total_Gas to the L2x_EnergyTotals file element [0].




8. Repeat steps 2, 3, and 7 to program MOV instructions for the remaining Add-On Instruction total energy tags (*AOIName.Val_Total_xxx.*)

9. Choose Map PLC/SLC Messages from the Logic menu.



10. In the PLC/SLC Mapping dialog box:


- a. Enter a PLC/SLC file number.
For this example, the PLC-5 file number 10 is entered.
- b. Choose the *ControllerName_EnergyTotals* tag from the Name list.
For this example, L2x_EnergyTotals is selected.
- c. Click OK.
This example shows the L2x_EnergyTotals 4-element, tag array mapped to the F10 PLC/SLC file.



TIP

FactoryTalk EnergyMetrix software meter tags reference these mapped tags by their PLC-5 equivalent addresses F10:0 through F10:3

For the [Efficient Industries Plant 1](#) example, the completed energy Add-On Instruction tag-mapping logic would look similar to this.



Notes:

FactoryTalk EnergyMetrix Software Installation

Introduction

In this chapter, you will install server software and FactoryTalk EnergyMetrix software on your computer, and launch FactoryTalk EnergyMetrix software from your web browser.

Before You Begin


- Determine business goals, complete energy assessment, and determine monitoring methods ([Chapter 1](#)).
- Select hardware and wire devices ([Chapter 2](#)).
- Configure data collection devices ([Chapter 3](#)).

What You Need

- Personal computer with internet access for launching and using FactoryTalk EnergyMetrix software.
- FactoryTalk EnergyMetrix CD, catalog number 9307-FTEMMENE.
- FactoryTalk EnergyMetrix online help and user manual, publication [FTEM-UM002](#).
- Energy Management Accelerator Toolkit CD, publication IASIMP-SP014, or visit the Integrated Architecture Tools and Resources website at <http://www.ab.com/go/iatools> to download toolkit files.

Follow These Steps

Follow these steps to install server software, prerequisite software, and FactoryTalk EnergyMetrix software on your computer. You will also modify settings to use FactoryTalk EnergyMetrix RT and Chart options and launch FactoryTalk EnergyMetrix software.



Contents of Installation DVD

The installation DVD contains the following required components:

- FactoryTalk EnergyMetrix software version 2.00.00
- FactoryTalk Activation Manager version 3.50
- RSLinx Classic Lite 2.57 CPR 9 SR 3
- Microsoft .NET Framework 3.5 SP1

And the following optional components:

- Adobe Acrobat Reader 9.1

The CD also includes the following applications, which are not accessible from the auto-run menu but can be browsed:

- FactoryTalk EnergyMetrix Software User Manual
- Internet Explorer WebControls 1.0

Server Requirements

We recommend, but do not require, that you install FactoryTalk EnergyMetrix software on a dedicated server with a local installation of Microsoft SQL Server.

Server Software Requirements for Installing FactoryTalk EnergyMetrix

- Windows 2003 Server or Windows 2008 Server, Application Server role. For 64-bit operating systems, RSLinx Classic version 2.57 CPR9 SR3 or later must be installed. Windows 2000 Server is not supported.
- Microsoft SQL Server 2005 or 2008, installed with mixed-mode authentication (Windows and SQL). TCP/IP access must be enabled. A system administrator SQL login must be used for the FactoryTalk EnergyMetrix installation.
- You must have machine administrator privileges to install FactoryTalk EnergyMetrix.

Hardware Requirements

These are the hardware requirements that you need to use FactoryTalk EnergyMetrix software.

Definitions

The following rules of thumb are offered as a starting point for determining server sizing for FactoryTalk EnergyMetrix. Other factors will affect the required size of a server. A higher number of tags being logged, a faster log rate, a larger number of users and a larger number of reports being run will require a more powerful server than the guidelines specify.

- A low-end server has up to 8 meters and logs up to 40 meter tags at a minimum 15 minute log rate
- A mid-range server has up to 64 meters and logs up to 320 meter tags at a minimum 15 minute log rate
- A high-end server has more than 64 meters and logs more than 500 meter tags at a minimum 15 minute log rate

Database Size Guidelines

FactoryTalk EnergyMetrix writes 16 bytes of data to the database for each meter tag logged. Over time, the database can grow to become quite large. Some examples include the following:

- A low-end server, logging 40 meter tags at 15 minute intervals, will grow the database at a rate of 2.56 KB per hour or 22 MB per year.
- A mid-level server, logging 320 meter tags at 15 minute intervals, will grow the database at a rate of 20.5 KB per hour, or 180 MB per year.
- A high-end server, logging 1000 meter tags at 15 minute intervals, will grow the database at a rate of 240 KB per hour, or 2.1 GB per year.

Consider these guidelines when determining hard disk requirements for a server as well as database maintenance schedules.

Recommendations

These are general guidelines. FactoryTalk EnergyMetrix software is capable of running on a variety of hardware platforms. The main scalability issue is related to processing of logged data (for example, report generation, trending). CPU speed, number of CPUs, RAM, and RAID 5 for the database files are the main scalability factors (in that order). All hardware platforms require the following:

- Processor, RAM and hard drive as noted below
- DVD drive
- One or more Ethernet network ports
- Internet access
- Monitor, keyboard, pointing device (mouse)
- Low-end Server
 - Single 2 GHz Pentium 4
 - 1...2 GB RAM
 - 80 GB hard disk
- Mid-range Server
 - 2 or 4 CPU 2 GHz Pentium 4 or better
 - 2...4 GB RAM
 - 160 GB hard disk (with separate disks for operating system and log files and RAID 5 for main database files preferred)
- High-end Server
 - High-end server requirements are very dependent upon the user's application requirements. Please contact Rockwell Automation for assistance in specifying hardware for a high-end server.

Client Requirements

The following are the client requirements for compatibility with FactoryTalk EnergyMetrix software:

- Microsoft Windows XP Professional, Vista Professional, Windows 7 (Windows 2000 is not supported) operating system.
- Internet Explorer 7, 8, or 9 web browser.

- Adobe Acrobat Reader 7.0 software or later is required to view reports.
- Microsoft .NET Framework 3.5 SP1 is required to use RT and Charts Plus options. .NET Framework 3.5 SP1 is included on the installation DVD or can be downloaded at no charge from Microsoft.

Your client workstation must also be permitted Intranet, Internet or dial-in access to the FactoryTalk EnergyMetrix server. Contact your IT support personnel for assistance.

TIP Your browser should be set to check for newer versions of stored pages automatically, not every visit to the page.


Installation (64-bit)

Perform the following steps while logged in as a Machine Administrator.


Configure Windows 2008 Server

IMPORTANT Start with a clean Windows Server 2008 R2 SP1.

1. If it hasn't launched automatically, launch Server Manager.
Wait until Server Manager has finished collecting data.
2. Right-click Roles and select Add Roles.
3. Click Next on Before You Begin page.
4. Select Application Server.
5. Click Add Required Features.
6. Click Next.
7. Click Next.
8. Click Web Services (IIS) Support.
9. Click Add Required Role Services.



10. Click Next.
11. Click Next.
12. Scroll down in the Role Services window and then select IIS 6 Management Compatibility.
13. Click Next.
14. Click Install.
15. Wait while installation proceeds.
16. Click Close when done.



TIP We recommend that you disable Internet Explorer Enhanced Security Configuration.

17. To do this, locate the Configure IE ESC link in the Security section In the Server Manager.
18. Click the link, turn off IE ESC for Administrators, and then click OK.

Install SQL Server 2008 R2


Microsoft SQL Server 2008 R2 must be installed on the local server even if the FactoryTalk EnergyMetrix database is to be hosted on another machine.

1. Insert disk into CD/DVD drive.
2. If necessary, run SETUP.EXE and click Yes to allow SQL Server 2008 R2 to install on the computer.
3. Review the documentation in the SQL Server Installation Center window.
4. Install the upgrade advisor if desired.
5. Click the Installation link in the menu.
6. Click the New installation or add features to an existing installation link.
7. Enter the product key and then click Next.
8. Accept the license terms and click Next
9. On the Setup Support Files page, click Install.
10. Wait while installation proceeds.
11. Make note of any issues or warnings listed in the Setup Support Rules page and take action as needed.
12. Click Next.
13. Select SQL Server Feature Installation.

14. Select the features shown as selected in the screen capture.
15. Click Next.
16. Click Next.
17. Leave the Default instance selected, click Next.
18. On the Disk Space Requirements page, click Next.
19. On the Service Account dialog, Click Use the same account for all SQL Server services.
20. Select NT AUTHORITY\SYSTEM in the dialog and then click OK.
21. Click Next.
22. On the Database Engine Configuration page, select Mixed Mode.
23. Enter a password.

Record the password in a safe location. You will need to enter it when you install FactoryTalk EnergyMetrix.
24. Click Add Current User.


Add additional users as administrators as desired.
25. Click Next.
26. Click Next.
27. Click Install.
28. Wait until installation completes.
29. Click Close.
30. Close the SQL Server Installation Center window.
31. Remove the SQL Server 2008 R2 installation DVD.



IMPORTANT In SQL Server 2008 R2, TCP/IP network access is enabled by default.

Enable 32-bit Applications

1. Using Internet Information Services (IIS) Manager > Application Pools > DefaultAppPool > Advanced Settings, set Enable 32-Bit Applications to True.
2. Click OK.



Install FactoryTalk EnergyMetrix Software Version 2.0

1. Insert the FactoryTalk EnergyMetrix installation DVD into the CD/DVD drive.

TIP If needed, browse the DVD and launch Autorun.exe to access the installation menu. Perform the following steps from the installation menu.

2. If needed, install Adobe Acrobat Reader (required for viewing reports on the server).
 - a. Click the Adobe Acrobat Reader link under Install Optional Software.
 - b. Select all defaults for a typical installation.
3. Install FactoryTalk Activation Manager.
 - a. Click the FactoryTalk Activation Manager link under Install Required Software.
 - b. Click Continue on the InstallShield Wizard screen.
 - c. When prompted, select No to installing the HASP USB dongle drivers.
 - d. Wait while prerequisite packages are installed.
 - e. On the FactoryTalk Activation Manager InstallShield Wizard, click Next.
 - f. Accept the terms of the license agreement, click Next.
 - g. Click Install.
 - h. When prompted, reboot the server.
4. Install RSLinx Classic Lite software version 2.57.
 - a. From the FactoryTalk EnergyMetrix installation menu, click RSLinx Lite 2.57.00.
 - b. Complete the steps to install RSLinx Classic Lite software.
 - c. After installation, RSLinx Classic starts as an application.

Refer to the RSLinx application notes section below for tips on using RSLinx Classic software on Windows 2008 Server R2.

IMPORTANT Do not install Microsoft .NET Framework 3.5 SP1 on Windows Server 2008 R2 SP1. It is already installed with the operating system.

IMPORTANT FactoryTalk EnergyMetrix software does not require the installation of Internet Explorer WebControls 1.0.

5. Install FactoryTalk EnergyMetrix.
 - a. From the FactoryTalk EnergyMetrix installation menu, click FactoryTalk EnergyMetrix 2.00.00.
 - b. Locate the InstallShield Wizard.

It may be behind other windows on the desktop, click Next.
 - c. Click Yes to accept the EULA.
 - d. Enter the customer information, click Next.
 - e. Click Next.
 - f. Click Next.
 - g. Presuming a local installation of the SQL database, enter the server SQL login username and password that you entered in step 2.v previously.

If the SQL server is hosted on a remote machine, enter the database server name and SQL authentication credentials. Click Next.
 - h. Click Next.
 - i. Wait while FactoryTalk EnergyMetrix software is installed.
 - j. When complete, click Finish to reboot the server.
6. Install activations by using the FactoryTalk Activation Manager.
7. Add local machine user IIS_IUSRS with read and modify rights to the C:\Program Files (x86)\Rockwell Software\FTEnergyMetrix\ChartFXNet folder.
8. Open Internet Explorer.
 - a. Browse to <http://localhost/ftenergymetrix>.
 - b. Log in with username admin and password admin.

TIP The RT and ChartsPlus options do not require specific security configuration in FactoryTalk EnergyMetrix software. They run as Microsoft ClickOnce applications by default. You will need to grant permission for the options to run, but only one time on each computer.

TIP When you set up Devices such as power monitors and PLCs in FactoryTalk EnergyMetrix software, you will need to access RSLinx Classic software running on the server to configure drivers and network addresses of devices. You access the RSLinx Classic user interface to perform tasks such as configure drivers, monitor devices in RSWho, and set up OPC topics.

Installation (32-bit)

IMPORTANT See [Installation \(64-bit\) on page 95](#) for instructions to install FactoryTalk EnergyMetrix software on a 64-bit operating system.

Pre-installation Checks

1. Check out the server for required customer-provided software:

- Windows 2003 R2 Server, set up in the Application Server role. ASPNET must be installed. Active Server Pages must be enabled in Internet Information Services. Network COM+ Access must be enabled. The server can not be set up as a Domain Server. FactoryTalk EnergyMetrix software installation on Windows 2000 Server is no longer supported.
 - SQL 2005 or 2008 Server, installed and set up for mixed mode authentication (SQL Server and Windows). TCP/IP access must be enabled.
 - If the SQL database server is hosted on a remote server, you must download from Microsoft (if necessary) and install Microsoft SQL Server 2005 or 2008 Express Edition on the FactoryTalk EnergyMetrix server. This installs the osql.exe application FactoryTalk EnergyMetrix software uses to connect to the remote database.
 - IIS 6, 7, or 7.5 installed and enabled to run.
2. You must use a machine administrator login in Windows and have full administrator rights for SQL.
 3. Ping all Ethernet devices (meters and/or controllers) the customer wishes to connect to.
 - Correct communication to any meters that don't respond.
 - Verify communication with Allen-Bradley Ethernet power monitors via their built-in web page.

Installation

1. Verify the Application Server role configuration in the host Windows Server operating system.

These are the minimum required components:

- ASPNET
- COM+ Services
- Internet Information Services (IIS), all options

Make any necessary changes before proceeding with the installation.

2. If not already installed, install Microsoft SQL Server 2005 or 2008 (NOT included in FactoryTalk EnergyMetrix base software but 2008 is available as a bundled option).

IMPORTANT SQL Server must be set up with mixed-mode authentication (Windows and SQL Server). You can make this selection during initial installation or by using Enterprise Manager and editing the server properties, security tab after installation. We recommend that you do not use the default system administrator login (username = 'sa', password = "") due to known security issues. Record the system administrator login credentials as you will be prompted to enter them when you install FactoryTalk EnergyMetrix software. The same SQL database login will be required when the software is upgraded to a new version eventually.

IMPORTANT If the SQL Server is to be hosted on another computer, download (if needed) and install SQL Server 2005 or 2008 Express Edition on the FactoryTalk EnergyMetrix server at this time.

3. Using Internet Information Services manager, verify that ASP.NET version 2.0 is selected in the default web page properties.

If it is not, select ASP.NET version 2.0 and run IISRESET before installing the software.
4. Insert the FactoryTalk EnergyMetrix software installation DVD into the server's DVD drive.

If auto-run is enabled, the installation menu will launch. If not enabled, browse to and launch autorun.exe in the root folder of the DVD.

TIP The installation menu provides a link to the FactoryTalk EnergyMetrix online Help.

5. From the installation menu, install the Factory Talk Activation Manager.

TIP This step is recommended but not required when upgrading an existing installation.

6. Install RSLinx Classic Lite software version 2.57 CPR 9 SR 3.

TIP This step is recommended but not required when upgrading an existing installation on a 32-bit Windows Server 2003 operating system.

7. Install Microsoft .NET Framework version 3.5 SP1.

8. If not already installed, install Adobe Acrobat Reader.

9. Install FactoryTalk EnergyMetrix software:

- a. Accept the license agreement and enter the serial number of the Manager software when prompted.
- b. When prompted, enter the computer name or IP address of the SQL Server (the default is (local) for a SQL server hosted on the FactoryTalk EnergyMetrix server).

Then, enter the SQL system administrator account login credentials.

- c. Accept the remaining prompts. The installation will proceed.

During the installation, the FactoryTalk EnergyMetrix SQL database is created, populated with stock values and updated to the current version.

- d. When prompted, reboot the server to complete the installation.

10. After the server restarts, log in as an administrator, and then open the Windows Control Panel > Administrative Tools > Computer Management > Local Users and Groups.

- a. Select Users and right-click the ASPNET user name option.
- b. Select Properties and select the Member Of tab.
- c. If Administrators does not appear in the list, then click Add, and then click Advanced.
- d. Click Find Now.
- e. Select Administrators and click OK.
- f. When finished, reset IIS (Start > Run > 'iisreset' > OK).

11. Install activations for Manager and all purchased options by using the Factory talk Activation Manager.

12. Launch Internet Explorer on the server.

13. Enter the server url (universal resource locator) into the Internet Explorer address field:

http://localhost/ftenergymetrix

TIP To use FactoryTalk EnergyMetrix software from a client workstation, substitute the FactoryTalk EnergyMetrix server name or IP address for 'localhost' in the url.

14. When the login screen appears, log in by using the default login credentials.

IMPORTANT If any errors are displayed when you try to log in or once you have logged in, please refer to the Troubleshooting section in the FactoryTalk EnergyMetrix Software user manual, publication [FTEM-UM002](#).

Activate FactoryTalk EnergyMetrix Software

FactoryTalk EnergyMetrix software is one software product. The Manager and Options are enabled by installing activations. For example, one activation enables Manager, another enables the Real Time (RT) option, and one enables the ChartsPlus option.

IMPORTANT It is the customer's responsibility to observe the requirements of all software licenses.

FactoryTalk EnergyMetrix software may be optionally purchased bundled with Microsoft SQL Server 2008 R2 Standard Edition Runtime Database licenses. SQL Server bundles are offered with a processor license (unlimited clients) or a single-client server license (1 client).

Any number of users may access the FactoryTalk EnergyMetrix server through its web interface.

IMPORTANT FactoryTalk EnergyMetrix software requires at minimum the activation for Manager for operation. Without a Manager activation, the software will not permit users to log in.

The basic Manager software includes a license for 10 meters. You can increase the meter limit on your server at any time by purchasing and installing additional meter licenses in 10, 50, 100, and 500-meter increments.

You can also add options such as RT, FTEMOPC, ChartsPlus, and ReportsPlus in the same manner. Check with your local Rockwell Automation representative for option pricing and availability.

FactoryTalk EnergyMetrix software uses FactoryTalk Activation. If you are a new user, you will need to activate your software by using FactoryTalk Activation because FactoryTalk EnergyMetrix software no longer ships with physical 'master disks' for activating the base software and options.

If you are upgrading from FactoryTalk EnergyMetrix software activated with EvRSI activation, please contact your local Rockwell Automation Sales office or Technical Support for information to migrate your activations to FactoryTalk activations.

For Rockwell Automation Technical Support in the U.S., call 1 (440) 646-3434. Outside the U.S., see <http://www.rockwellautomation.com/locations/>.

When you log in to the FactoryTalk EnergyMetrix web page, the software checks for the activation file. If the system fails to detect the activation file, an error is displayed and logged to FactoryTalk Diagnostics. For more information, refer to the online help included with the FactoryTalk Manager software.

How to Activate Your Software

To activate FactoryTalk EnergyMetrix software, perform the following steps.

1. Install the FactoryTalk Manager software available from the Optional Steps screen of the Install program.
2. Once FactoryTalk Manager is installed, click Start > Programs > Rockwell Software > FactoryTalk Activation > FactoryTalk Manager to launch the FactoryTalk Manager.
3. Click Get Activations.
4. Follow the instructions to select an activation method, enter activation information, validate the activation and download the activation to your computer.
5. Refer to the Activation Manager Help topics for additional information.

FactoryTalk EnergyMetrix software does not provide a grace period. The software will not permit users to log in if a valid activation is not available.

A Host ID is an internal code that uniquely identifies a hardware device. FactoryTalk Activation uses the Host ID to 'lock' each software activation file to a specific hardware device.

To prevent activations from failing unexpectedly at runtime, do not lock activations to virtual network adapters, such as those used for virtual private networks (VPN) or virtual machines. Instead, lock activations to the Host IDs of fixed devices such as hardware network adapters or hard disk serial numbers. If you need help determining which network adapters are virtual adapters, contact your Information Technology department.

For help at any point, click the Help link on FactoryTalk Manager software, or click the Help link on the Rockwell Software Activation website:

<https://activate.rockwellautomation.com/>.

For Rockwell Automation Technical Support in the U.S., call 1 (440) 646-3434. Outside the U.S., see <http://www.rockwellautomation.com/locations/>.

Notes:

FactoryTalk EnergyMetrix Groups and Security Setup

Introduction

In this chapter, you will set up domains and groups for an FactoryTalk EnergyMetrix project, and also assign user roles and privileges for accessing domains.

Examples are based on the [Efficient Industries Plant 1](#) example on page [108](#).

Before You Begin


- Determine business goals, complete energy assessment, and determine monitoring methods ([Chapter 1](#)).
- Select hardware and wire devices ([Chapter 2](#)).
- Configure data collection devices ([Chapter 3](#)).
- Install FactoryTalk EnergyMetrix software ([Chapter 4](#)).

What You Need

- FactoryTalk EnergyMetrix CD, catalog number 9307-FTEMMENE
- FactoryTalk EnergyMetrix online help and user manual, publication [FTEM-UM002](#).
- Energy Management Accelerator Toolkit CD, publication IASIMP-SP014, or visit the Integrated Architecture Tools and Resources website at <http://www.ab.com/go/iatools> to download toolkit files.

Follow These Steps

Follow these steps to create domains and groups, configure security, and configure devices and meters.



Creating Domains and Groups

The first step in configuring an FactoryTalk EnergyMetrix software project is to set up domains and groups based on your plant's departments, production areas, or energy types.


- **Group** - A named collection of devices and meters that represent a subdivision of your enterprise such as a department or process.
- **Domain** - A group that is assigned roles and users. Users assigned to a domain may only access objects assigned to that domain. This allows an administrator to restrict user access to specific parts of the system.

A typical setup is to organize meters into domain groups by energy type, substation, boiler room, or other function. A second domain is then set up to organize meters into energy accounting groups.

This quick start uses the [Efficient Industries Plant 1](#) example on page 108 to set up groups and domains in the FactoryTalk EnergyMetrix software. It organizes the plant's energy data from the Energy Data Worksheet into two functional subdomains and groups.

- **Engineering** - includes all of the energy data points and is subdivided into energy types for load profiling, consumption reporting, and power quality monitoring needs.
- **Accounting** - organized into production, and shipping/receiving departments for cost allocation analysis. This group also includes a utilities subgroup for nonproduction cost allocation analysis and utility shadow billing.

Efficient Industries Plant 1



Add a Parent Domain

You will now set up a parent domain for your project. Typically, this is the name you want to use for your system or plant configuration.

1. Click the System tab.
2. Select the Groups folder.
3. Click Add.



4. Enter the parent domain name.
For this example, enter Efficient Industries Plant 1.

Make sure to check
This group is a domain.

The domain name can also be
used for report titles.

5. Click Save.

The new plant domain appears in
the Groups folder.

 The screenshot shows the 'Add Group' dialog box. The 'Save' button is circled. The 'Parent group' dropdown is set to 'None'. The checkbox 'This group is a domain' is checked. The 'Name' field contains 'Efficient Industries Plant 1'. The 'Default log rate' is set to 15. The 'Reports title line 1' field also contains 'Efficient Industries Plant 1'. At the bottom, there are two sections: 'Meters Not Assigned to Group' and 'Meters Assigned to Group (Contribution factor %)', with a 'Contribution factor (%)' column header visible.


Add a Subdomain

Follow these steps to set up a new subdomain.


1. Select the parent domain under Groups.

In this example, the parent domain is Efficient Industries Plant 1.


2. Click Add to add a subdomain.



3. Create the subdomain.
 - a. Choose the parent domain from the Parent group pull-down menu.
 - b. Check This group is a domain.
 - c. Enter a subdomain name.
In this example, the subdomain name is Engineering.
 - d. Enter the report titles as shown.
4. Click Save.



You should see the new subdomain under the parent domain.



Add Subdomain Groups

Follow these steps to set up groups under a subdomain.

1. Select the subdomain under the parent domain.

In this example, the subdomain is Engineering.

2. Click Add to add a group to the subdomain.

The screenshot shows the 'Group Setup' dialog box. On the left is a tree view with 'System' selected, and 'Engineering' highlighted under 'Efficient Industries Plant 1'. The dialog box has tabs for 'System', 'Meters', 'Reports', and 'Custom'. It contains buttons for 'Edit', 'Add', and 'Delete'. The 'Parent group' is set to 'Efficient Industries Plant 1'. The 'Name' field contains 'Engineering'. The checkbox 'This group is a domain' is checked. The 'Default log rate' is set to 15. The 'Reports title line 1' is 'Engineering'.

3. Create the subdomain group.
 - a. Select the subdomain from the Parent group list.

- b. Clear the This group is a domain checkbox.
In this example, the groups under the Engineering subdomain do not require security. This is why the checkbox is cleared.

- c. Enter a name for the group.

For this example, the group name is Electricity.

- d. Enter the report titles as shown.

4. Click Save.

The screenshot shows the 'Add Group' dialog box. On the left is the same tree view as before, with 'Electricity' highlighted under 'Engineering'. The dialog box has buttons for 'Save' and 'Cancel'. The 'Parent group' is set to '-Engineering'. The 'Name' field contains 'Electricity'. The checkbox 'This group is a domain' is unchecked. The 'Default log rate' is set to 15. The 'Reports title line 1' is 'Efficient Industries Plant 1' and the 'Reports title line 2' is 'Engineering - Electricity'.

You should see the new group under the subdomain.


The screenshot shows the 'System Status' window. The tree view on the left shows 'System' selected, and 'Electricity' is now listed under 'Engineering' in the 'Efficient Industries Plant 1' group. The 'Electricity' group is circled in red.

5. Repeat steps 1...4 to add other groups to the subdomain.

For the Efficient Industries Plant 1 example, enter the groups:


- Air
- Fuels
- Steam
- Water

The Engineering group structure should look like this.



You are now ready to set up the Accounting subdomain under Efficient Industries Plant 1.

Follow the steps in [Add a Subdomain](#) on page 110 and [Add Subdomain Groups](#) on page 111 to complete the Accounting structure. When you are done, the domain and group structure should look like this.



IMPORTANT

The only difference in setting up the Accounting subdomain is that the groups require security. Security is assigned only at the domain level. Make sure this setting is checked. ☒ **This group is a domain**

Configuring Security

Security is used to restrict various levels of user access to a project on a need-to-know basis. For example, corporate users typically require only viewing access to plant summary data, where plant maintenance may require editing and viewing access to the engineering domain.

FactoryTalk EnergyMetrix software provides default roles and users to control access to parts of a project. You can optionally set up special roles and users.

- **Role** - A named collection of privileges assigned to a user to manage security. Roles may be global, where they apply to the entire FactoryTalk EnergyMetrix software system, or domain specific.
- **User** - A named set of security credentials, user name and password, that permit a user to access privileges of an assigned role. You can assign more than one role to a user.

Default Roles	Default User Name	Default Password
Admin	admin	admin
User	user	user
Guest	guest	guest

TIP It is recommended that you change the default password for the Admin user to prevent inadvertent changes to the database.

In addition to the FactoryTalk EnergyMetrix software default roles, the Efficient Industries Plant 1 example has three roles:

- **Engineering Manager** - This role has Admin privileges that are limited to the Engineering subdomain. Admin privileges allow a user to perform editing and viewing operations.
- **Accounting Manager** - This role has a subset of the Admin privileges that are limited to the Accounting subdomain.
- **Production 1 Manager** - This role has User privileges that are limited to the Production 1 subdomain. User privileges allow a user to perform read-only or viewing operations.

The [Roles and Privileges](#) table on page [114](#) provides a list of the roles and privileges assigned to each role.


Roles and Privileges

Privilege Name	Description	Default Roles			Engineering Manager	Accounting Manager	Production 1 Manager
		Admin	User	Guest			
View Groups	View the structure of the project	•	•	•	•	•	•
Edit Groups	Add, delete, and modify groups and domains	•			•		
View Users	View the list and properties of defined users	•	•		•	•	•
Edit Users	Add, delete, and modify users and their properties	•			•	•	
Overwrite Passwords	Change the password of other users	•			•	•	
View Roles	View the list and properties of defined roles	•	•		•	•	•
Edit Roles	Add, delete, and modify roles and their properties	•			•	•	
View Devices	View devices and their properties	•	•	•	•	•	•
Edit Devices	Add, delete, and modify devices and their properties	•			•		
View Meters	View meters and their properties	•	•	•	•	•	•
Edit Meters	Add, delete, and modify meters and their properties	•			•		
View Meter Tags	View meter tags and their properties	•	•	•	•	•	•
Edit Meter Tags	Add, delete, and modify meter tags and their properties	•			•		
View Alarm Subscript.	View alarm subscriptions	•			•		
Edit Alarm Subscript.	Add, delete, and modify alarm subscriptions	•			•		
Purge Alarms	Purge alarms	•			•		
Edit Units	Add, delete, and modify units, base units, and value types	•			•		
View Meter Data	View meter data in Summary, Trend, and Calendar Trend mode	•	•	•	•	•	•
Edit Meter Data	Edit logged meter data in database	•			•		
View Man. Meter Data	View meter data in Summary, Trend, and Calendar Trend mode	•	•	•	•	•	•
Edit Man. Meter Data	Input and modify manual meter data	•			•	•	
Purge Device Errors		•			•		
View Rate Schedules	View rate schedules	•	•		•	•	•
Edit Rate Schedules	Add, delete, and modify rate schedules/properties	•			•	•	
View Reports	View reports including edit start and end dates	•	•	•	•	•	•
Edit Reports	Add, delete, and modify reports and their properties	•			•	•	
View Custom Pages	View custom pages	•	•		•	•	•
Edit Custom Pages	Add, delete, and modify custom pages	•			•	•	
View Report Jobs	View the setup information for autorun report jobs	•	•		•	•	•
Edit Report Jobs	Create and edit autorun report jobs	•			•	•	
Purge Logged Data	Purge meter data from the database	•			•	•	
View Multi-purpose Report Scripts	View multipurpose report scrips	•	•		•	•	•
Edit Multi-purpose Report Scripts	Add, delete, and modify multipurpose report scripts	•			•	•	
Edit System Config		•			•	•	
View Alarms		•	•	•	•	•	•
Edit Alarms		•			•	•	
View Logged In Users		•			•	•	•
View Fiscal Calendars	View Fiscal Calendars and select fiscal periods for functions	•	•	•	•	•	•
Edit Fiscal Calendars	Add, delete, and modify fiscal calendars	•			•	•	

Create a Role and Assign Privileges

Follow these steps to create a role and assign privileges.

1. Click Roles and Users on the System tab.
2. Click Add.



3. Choose a domain from the Parent group pull-down menu.

For this example, choose Engineering.

4. Enter a role name.


For this example, enter Engineering Manager.

5. Assign all Admin privileges to the Engineering Manager by moving all privileges from the right pane to the left pane. Clicking the left double-arrow icon will move all privileges in one operation.

You can also move or assign individual privileges by using the single arrow icons. To select noncontiguous privileges, hold down the Ctrl key while making selections.

The Engineering Manager has Admin privileges, but only for the Engineering subdomain. Refer to page 114 for a list of Admin privileges.

6. Click Save.




You should see the Engineering Manager role under the Engineering subdomain.



7. Repeat steps 1...6 to add the Accounting Manager and Production 1 Manager roles.
 - The Accounting Manager will have a subset of the Admin privileges, but only for the Accounting subdomain.
 - The Production 1 Manager will only have User or viewing privileges for the Production 1 subdomain.

Refer to the [Roles and Privileges](#) table on page 114.

When done, you should see three roles defined.




Create a User and Assign Roles

Follow these steps to create a user and assign a role to that user.

1. Select a role.

In this example, click the Accounting Manager role just created.

2. Click the [Add User](#) link on the right.



3. Enter a user name and password for the new user.


In this example, the user name is Account 1.

4. Assign a role to the user by checking the appropriate role under User Roles.

In this example, the Accounting Manager role is assigned to the Account 1 user.

Enter other user information as necessary.

5. Click Save.



TIP You can assign more than one role to a user. For example, a user may have viewing (read-only) access to meters and published reports, but admin (read and write) access to a personal scratch-pad domain.


You should see the Account 1 user under the Accounting Manager role.

6. Repeat steps 1...5 to add additional users.

For this example, add two more users.

- Production 1
- Engineering 1

When done, Roles and Users should look like this.



Windows Active Directory Security

FactoryTalk EnergyMetrix software supports Windows Active Directory security. No configuration is required to use Active Directory / LDAP (Lightweight Directory Access Protocol). Simply create a user name in the format DomainName\UserName for logging into Windows.

The password fields and password button are displayed for Active Directory users, however, the password entered into the user setup will only be used if the user cannot be authenticated with the Active Directory server. When the user IS is authenticated against the Active Directory server, FactoryTalk EnergyMetrix software updates the password stored in the database to keep the passwords synchronized.

FactoryTalk EnergyMetrix Software Device Setup

Introduction

In this chapter, you will create and configure FactoryTalk EnergyMetrix software devices for your project.

Refer to the FactoryTalk EnergyMetrix tab in your Energy Data Worksheet for device class and device names in your project.

Examples are based on the [Efficient Industries Plant 1](#) example on page [108](#).

Before You Begin


- Determine business goals, complete energy assessment, and determine monitoring methods ([Chapter 1](#)).
- Select hardware and wire devices ([Chapter 2](#)).
- Configure data collection devices ([Chapter 3](#)).
- Install FactoryTalk EnergyMetrix software ([Chapter 4](#)).
- Configure groups and security in ([Chapter 5](#)).

What You Need

- FactoryTalk EnergyMetrix software CD, catalog number 9307-FTEMMENE
- RSLinx Classic software, version 2.5 or later
- FactoryTalk EnergyMetrix online help and user manual, publication [FTEM-UM002](#).
- Energy Management Accelerator Toolkit CD, publication IASIMP-SP014, or visit the Integrated Architecture Tools and Resources website at <http://www.ab.com/go/iatools> to download toolkit files.

Follow These Steps

Follow these steps to configure FactoryTalk EnergyMetrix devices including the power monitor, controller, and OPC Server device.



Overview of Devices

Devices are physical entities that FactoryTalk EnergyMetrix software communicates with over a network. Setting up a device in FactoryTalk EnergyMetrix software establishes communication and creates database definitions for the device.

Devices may be directly connected to the server over a network if the FactoryTalk EnergyMetrix server is also on the network through an appropriate network interface and you have configured the appropriate RSLinx Classic device drivers. Devices routed through a ControlLogix gateway or RSLinx Classic gateway are also considered directly connected devices.

Device Classes

FactoryTalk EnergyMetrix software uses device classes to determine how to interact with a particular device. The device class includes the device family, communication type, and specifies whether the device has a clock that can be synchronized. The device classes covered in this quick start include:

- PowerMonitor 1000 device
- PowerMonitor 3000 device
- PowerMonitor W250 device
- PowerMonitor 500 device
- PowerMonitor 5000 device
- ControlLogix controller
- OPC Server on Ethernet

For a complete list of device classes, refer to:

- FactoryTalk EnergyMetrix Software User Manual, publication [FTEM-UM002](#)
- FactoryTalk EnergyMetrix Online Help provided with FactoryTalk EnergyMetrix software

Configure Communication Drivers

Before setting up devices, you need to configure the drivers required for communication. This example uses the RSLinx Classic Ethernet driver for the PowerMonitor and ControlLogix devices, and the Kepware OPC driver for the Data Center device.


Configure RSLinx Ethernet Driver

Follow these steps to configure the RSLinx Classic Ethernet driver.


1. Open RSLinx Classic by clicking its icon in the Windows System Tray (SysTray).




2. Choose Configure Drivers from the Communications menu.



3. Choose Ethernet Devices from the pull-down menu.
4. Click Add New.




5. Click OK to accept the default driver AB_ETH-1.



6. Enter the IP address of your first device (Station).
7. Click Add New to enter the IP address for each additional device you want to add, then click OK.

In this example, you will enter eight IP addresses for:

- (1) PowerMonitor 3000 device.
 - (6) PowerMonitor 1000 devices.
 - (1) CompactLogix controller.
8. Click OK when done entering IP addresses.
 9. Click Close to exit the Configure Drivers dialog box.



Configure OPC Server


Before setting up devices and meters based on OPC servers, you need to configure an OPC server. This example uses the Kepware OPC driver for the Data Center device. For our example, the facility data center has an uninterruptible power supply (UPS) with a Modbus interface providing energy and real power demand data.

You may download KepServerEx V5 OPC server software and the Modbus communication driver suite from <http://www.kepware.com>. The Kepware server operates in full-featured demo mode for two hours. You may install and run KepServerEx V4 and V5 side-by-side on a single computer. Production use of Kepware server software requires that you purchase the applicable software and driver licenses.


Install the KepServerEx V5 software. Be sure to select the Simulation Suite during the installation.

Follow these steps to configure the OPC server after software is installed.

1. Open the Kepware KepServerEx V5 configuration.
2. Use the File menu to open the file `simdemo.opf` found in the default Projects folder.




3. Expand the `Channel_0_User_Defined` channel, then select the Ramp device.
Note the list of simulated data tags in the right pane.




Later in this document, you will set up a device, meter, and meter tag by using data from the tag `Channel_0_User_Defined.Ramp.Ramp4`.

4. To view this data now, launch the OPC Quick Client by clicking Quick Client in the toolbar.



5. When the Quick Client opens, drill into the channel, device and tags as shown.
Note the changing values of the data.



6. Exit from the Quick Client and the KepServerEx 5 configuration window.
You don't need to save changes.

Configure a PowerMonitor Device


Follow these steps to configure a PowerMonitor device.

1. Select the Devices folder on the System tab.

2. Navigate to and select the appropriate group or domain.

In this example, select the Electricity group under the Engineering subdomain.

3. Click the [Add a device](#) link.



4. Choose a subdomain or group from the Parent group list.

For this example, choose Electricity.

5. Check the boxes as shown.

The checkboxes vary by device type.

If the device will not be connected during configuration, clear the Enable device checkbox to avoid timeout errors.

6. Choose a device from the Device class list.

For this example, choose PowerMonitor 1000 (EM3) on EtherNet/IP.

7. Enter a name for the device.

For this example, enter Boiler House.

8. Enter the Time zone and Time sync interval.

Devices with internal clocks may be time-synched, such as power monitors and controllers.

9. Enter the communication path to the device.

For this example the communication path to the first PowerMonitor 1000 EM3 device is AB_ETH-1\10.10.10.1.


10. Modify other communication settings as needed.

For details, refer to the FactoryTalk EnergyMetrix software help.

11. Click Save.



You should see the Boiler House device under Electricity.



12. If the device is connected to the network, click Test Connection to verify communication with the device.




If you see connection failed, try again. If the test times out, check that you entered the correct communication path in step 2 and that the device is on line. Try to access the PowerMonitor's web page or try to ping it from the FactoryTalk EnergyMetrix server.

Copy Devices


Follow these steps to create additional devices by using the copy function. For the Efficient Industries Plant 1 example, you will use the copy function to create five remaining PowerMonitor 1000 devices (Power House, Production 1, Production 2, Shipping/Receiving/DC, MCC2).

1. Select an existing device, then click Copy.

For this example, select the Boiler House device.




2. Change the name of the copied device.
For this example, replace 'Copy of Boiler House' with Power House.
3. Change the Communication path to match the device for this example.
If the device will not be connected during configuration, clear the Enable device checkbox to avoid timeout errors.
4. Click Save.



You should see the Power House device under Electricity.


5. For this example, repeat steps 1...4 to copy the remaining PowerMonitor 1000 devices.



Change the name and communication path to each device as shown in the table. Note that all devices fall under the Electricity parent group except for the MCC 2 device that is under Fuels. For reference, see the [Efficient Industries Plant 1](#) example on page 108.

Parent Group	Name	Communication Path
Electricity	Production 1	AB_ETH-1\10.10.10.3
Electricity	Production 2	AB_ETH-1\10.10.10.4
Electricity	Shipping/Receiving/DC	AB_ETH-1\10.10.10.5
Fuels	MCC 2	AB_ETH-1\10.10.10.6

You should see six PowerMonitor 1000 devices and one PowerMonitor 3000 device under the appropriate groups.



Configure a CompactLogix Device


Follow these steps to configure a CompactLogix device.

1. Select the Devices folder on the System tab.

2. Navigate to and select the appropriate group or domain.

In this example, select the Fuels group under the Engineering subdomain.

3. Click the Add a device link.



4. Choose a subdomain or group from the Parent group list.

For this example, choose Fuels.

5. Check the boxes as shown.

The checkboxes vary by device type.

If the device will not be connected during configuration, clear the Enable device checkbox to avoid timeout errors.

6. Choose a device from the Device class list.

For this example, choose ControlLogix on Ethernet. You would make this selection for CompactLogix or ControlLogix.

7. Enter a device name.


For this example, L2x is entered.

8. Enter the Time zone and Time sync interval.

Devices with internal clocks may be time-synched, such as power monitors and controllers.

9. Enter the communication path to the device.

For this example, the communication path to the CompactLogix device is AB_ETH-1\10.10.10.7.



The 'Device Communications' dialog box contains the following fields:

- Communications path:** AB_ETH-1\10.10.10.7
- Comm. timeout (seconds):** 5
- Comm. retries:** 2

For a ControlLogix device, the path would also include a backplane address, for example, AB_ETH-1\10.10.10.7\Backplane\0, where the CPU is slot 0.

10. Modify other communication settings as needed.


For details, refer to the FactoryTalk EnergyMetrix software online help.

11. Click Save.



The 'Add Device' dialog box has two buttons: **Save** and **Cancel**.

You should see the L2x device under Fuels. Notice that the icon is a controller.



12. If the device is connected to the network, click Test Connection to verify communication with the device.

If you see connection failed, try again. If the test times out, check that you entered the correct communication path in step 2 and that the device is on line. Try to ping it from the FactoryTalk EnergyMetrix server.




The 'Test Connection' button is highlighted, and the status 'Connection successful' is displayed.


Configure OPC Server Device

Follow these steps to configure an OPC Server device.

1. Select the Devices folder.
2. Navigate to and select the desired group or domain.
For this example, select the Electricity group under the Engineering subdomain.
3. Click the [Add a device](#) link.




4. Choose a subdomain or group from the Parent group list.
For this example, choose Electricity.
5. Check the boxes as shown.
6. Choose a device from the Device class list.
For this example, choose OPC Server on Ethernet.
7. Enter a device name.
For this example, enter Data Center.
8. Enter the OPC server name.
For this example, the name is Kepware.KepServerEx.v5.
9. Click Save.



You should see Data Center under Electricity. The icon shows that the device is an OPC server.

All devices are now configured.



FactoryTalk EnergyMetrix Software Meter and Tag Setup

Introduction

In this chapter, you will create meters and assign meter tags for your FactoryTalk EnergyMetrix software project.

- A meter is a logical source of data to FactoryTalk EnergyMetrix software. It is the unit used for licensing FactoryTalk EnergyMetrix Manager software. Meters are associated with device data sources.
- A meter tag is the basic unit of data collection. Tags assigned to device meters are logged automatically at a selected log rate.

Refer to the FactoryTalk EnergyMetrix tab in your Energy Data Worksheet for meter information in your project including meter name, meter type, and meter tag names.

Meter configuration groups are based on the [Efficient Industries Plant 1](#) example on page [108](#).

Before You Begin


- Determine business goals, complete energy assessment, and determine monitoring methods ([Chapter 1](#)).
- Select hardware and wire devices ([Chapter 2](#)).
- Configure data collection devices ([Chapter 3](#)).
- Install FactoryTalk EnergyMetrix software ([Chapter 4](#)).
- Configure groups and security in ([Chapter 5](#)).
- Configure FactoryTalk EnergyMetrix devices in ([Chapter 6](#)).

What You Need

- FactoryTalk EnergyMetrix software CD, catalog number 9307-FTEMMENE
- FactoryTalk EnergyMetrix online help and user manual, publication [FTEM-UM002](#).
- Energy Management Accelerator Toolkit CD, publication IASIMP-SP014, or visit the Integrated Architecture Tools and Resources website at <http://www.ab.com/go/iatools> to download toolkit files.


Follow These Steps

Follow these steps to create meters and meter tags.



Creating Electric Meters for PowerMonitor Devices


You will now create a meter for a PowerMonitor device and assign tags to the meter. Examples are based on the [Efficient Industries Plant 1](#) groupings on page [108](#).



Create a PowerMonitor Electric Meter

Follow these steps to create a PowerMonitor electric meter.

1. Click the Meters tab.
2. Navigate to and select a group to assign the meter.
For this example, select Electricity under the Engineering subdomain.
3. Click the Meters tab on the right.
4. Click the Add a new meter link.



5. Select the Parent group.
For this example, select Electricity.
6. Choose the meter type.
For this example, choose Electric.
7. Choose the device associated with the meter.
For this example, choose Boiler House.
8. Enter a meter name.
For this example, enter Boiler House Meter.
9. Click Save.


Add a Meter

Save Cancel

Meter Information	
Parent group	--Electricity
Type	Electric
Device	Boiler House
Name	Boiler House Meter
Notes	
Time zone	(GMT-06:00) Central Time (US & Canada)

Assigned to Group: Electricity (100)

10. Confirm the meter was created in the correct group.




Assign Meter Tags to a PowerMonitor Electric Meter

You will now assign tags to a PowerMonitor electric meter. For this example, Real Energy Net, Reactive Energy Net, and Real Power Demand are assigned to the Boiler House Meter.

1. Select the meter to assign tags.

For this example, select Boiler House Meter.



2. Click the Meter Setup tab.
3. Click the [Add a new meter tag](#) link.

Domain/Meter: Engineering/Electricity/Boiler House Meter
Meter type: Electric Device class: Powermonitor 1000 (EM3)

Meter Data Trend Calendar Trend **Meter Setup**

Meter Setup

Edit Add Copy Delete

Meter Information

Type: Electric
Device: Boiler House
Name: Boiler House Meter
Notes:
Time zone: (GMT-06:00) Central Time (US & Canada)

Assigned to Groups (Contribution factor %)
Electricity (100)

Meter Tags

ID	Type	Name	Units	Log Rate	Address
Add a new meter tag					

4. Verify the Meter tag type is Device.
5. Choose Real Energy Net from the device tag list.

For a PowerMonitor device, the rest of the settings are autofilled.

Do not change the autofill values. Changing the values may prevent logging of the tag or cause incorrect data to be logged.

The log rate is set to the default log rate of meter's assigned group. It is typically the utility demand interval rate.

Refer to the FactoryTalk EnergyMetrix software help before changing the log rate or maximum consumption per hour.

6. Click Save.

Add a Meter Tag

Save Cancel

Meter tag type: Device
Real Energy Net

Meter tag name: Real Energy Net
Value type: Real Energy Net
Log rate: 15
Number of demand periods: 1
Address: 16:8
Tag format: Powermonitor 1000 Double Float
Unit: kWh
Number of decimals to display: 1
Scale: 1
Offset: 0
Log delta reading: ☐
Rollover value: 1000000000
Trend log parameter: 9
Max consumption per hour:

7. Click Add when the screen refreshes.




8. Repeat steps 4...7 to add the remaining tags:

- Reactive Energy Net
- Real Power Demand

These are typical tags for electric meters.

9. When done, click the [Return to meter screens](#) link or the meter tag.



The tags just entered should appear on the Meter Setup tab.

Domain/Meter: Engineering/Electricity/Boiler House Meter
 Meter type: Electric Device class: Power monitor 1000 (EM3)

[Meter Data](#) [Trend](#) [Calendar Trend](#) [Meter Setup](#)

Meter Setup

[Edit](#) [Add](#) [Copy](#) [Delete](#)

Meter Information

Type: Assigned to Groups (Contribution factor %):
 Device:
 Name:
 Notes:
 Time zone:

Meter Tags			Read device tags		Add a new meter tag	
ID	Type	Name	Units	Log Rate	Address	
4	Device	Real Energy Net	kWh	15 minutes	16.8	View
5	Device	Reactive Energy Net	kVARh	15 minutes	16.14	View
6	Device	Real Power Demand	kW	15 minutes	17.0	View

For this example, you should see these tags.

10. Click the Meter Data tab to verify that the meter data is being logged.

The data will not appear until the next logging interval has occurred.

Another way to check the data is to return to the Meter Setup tab and click the [Read device tags](#) link just above the list of meter tags.

You can click Current Date/Time to refresh the data.

Domain/Meter: Engineering/Electricity/Boiler House _Meter
 Meter type: Electric

[Meter Data](#) [Trend](#) [Calendar Trend](#) [Meter Setup](#)

Time zone:
 Date/Time: [Get Data](#) [Current Date/Time](#)
[< Page >](#) [Enter Data](#)


15-Min Auto Data

Date/Time	Reactive Energy Net (kVARh)	Real Energy Net (kWh)	Real Power Demand (kW)
8/26/2009 2:45:00 PM	295999.9	987213.4	516.5
8/26/2009 2:30:00 PM	295963.4	987084.3	526.9
8/26/2009 2:15:00 PM	295923.4	986952.6	537.7
8/26/2009 2:00:00 PM	295885.5	986818.1	544.6
8/26/2009 1:45:00 PM	295847.8	986682	519.7
8/26/2009 1:30:00 PM	295809	986552.1	508.8
8/26/2009 1:15:00 PM	295769.6	986424.9	550.4

Copy Meters and Tags


Meters with the same device class and tags can be copied. It's a real time saver to create the first meter and its tags, then use the copy function to create the rest of the meters.

For the [Efficient Industries Plant 1](#) example, the PowerMonitor 1000 electric meters all use the Real Energy Net, Reactive Energy Net, and Real Power Demand tags. You will copy the Boiler House meter and tags to create the Power House, Production 1, Production 2, and Shipping/Receiving/DC electric meters. The tags are copied with the meter.



1. Select the meter to copy.

For this example, select Boiler House under the Electricity group.



2. Click the Meter Setup tab.

3. Click Copy.

A copy of the meter is created under the selected group with the name 'Copy of Boiler House Meter'.

Domain/Meter: Engineering/Electricity/Boiler House _Meter
Meter type: Electric

Meter Data | Trend | Calendar Trend | **Meter Setup**

Meter Setup

Edit | Add | **Copy** | Delete

Meter Information

Type: Electric
Device: None
Name: Boiler House _Meter
Notes:
Time zone: (GMT-05:00) Eastern Time (US & Canada)

Assigned to Groups (Contribution factor %)
Electricity (100)

Meter Tags

ID	Type	Name	Units	Log Rate	Address
44	Derived	Real Energy Net	KWh	15 minutes	View
45	Derived	Real Power Demand	KW	15 minutes	View
49	Derived	Reactive Energy Net	KVARh	15 minutes	View

[Add a new meter tag](#)

4. Change the device to Power House.

5. Change the meter name to Power House Meter.

6. Click Save.

The copied meter and its tags are created under the Electricity group with the new name.

7. Repeat steps 1...6, copy the rest of the PowerMonitor 1000 electric meters.

Domain/Meter: Engineering/Electricity/Copy of Boiler House Meter
Meter type: Electric Device class: Powermonitor 1000 (EM3)

Meter Data | Trend | Calendar Trend | **Meter Setup**

Edit Meter

Save | Cancel

Meter Information


Type: Electric
Device: Power House
Name: Power House Meter
Notes:
Time zone: (GMT-06:00) Central Time (US & Canada)

Assigned to Groups (Contribution factor %)
Electricity (100)

The Real Energy Net, Reactive Energy Net, and Real Power Demand tags are automatically copied with each device. Change the device name and meter name as shown in the table.

Meter	Parent Group	Device	Name
Production 1	Electricity	Production 1	Production 1 Meter
Production 2	Electricity	Production 2	Production 2 Meter
Shipping/Receiving/DC	Electricity	Shipping/Receiving/DC	Shipping/Receiving/DC Meter

For the [Efficient Industries Plant 1](#) example, the electric meter listing should look like this.




TIP Remember that the device class must be the same in the source and copied meters, otherwise the meter tag addressing will be incorrect in the copied meter.

Creating Energy Meters for PowerMonitor Status Inputs

You will now create energy meters for PowerMonitor status inputs and assign tags to the meters.

For the [Efficient Industries Plant 1](#) example, you will create a gas main, air flow, and water main meter, then assign tags to each meter.




Create Energy Meters

Follow these steps to create a fuel meter for a PowerMonitor 1000 status input.

1. Click the Meters tab.
2. Navigate to and select a group to assign the meter.

For this example, select Fuels under the Engineering subdomain.
3. Click the Meters tab on right.
4. Click the Add a new meter link.



5. Choose the Parent group.

For this example, choose Fuels.
6. Choose the meter type.

For this example, choose Gas.


If the meter type you want to use is not in the standard list of meter types, you can create custom meters. Refer to [Appendix A](#).
7. Choose the device associated with the meter.

For this example, choose MCC 2.
8. Enter a meter name.

For this example, enter Gas Main Meter.
9. Click Save.

Add a Meter

10. Confirm the meter was created in the correct group.




11. Repeat steps 1...10 to create the rest of the energy meters that are assigned to PowerMonitor status inputs.

For this example, enter the data in the table for the Air Flow and Water Main meters. Make sure to create each meter under the correct parent group.

Meter	Parent Group	Meter Type	Device	Name
Air Flow	Air	Air	Production 2	Air Flow Meter
Water Main	Water	Water	MCC 2	Water Main Meter

For the [Efficient Industries Plant 1](#) example, the meter listing should look like this.



Verify Units and Value Types

To create tags for meters, the appropriate base units and value types that will be used by the tags must be available. FactoryTalk EnergyMetrix software provides the most common value types and units.

Refer to [Appendix B](#) for details on how to check if the value types and base units you need are in the FactoryTalk EnergyMetrix software default list, and how to create them if necessary.

For the [Efficient Industries Plant 1](#) example, the gas main, air flow, and water main meters require custom units and value types not in the FactoryTalk EnergyMetrix software default list. The table shows the base units, units, and value types required.

Meter Type	Value Type	Base Unit	Unit
Gas Main Meter	Natural Gas Usage	thm	thm
Water Main Meter	Water Usage	Gal	Gal
Air Flow Meter	Air Usage	cf	Cf

Assign Meter Tags to Status Inputs

You will now assign meter tags to energy meters from a PowerMonitor status input.

For the [Efficient Industries Plant 1](#) example, you will assign tags to the Gas Main, Water Main, and Air Flow meters.

1. Select the meter.

For this example, select Gas Main Meter.

2. Click the Meter Setup tab.
3. Click the [Add a new meter tag](#) link.

System | Meters | Reports | Custom

Layout: Save Restore Collapse

Efficient Industries Plant 1

- Accounting
- Engineering
 - Air
 - Electricity
 - Fuels
 - Boiler House Gas Meter
 - Fuel Oil Meter
 - Gas Main Meter**
 - Propane Meter
 - Steam
 - Water

Domain/Meter: Engineering/Fuels/Gas Main Meter
 Meter type: Gas Device class: Powermonitor 1000 (EM3)

Meter Data | Trend | Calendar Trend | **Meter Setup**

Meter Setup

Edit Add Copy Delete

Meter Information

Type: Gas
 Device: MCC 2
 Name: Gas Main Meter
 Notes:
 Time zone: (GMT-06:00) Central Time (US & Canada)

Assigned to Groups (Contribution factor %)
 Fuels (100)

Meter Tags [Add a new meter tag](#)

4. Verify the meter tag type is Device.
5. Choose a status input counter from the device tag list.

For this example, Status Input 1 Counter is chosen because the Gas Main Meter is connected to the MCC 2 PowerMonitor 1000 status input 1.

6. Change the Meter tag name.

For this example, enter Natural Gas Usage (status input 1).

7. Choose the Value type.

For this example, choose Natural Gas Usage.

8. Accept the default Scale, Offset, and Rollover values.

When using a PowerMonitor 1000 device, it is good practice to set the pulse counter scaling factor in the power monitor advanced setup menu. The meter tag setup then uses the default scale and rollover value.

9. Accept the other default settings.

For a power monitor device, the remaining settings are autofilled.

Do not change the autofill values. Changing the values may prevent logging of the tag or cause incorrect data to be logged.

The log rate is set to the default log rate of meter's assigned group. It is typically the utility demand interval rate. Refer to the FactoryTalk EnergyMetrix software help before changing the log rate or maximum consumption per hour.

10. Click Save.

11. When done, click the [Return to meter screens](#) link.

Add a Meter Tag

Save Cancel

Meter tag type Device

Status Input 1 Counter

Meter tag name Natural Gas Usage

Value type Natural Gas Usage

Log rate 15

Number of demand periods 1

Address 16:0

Tag format Powermonitor 1000 Double Float

Unit thm

Number of decimals to display 2

Scale 1

Offset 0

Log delta reading ☐

Rollover value 1000000000

Trend log parameter 5

Max consumption per hour

Return to meter screens

Add a Meter Tag

Save Cancel

The tag just entered should appear on the Meter Setup tab.

Domain/Meter: Engineering/Fuels/Gas Main Meter
 Meter type: Gas Device class: Powermonitor 1000 (EM3)

Meter Data Trend Calendar Trend **Meter Setup**

Meter Setup

Edit Add Copy Delete

Meter Information

Type: Gas
 Device: MCC 2
 Name: Gas Main Meter
 Notes:
 Time zone: (GMT-06:00) Central Time (US & Canada)

Assigned to Groups (Contribution factor %)
 Fuels (100)

ID	Type	Name	Units	Log Rate	Address	
20	Device	Natural Gas Usage	thm	15 minutes	16:0	View

For this example, you should see this tag.

12. Click the Meter Data tab to verify that the meter data is being logged.

The data will not appear until the next logging interval has occurred.

Another way to check the data is to return to the Meter Setup tab and click the [Read device tags](#) link just above the list of meter tags.

You can click Current Date/Time to refresh the data.

Domain/Meter: Engineering/Fuels/Gas Main _Meter
 Meter type: Gas

Meter Data Trend Calendar Trend Meter Setup

Time zone: (GMT-06:00) Central Time (US & Canada)

Date/Time: 8/28/2009 11:29 AM [Get Data](#) [Current Date/Time](#)

< Page > Enter Data

15-Min Auto Data

Date/Time	Natural Gas Usage (thm)
8/28/2009 11:15:00 AM	147.5
8/28/2009 11:00:00 AM	139.06
8/28/2009 10:45:00 AM	130.36
8/28/2009 10:30:00 AM	121.55
8/28/2009 10:15:00 AM	113.05
8/28/2009 10:00:00 AM	104.38
8/28/2009 9:45:00 AM	95.84
8/28/2009 9:30:00 AM	87.62

13. Repeat steps 1...12 to assign other energy meter tags to PowerMonitor status inputs.

Refer to the Energy Data Worksheet for the appropriate meter tag names.

For the [Efficient Industries Plant 1](#) example, you will assign meter tags to the Air Flow and Water Main meters by using the information in the table.

Meter Name	Meter Tag	Meter Tag Name	Value Type
Air Flow Meter	Status Input 1 Counter	Air Usage	Air Usage
Water Main Meter	Status Input 2 Counter	Water Usage	Water Usage


TIP

If you use a PowerMonitor 3000 device as a pulse meter input, the setup is different. The PowerMonitor provides a raw pulse count that rolls over at 30,000. In the meter tag setup, set the Scale factor to the value in engineering units of each 0-to-1 transition of the meter pulse. Set the rollover value equal to the product of scale factor x 30,000.

Creating Energy Meters for CompactLogix Devices

You will now create energy meters for a CompactLogix (L2x) controller analog or digital inputs.


For the [Efficient Industries Plant 1](#) example, you will create energy meters for one L2x digital input and three L2x analog inputs.



Create Energy Meters

Follow these steps to create an energy meter for an L2x digital or analog input.

1. Click the Meters tab.
2. Navigate to and select a group to assign the meter.
For this example, select Fuels under Engineering.
3. Click the Meters tab.
4. Click Add a new meter.



5. Choose the Parent group.

For this example, choose Fuels.

If the meter type you want to use is not in the standard list of meter types, you can create custom meters. Refer to [Appendix A](#).

6. Choose the meter type.

For this example, choose Gas.

7. Choose the device associated with the meter.

For this example, choose L2x.

8. Enter a meter name.

For this example, enter Boiler House Gas Meter.

9. Click Save.

Add a Meter

Save Cancel

Meter Information

Parent group: --Fuels

Type: Gas

Device: L2x

Name: Boiler House Gas Meter

Notes:


Time zone: (GMT-06:00) Central Time (US & Canada)

Assigned to Groups (Contrib): Fuels (100)

10. Confirm the meter was created in the correct group.

11. Repeat steps 1...10 to create other energy meters for the L2x analog or digital inputs.

If the meter type you want to use is not in the standard list of meter types, you can create custom meters. For this example, you will have to create custom meter types for the Fuel Oil and Propane meters. Refer to [Appendix A](#) for details.



For the [Efficient Industries Plant 1](#) example, create the Fuel Oil, Propane, and Steam Flow Meters. Enter the data shown in the table for each meter. Make sure to create the meter under the correct parent group.

Meter	Parent Group	Type	Device	Name
Fuel Oil Meter	Fuels	Fuel Oil	L2x	Fuel Oil Meter
Propane Meter	Fuels	Propane	L2x	Propane Meter
Steam Flow Meter	Steam	Steam	L2x	Steam Flow Meter

Verify Units and Value Types

To create tags for meters, the appropriate base units and value types that will be used by the tags must be available. FactoryTalk EnergyMetrix software provides the most common value types and units.

Refer to [Appendix B](#) for details on how to check if the value types and base units you need are in the FactoryTalk EnergyMetrix software default list, and how to create them if necessary.

For the [Efficient Industries Plant 1](#) example, the natural gas, fuel oil, propane, and steam meters require units and value types not in the FactoryTalk EnergyMetrix software default list. The table shows the base units, units, and value types required.

Meter	Meter Type	Value Type	Base Unit	Unit
Boiler House Gas Meter	Natural Gas	Natural Gas Usage ⁽¹⁾	cf ⁽¹⁾	cf ⁽¹⁾
Fuel Oil Meter	Fuel Oil	Fuel Oil Usage	Gal	Gal
Propane Meter	Propane	Propane Usage	Gal	Gal
Steam Flow Meter	Steam Flow	Steam Usage	lb	lbs

(1) Natural Gas units and value type was created earlier when the Gas Main meter was configured.


Assign Meter Tags to CompactLogix Inputs

You will now assign meter tags to energy meters from CompactLogix digital and analog inputs.

For the [Efficient Industries Plant 1](#) example, you will assign tags to the Boiler House Gas, Fuel Oil, Propane, and Steam meters.

Follow these steps to assign a tag to an energy meter from an L2x digital or analog input.

1. Select the meter.
For this example, select Boiler House Gas Meter.
2. Click the Meter Setup tab.
3. Click the [Add a new meter tag](#) link.



System | Meters | Reports | Custom

Layout: [Save](#) [Restore](#) [Collapse](#)

Efficient Industries Plant 1

- Accounting
- Engineering
 - Air
 - Electricity
 - Fuels
 - Boiler House Gas Meter**
 - Fuel Oil Meter
 - Gas Main Meter
 - Propane Meter
 - Steam
 - Water

Domain/Meter: Engineering/Fuels/Boiler House Gas Meter
Meter type: Gas Device class: ControlLogix

Meter Data | Trend | Calendar Trend | **Meter Setup**

Meter Setup

Edit Add Copy Delete

Meter Information

Type: Gas
Device: L2x
Name: Boiler House Gas Meter
Notes:
Time zone: (GMT-06:00) Central Time (US & Canada)

Assigned to Groups (Contribution factor %)

Fuels (100)

Meter Tags

[Read device tags](#) [Add a new meter tag](#)

4. Verify the Meter tag type is Device.

5. Change the Meter tag name.

For this example, enter Boiler House Natural Gas Usage.

6. Choose a Value type.

For this example, choose Natural Gas Usage.

7. Verify the log rate.

The log rate is set to the default log rate of meter's assigned group. It is typically the utility demand interval rate. Refer to the FactoryTalk EnergyMetrix software help for details.

8. Enter an L2x controller address.

Refer to the Energy Data Worksheet for the L2x PLC-5 type address.

FactoryTalk EnergyMetrix software communicates with PLC-5 or SLC 500 mapped tags in ControlLogix controllers so the address format is Fx:x.

In this example, the Boiler House Gas meter tag, Boiler House Natural Gas Usage, is assigned to the PLC-5 tag F10:0.

This F10:0 tag is then mapped to the L2x_EnergyTotals [0] tag in the ControlLogix controller as configured on page 86.

9. Choose a tag format.

For this example, choose 32-bit Floating Point for this analog tag.

10. Fill in the appropriate scale and offset values.

For this example, the scale is 1 and the offset is 0 because the energy Add-On Instruction has already scaled the tag units.

11. Enter appropriate rollover value, which is 10 million when using the energy Add-On Instructions.

12. Click Save.

13. When done, click the [Return to meter screens](#) link or the meter tag.

Add a Meter Tag

Save Cancel

Meter tag type Device

Meter tag name Boiler House Natural Gas Usage

Value type Natural Gas Usage

Log rate 15

Number of demand periods 1

Address F10:0

Tag format 32-bit Floating Point

Unit thm

Number of decimals to display 2

Scale 1

Offset 0

Log delta reading ☒

Rollover value

Trend log parameter

Max consumption per hour

[Return to meter screens](#)

Add a Meter Tag

Save Cancel

The tag just entered should appear on the Meter Setup tab.

Domain/Meter: Engineering/Fuels/Boiler House Gas Meter
Meter type: Gas Device class: Control only

Meter Data Trend Calendar Trend **Meter Setup**

Meter Setup

Edit Add Copy Delete

Meter Information

Type: Gas
Device: L2x
Name: Boiler House Gas Meter
Notes:
Time zone: (GMT-06:00) Central Time (US & Canada)

Assigned to Groups (Contribution factor %)
Fuels (100)

Meter Tags

ID	Type	Name	Units	Log Rate	Address	
56	Device	Boiler House Natural Gas Usage	thm	15 minutes	F10:0	View

Read device tags Add a new meter tag

For this example, you should see these tags.

14. Click the Meter Data tab to verify that the meter data is being logged.

The data will not appear until the next logging interval has occurred.

Another way to check the data is to return to the Meter Setup tab and click the [Read device tags](#) link just above the list of meter tags.

You can click Current Date/Time to refresh the data.

Domain/Meter: Engineering/Fuels/Boiler House Gas _Meter
Meter type: Gas

Meter Data Trend Calendar Trend Meter Setup

Time zone: (GMT-06:00) Central Time (US & Canada)
Date/Time: 8/28/2009 11:29 AM Get Data Current Date/Time
< Page > Enter Data

15-Min Auto Data

Date/Time	Natural Gas Usage (thm)
8/28/2009 11:15:00 AM	117.08
8/28/2009 11:00:00 AM	110.68
8/28/2009 10:45:00 AM	104
8/28/2009 10:30:00 AM	97.19
8/28/2009 10:15:00 AM	90.72
8/28/2009 10:00:00 AM	84.06
8/28/2009 9:45:00 AM	77.55
8/28/2009 9:30:00 AM	71.37
8/28/2009 9:15:00 AM	64.34
8/28/2009 9:00:00 AM	58.1
8/28/2009 8:45:00 AM	51.5

15. Repeat steps 1...14 to assign other energy meter tags to L2x analog or digital inputs.

Refer to the Energy Data Worksheet for the appropriate meter tag names.


For this [Efficient Industries Plant 1](#) example, you will assign meter tags to the Fuel Oil, Propane, and Steam Flow meters by using the information in the table.

Meter Name	Meter Tag Name	Value Type	Address	Tag Format	Roller value
Fuel Oil Meter	Fuel Oil Usage	Fuel Oil Usage	F10:1	32-bit Floating Point	10,000,000
Propane Meter	Propane Usage	Propane Usage	F10:2	32-bit Floating Point	10,000,000
Steam Flow Meter	Steam Usage	Steam Usage	F10:3	32-bit Floating Point	10,000,000

Creating Energy Meters for OPC Server Device

You are now ready to create an energy meter for the OPC Server device and assign tags to the meter.

For the [Efficient Industries Plant 1](#) example, you will create a Data Center meter for the OPC Server.




Create Energy Meter

1. Click the Meters tab.
2. Navigate to and select a group to assign the meter.

For this example, select Electricity under the Engineering subdomain.

3. Click the Meters tab on the right.
4. Click Add a new meter.



5. Choose the Parent group.
For this example, choose Electricity.

6. Choose the meter type.
For this example, choose Electric.

7. Choose the device associated with the meter.
For this example, choose Data Center.

8. Enter a meter name.

For this example, enter Data Center Meter.

9. Enter the access path of the OPC Server.

For this example, Channel_0_User_Defined was entered, which is the same as the Kepware channel name.

10. Click Save.


Add a Meter

Meter Information	
Parent group	--Electricity
Type	Electric
Device	Data Center
Name	Data Center Meter
Notes	
Time zone	(GMT-06:00) Central Time (US & Canada)
Access path	Channel_0_User_Defined

Assigned to Groups (Contribution factor)
Electricity (100)

11. Confirm the meter was created in the correct group.

For the [Efficient Industries Plant 1](#) example, the electric meter listing should look like this.



Assign Meter Tags to OPC Device

You will now assign meter tags to an OPC server.

For the [Efficient Industries Plant 1](#) example, you will assign only the Real Energy Net meter tag to the Data Center (OPC Server) for logging consumption.

1. Select the meter.
For this example, select Data Center (OPC Server).
2. Click the Meter Setup tab.
3. Click the [Add a new meter tag link](#).



4. Verify the Meter tag type is Device.
5. Enter Real Energy Net as the name.
6. Choose Real Energy Net as the value type.
7. Set the Log rate to 1 minute.
8. Enter the OPC server data address.
For this example, enter ramp.ramp.4
9. Set the Tag format to 32-bit Floating Point.
10. Check the Log delta reading checkbox. This is an example of a tag whose value represents the consumption during the logging interval. Leave the Rollover value blank.
11. Click Save.

Meter Tag Setup

Edit Add Delete

Meter tag type: Device

Meter tag name: Real Energy Net

Value type: Real Energy Net

Log rate: 1 ☐ Log on change-of-state

Conditional logging expression:

Number of demand periods: 1

Address: ramp.ramp.4

Tag format: 32-bit Floating Point

Unit: kWh

Number of decimals to display: 1

Scale: 1

Offset: 0

Log delta reading: ☒

Rollover value:

Trend log parameter:

Max consumption per hour:

12. When done, click the [Return to meter screens](#) link or the meter tag.

[Return to meter screens](#)

Add a Meter Tag

Save Cancel

The tag just entered appears on the Meter Setup tab.

Meter type: Electric Device class: OPC Server

Meter Data Trend Calendar Trend **Meter Setup**

Meter Setup

Edit Add Copy Delete

Meter Information

Type: Electric

Device: Data Center

Name: Data Center Meter

Notes:

Time zone: (GMT-06:00) Central Time (US & Canada)

Access path: Channel_0_User_Defined

Assigned to Groups (Contribution factor %)

Data Center (100)

Electricity (100)

ID	Type	Name	Units	Log Rate	Address	Add a new meter tag
19	Device	Real Energy Net	kWh	1 minute	ramp.ramp4	View

For this example, you should see this tag.

13. Click the Meter Data tab to verify that the meter data is being logged.

The data will not appear until the next logging interval has occurred.

Another way to check the data is to return to the Meter Setup tab and click the [Read device tags](#) link just above the list of meter tags.

You can click Current Date/Time to refresh the data.

Domain/Meter: Engineering/Electricity/Data Center _Meter

Meter type: Electric

Meter Data Trend Calendar Trend Meter Setup

Time zone: (GMT-06:00) Central Time (US & Canada)

Date/Time: 8/28/2009 12:01 PM [Get Data](#) [Current Date/Time](#)

< Page > Enter Data

15-Min Auto Data

Date/Time	Reactive Energy Net (kVARh)	Real Energy Net (kWh)	Real Power Demand (kW)
8/28/2009 11:45:00 AM	494.6	2462.8	505.8
8/28/2009 11:30:00 AM	469.8	2336.3	494.8
8/28/2009 11:15:00 AM	444.2	2212.6	489.5
8/28/2009 11:00:00 AM	417.1	2090.3	490
8/28/2009 10:45:00 AM	394.1	1967.8	508.2
8/28/2009 10:30:00 AM	371.5	1840.7	496.5
8/28/2009 10:15:00 AM	349.5	1716.6	499.9

Sharing and Moving Meters


You can assign a meter to multiple groups, move a meter from one group to another, or apportion a meter among different groups or domains.

Sharing Meters Between Groups and Domains

You will now learn how to assign a meter to multiple groups, so it is shared, or apportion a meter among different groups or domains for running billing and cost allocation reports.

For the [Efficient Industries Plant 1](#) example, meters in the Engineering subdomain will be shared by the Accounting subdomain.

1. On the System tab, navigate to a group or domain that will share the meter.
In this example, navigate to and select Data Center in the Accounting subdomain.
2. In Group Setup, click Edit.



3. Select the meters to share.

In this example, select the Data Center meter in the Meters Not Assigned to Group and click the right arrow to assign it.

Edit Group

Save Cancel

Parent group: -Accounting

☒ This group is a domain

Name: Data Center

Notes:

Default log rate: 15

Reports title line 1: Efficient Industries Plant 1

Reports title line 2: Accounting - Data Center

Meters Not Assigned to Group	Meters Assigned to Group (Contribution factor %)
Air Flow Meter	
Boiler House Gas Meter	
Boiler House Meter	
Data Center Meter	
Electric Main Meter	
Fuel Oil Meter	
Gas Main Meter	
Power House Meter	

4. With the meter selected in the Meters Assigned to Group, enter a Contribution Factor between 0...100%.

For this example, accept 100% as the default contribution factor.

You can share portions of the total meter data with multiple groups. For example, an electric meter feeding two production lines may apportion 60% of the total power to production line 1 and 40% to production line 2. You would set the Contribution Factor to 60% and 40%, respectively.

5. Click Save Factor if you modify the Contribution Factor.

Edit Group

Save Cancel

Parent group: -Accounting

☒ This group is a domain

Name: Data Center

Notes:

Default log rate: 15

Reports title line 1: Efficient Industries Plant 1

Reports title line 2: Accounting - Data Center

Meters Not Assigned to Group	Meters Assigned to Group (Contribution factor %)
Air Flow Meter	
Boiler House Gas Meter	
Boiler House Meter	
Data Center Meter (100)	
Electric Main Meter	
Fuel Oil Meter	
Gas Main Meter	
Power House Meter	
Production 1 Meter	
Production 2 Meter	

Contribution factor (%)

100

Save Factor

Cancel

TIP Use caution before assigning fixed percentages of meters to groups for cost allocation. If and when actual conditions differ from the assigned percentages, reports will provide incorrect data.

6. Click Save at the top of the Edit Group.


You should see the meter in the Meters Assigned to Group with the contribution factor.

7. Repeat steps 1...6, for all the groups and subdomains that will share meters.

In this example, all the subdomains and groups under Accounting will share meters with the Engineering subdomain.

All the meters will have a contribution factor of 100% except for those within the Shipping/Receiving subdomain.

For this example, the Data Center (OPC Server) meter is assigned a contribution factor of -100%. This is set up for a cost allocation report where electrical consumption of the Shipping/Receiving area is equal to 100% of the Shipping/Receiving/DC meter minus 100% of the Data Center meter.



Moving Meters Between Groups and Domains

You will now learn how to move a meter and its data from one group to another. This is useful if you need to reassign one or more meters after initial configuration. The procedure is to assign the meter to the new target group, then unassign the meter from its initial group.


TIP When moving a meter, do not use the copy and delete meter functions. The copy function will not copy meter data. The delete function will delete the meter from all groups to which it is assigned and permanently remove all existing meter data.

Follow these steps to move a meter from one group to another.

1. Click the System tab.
2. Open the Group folder and select the target group or domain where you want to move the meter.

For this example, the New Meter Group is selected.

3. Click Edit.



4. Select a meter from the Meters Not Assigned to Group that you want to move to the target group or domain, then click the right arrow.

You should see the meter in the Meters Assigned to Group.

5. Click Save.

6. Select the initial group to which the meter was assigned.

For this example, Initial Meter Group is selected.

7. Click Edit.

TIP You cannot unassign a meter from a group if it is the only group to which the meter is assigned.

8. Unassign the meter by clicking the left arrow to move the meter to the Meters Not Assigned to Group.
9. Click Save.

Edit Group

Save Cancel

Parent group: None

☒ This group is a domain

Name: Initial Meter Group

Notes:

Default log rate: 15

Reports title line 1:

Reports title line 2:

Meters Not Assigned to Group	Meters Assigned to Group (Contribution factor %)
Air Flow _Meter Air Flow Meter Boiler House _Meter Boiler House Gas _Meter Boiler House Gas Meter Boiler House Meter Data Center _Meter Data Center Meter Electric Main _Meter	Electric Meter Example (100) Contribution factor (%) 100 Save Factor Cancel

Now that the meter is unassigned to the initial meter group, you can optionally delete the group if it's not needed.

System Meters Reports Custom

Layout: Save Restore Collapse

- System Status
- Groups
 - Efficient Industries Plant 1
 - Efficient Industries Plant 1
 - Initial Meter Group
 - New Meter Group
- Devices
- Roles and Users
- Rate Schedules
- Multi-Purpose Report Scripts
- Alarm Setup
- Unit Setup
- Configuration
- System Configuration Report
- My User Settings
- About

Group Setup

Edit Add Delete

Parent group: None

☒ This group is a domain

Name: Initial Meter Group

Notes:

Default log rate: 15

Reports title line 1:

Reports title line 2:

Meters Assigned to Group (Contribution factor %)

TIP

You cannot unassign a meter from a group if it is the only group to which the meter is assigned.

Notes:

FactoryTalk EnergyMetrix Software Alarm Setup

Introduction

In this chapter, you will learn how to configure, edit and view FactoryTalk EnergyMetrix software alarms.

Before You Begin


- Determine business goals, complete energy assessment, and determine monitoring methods ([Chapter 1](#)).
- Select hardware and wire devices ([Chapter 2](#)).
- Configure data collection devices ([Chapter 3](#)).
- Install FactoryTalk EnergyMetrix software ([Chapter 4](#)).
- Configure groups and security in ([Chapter 5](#)).
- Configure FactoryTalk EnergyMetrix software devices in ([Chapter 6](#)).
- Configure meters and tags in ([Chapter 7](#)).

What You Need

- FactoryTalk EnergyMetrix software CD, catalog number 9307-FTEMMENE
- FactoryTalk EnergyMetrix online help and user manual, publication [FTEM-UM002](#).
- Energy Management Accelerator Toolkit CD, publication IASIMP-SP014, or visit the Integrated Architecture Tools and Resources website at <http://www.ab.com/go/iatools> to download toolkit files.

Follow These Steps

Follow these steps to configure, view, and edit alarms.



Overview of Alarms

FactoryTalk EnergyMetrix alarms operate on events or conditions. You can define one or more alarms per meter tag. When alarms occur, they are displayed in an alarm summary page and entered into an alarm log. You can send emails or run reports when alarms are triggered.


When configuring an alarm, you can specify an analog or digital trigger.

- Analog triggers have a high and low threshold value that can activate an alarm inside or outside the threshold value range.
- Digital triggers are either equal or not equal. Digital alarms may also be triggered by any change in a meter tag value.

Configure an Analog Alarm

Follow these steps to configure an analog alarm.

1. Click the Meters tab and navigate to the meter you want to assign an alarm.
For this example, assign the alarm to the Electric Main Meter under the Electricity group.
2. Click the Meter Setup tab.
3. Click the [Add a new alarm](#) link.



4. Enter an Alarm Name.

For this example, enter High Demand.

5. Choose a Meter Tag.

For this example, choose Real Power Demand.

6. Choose the Alarm Severity.

For this example, choose Critical Alarm.

7. Enter a message for the alarm.

8. Check the email checkboxes if you want to send emails when the alarm is triggered or cleared.

Refer to page 170 for details on how to [Configure Email Alarm Subscriptions](#).

9. Select the trigger type.

For this example, select Analog.

10. Enter the high and low thresholds for the alarm trigger value.

For this example, enter 300 and 0.

11. Select the trigger range for the alarm.

- Alarm on outside - triggers the alarm when the meter tag value is outside of the high and low threshold range. For this example, the alarm will trigger if the tag value is >300 or <0.
- Alarm on inside - triggers the alarm when the meter tag value is between the high and low threshold value. For this example, the alarm will trigger if the tag value is < 300 or >0.

12. Click Save.

Add a Alarm

The screenshot shows the 'Add a Alarm' dialog box. At the top, there are 'Save' and 'Cancel' buttons. The 'Alarm Information' section includes:

- ☒ Enabled
- Alarm Name:** High Demand
- Meter Tag:** Real Power Demand (selected from a dropdown)
- Alarm Severity:** Critical Alarm (selected from a dropdown)
- Message:** Electric Demand approaching high level. (text area)
- ☒ Send email on trigger
- ☒ Send email on clear

 The 'Trigger Settings' section includes:

- ☒ **Analog**
 - High threshold: 300
 - Low threshold: 0
- ☐ **Digital**
 - ☒ On
 - ☐ Off
 - ☐ Changes to On
 - ☐ Changes to Off
 - ☐ Any Change
- Range:**
 - ☒ Alarm on outside
 - ☐ Alarm on inside

Configured alarms appear on the Meter Setup tab for the meter. The Meter Setup tab would look like this for the alarm just configured.

Efficient Industries Plant 1

Accounting

Engineering

Electricity

Boiler House Meter

Data Center Meter

Electric Main Meter

Power House Meter

Production 1 Meter

Production 2 Meter

Shipping/Receiving Meter

Fuels

Steam

Water

Meter Setup

EditAddCopyDelete

Meter Information

TypeElectric

Assigned to Groups (Contribution factor %)

DeviceElectric Main

Electricity (100)

NameElectric Main Meter

Notes

Time zone(GMT-06:00) Central Time (US & Canada)

Meter Tags

Read device tags

Add a new meter tag

ID	Type	Name	Units	Log Rate	Address	
1	Device	Real Energy Net	kWh	15 minutes	20:12	View
2	Device	Reactive Energy Net	kVARh	15 minutes	22:12	View
3	Device	Real Power Demand	kW	15 minutes	17:1	View
20	Device	Voltage Sag Alarm - Flag 3		1 minute	3:2/2	View

Alarms

Add a new alarm

Enabled	Severity	Name	Meter tag	Trigger	Email
<input checked="" type="checkbox"/>	CriticalAlarm	High Demand	Real Power Demand	Higher than 300 or lower than 0	<input checked="" type="checkbox"/> View

Configure a Digital Alarm

Configuring a digital alarm requires that you perform three actions.

- Set the appropriate alarm flag in the PowerMonitor device.
- Assign a meter tag to a PowerMonitor device for use with the digital alarm.
- Create the digital alarm.

Set Alarm Flag in PowerMonitor Device

To use a digital alarm with a PowerMonitor device, you must set the appropriate alarm flag within the device. For this example, Flag 3 is assigned to a voltage sag setpoint in the PowerMonitor 3000 device.

Follow these steps to configure alarm Flag 3 in the PowerMonitor 3000 module by using the PowerMonitor 3000 display module. Refer to the [Setpoint Configuration](#) table on [page 165](#) for a list of setpoint parameters and user settings to use for this example.

TIP Refer to [Configure a PowerMonitor 3000 Device](#) on [page 57](#) for an overview of the PowerMonitor 3000 display module navigation menus.

1. Press the Escape key until DISP appears.
2. Press the Down Arrow Key to select PROG mode.
3. Press the Enter key to access Edit mode.
The display shows PASS.? with four flashing zeroes, 0000.
4. Press the Up and Down arrow keys to select the four-digit password and press Enter.
The default password is 0000.
5. Press the Down Arrow key to select CONFIGURATION, then press the Enter key.
6. Press the Down Arrow key until you see SETPOINT, then press the Enter key.
7. Press the Down Arrow key to select the setpoint number to configure, then press Enter key.
8. Press the Down Arrow key to select a setpoint parameter.
The initial setpoint parameter is TYPE.
9. Press Enter to access Edit mode.
10. Press the Down Arrow key to select a value for the setpoint parameter.
For this example, VOLTAGE SAG is selected for the setpoint TYPE parameter.

TIP For parameters that require numeric values, you can press and hold the Up Arrow or Down Arrow key for a few seconds to increase the rate the value increments or decrements.

11. Press the Enter key to write the new value to the master module.

12. Repeat steps 7...10 to edit the remaining setpoint parameters in the [Setpoint Configuration](#) table.
13. Press the Escape key to return to PROG. or DISP. menus.

Repeat this procedure to configure other setpoints.

TIP Refer to Bulletin 1404 PowerMonitor 3000 User Manual, publication [1404-UM001](#) for details on how to use data messaging as an alternative for configuring PowerMonitor 3000 setpoints.

Setpoint Configuration

Parameter Name	Parameter Description	Range	Units	Default	Example Settings
Setpoint Number	The number of the setpoint being configured.	1...10 (M4, M5) 1...20 (M6, M8)	-	N/A	1
Setpoint Type	The parameter value to be evaluated by the setpoint.	0...52 ⁽¹⁾	-	0	VOLTAGE SAG
Setpoint Evaluation Condition	The operator used to evaluate the parameter value.	0 = Over forward (+) 1 = Over reverse (-) 2 = Under forward (+) 3 = Under reverse (-) 4 = Equal (=) 5 = Not equal (<>)	-	0	U. FWD.
Setpoint High Limit	The value being used as a reference to activate the setpoint for over comparisons, or to deactivate the setpoint for under comparisons. Note: This parameter is non-numeric when viewed via the display module, and the Setpoint Type is Phase Rotation or Status input.	0...10,000,000	Depends on type	0	249
Setpoint Low Limit	The value being used as a reference to deactivate the setpoint for over comparisons, or to activate the setpoint for under comparisons.	0...10,000,000	Depends on type	0	249 ⁽²⁾
Setpoint Action Delay (Pickup Delay)	The minimum time in seconds that the setpoint limit must be exceeded continuously before the setpoint will trigger.	0...3600	Sec (M4, M5)	0	0
		0...30,000	0.1 Sec (M6, M8)		
Setpoint Release Delay (Dropout Delay)	The minimum time in seconds that the setpoint limit must not be exceeded continuously before the setpoint releases.	0...3600	Sec (M4, M5)	0	90
		0...30,000	0.1 Sec (M6, M8)		
Setpoint Action Type	The action that occurs when the setpoint is triggered.	0...32 ⁽¹⁾		0	OUTPUT FLAG 3
Clear Accumulated Time	Clear the time accumulator for this setpoint	Yes No		N/A	N/A

(1) Refer to Bulletin 1404 PowerMonitor 3000 User Manual, publication [1404-UM001](#) or details on these settings.

(2) This value is typically (line-to-neutral voltage -10%) for WYE systems and (line-to-line voltage -10%) for Delta systems.

Assign Meter Tag for a PowerMonitor Digital Alarm

You will now assign a meter tag to a PowerMonitor device for use with a digital alarm.

For the [Efficient Industries Plant 1](#) example, an alarm flag (Flag 3) is assigned to a voltage sag setpoint in the PowerMonitor 3000 device. You must assign a meter tag to the Flag 3 device tag.

Follow these steps to assign a meter tag for a digital alarm.

1. Select the meter.

For this example, select Electric Main Meter.

2. Click the Meter Setup tab then click Add a new meter tag.

3. Set the Meter tag type to Device.

4. Choose a Flag *X* tag from the device tag list.

For this example, choose Flag 3.

5. Enter a Meter tag name.

For this example, enter Voltage Sag Alarm - Flag 3.

6. Set the Value Type to None.

7. Set the Log rate to a value that is less than the Setpoint release delay in the PowerMonitor.

8. Accept the default address. Changing the address may cause logging of the incorrect flag or data.

9. Choose Boolean as the Tag format.

10. Change the Unit to None.

11. Accept the defaults for other settings.

12. Click Save.

You should see the new meter tag listed on the Meter Setup tab.

Add a Meter Tag


The screenshot shows the 'Add a Meter Tag' dialog box with the following configuration:

- Buttons:** 'Save' (circled) and 'Cancel'.
- Meter tag type:** Device (dropdown)
- Flag 3:** Flag 3 (dropdown)
- Meter tag name:** Voltage Sag Alarm - Flag 3
- Value type:** None (dropdown)
- Log rate:** 1
- Number of demand periods:** 1
- Address:** 3:2/2
- Tag format:** Boolean (dropdown)
- Unit:** None (dropdown)
- Number of decimals to display:** 0
- Scale:** 1
- Offset:** 0
- Log delta reading:** ☐
- Rollover value:** (empty text box)
- Trend log parameter:** 3
- Max consumption per hour:** (empty text box)

Create a Digital Alarm

Follow these steps to create a digital alarm.

1. Click the Meters tab and navigate to the meter you want to assign an alarm.
For this example, assign the alarm to the Electric Main Meter under the Electricity group.
2. Click the Meter Setup tab.
3. Click the Add a new alarm link.



4. Enter an Alarm Name.

For this example, enter Voltage Sag Alarm - Electric Main.

5. Choose a Meter Tag.

For this example, choose Voltage Sag Alarm - Flag 3.

6. Choose the Alarm Severity.

For this example, choose Alarm.

7. Enter a message for the alarm.

8. Check the email checkboxes if you want to send emails when the alarm is triggered or cleared.

Refer to page 170 for details on how to [Configure Email Alarm Subscriptions](#).

9. Select Digital for the trigger type.

10. Select the trigger condition.

For this example, select Change to On. This condition will trigger the alarm when the meter tag value associated with the alarm changes from 0 to 1.

11. Click Save.

Add a Alarm

Save **Cancel**

Alarm Information

☒ Enabled

Alarm Name Voltage Sag Alarm - Electric Main

Meter Tag Voltage Sag Alarm - Flag 3

Alarm Severity Alarm

Message Voltage Sag detected at Electric Main.

☒ Send email on trigger

☒ Send email on clear

Trigger Settings

☐ Analog High threshold Low threshold **Range:** ☐ Alarm on outside ☐ Alarm on inside

☒ Digital ☐ On ☐ Off ☒ Changes to On ☐ Changes to Off ☐ Any Change

Alarm Report Jobs

You should see the configured alarm on the Meter Setup tab for the meter.

Alarms						Add a new alarm	
Enabled	Severity	Name	Meter tag	Trigger		Email	
<input checked="" type="checkbox"/>	CriticalAlarm	High Demand	Real Power Demand	Higher than 300 or lower than 0		<input checked="" type="checkbox"/>	View
<input checked="" type="checkbox"/>	Alarm	Voltage Sag Alarm - Electric Main	Voltage Sag Alarm - Flag 3	ChangesToOn		<input checked="" type="checkbox"/>	View

TIP

You can use a similar procedure as that outlined in this example to set up any PLC or OPC digital tag as a digital alarm.

View and Edit Alarm Setups

You can view and edit alarm configurations by selecting Alarm Setup on the System tab. The Alarm Setup view provides a summary list of all the alarms configured in the system. The list may be sorted by severity, name, meter tag name, or meter name by clicking the underlined links. The [View](#) link directs you to the alarm setup page where you can view, edit or delete the alarm.

You must have privileges to view and edit alarm setups.

System | Meters | Reports | Custom
Layout: [Save](#) [Restore](#) [Collapse](#)

- System Status
- Groups
- Devices
- Roles and Users
- Rate Schedules
- Multi-Purpose Report Scripts
- Alarm Setup**
- Unit Setup

Alarm Setups

Enabled	Severity	Name	Meter Tag Name	Meter	Trigger	Email
<input checked="" type="checkbox"/>	CriticalAlarm	High Demand	Real Power Demand	Electric Main Meter	Higher than 300 or lower than 0	<input checked="" type="checkbox"/> View
<input checked="" type="checkbox"/>	Alarm	Voltage Sag Alarm - Electric Main	Voltage Sag Alarm - Flag 3	Electric Main Meter	ChangesToOn	<input checked="" type="checkbox"/> View

Configure Communication Alarms

A communication alarm is triggered when a device fails to respond to four consecutive polls. An error is logged to the alarm log for each communication alarm that occurs.

Follow these steps to enable communication alarms.

1. Select the Devices folder on the System tab.
2. Navigate to and select the appropriate group or domain.
For this example, Electricity is selected.
3. Click Edit.
4. Check Enable comm. loss alarm.
5. Click Save.

Save Cancel

Device Information

☐ Enable device
☒ Enable real-time logging
☒ Enable auto data repopulation
☒ Enable PQ events logging

Parent group: --Electricity
Device class: Powermonitor 3000 (M6) on EtherNet/IP
Name: Electric Main
Notes:
Time zone: (GMT-06:00) Central Time (US & Canada)
Time sync: Daily
Device password: Password

Device Communications

Communications path: AB_ETH-1110.10.10.0
Comm. timeout (seconds): 5
Comm. retries: 2
Max. messages: 1
☒ Enable comm. loss alarm

Configure Email Alarm Subscriptions

You can configure one or more email subscriptions for an alarm. A subscription supports three email addresses and a schedule that determines when each email address is active. Alarm subscriptions are assigned to a specific domain or all domains.

Follow these steps to set up an email subscription for an alarm.

1. Select My User Settings on the System tab, then click the Edit.
2. Check Enable alarm notifications, then click Save.
3. Click the [Add a new alarm subscription](#) link.
4. Select the group or domain to which you want to subscribe.
To subscribe to all domains, select the default of All.

5. Enter up to three email addresses.
6. Click the [Add new notification period](#) link to set up each alarm notification period.
 - Select a day or day range from the pull-down list.
 - Enter start and end times for each period.

To set up a notification period of all day, leave all times at zero.

For this example, a weekday notification was set for email address #1, and a weekend notification was set for email address #2.

7. Click Save.

Notification Periods						Add new notification period		
Day	Start Hour	Start Minute	End Hour	End Minute	Send to Email #1	Send to Email #2	Send to Email #3	
Weekdays	0	0	0	0	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Delete
Weekends	0	0	0	0	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Delete

IMPORTANT

For emails to be sent on alarm, you must also:

- Check Send email on trigger or Send email on clear from the Add Alarm page when configuring alarm.
- Configure an SMTP server by selecting Configuration on the System tab. Refer to page [171](#).

Configure SMTP Server

You may need to make changes to the system configuration, for example, to set up an email SMTP server for alarm and report emailing. You must have the Edit System Config privilege, an Admin privilege, to edit the system configuration.

For details on other system configuration parameters, refer to the FactoryTalk EnergyMetrix software online help.

Follow these steps to configure the SMTP server for emailing alarms or reports.

1. Select Configuration on the System tab.
2. Under Email SMTP Server Configuration, edit the parameters as appropriate.

Parameter
Email Server Name or IP Address
Sender Email Address
Send Test Email To

3. Click Save.

System | Meters | Reports | Custom

Layout: Save Restore Collapse

System Status

Groups

Efficient Industries Plant 1

Devices

Roles and Users

Rate Schedules

Alarm Setup

Unit Setup

Configuration

System Configuration Report

My User Settings

About

System Configuration

Edit

Logger Telnet Debugging

Telnet Remote Debug ☒ Enabled ☐ Disabled

Remote Debug Port 23 (typically 23)

Remote Debug Password

Email SMTP Server Configuration

SMTP Server Name or IP Address

Sender Email Address

Send test email to Send

Logger Configuration

Derived Tag Delay 5 mins

Maximum Active DTL Operations 20 (typically 20)

Miscellaneous Settings

SQL Command Timeout Delay 120 seconds

Rollup Interval 60 mins (typically 60)

OPC Update Rate 1000 milliseconds (range 100 - 60000)

New Meter Data Page ☒ Enabled ☐ Disabled

New Consumption Calculation ☒ Enabled ☐ Disabled

View Active Alarms and Alarm Log

You can view active alarms and the alarm log by selecting System Status on the System tab, then selecting either the Active Alarms tab or the Alarm Log tab.

On activation, an alarm displays on the Active Alarms and Alarm Log tab. When the alarm clears, it is removed from Active Alarms but remains in the Alarm Log until purged.

System Status

Active Alarms Alarm Log Device Comm. Errors Application Statistics Logged In Users

Time zone: (UTC-05:00) Central Time (US & Canada)

☒ List alarms since my last log in
☐ List alarms in last seven days
☐ List alarms in previous month
☐ List alarms in current month
☐ List all alarms

Purge All

Status	Severity	Name	Meter	Value	Triggered	Message
On	Info	test	PM3000 (M8) on Ethernet/IP 10_90_172_84	1033	05/08/2012 12:30 PM	Purge View
On	Alarm	Test -SS	PM1000-Valid	806124888.5	05/08/2012 12:30 PM	To test Alarm Setup Purge View
On	Info	Build 17 Apparent Power Demand Alarm	PM5000 (M5) on Ethernet/IP 10_90_172_151	4.5	05/08/2012 12:22 PM	Test Purge View

The Alarm Log tab lists the alarm history. You can view or purge individual alarms by clicking the appropriate link. You can view Device communication errors by selecting the Device Comm. Errors tab.

Active Alarms		Alarm Log					
Status	Severity	Name	Meter	Value	Triggered	Cleared	Message
On	Info	High current alarm	Richs M8	69.2029113769531	10/17/2005 04:09 PM		Richs M8: Average current greater than 50 amps Purge View
Off	Info	High current alarm	Richs M8	68.6537475585938	10/17/2005 08:39 AM	10/17/2005 08:45 AM	Richs M8: Average current greater than 50 amps Purge View
Off	Info	High current alarm	Richs M8	68.6537475585938	10/17/2005 08:39 AM	10/17/2005 08:45 AM	Richs M8: Average current greater than 50 amps Purge View
Off	Info	High Avg V IEEE THD	Richs M8	1	10/17/2005 08:37 AM	10/17/2005 08:55 AM	Avg V IEEE THD > 5% Purge View
Off	Info	High current alarm	Richs M8	68.5393295288086	10/17/2005 08:30 AM	10/17/2005 08:33 AM	Richs M8: Average current greater than 50 amps Purge View

FactoryTalk EnergyMetrix Software Reports and Charts

Introduction

In this chapter, you will learn how to configure and run standard reports and charts for your FactoryTalk EnergyMetrix software project.


- Determine business goals, complete energy assessment, and determine monitoring methods ([Chapter 1](#)).
- Select hardware and wire devices ([Chapter 2](#)).
- Configure data collection devices ([Chapter 3](#)).
- Install FactoryTalk EnergyMetrix software ([Chapter 4](#)).
- Configure groups and security in ([Chapter 5](#)).
- Configure FactoryTalk EnergyMetrix software devices in ([Chapter 6](#)).
- Configure meters and tags in ([Chapter 7](#)).
- Configure, edit, and view alarms in ([Chapter 8](#)).

What You Need

- FactoryTalk EnergyMetrix software CD, catalog number 9307-FTEMMENE
- FactoryTalk EnergyMetrix software online help and user manual, publication [FTEM-UM002](#).
- Energy Management Accelerator Toolkit CD, publication IASIMP-SP014, or visit the Integrated Architecture Tools and Resources website at <http://www.ab.com/go/iatools> to download toolkit files.

Follow These Steps

Complete these steps to create and view energy management reports and charts.



Standard Reports

FactoryTalk EnergyMetrix software standard reporting converts logged energy and production data into information you can use to manage your business, improve efficiency, and reduce costs. You can run reports on demand, automatically on a configured schedule, or event-driven in response to an alarm condition.

Standard Report Type	Description
Consumption	Reports all consumption values (for example, kWh, kVARh) for selected meters for a specified time interval. The report groups meters as they are organized in the FactoryTalk EnergyMetrix software navigation tree, with subtotals calculated for each group. The report includes all meters that have Consumption enabled for the value type.
Demand Analysis	Reports real power (for example kW) demand values for selected meters or groups for a specified time interval, and itemizes each meter or group's contribution to the total. It also reports the worst case peak demand that would have occurred had each meter or group's peak demand occurred in the same demand interval. The report includes all meters that have Demand enabled for the value type.
Billing	Generates a replication of a monthly bill (shadow bill) from your energy provider for comparative billing analysis and potential energy cost recovery. The report is based on data from your energy meters and utility rate schedules. The report is a list of line items and a total charge amount. Each line item consists of a description, quantity, rate and charge.
Cost Allocation	Runs a report that lists each meter's contribution to the total energy cost, based on a rate schedule that you configure. Cost allocation reports are generated in Microsoft Excel output format.
Power Quality	Runs a report that combines a graph and a grid display of power quality, sag and swell events. This report is used only for the PowerMonitor 3000 M6 and M8 models that have configured sag and swell setpoints. Enable PQ events logging must be checked on the Device setup page. FactoryTalk EnergyMetrix software will periodically read the PowerMonitor event log, and store sag and swell events in the database. Each sag and swell record lists the time, duration, and maximum deviation of the sag or swell.

TIP

In addition to standard reports, the ReportsPlus option extends reporting capabilities by including custom script-driven multipurpose, efficiency, load factor, power factor, and electrical summary reports.

Consumption Report

A consumption report shows all consumption values, in specified units kWh, kVARh, of selected meters for a specified time interval. The report includes group meters as organized in the project and subtotals for each group.

A consumption report is typically used to monitor daily energy use and assists with the early detection of production/equipment problems. You can configure the report to automatically run at a specific time every day and emailed to specific users. The procedure for creating this type of report, or any other report, is to:

- set up, view, and print the report.
- configure a job option to automatically run the report on a set schedule.

For the [Efficient Industries Plant 1](#) example, you will run and email a daily consumption report for the energy main meters: air, electric, gas, fuel oil, propane, steam, and water.

Create and View Report

Follow these steps to set up a consumption report.

1. Click the Reports tab.
2. Navigate to and select a domain to create the report for.

For this example, select Engineering.

Only users with access to the domain will be able to view the report.

3. Click Add.



4. Enter a Report name.

For this example, enter Consumption Report.

5. Choose the Consumption Report template.

6. Accept the default Report file for correct operation.


7. Verify the Report parent group.

For this example, Engineering was selected in step 2.


8. Select meters to include in report.

For this example, select the meters as checked.

9. Click Save.



The report appears under the Engineering domain.



10. Verify the report is selected.

11. Choose the Export type.

By default, the report is exported in a PDF format.

12. Select report parameters.

a. Select time zone.

The default is the logged-in user time zone.

b. Select a predefined or custom time span.

c. Check Suppress meter details to list only group totals in report.

This is useful when percentages of meters are allocated to groups.

13. Click View.

A new browser window opens while the report is being generated and then closes automatically.

Reports

View Edit Add Copy Delete

Report Information

Report name: Consumption Report

Report template: Consumption

Report file: Consumption.rpx

Report parent group: -Engineering

Export type: PDF

Report Parameters

Time zone: (GMT-06:00) Central Time (US & Canada)

☒ Predefined: Yesterday

☐ Custom: Start date: 8/30/2009 Start time: 12:00 AM End date: 8/31/2009 End time: 12:00 AM

☐ Suppress meter details


Auto-run report jobs

[Add a new report job](#)

Name	Notes	Schedule
------	-------	----------

The report opens in a new window.

TIP If the new browser window does not open, make sure the browser pop-up blocker is not active.



14. To print or save the report to the specified output file, use the menu commands in the browser.

- TIP**
- To edit an existing report, navigate to and select the report. Click Edit to modify the report parameters. When you are done, click the Save.
 - To copy a report, click copy on the Reports page. The report is copied with the name: Copy of <existing report name>.

Create a Job to Run Report Automatically

You can set up a report to run automatically by defining a report job. Reports that run automatically are saved in the database and sent to one or more email addresses provided the SMTP mail server is configured.

Follow these steps to create a job option to run a daily consumption report at 12:00 am for the previous day, and email the report to several engineering managers.

1. Navigate to and select a report on the Reports tab.

For this example, select Consumption Report under the Engineering subdomain.

2. Click the [Add a New Report Job](#) link.



3. Make sure the report job is enabled.

4. Enter a name for the report job.

For this example, enter Daily Consumption Report.

5. Select the time zone to run the report.

6. Enter email addresses, one per line, for each user you want receive the scheduled report.
You must configure the email SMTP server path in system configuration. Refer to [page 171](#) for details.

7. Enter optional start and end dates to run the report job.

8. Select a schedule to run the report job.

For this example, select daily to run the report every day at 12:00 am.

9. Select a predefined or custom report date range.

For this example, select Predefined and Yesterday to run report for previous day.

10. Click Save.

Add Report Job

Save Cancel

Report name: Consumption Report

Report Job Information

☒ Enabled

Name: Daily Consumption Report

Notes:

Time zone: (GMT-06:00) Central Time (US & Canada)

Email addresses (one per line): ramorgan@ra.rockwell.com, scschmelzer@ra.rockwell.com

Job start date: (optional)

Job end date: (optional)

Export type: PDF

Report Job Schedule

☒ Daily ☐ Weekly ☐ Monthly ☐ On Alarm

Every 1 day(s) at 12:00 AM

Report Date Range

☒ Predefined Yesterday

☐ Custom 0 Hours, 1 Days, 0 Months

You should see the report job at the bottom of the Reports page under Auto-run report jobs.

You can view the output of automatically run reports by clicking the [Generated Reports](#) link in the Reports tab.

Demand Analysis Report

A demand analysis report analyzes the electrical demand of plant areas so that you can make energy saving production scheduling, and/or demand control decisions.

For the [Efficient Industries Plant 1](#) example, you will create a report to list real power demand values for the plant's electrical submeters including all PowerMonitor 1000 meters: Boiler House, Power House, Production 1, Production 2, Shipping/Receiving/DC.

Create and View Report

Follow these steps to set up and view a demand analysis report.


1. Click the Reports tab.

2. Navigate to and select a domain to create the report for.

For this example, select the Engineering subdomain.

Only users with access to the domain will be able to view the report.

3. Click Add.



4. Enter a Report name.

For this example, enter Electrical Demand Analysis Report.

5. Choose the Demand Analysis Report template.

6. Accept the default Report file.

7. Verify the Report parent group.

For this example, Engineering was selected in step 2.


8. Select the meters or groups to include in the report.

For this example, select the meters as checked.

9. Click Save.

Add a new report

The report appears under the Engineering domain.



10. Verify the report is selected.
11. Accept PDF as the Export type.
12. Select the report parameters.
 - a. Select the time zone.
 - b. Select a predefined or custom time span. For this example, select Previous Month.
 - c. Check Suppress meter details to list only group totals in the report.

This is useful when percentages of meters are allocated to groups.

13. Click View.

The report is generated and opened in a new browser window.

Electrical Demand Analysis			
Time Zone: (GMT-06:00) Central Time (US & Canada)			
kW			
Peak Demand Summary			
Boiler House _Meter	665.5 kW	9.2%	7/22/2009 1:30:00 PM
Power House _Meter	352.0 kW	4.9%	7/22/2009 1:30:00 PM
Production 1 _Meter	1,787.9 kW	24.7%	7/22/2009 1:30:00 PM
Production 2 _Meter	1,224.6 kW	16.9%	7/22/2009 1:30:00 PM
Shipping/Receiving _Meter	3,222.4 kW	44.4%	7/22/2009 1:30:00 PM
Total	7,252.3 kW	100.0%	
Worst Case Peak Demand Analysis			
Boiler House _Meter	732.0 kW	9.8%	7/29/2009 10:15:00 AM
Power House _Meter	388.2 kW	5.2%	7/15/2009 10:30:00 AM
Production 1 _Meter	1,851.8 kW	24.8%	7/1/2009 3:45:00 PM
Production 2 _Meter	1,250.4 kW	16.8%	7/8/2009 11:45:00 AM
Shipping/Receiving _Meter	3,236.0 kW	43.4%	7/7/2009 4:00:00 PM
Total	7,458.3 kW	100.0%	

TIP If the new browser window does not open, make sure the browser pop-up blocker is not active.

14. To print or save the report to the output file, use the menu commands in the browser.
15. Refer to [Create a Job to Run Report Automatically](#) on [page 179](#) for details on how to configure a report job to automatically run the report.

Billing Report

A billing report generates a replication of a monthly bill (shadow bill) from your energy provider, for comparative billing analysis and potential energy cost recovery. The report is based on data from your energy meters and utility rate schedules. Creating a billing report requires you to:

- add or import a rate schedule.
- set up, view, and print the report using the selected rate schedule.

For the [Efficient Industries Plant 1](#) example, you will create a billing report for the electric utility.

Import or Create a Rate Schedule

A rate schedule defines a set of rules that FactoryTalk EnergyMetrix software uses to convert energy usage data into usable billing or cost allocation information. For details on how to configure rate schedules, refer to the FactoryTalk EnergyMetrix software online help.

For your convenience, the Energy Management Accelerator Toolkit CD provides sample rate schedules that you can import and modify for your needs.

Sample Rate Schedules


Rate Schedule	Description
AEP Indiana Michigan Power Company Tariff IP	Includes demand charges based on kVA, power factor penalty if < 0.85 , secondary metering correction factor of 1.01, time of use on and off peak, and no seasons or holidays.
Alliant Cg-2 TOD	Includes summer and winter seasons with different rates, time of use on and off peak, and no holidays.
Alliant Cp-1 - 12 hr 10-10	Includes holidays, summer and winter seasons with different rates, time of use on and off peak, global variables, and hidden line items for preliminary calculations.
Alliant IP	Includes seasons based on Daylight Savings Time (DST) start and end dates in 2007. For accuracy, seasons should be adjusted for DST each year. The value type EAC is needed for manual meter to store monthly energy adjustment rates. Rate schedule is based on Alliant IP&L tariff sheet 26 issued on June 26, 2006.
Black Hills Power General Service 20	Includes global variables, hidden line items for preliminary calculations, stepped (banded) energy and demand charges, and a power factor penalty < 0.85. Rate schedule does not include seasons, holidays, or times of use.
Dominion VA Power Non-Residential Sched 130	Includes summer and winter seasons with different rates, time of use with different season schedules, global variables, hidden line items for preliminary calculations, and several fixed facility charges.
Progress Energy LGS-9	Includes seasons for ratchet demand calculation, stepped (banded) demand charges, global variables, global proration factor for partial month reporting.
Virginia Electric and Power Company GS-4	Includes summer and winter seasons, time of use with different season schedules, global variables, and many riders.
WE General Primary Service TOU Cp1	Includes holidays, global variables, sales tax, and blended rate per kWh calculation.

Follow these steps to import a rate schedule.

1. Click the System tab.
2. Open the Rate Schedules folder.
3. Navigate to and select the group or domain to create the report for.


For this example, select the Utilities group under the Accounting subdomain.

4. Click Import.




5. Navigate to the Sample Rate Schedules folder on the Energy Management Toolkit CD image.
6. Select the WE General Primary Service TOU Cp1 rate schedule and click Open.

This rate schedule will be used by the billing report for the electrical utility.



7. Click Upload File.



You should see the imported rate schedule on the Rate Schedules page and under the Utilities group.

8. Click the View link to open the Rate Schedule.

Rate Schedules

Domain: Utilities

Add a rate schedule Import

ID Name	Notes
3 WE General Primary Service TOU Cp1	View Delete

- Click a tab containing the information you want to change, then click Edit.

For details on rate schedules, refer to the online help.

- Click Save when done to save your rate schedule changes.
- Repeat steps 1...9 to import rate schedules for other billing reports.

Rate Schedule Setup

Edit **Add** **Copy** **Delete** **Print** **Export** **Import**

Rate schedule name: WE General Primary Service TOU Cp1

Information **Seasons** **Non-Working Days** **Holidays** **Times Of Use** **Line Items** **Global Variables**

Line Items			
Line	Group	Description	
1	Fixed Charges	Facilities Charge	View
2	Demand Charges	Peak Power Factor calculation	View
3	Demand Charges	Demand, On-peak	View
4	Demand Charges	Demand, Customer Maximum	View
5	Energy Charges	Energy, On-peak	View
6	Energy Charges	Energy, Off-peak	View
7	Other Charges	Minimum Charge Adder	View
8	Taxes and Fees	Sales Tax	View
9	Blended rate	Blended energy rate per kWh	View

Edit Line Item

Description **Hide**

Create and View Report

Follow these steps to set up and view a billing report that uses a selected rate schedule.

For the [Efficient Industries Plant 1](#) example, you will create two billing reports; one for the electric utility and one for gas utility.

1. Click the Reports tab.
2. Navigate to and select a domain for the report.

For this example, select Utilities under the Accounting subdomain.

Only users with access to the domain will be able to view the report.

3. Click Add.



4. Enter a Report name.

For this example, enter Electric Billing Report.

5. Choose the Billing report template.

6. Accept the default Report file for correct operation.

7. Verify the Report parent group.

For this example, Utilities was selected in step 2.

8. Choose a Rate schedule.

For this example, choose WE General Primary Service TOU Cp1.


9. Select meters to include in report.

For this example, check the Electric Main Meter.

10. Click Save.

The report appears under Utilities group of the Accounting domain.

Add a new report



11. Verify the report is selected.
12. Edit the report parameters as needed.
13. Click View.

Reports

View Edit Add Copy Delete

Report Information

Report name: Electric Billing Report

Report template: Billing

Report file: Billing.rpx

Report parent group: --Utilities

Rate schedule: WE General Primary Service TOU Cp1

Export type: PDF

Report Parameters

Time zone: (GMT-06:00) Central Time (US & Canada)

☒ Predefined Previous Month

☐ Custom Start date: 8/1/2009 Start time: 12:00 AM End date: 9/1/2009 End time: 12:00 AM

Auto-run report jobs Add a new report job

Select By: Meters

- Efficient Industries Plant 1
 - Accounting
 - Engineering
 - Air
 - Electricity
 - Boiler House Meter
 - Data Center Meter
 - ☒ Electric Main Meter
 - Power House Meter
 - Production 1 Meter
 - Production 2 Meter
 - Shipping/Receiving Meter
 - Fuels
 - Steam
 - Water

The report is generated and opened in a new browser window.

FactoryTalk EnergyMetrix

Efficient Industries Plant 1

Electric Billing Report

8/1/2009 12:00 AM to 9/1/2009 12:00 AM

Time Zone: (GMT-06:00) Central Time (US & Canada)

Rate Schedule: WE General Primary Service TOU Cp1

Total Charge: \$175,405.72

Fixed Charges

Description	Quantity	Rate	Charge
Facilities Charge	1.0	525	\$525.00
Subtotal:			\$525.00

Demand Charges

Description	Quantity	Rate	Charge
Demand, On-peak	7,400.7 kW	8.72	\$64,533.81
Demand, Customer Maximum	7,815.1 kW	0.76	\$5,939.46
Subtotal:			\$70,473.27

Energy Charges

Description	Quantity	Rate	Charge
Energy, On-peak	1,585,749.1 kWh	0.03459	\$54,851.06
Energy, Off-peak	1,877,882.2 kWh	0.02152	\$40,412.02
Subtotal:			\$95,263.08

Taxes and Fees

Description	Quantity	Rate	Charge
Sales Tax	166,261.4	0.055	\$9,144.37
Subtotal:			\$9,144.37

TIP If the report does not open in the browser window, make sure the browser pop-up blocker is not active.

14. To print or save the report to the output file, use the menu commands in the browser.
15. Refer to [Create a Job to Run Report Automatically](#) on [page 179](#) for details on how to configure a report job to automatically run the report.

Cost Allocation Report

A cost allocation report lists each meter's contribution to the total energy cost, based on a rate schedule. Cost allocation reports are generated in a Microsoft Excel output format.

For the [Efficient Industries Plant 1](#) example, you will create a cost allocation report for all of the electric submeters including Boiler House, Power House, Production 1, Production 2, Shipping/Receiving/DC, and the Data Center.

Create a Rate Schedule

A rate schedule for a cost allocation report typically includes only energy consumption (kWh) calculations. More complex reports can be created by using the ReportsPlus option.


For the [Efficient Industries Plant 1](#) example, you will create a simple rate schedule that calculates energy charges from the Real Energy Net (kWh) tag values of the electric submeters by using a single rate per unit value.

Follow these steps to create a rate schedule.

1. Click the System tab.
2. Open the Rate Schedule folder.
3. Navigate to and select a domain for the rate schedule.

For this example, select the Accounting subdomain.

4. Click the [Add a rate schedule](#) link.



5. On the Information tab:
 - a. Verify the selected domain.
 - b. Enter a rate schedule name.

For this example, enter Electric Cost Allocation.

- c. Verify the time zone.
- d. Enter optional information.

Add Rate Schedule

Save Cancel

Rate schedule name:

Information Seasons Non-Working Days Holidays Times Of Use Line Items Global Variables

General Information

Domain: -Accounting

Name: Electric Cost Allocation

Time zone: (GMT-06:00) Central Time (US & Canada)

Start date: End date:

Contact name:

Contact phone:

Contact email:

Notes:

6. Click the Line Items tab, then click the [Add a line item](#) link.

Add Rate Schedule

Save Cancel

Rate schedule name:

Information Seasons Non-Working Days Holidays Times Of Use **Line Items** Global Variables

Line Items Add a line item

Line Group Description

7. Enter a description of the rate schedule.

For this example, enter Real Energy Charge (kWh).

8. Enter the Rate per unit (kWh).

For this example, enter 0.03459.

9. Enter a cost allocation script.

For this example, enter the scripts shown.

10. Click Validate to check the script syntax.

Add Rate Schedule

Save Cancel

Rate schedule name:

Information Seasons Non-Working Days Holidays Times Of Use **Line Items** Global Variables

Line Items Add a line item

Line Group Description

1 Insert Copy Delete Edit View

Edit Line Item

Description Real Energy Charge (kWh) Save Item Cancel Item

Group

Start date End date Rate per unit 0.03459

Script Validate


Quantity = Total(ValueType.RealEnergyNet)
Unit = GetUnit(ValueType.RealEnergyNet)
Charge = Quantity * RatePerUnit

Validation results No errors.

Script	Description
Quantity = Total(ValueType.RealEnergyNet)	Specifies the energy value for the report.
Unit = GetUnit(ValueType.RealEnergyNet)	Specifies the unit for the quantity value on the report.
Charge = Quantity*RatePerUnit	Specifies the energy calculation charge for the report.

Refer to the FactoryTalk EnergyMetrix software help for more details on scripts.

11. Click Save.
12. Verify the new rate schedule appears under the specified domain.



Create and View Report

Follow these steps to create a cost allocation report that uses a defined rate schedule.

For the [Efficient Industries Plant 1](#) example, you will create a cost allocation report that uses the Electric Cost Allocation rate schedule.

1. Click the Reports tab.
2. Navigate to and select a domain for the report.

For this example, select the Accounting subdomain.

Only users with access to the domain will be able to view the report.

3. Click Add.



4. Enter a Report name.

For this example, enter Electric Cost Allocation Report.

5. Choose the Cost Allocation report template.

6. Verify the Report parent group.

For this example, Accounting was selected in step 2.


7. Choose a Rate schedule.

For this example, choose Electric Cost Allocation.

8. Click the Meters or Groups link to determine the report selection criteria.

The Groups link is typically chosen to report energy costs by production areas (groups) that are derived from multiple meter allocations.

For this example, groups were selected so a single cost allocation could be reported for the Shipping/Receiving area based on the Shipping/Receiving/DC meter (100%) minus the Data Center meter (-100%). Refer to [page 153](#) for details on how to assign contribution factors.




9. Select the meters or groups to include in report.

For this example, cost allocation for the Data Center, Production 1, Production 2, and the Shipping/Receiving groups will be reported.

10. Click Save.

The report appears under the Accounting domain.

11. Verify the report is selected.



12. Edit the report parameters as needed.


13. Click View.



The report is generated in a .csv Microsoft Excel format. A File Download dialog box prompts you to open or save the report to a file.

14. Click Open to view the report.

The report opens in a browser window. You may need to adjust column widths to view the data.



	A	B	C	D	E	F
1	Report name:	Electric Cost Allocation Report				
2	Starting date/time:	8/1/2009 0:00				
3	Ending date/time:	9/1/2009 0:00				
4	Time zone:	(GMT-06:00) Central Time (US & Canada)				
5	Rate schedule:	Electric Cost Allocation				
6	Total charge:	\$89,204.20				
7						
8		Real Energy Charge (kWh)		Subtotals		
9	Data Center	\$11,947.60		\$11,947.60		
10	Production 1	\$26,717.20		\$26,717.20		
11	Production 2	\$17,784.00		\$17,784.00		
12	Shipping/Receiving	\$32,755.40		\$32,755.40		
13						
14	Subtotals	\$89,204.20		\$89,204.20		
15						
16						
17						
18						

TIP If the report does not open in the browser window, make sure the browser pop-up blocker is not active.

15. To print or save the report, use the File menu in the browser.
16. Refer to [Create a Job to Run Report Automatically](#) on [page 179](#) for details on how to configure a report job to automatically run the report.

Power Quality Report

A power quality report combines a graph and grid display of power quality (sag and swell) events. FactoryTalk EnergyMetrix software periodically reads the power monitor event log from the PowerMonitor 3000, and stores sag and swell events in the database. The power quality report displays events logged during the selected report interval on a ITI/CBEMA chart and in a grid (tabular) listing.

TIP The power quality report is supported only for PowerMonitor 3000 M6/M8 models with configured sag and swell setpoints. Enable PQ events logging must be checked when configuring the device.

For the [Efficient Industries Plant 1](#) example, you will create a power quality report for the PowerMonitor 3000 Electric Main meter.

Create and View Report

Follow these steps to set up and view a power quality report.

1. Click the Reports tab.
2. Navigate to and select a domain for the report.
For this example, select Engineering.
Only users with access to the domain will be able to view the report.
3. Click Add.



4. Enter a Report name.
For this example, enter Electric Main Power Quality Report.

5. Choose the Power Quality template.

6. Accept the default Report file.

7. Verify the Report parent group.

For this example, Engineering was selected in step 2.

8. Select the meters or groups to include in the report.

For this example, check the Electric Main meter.

9. Click Save.


Add a new report

Save

Cancel

Report Information	Select By: PQ devices
<div>Report name</div> <div>Electric Main Power Quality Report</div>	<div>Select All Clear All</div>
<div>Report template</div> <div>Power Quality</div>	<div>Devices</div> <div> <div>Efficient Industries Plant 1</div> <div> <div>Accounting</div> <div>Engineering</div> <div> <div>Air</div> <div>Electricity</div> <div> <div>Fuels</div> <div>Steam</div> <div>Water</div> </div> </div> </div> </div>
<div>Report file</div> <div>PowerQuality.rpx</div>	
<div>Report parent group</div> <div>-Engineering</div>	

The report appears under the Engineering domain.



10. Verify the report is selected.
11. Accept PDF as the Export type.
12. Edit the report parameters as needed.
13. Click View.

Reports

View Edit Add Copy Delete

Report Information

Report name: Electric Main Power Quality Report

Report template: Power Quality

Report file: PowerQuality.rpx

Report parent group: -Engineering

Export type: PDF

Report Parameters

Time zone: (GMT-06:00) Central Time (US & Canada)

☒ Predefined: Previous Month

☐ Custom

Start date: 9/1/2009 [Pick](#)

Start time: 12:00 AM

End date: 10/1/2009 [Pick](#)

End time: 12:00 AM

Select By: PQ devices

Devices

- Efficient Industries Plant 1
 - Efficient Industries Plant 1
 - Accounting
 - Data Center
 - Production 1
 - Production 2
 - Shipping/Receiving
 - Utilities
 - Engineering
 - Air
 - Electricity
 - ☒ Electric Main
 - Fuels
 - Steam

The report opens in a new browser window.

14. To print or save the report to the output file, use the menu commands in the browser.
15. Refer to [Create a Job to Run Report Automatically](#) on [page 179](#) for details on how to configure a report job to automatically run the report.

TIP If the new window does not appear, make sure the browser pop-up blocker is not active.


FactoryTalk EnergyMetrix

Efficient Industries Plant 1

Electric Main Power Quality Report

9/1/2009 12:00 AM to 10/1/2009 12:00 AM

Time Zone: (GMT-06:00) Central Time (US & Canada)



Standard Charts

Two standard charting tools are available to view and analyze energy usage and demand.

Chart Type	Description
Trend	Displays a trend of one or more logged parameters from one or more meters over a specified time interval. You can select up to five parameters on the same chart.
Calendar	Displays a trend line of one logged parameter in a calendar format. This chart is typically used to display real or reactive power demand over time to pinpoint peaks that vary by day, week or month. You can zoom in on a day's chart by clicking on the day in the calendar view. Selecting multiple days overlays one trend line on top of another, allowing you to compare, for instance, all Mondays in a month.

TIP In addition to the standard charts, the optional ChartsPlus package extends custom charting capabilities. This client application downloads and runs on the client computer.

Setup and View a Trend

1. Click the Meters tab.
2. Navigate to and select the group and meter for the trend.

For this example, select the Electric Main Meter under the Electricity group in the Engineering subdomain.


3. Click the Trend tab.

A blank chart appears and is labeled No meter tags selected.

4. Select a time zone for the chart.

The default is the logged-in user time zone.

5. Choose a meter tag to display from the list.



For this example, RealEnergyNet is selected. Data is trended for the tag displayed under the chart, in the specified unit.



6. Select a start and end date for the trend by using the calendars.

Or, enter the start and end dates into the data entry fields then click Go.

For this example, August 1, 2009 through August 31, 2009 is selected.

7. Optionally, choose another meter tag from the list.

You can view up to five tags in a standard trend chart. Trend selections are active until you log out or remove from the chart.

TIP To add a tag from another meter, navigate to and select the other meter on the meters tab, then choose a tag from its list.

For this example, electric consumption from three other production areas is selected and viewed relative to the Electric Main consumption data.



8. Choose other charting options to view, remove, and export trend data.

Click This Button	To
Hide	Temporarily hide the view of a tag on the trend chart. The tag is still selected but not visible. To view the tag again, click Show.
Bar	Display a bar chart for the selected tag. The button toggles between Bar and Line so you can choose the desired chart type for each tag.
Remove	Permanently remove a tag from the chart.
Export Data	Save the data series displayed in the chart to a .csv file.

TIP Move the mouse cursor over the trend chart until a menu bar appears. From this menu bar, you may save, print, or email the chart image.

Setup and View a Calendar Trend

The calendar trend is most commonly used to display demand-type values.

Follow these steps to view a calendar trend of meter or group data.

1. Navigate to and select a meter or group on the Meters tab.


For this example, select the Electric Main Meter under Electricity in the Engineering subdomain.

2. Click the Calendar trend tab.

3. Choose the meter tag you want to trend from the list.

For this example, choose Real Power Demand.

4. Choose a month and year from the pull-down menus.



5. Zoom-in by clicking on a day in the calendar.
6. Optionally, select up to five days by clicking on each day, one at a time.

This allows you to view multiple days on one chart.



7. Click Export Data to save the calendar trend data series as a .csv file.

FactoryTalk EnergyMetrix Software and PowerMonitor Device Maintenance

Introduction

This chapter describes ways to maintain your power monitoring system to achieve a high level of performance on an ongoing basis.

Before You Begin


- Determine business goals, complete energy assessment, and determine monitoring methods ([Chapter 1](#)).
- Select hardware and wire devices ([Chapter 2](#)).
- Configure data collection devices ([Chapter 3](#)).
- Install FactoryTalk EnergyMetrix software ([Chapter 4](#)).
- Complete FactoryTalk EnergyMetrix software chapters ([Chapter 5](#) through ([Chapter 9](#)).

What You Need

- For FactoryTalk EnergyMetrix software updates:
 - Updated FactoryTalk EnergyMetrix software CD, catalog number 9307-FTEMMENE
 - Downloaded software updates from the Rockwell Automation website at <http://www.rockwellautomation.com/support>.
- For FactoryTalk EnergyMetrix software upgrades:
 - Product option license
 - Activation master disks or FactoryTalk activation data
- For PowerMonitor firmware updates:
 - RS-232-to-RS-485 converter such as B&B Electronics USOPTL4
 - Downloaded firmware update from the Rockwell Automation Knowledgebase at <http://www.rockwellautomation.com/knowledgebase>.

Follow These Steps

Follow this path for details on how to perform common maintenance tasks. Not all tasks will be required at all times.



Set Up Database Maintenance

FactoryTalk EnergyMetrix software connects to the Microsoft SQL database named EMMA to store configuration parameters and logged data. It is a system requirement to back up and shrink the EMMA database on a regular schedule. Backups create a record of the database so it may be restored in case of database corruption or a system crash. Regularly scheduled database backup and shrink operations control the growth of the SQL transaction log.


Many FactoryTalk EnergyMetrix software users maintain established backup and archiving procedures for business databases. FactoryTalk EnergyMetrix software does not have any unusual database maintenance requirements, so established IT database procedures will generally meet the backup needs. Rockwell Automation recommends a daily scheduled backup and shrink of the EMMA database.

If your site does not have established database administration routines, the following steps are suggested to provide a basic level of database management. Also, refer to Microsoft SQL Server documentation for database backup, shrink, and restore procedures.

Follow these steps to set up a database maintenance plan in Microsoft SQL Server 2005.


1. Access the FactoryTalk EnergyMetrix server and log in as an administrator.
2. Open Microsoft SQL Server Management Studio.
3. Connect to the local server by using Windows authentication.

4. Open the Management folder in the tree, and select Maintenance Plans.
5. Right-click the Maintenance Plans folder and choose New Maintenance Plan.
6. Type in a name for the plan and click OK.




7. In the design view, drag and drop the following from the Toolbox into the blank plan page:

- Back Up Database Task
- Shrink Database Task
- Maintenance Cleanup Task




8. Select the Back Up Database Task box, then select the tip of the green arrow and drag it to the Shrink Database Task Box.

9. In the same way, connect the Shrink Database Task to the Maintenance Cleanup Task.






10. Select the Back Up Database Task.
 - a. Right-click and choose Edit.
 - b. Choose the EMMA database.
 - c. Accept the remaining defaults and click OK.



11. In the same way, choose the EMMA database in the Shrink Database Task.

12. Edit the Maintenance Cleanup Task.

- Select the backup folder used for the backups as the search target, and enter the BAK file extension.
- Select to delete files older than 1 week.

**13. Click the browse icon next to the Schedule field.****14. Set up a recurring schedule to occur daily at a convenient time, then Click OK.****15. Click the Save icon to save the maintenance plan.**

If notified that the SQL Agent is not running, follow the prompts to autostart the SQL Agent.

16. When done, close SQL Management Studio.

Emergency Transaction Log Backup and Shrink Procedure

If routine database maintenance is not performed or fails, the transaction log can become very large and in the extreme can fill the hard drive. Executing this query will back up and shrink the transaction log to correct the situation.

Use EMMA

```
DBCC SHRINKFILE (EMMA_Log, 0)
```

```
BACKUP LOG EMMA WITH TRUNCATE_ONLY
```

```
DBCC SHRINKFILE (EMMA_Log, 0)
```

```
GO
```

Run this query from Microsoft SQL Management Studio.

Automatic Data Repopulation

ADR, a standard Manager function, gathers selected data from device data logs to repopulate database gaps caused by network or server outages. ADR will not repopulate gaps in the database that are caused by loss of power to or failure of the metering devices.

ADR periodically reads data logs from the device and, inserts records in the database where no corresponding data exists. It will not overwrite existing database records.

IMPORTANT ADR is designed to help assure the integrity of data for billing, cost allocation, demand analysis and consumption reporting, such as real energy, reactive energy and demand real power. Data not contained in the device snapshot, energy or trend logs is not available for data repopulation.

Devices that Support ADR

The following devices support Automatic Data Repopulation.

Allen-Bradley PowerMonitor 5000 Unit

The PowerMonitor energy and data logs provide the source for ADR. The energy log collects a fixed collection of energy and demand parameters at a user-settable logging rate. The data log content and logging rate are user-configurable.

Allen-Bradley PowerMonitor 1000 Unit

The PowerMonitor 1000 energy log contains a predefined collection of energy, status input and demand parameters (depending on the model) logged at a user-configurable interval.

Allen-Bradley PowerMonitor 3000 Unit

All communication networks are supported. The trend log is user configurable and holds a variable number of records depending on the user configuration. The PowerMonitor 3000 unit trend log should be configured to align with parameters and logging rate of parameters being logged as meter tags.

TIP PowerMonitor 3000 unit trend log energy data is expressed with 7 digit precision while real-time energy data is expressed with 15 digit precision. For accurate reporting results when using ADR, configure the PowerMonitor 3000 energy counters to roll-over at 7 or 8 digits depending on your accuracy requirements. This option is available with master module firmware version 1.12 or higher. The rollover value in consumption meter tags must be adjusted to match the actual energy rollover value.

Allen-Bradley PowerMonitor II Unit

Remote I/O, Ethernet and serial communication are supported. The PowerMonitor II must be at firmware version 3.00 or later and set up to use either the 16 parameter or 3 and 7 parameter snapshot log.

TIP Snapshot log energy data is expressed with 7 digit precision while real-time energy data is expressed with 15 digit precision. ADR used with the PowerMonitor II may result in inaccuracies in energy consumption and billing reports, especially if the repopulated data occurs at the beginning or end of the reporting period.

Allen-Bradley PowerMonitor Unit

The power monitor's snapshot log holds up to 50 records. Remote I/O communication is supported.

Allen-Bradley MicroLogix EEM (1803-EEM) Module

The MicroLogix EEM trend log contains an accumulated energy counter and a demand value for each configured meter.

Allen-Bradley Programmable Controllers

ControlLogix, CompactLogix, MicroLogix, SLC 500, and PLC-5 controllers support ADR when programmed with specific logic. The ADR Wizard for RSLogix software is used to develop the specific logic that supports ADR.

Refer to the FactoryTalk EnergyMetrix user manual, publication [FTEM-UM002](#), for details on setting up ADR.

Monitor Health of Data Logging

It is important to monitor the health of the FactoryTalk EnergyMetrix software data logging periodically. Any system may lose functionality over time due to issues with devices or communication. FactoryTalk EnergyMetrix software has status pages that provide information on the health of the system at a glance.

Device Status Page

The Device Status page provides a color-coded view of the communication status of each device in the system. To view the Device Status page, launch and log into the FactoryTalk EnergyMetrix software web page. In the System tab, click the Devices folder.

Device Status

Add a device

Refresh

Legend:

Online

Online, not fully scanned

Online, tag error(s)

Offline

Not scanned

Disabled

1P-SW	2-A7	2D26-1	2D26-2	2F15-1
2F15-2	2F15-3	2F15-4	2F15-5	3B20-1
3B20-2	3B20-3	3B26-1	3B26-2	3B26-3
3N24-E	3N24-W	3P-SOUTH	4G28-1	4G28-2

Each device name is a hyperlink to a web page that provides more detail as to issues encountered by the data logger, including RSLinx error codes.

System Status Page

The System Status page provides a list of device communication errors. To view the System Status page, launch and log into the FactoryTalk EnergyMetrix software web page. Click System Status in the System tab.

A device communication error occurs when four consecutive logging intervals occur with no response from the device.

Click the device name for a new page with additional detail. Occasional communication errors occur normally and have little impact on data integrity. Sustained or frequent communication errors indicate a need to troubleshoot the network and/or device.

System Status					
Active Alarms Alarm Log Device Comm. Errors Application Statistics Logged In Users					
Time zone: (UTC-08:00) Central Time (US & Canada)					
<input checked="" type="radio"/> List alarms since my last log in <input type="radio"/> List alarms in last seven days <input type="radio"/> List alarms in previous month <input type="radio"/> List alarms in current month <input type="radio"/> List all alarms					
Purge All					
Active Alarms					
Status	Severity	Name	Meter	Value	Triggered
On	Info	test	PM3000 (M5) on Ethernet/IP 10_80_172_84	1033	06/08/2012 12:30 PM
On	Alarm	Test -SS	PM1000-Valid	606124888.5	06/08/2012 12:30 PM To test Alarm Setup
On	Info	Build 17 Apparent Power Demand Alarm	PM5000 (M5) on Ethernet/IP 10_80_172_151	4.5	06/08/2012 12:22 PM Test

Daily Consumption Report

A popular method for monitoring the health of the data logger and the integrity of the facility utility systems is the daily consumption report. This is an automatically generated report that lists the consumption of each meter over the previous day. A plant engineer may receive this report in the morning email. Meters that indicate zero consumption may indicate an offline metering point (or it may indicate actual conditions in the facility). Consumption line items that are significantly higher than expected may indicate a leak or a failure of a facility subsystem, causing a waste of energy or raw material.

See [Chapter 9, FactoryTalk EnergyMetrix Software Reports and Charts](#) for procedures on setting up a daily consumption report and generating the report automatically.

Using the Windows Event Viewer

The Windows Event Viewer can be helpful in diagnosing software issues that cause performance issues in the FactoryTalk EnergyMetrix software system. Issues such as slow response, missed report output, and server errors may be attributed to the interactions between FactoryTalk EnergyMetrix software and other programs it needs, such as SQL Server, IIS, RSLink Classic, and ASPNET.


To open the Event Viewer, follow these steps.

1. From the Windows Start menu, choose Control Panel and then launch Administrative Tools.

Your start menu setup may be different.

2. Launch the Event Viewer.


The Application and System logs can provide clues to help diagnose performance issues.



- 3. To check or edit settings of a specific event log, right-click the log name and choose Properties.

For this example, the System log was selected.

For best results, the application and system logs should be set to at least 512 MB in size, and to overwrite as needed.



At times it may be helpful to restart the FactoryTalk EnergyMetrix software logger service. To restart the service, open the Windows Service Control panel, in the Administrative Tools, find the FactoryTalk EnergyMetrix Logger Service in the listing of services, and restart the service.

Running System Configuration Reports

The system configuration report documents the configuration of any or all of the FactoryTalk EnergyMetrix software objects listed in the Report Setup page. In addition, you may select all groups or an individual group/domain and its subgroups. Groups are limited to those accessible to your login role.

System configuration reports are useful in documenting the installed and configured system, and identifying details of devices, meters, and meter tags such as Device ID and Meter ID.

This is an example of the Devices report run on the Efficient Industries Plant 1 project.

Efficient Industries Plant 1 / Engineering / Electricity									
DeviceId	Name	Device Class	Time zone	Time sync	Device	Enabled			
						RT	ADR	PQ	Logs
1	Electric Main	Powermonitor 3000 (M6) on EtherNet/IP	(GMT-06:00) Central Time (US & Canada)	Daily	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
Parent Device		Communications Path		Comm Timeout (secs)	Comm Retries	Max Msgs	Comm Loss Alarm	RIO Rack	RIO Group
		AB_ETH-1\10.10.10.0		5	2	1	<input type="checkbox"/>		
DeviceId	Name	Device Class	Time zone	Time sync	Device	Enabled			
						RT	ADR	PQ	Logs
2	Boiler House	Powermonitor 1000 (EM3) on EtherNet/IP	(GMT-06:00) Central Time (US & Canada)	Daily	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	

System Updates and Upgrades

Part of any maintenance program is keeping your software and device firmware up to date. Rockwell Automation regularly updates software and firmware to include features requested by customers, adapt to a changing software environment, and resolve issues. As your system grows and your use of it becomes more in depth, you may also need to add meter licenses or other options.

Upgrade FactoryTalk EnergyMetrix Software by Adding Meters or Product Options

Product upgrades may be purchased from your local Rockwell Automation representative. Note that FactoryTalk EnergyMetrix software is one software product with different licensing options that are enabled by installing activations. The current version of FactoryTalk EnergyMetrix software, Version 2.0, uses the EVRSI floppy-disk activation system.

Follow these steps to upgrade your system by adding options.

1. Purchase the desired product option from your local Rockwell Automation representative.
2. Locate the activation master disk in the product packaging.
3. Access the FactoryTalk EnergyMetrix server.
Locate the floppy disk drive, or connect to a shared floppy disk drive on another computer.
4. Using the Windows Services control panel, shut down all activated Rockwell Software applications.
5. Insert the master disk into the floppy drive.
6. From the Windows Start menu, drill down through All Programs>Rockwell Software>Utilities and launch Move Activation -32 bit.
7. Use the program to move the new activation to the hard drive of the FactoryTalk EnergyMetrix software server.
8. Restart the services that you stopped in an earlier step.

Update FactoryTalk EnergyMetrix Software Version

A benefit of purchasing a TechConnect support agreement on your FactoryTalk EnergyMetrix software is the ability to upgrade your software at no charge. You may download the latest major release, for example, Version 1.7, from the Rockwell Automation Software Updates web page. You will need the serial number of the registered software along with the name of the person to whom the software is registered.

TIP You need to only download one FactoryTalk EnergyMetrix software installer regardless of how many options you have installed.

Under certain circumstances you may need a service pack, for example, version 1.7 SP1, for your particular needs. Please contact Rockwell Automation technical support for access to the download site for FactoryTalk EnergyMetrix software service packs.

Follow these steps to install an update.

1. Write down the serial number of your FactoryTalk EnergyMetrix software.
You may find this on the System Tab>About link.
2. Locate and write down the system administrator login for the Microsoft SQL Server.
This is typically a username of 'sa' with a password. You must have this login to complete installing the update.
3. Download the update installation files.
Unzip the downloaded installer to a folder on the FactoryTalk EnergyMetrix software server.
4. Browse to the FactoryTalk EnergyMetrix subfolder and locate the file setup.exe.
5. Double-click setup.exe to run the program.
Accept the prompt to uninstall the existing software.
6. After the existing version has been uninstalled, run setup.exe once again.
7. When prompted, accept the license agreement
8. When prompted, enter the serial number you wrote down in step 1.
9. When prompted, select the SQL server host computer (default = local) and enter the system administrator login username and password.
10. When installation completes, reboot the server.

Upgrade PowerMonitor Firmware

You may find the latest PowerMonitor firmware in the Rockwell Automation Knowledgebase at <http://www.rockwellautomation.com/knowledgebase>.

You may be required to have a TechConnect agreement for access to the Knowledgebase. Please contact your local Rockwell Automation for information on available TechConnect support programs.

Search for PowerMonitor 1404 or 1408 in the Knowledgebase. Instructions and firmware upgrade files are included.


Notes:

FactoryTalk View ME Energy Faceplates


Introduction

The Energy Management toolkit provides a variety of HMI faceplates for displaying real-time energy data and device status/diagnostic information on plant floor HMI devices, such as PanelView Plus terminals and industrial computers.

PowerMonitor 1000 Faceplate



Provides real, reactive, and apparent energy, status count and demand data.



Provides three phase voltage, current, and frequency information.

Equipment Status Faceplate

Efficient Plant 1_ Boiler House

Device	State	Value 1	Value 2	Value 3	Value 4
Gas Main	ACTIVE	9565.000 therms	503.000 therms/hr	0.000	0.000
Boiler House Gas	ACTIVE	7654.000 therms	385.000 therms/hr	0.000	0.000
Propane	HIGH FLOW	43225.000 gal	4.300 gpm	0.000	0.000
Fuel Oil	CRITICAL FLOW	21653.000 gal	5.900 gpm	0.000	0.000
Boiler House Electric	Comms Fault	0.000 kW	0.000 Volts	0.000 Amps	0.000 Pf

11:32:28 AM Tuesday, September 29, 2009

Provides data collector device status and energy data information.

Alarm History Faceplate

Alarm History

Alarm time	Acknowledge time	Message
9/15/2009 4:21:03 PM		Gas Main Comms Fault
9/15/2009 4:21:03 PM		Propane Meter Critical Flow
9/15/2009 4:21:03 PM		Fuel Oil Meter Critical Flow

Ack Alarm Silence Alarms Ack All Clear All Print History Alarm Status Sort Alarms Close

Provides date and time-stamped alarm and fault information for energy data collector devices.

Before You Begin


- Determine business goals, complete energy assessment, and determine monitoring methods ([Chapter 1](#)).
- Select hardware and wire devices ([Chapter 2](#)).
- Configure data collection devices ([Chapter 3](#)).
- Complete FactoryTalk EnergyMetrix software chapters ([Chapter 5](#) through [Chapter 9](#)).
- FactoryTalk View Machine Edition software loaded on your personal computer.


What You Need

- RSLogix 5000 software, version 17 or later or Studio 5000 Logix Designer application, version 21.00 or later
- FactoryTalk View Machine Edition software, version 5.0 or later
- Energy Management Accelerator Toolkit, publication IASIMP-SP014
or visit the Integrated Architecture Tools and Resources website at <http://www.ab.com/go/iatools>
- Hardware installation and wiring complete with power applied
- FactoryTalk View ME runtime application file downloaded to the PanelView Plus terminal

Follow These Steps

Follow these paths to run the preconfigured logic and faceplates to gain an understanding of how to use these tools in your application.





Configure PowerMonitor 1000 Faceplates

The PowerMonitor 1000 faceplate is a graphic display that you can add to your FactoryTalk View ME application. The display provides real-time data such as voltage, current, power, and energy from a PowerMonitor 1000 meter. Data is polled from a PowerMonitor 1000 meter via RSLinx Enterprise so a controller is not required. Because parameter passing has been implemented, you only have to maintain a single display for all PowerMonitor 1000 meters on a plant floor.

The PowerMonitor 1000 faceplate is compatible only with the PowerMonitor 1000 EM3 model over an Ethernet connection.

Configuration Display

Renames the Device, and the Status 1 and Status 2 counters.

VIF Display

VOLTAGE		CURRENT (AMPS)	
L1-L2:	502.95	L1:	532.66
L2-L3:	501.83	L2:	533.22
L3-L1:	503.17	L3:	532.71
AVG:	502.65	AVG:	533.27
% UNBAL:	0.5	% UNBAL:	0.1
FREQUENCY (HZ)			
60.02			

Shows voltage, current, and frequency information for three phases.

PWR Display

	kW	kVAR	kVA
L1:	132.87	66.16	148.43
L2:	132.77	66.17	148.33
L3:	132.90	66.20	148.43
TTL:	398.54	198.53	445.18

Power Factor	
L1:	-89.52
L2:	-89.52
L3:	-89.54
TTL:	-89.52

Shows real, reactive, and apparent power, and power factor data.


E Display

ENERGY		
kWh Net:	664.99	
kVARh Net:	316.87	
kVAh Net:	741.84	
Status 1 Count:	11	
Status 2 Count:	11	

DEMAND	LAST	PROJECTED
kW Demand:	398.26	398.52
kVAR Demand:	198.46	198.47
kVA Demand:	444.97	445.12

Shows real, reactive, and apparent energy, status count and demand data.

PH Display




Shows voltage and current phase angles. A phasor diagram shows the vector angles for each phase.


Add PowerMonitor 1000 Faceplate to ME Application

Follow these steps to add the PowerMonitor 1000 faceplate to a FactoryTalk View ME application.

1. Launch FactoryTalk View Studio for Machine Edition.
2. Create a new or open an existing application to which you want to add the faceplate.



3. Right-click Displays and choose Add Component Into Application.



4. Browse to the ME PowerMonitor 1000 Faceplate Files folder on the Energy Management Toolkit CD image and choose PM1K_FP.gif.


5. Select the file and click Open.

The faceplate display is added to application.

Configure Communication to PowerMonitor 1000


Follow these steps to configure RSLinx Enterprise software to communicate with the PowerMonitor 1000 meter.

1. Launch RSLinx Enterprise software.
2. Double-click Communication Setup under RSLinx Enterprise in the Explorer window.




You will see this dialog box if a communication setup does not exist.

3. Select Create a new configuration and click Finish.
4. Click Add under Device Shortcuts to create a new shortcut, then rename the shortcut PM1K_172_144.





5. Write down the shortcut name, PM1K_172_44, for later use.
6. Click the Design Local tab.
7. Expand the Ethernet network and select the PowerMonitor 1000 meter.




8. Verify that the shortcut name is highlighted, then click Apply.

9. Click Yes to apply the changes when prompted.

10. Click Copy from Design to Runtime to copy changes to the runtime communication setup.




11. Click Yes when prompted to continue with the copy operation.
12. Click OK at the bottom of the RSLinx Enterprise dialog box to save the communication setup changes.




Import and Configure HMI Tags

Because a controller is not used with the faceplate, HMI tags are required to control visibility animation and edit custom properties. You will now import the tags needed to interface with the PowerMonitor 1000 faceplate in FactoryTalk View Studio for Machine Edition.


1. From the Tools menu, choose Tag Import and Export wizard.




2. Choose Import FactoryTalk View tag CSV files from the pull-down menu, then click Next.




3. Click the ellipse icon to browse for the FactoryTalk View ME project (.med) you want to import tags into.



4. Select your FactoryTalk View ME project file (.med), then click Open.




5. Click Next.




6. Click the ellipse icon to browse for PM1K_FP_HMI_tags_default.csv.

The file is in the
ME_PowerMonitor1000_Faceplates_Files folder
on the Energy Management Toolkit CD.



7. Select PM1K_FP_HMI_tags_default.csv and click open.




8. Click Next.



9. Select Skip existing, then click Next.




10. Click Finish.




The tag folder PM1K_FP_DEFAULT should appear in the HMI Tags database. This folder contains the correct tags but must be renamed to the shortcut name PM1K_172_144 created on page 219. You cannot rename an existing tag folder but you can create a duplicate folder and rename it.

11. Double-click Tags to open the HMI Tag database.




12. Select the PM1K_FP_DEFAULT tag folder.



13. Click the Duplicate Tag Folder icon in the Tag Database menu.



14. Rename the folder to the shortcut name PM1K_172_144, then click OK.




15. Verify that the tag folder was duplicated.
16. Click Close to close the HMI Tag database.

Create a Parameter File

You will now create a parameter file to use when calling the faceplate display. A parameter is used to replace the shortcut name in the tags referenced on the display. This allows the use of one display for multiple PowerMonitor 1000 meters.

Follow these steps to create a parameter file.

1. Right-click Parameters in the Explorer window and choose New.




2. Set the parameter #1 = <device shortcut> to the shortcut name PM1K-172-144.
3. Click X to save and close the Parameter file.
4. Rename the file PM1K-172-144.


Create a Display Navigation Button

Follow these steps to create a Goto Display navigation button to launch the faceplate display.

1. Create a new or open an existing display from which you want to launch the PowerMonitor 1000 faceplate.




- Choose Goto from the Objects>Display Navigation menu.




- Draw the Goto Display push button on the display.




- Double-click the Goto Display push button to configure its properties.
- Click the ellipse icon under Display.




6. Select the PowerMonitor 1000 faceplate, PM1K_FP, then click OK.



7. Click the ellipse icon below Parameter file.




8. Select the parameter file you created on page [225](#) and click OK.



A bitmap image of the PowerMonitor 1000 device has been included with the PowerMonitor 1000 faceplate files. You can add this image to your project and use it as the button image if you want.

9. Click OK to close the Goto Display push button Properties dialog box.
10. Save your display and run the application to verify that the PowerMonitor faceplate works properly.



TIP If the Test Application function is used to verify faceplate operation, press the x key to escape test.

To integrate the faceplate with additional PowerMonitor 1000 meters on the plant floor, repeat all procedures under sections [Configure PowerMonitor 1000 Faceplates](#) starting on page [page 217](#). You do not have to add the faceplate display again or import the HMI tags. You just need to duplicate the default Faceplate tag folder and rename according to the shortcut name.

Configure ME PowerMonitor 500 Faceplates

The ME PowerMonitor 500 Faceplate files let you quickly load, configure, and use a preconfigured status display or 'faceplate' for the PowerMonitor 500 unit by using FactoryTalk View Machine Edition software.

These instructions are for the PowerMonitor 500 unit communicating over an EtherNet/IP network only.

VIF Display

My PM500 X

PWR **E**

VOLTAGE (VOLTS)		CURRENT (AMPS)	
L1-L2:	481.27	L1:	5.80
L2-L3:	489.42	L2:	5.60
L3-L1:	485.73	L3:	5.37
AVG L-L:	485.47	AVG:	5.59
% UNBAL:	1.0		
L1-N:	278.75	FREQUENCY (HZ) <div>60.02</div>	
L2-N:	282.09		
L3-N:	282.65		
AVG L-N:	281.16		

Shows voltage, current, and frequency status.

PWR Display

My PM500 X

VIF **E**

	kW	kVAR	kVA
L1:	1.50	0.55	1.61
L2:	1.46	0.54	1.57
L3:	1.41	0.52	1.52
TTL:	4.36	1.61	4.69
Power Factor			
L1:	-93.03		
L2:	-92.93		
L3:	-93.00		
TTL:	-92.98		

Shows the power status.

Energy Display

My PM500 X

VIF **PWR**

kWh Consumed:	000000695.242
kWh Generated:	000000000.000
kWh Net:	000000695.242
kVARh Consumed:	000000259.782
kVARh Generated:	000000000.000
kVARh Net:	000000259.782

Device Name:

Shows real, reactive, and apparent energy odometers.
Also lets the operator configure the device name for display at the top of the faceplate.

Alarm Display

My PM500 X

VIF **PWR** **E**

Last Fault

Virtual Alarm 2

The PowerMonitor 500 unit provides two user configurable alarms (Virtual Alarm 1 and 2). The alarm display indicates when either of these alarms is active or if there is a communication fault.

Configure RSLogix5000 for the PowerMonitor 500 Unit Faceplate


Follow these procedures to configure the faceplate.

Add the PowerMonitor 500 Unit to your Ethernet Network

1. Create a new or open an existing RSLogix5000 software (or Studio 5000 Logix Designer application) file.
2. Under I/O Configuration, right-click the network communication module to be used for the intended unit.

IMPORTANT This step assumes you have already added and configured an Ethernet module to your I/O tree.


3. Select 'New Module'.
4. From the Communication pull-down menu, choose ETHERNETMODULE Generic Ethernet Module.
5. Enter a distinct module name and the IP Address of your power monitor.
(For example, we use 'MyPM500' for the module name throughout this document.)
6. Enter the Connection Parameters as listed in this dialog box.



7. Click OK.


Import the PowerMonitor 500 Unit Faceplate Routine

1. From the Controller Organizer, right-click on the program where you would like to add the power monitor faceplate routine, and choose Import Routine.




2. Navigate to the ME PowerMonitor 500 Faceplate Files folder, select the RXX_PowerMonitor500_Faceplate routine, and click Import.

The Import Configuration dialog box opens.




3. Enter the name for your routine in the Final Name field.




4. In the Import Content organizer, select tags.

The Configure Tag References dialog box opens.

5. Replace `_DeviceName` in the Final Name with the name of your device.




For the 'MyPM500' example, the Final Names are renamed to the following:




6. In the Import Content organizer, select Other Components.

The communication path can be set for all messages by selecting the device from the I/O configuration drop-down in the Component References.


7. Click OK.



The new Routine appears in the Controller Organizer in the selected program.



8. Add a JSR to your main routine, or other desired location, to execute the new routine.




Configure FactoryTalk View ME for the PowerMonitor 500 Unit Faceplate


Follow these procedures to configure the faceplate.

Add PowerMonitor 500 Unit Faceplate to ME Application

1. Launch FactoryTalk View Studio software and create or open an existing application file.
2. In the Graphics folder, right-click on Displays and choose 'Add Component Into Application.'




3. Navigate to the ME PowerMonitor 500 Faceplate Files folder, select the PowerMonitor500_Faceplate, and click Open.




Add a Parameter File

1. Right-click on Parameters, and choose 'Add Component Into Application'.




2. Navigate to the ME PowerMonitor 500 Faceplate Files folder, select the ME_PowerMonitor500_Parameter.par file, and click Open.




Configure a Parameter File

1. From the explorer window in FactoryTalk View Studio, in the Parameters folder, right-click the ME_PowerMonitor500_Parameter.par file, and choose Rename.



2. Rename the parameter file with the name of the corresponding device in your RSLogix500 application.
For example, MyPM500_Parameter.



3. Double-click the parameter file to open it.

Parameter #1 represents the tag name for the specific Faceplate tag in your RSLogix 5000 project. Each tag contains a controller shortcut name in brackets. This matches the shortcut name created in your RSLinx Enterprise communication setup.

```

===== Parameter File Created 2013/05/13 =====
! Parameter files are used with graphic displays to specify the tags a display
! uses at run time. You assign parameter files in certain application components
! and object properties dialog boxes. Please see the Help for details.
! Syntax:
!   #replacement=tagname
! Example:
!   #1::[CLX]DeviceName_FP
! #1 in any expression is replaced by the tag ::[CLX]DeviceName_FP
!
! For Example:
! ::[CLX] --> Represents the 'Device Shortcut' name of Logix controller you configured in
! RSLinx Enterprise Communication Setup.
!
! DeviceName_FP --> Represents the AOI name for the device configured in your Logix application.
! =====
#1=[CLX]DeviceName_FP

```

4. For parameter #1, change the shortcut name [CLX] to match your communication setup and DeviceName to match the tag configured in your RSLogix5000 project.

For the MyPM500 example, the configuration looks like the following:

```

MyPM500_Parameter - /DMAT/ (Parameters)
===== Parameter File Created 2013/05/13 =====
! Parameter files are used with graphic displays to specify the tags a display
! uses at run time. You assign parameter files in certain application components
! and object properties dialog boxes. Please see the Help for details.
! Syntax:
!   #replacement=tagname
! Example:
!   #1::[CLX]_DeviceName_FP
! #1 in any expression is replaced by the tag ::[CLX]_DeviceName_FP
!
! For Example:
! ::[CLX] --> Represents the 'Device Shortcut' name of Logix controller you configured in
! RSLinx Enterprise Communication Setup.
!
! _DeviceName_FP --> Represents the AOI name for the device configured in your Logix application.
! =====
#1=[MyCLX]MyPM500_FP


```

5. Save your parameter file.
6. To add parameter files for additional power monitors:
 - a. Right-click on the parameter file that you just created and choose Duplicate.
 - b. Rename the file with the new device name.
 - c. Open the parameter file and configure the tag to match the associated device.


Create a Display Navigation Button

A display navigation button must be created to launch the PowerMonitor Faceplate at runtime. This can be drawn over an existing graphic object that represents the device you intend to monitor/control or it can be configured to use a bitmap image as the display.

1. From the display where you want to launch the faceplate (can be a new or an existing display), choose Objects > Display Navigation > Goto.




2. Draw the Goto button rectangle.
3. Double-click the new Goto rectangle to configure the button properties.
 - a. Modify the appearance as desired for your application (for example, choose Transparent as the Back style if you are drawing the Goto button over an existing object on your display).
 - b. Click the ellipse next to the Display field and assign the PowerMonitor500_Faceplate display.
 - c. Click the ellipse next to the Parameter file field and assign the PowerMonitor parameter file you created earlier for this intended device.



4. Follow these steps to use a bitmap image with the button.
 - a. Click the Label Tab and click the ellipse next to the Image field.
 - b. Click Add from File and select the PowerMonitor500 Bitmap Image located in the ME PowerMonitor 500 Faceplates Files folder.

IMPORTANT You only need to add the image from File the first time you use the image. Once added, the image can be selected from the image list.

- c. Click Open to add the image then OK to close the Image Browser window.
- d. Add text in the Caption field if desired.



- e. Click OK to close the Goto button properties window.
- This is an example of a final goto button on your display.




5. To support additional PowerMonitor 500 devices, create a new Goto display navigation button, assign the PowerMonitor500 faceplate display, and assign a unique parameter file associated with the additional device.


Configure PowerMonitor 5000 Unit Faceplates

The ME PowerMonitor 5000 Faceplate files lets you quickly load, configure, and use a preconfigured status display or 'faceplate' for the PowerMonitor 5000 using FactoryTalk View Machine Edition.


These instructions are for PowerMonitor 5000 units communicating over the EtherNet/IP network only.




Shows voltage, current, and frequency status.



Shows the power status.



Shows real, reactive, and apparent energy odometers.
Also lets the operator configure the device name for display at the top of the faceplate.



Only the most critical alarms are displayed on the PowerMonitor 5000 faceplate.

- Metering Conditions - Loss of Metering Voltage
- Over Range - Voltage/Ampere Over Range
- Power Quality - Sag/Swell Detected

Configure RSLogix5000 for the PowerMonitor 5000 Unit Faceplate


Follow these procedures to configure the faceplate.

Add the PowerMonitor 5000 Unit to your Ethernet Network


1. Create a new or open an existing RSLogix5000 file.
2. Under I/O Configuration, right-click the network communication module to be used for the intended drive.

IMPORTANT This step assumes you have already added and configured an Ethernet module to your I/O tree.


3. Select 'New Module.'
4. Select the PowerMonitor 5000 unit and click OK.



5. Enter a distinct module name and the IP Address of your power monitor.
(For example, we use 'MyPM5000' for the module name throughout this document.)




6. Click Change to launch the Module Definition window.
7. Select the firmware of the device you are using.



8. Click OK to accept the changes.
9. Click OK again to close the dialog.


Import the PowerMonitor 5000 Unit Faceplate Routine

1. From the Controller Organizer, right-click on the program where you would like to add the power monitor faceplate routine, and choose Import Routine.




- Navigate to the ME PowerMonitor 5000 Faceplate Files folder, select the RXX_PowerMonitor5000_Faceplate routine, and click Import.

The Import Configuration dialog box opens.




- Enter the name for your routine in the Final Name field.




- In the Import Content organizer, select tags.

The Configure Tag References dialog box opens.

- Replace _DeviceName in the Final Name with the name of your device.




For the 'MyPM5000' example, the Final Names are renamed to the following:




6. In the Import Content organizer, select Other Components.

The communication path can be set for all messages by selecting the device from the I/O configuration drop-down in the Component References.

7. Click OK.



The new Routine appears in the Controller Organizer within the selected program.



8. Add a JSR to your main routine, or other desired location, to execute the new routine.




Configure FactoryTalk View ME for the PowerMonitor 5000 Unit Faceplate


Follow these procedures to configure the faceplate.

Add PowerMonitor 5000 Unit Faceplate to ME Application

1. Launch FactoryTalk View Studio software and create or open an existing application file.
2. In the Graphics folder, right-click on Displays and choose 'Add Component Into Application'.




3. Navigate to the ME PowerMonitor 5000 Faceplate Files folder, select the PowerMonitor5000_Faceplate, and click Open.



Add a Parameter File

1. Right-click on Parameters, and choose 'Add Component Into Application'.



2. Navigate to the ME PowerMonitor 5000 Faceplate Files folder, select the ME_PowerMonitor5000_Parameter.par file, and click Open.

Configure a Parameter File

1. From the explorer window in FactoryTalk View Studio, in the Parameters folder, right-click the ME_PowerMonitor5000_Parameter.par file, and choose Rename.
2. Rename the parameter file with the name of the corresponding device in your RSLogix5000 application.
3. For example, MyPM5000_Parameter.
4. Double-click the parameter file to open it.

Parameter #1 represents the tag name for the specific Faceplate tag in your RSLogix 5000 project. Each tag contains a controller shortcut name in brackets. This matches the shortcut name created in your RSLinx Enterprise communication setup.

```

===== Parameter File Created 2013/05/13 =====
! Parameter files are used with graphic displays to specify the tags a display
! uses at run time. You assign parameter files in certain application components
! and object properties dialog boxes. Please see the Help for details.
! Syntax:
!   #replacement=tagname
! Example:
!   #1=::[CLX]DeviceName_FP
! #1 in any expression is replaced by the tag ::[CLX]DeviceName_FP
!
! For Example:
! ::[CLX] --> Represents the 'Device Shortcut' name of Logix controller you configured in
! RSLinx Enterprise Communication Setup.
!
! DeviceName_FP --> Represents the AOI name for the device configured in your Logix application.
! =====
#1=[CLX]DeviceName_FP
  
```


- For parameter #1, change the shortcut name [CLX] to match your communication setup and DeviceName to match the tag configured in your RSLogix5000 project.

For the MyPM5000 example, the configuration would look like the following:

```

===== Parameter File Created 2013/05/13 =====
! Parameter files are used with graphic displays to specify the tags a display
! uses at run time. You assign parameter files in certain application components
! and object properties dialog boxes. Please see the Help for details.
! Syntax:
! #replacement=tagname
! Example:
! #1=::[CLX]DeviceName_FP
! #1 in any expression is replaced by the tag ::[CLX]DeviceName_FP
!
! For Example:
! ::[CLX] --> Represents the 'Device Shortcut' name of Logix controller you configured in
! RSLinx Enterprise Communication Setup.
!
! DeviceName_FP --> Represents the AOI name for the device configured in your Logix application.
! =====
#1=[CLX]MyPM5000_FP


```

- Save your parameter file.
- To add parameter files for additional power monitors:
 - Right-click on the parameter file that you just created and choose Duplicate.
 - Rename the file with the new device name.
 - Open the parameter file and configure the tag to match the associated device.

Create a Display Navigation Button


A display navigation button must be created to launch the PowerMonitor Faceplate at runtime. This can be drawn over an existing graphic object that represents the device you intend to monitor/control or it can be configured to use a bitmap image as the display.

- From the display where you want to launch the faceplate (can be a new or an existing display), choose Objects > Display Navigation > Goto.



- Draw the Goto button rectangle.


3. Double-click the new Goto rectangle to configure the button properties.
 - a. Modify the appearance as desired for your application (for example, choose Transparent as the Back style if you are drawing the Goto button over an existing object on your display).
 - b. Click the ellipse next to the Display field and assign the PowerMonitor5000_Faceplate display.
 - c. Click the ellipse next to the Parameter file field and assign the PowerMonitor parameter file you created earlier for this intended device.



4. Follow these steps to use a bitmap image with the button.
 - a. Click the Label Tab and click the ellipse button next to the Image field.
 - b. Click Add from File and select the PowerMonitor5000 Bitmap Image located in the ME PowerMonitor 5000 Faceplates Files folder.

IMPORTANT You only need to add the image from File the first time you use the image. Once added, the image can be selected from the image list.

- c. Click Open to add the image then OK to close the Image Browser window.
- d. Add text in the Caption field if desired.



- e. Click OK to close the Goto button properties window.

This is an example of a final goto button on your display.



To support additional PowerMonitor 5000 devices, create a new Goto display navigation button, assign the PowerMonitor5000 faceplate display, and assign a unique parameter file associated with the additional device.

Configure ME PowerFlex Drives Faceplates

The ME PowerFlex® Faceplates files let you quickly load, configure, and use preconfigured status, control, and diagnostic displays or ‘faceplates’ for the PowerFlex family of drives using RSVIEW Machine Edition software.


These instructions are for PowerFlex drives communicating over the EtherNet/IP network only.




Shows status and provides operator control of the drive.




Shows the last fault.




Lets you set the communication fault time, the accel/decel times, and rename the device for display at the top of the faceplate.



Shows basic energy data.



Press Next Pen to shift between the voltage, current, and speed trends.



Lets you set the minimum and maximum values of the trend scale.

Configure RSLogix5000 for the PowerFlex Drive Faceplate


Follow these procedures to configure the faceplate.

Add the PowerFlex Drive to your Ethernet Network

1. Create a new or open an existing RSLogix5000 file.
2. Under I/O Configuration, right-click the network communication module to be used for the intended drive.

IMPORTANT This step assumes you have already added and configured an Ethernet module to your I/O tree.

3. Select 'New Module'.
4. Expand the Drives folder and select the appropriate PowerFlex drive module and click OK.



5. Enter a distinct module name and the IP Address of your drive.

(For example, we use 'Motor_1' for the module name throughout this document.)

IMPORTANT The IP address must match with that of your 20-COMM-E module. This step assumes you already assigned an IP address to your 20-COMM-E module. Refer to the PowerFlex 20-COMM-E EtherNet/IP Adapter User Manual, publication [20COMM-UM010](#), for information on how to assign it an IP address.

6. Click Change to launch the Module Definition window.

7. Select the firmware of the device you are using.

IMPORTANT If the firmware revision of your drive is not listed, refer to the lower left corner of the Module Definition window for instructions on how to create a database.

Datalink	Input Data	Output Data
	DriveStatus	DriveLogicRslt
	OutputFreq	CommandedFreq
		<input checked="" type="checkbox"/> Use Network Reference
<input checked="" type="checkbox"/> A	AccelTime1 - 140	AccelTime1 - 140
	DecelTime1 - 142	DecelTime1 - 142
<input checked="" type="checkbox"/> B	Fault1 Code - 243	Undefined_B1
	DCBusVoltage - 12	Undefined_B2
<input checked="" type="checkbox"/> C	OutputCurrent - 3	Undefined_C1
	OutputCurrent - 3	Undefined_C2
<input type="checkbox"/> D		

☒ Sort Input/Output selection lists by Parameter Name

! DANGER: Unexpected, hazardous motion of machinery may occur when improperly using software to configure a drive.

If the revision of your drive is not listed:
 - click Create Database... button below if drive is online.
 - click Web Update... to download the database from the web if drive is offline.

To match revision and upload the configuration of an online drive:
 - click Match Drive.

Parameter names selected for the Input and Output Data appear as member names in the drive Module-Defined Data Types and defines necessary Datalink parameters in the RSLogix 5000 project. Actual data transfer between controller and drive is determined by Datalink parameters.

You must download configuration to the drive to ensure that the controller, drive and communication module configurations are consistent with each other.

Buttons: Create Database..., Web Update..., Match Drive, OK, Cancel, Help.

8. Enter the DataLink Module Definitions exactly as shown for your specific PowerFlex drive.

IMPORTANT The datalinks listed must be configured exactly as shown for successful faceplate AOI import and operation. If additional datalinks are required for your application, modifications to the corresponding AOIs are required. See [Set Other PowerFlex Drive Parameters](#) for more information.

PowerFlex 70, 70EC, 700, & 700H
Datalinks

Datalink	Input Data	Output Data
	DriveStatus	DriveLogicRslt
	OutputFreq	CommandedFreq
		<input checked="" type="checkbox"/> Use Network Reference
<input checked="" type="checkbox"/> A	AccelTime1 - 140	AccelTime1 - 140
	DecelTime1 - 142	DecelTime1 - 142
<input checked="" type="checkbox"/> B	Fault1 Code - 243	Undefined_B1
	DCBusVoltage - 12	Undefined_B2
<input checked="" type="checkbox"/> C	OutputCurrent - 3	Undefined_C1
	OutputCurrent - 3	Undefined_C2
<input type="checkbox"/> D		

PowerFlex 700S & 700S 2P Datalinks

Datalink	Input Data	Output Data
	LogicStatus	LogicCommand
	SpeedFeedback	SpeedReference
		<input checked="" type="checkbox"/> Use Network Reference
<input checked="" type="checkbox"/> A	AccelTime - 32	AccelTime - 32
	DecelTime - 33	DecelTime - 33
<input checked="" type="checkbox"/> B	DCBusVoltage - 306	Undefined_B1
	OutputCurrent - 308	Undefined_B2
<input type="checkbox"/> C		
<input type="checkbox"/> D		

PowerFlex 753 Datalinks

Datalink	Input Data	Output Data
	DriveStatus	LogicCommand
	Feedback	Reference
		<input checked="" type="checkbox"/> Use Network Reference
<input checked="" type="checkbox"/> A	AccelTime1	AccelTime1
	DecelTime1	DecelTime1
<input checked="" type="checkbox"/> B	LastFaultCode	Undefined_B1
	DCBusVolts	Undefined_B2
<input checked="" type="checkbox"/> C	OutputCurrent	Undefined_C1
	Undefined_C2	Undefined_C2
<input type="checkbox"/> D		

PowerFlex 755 Datalinks

Input Data	Output Data
DriveStatus	LogicCommand
Feedback	Reference
	<input checked="" type="checkbox"/> Use Network Reference
AccelTime1	AccelTime1
DecelTime1	DecelTime1
LastFaultCode	
DCBusVolts	
OutputCurrent	
OutputPower	


For the PowerFlex 750 drives, in addition to configuring datalinks, verify that Use Network Reference is checked.

IMPORTANT If you create multiple PowerFlex Module Definitions for the same type of drive (PF 70) with unique datalink definitions, you also have to create unique AOIs with unique names for those modules.


9. Click OK to accept the changes.
10. Click OK again to close the dialog box.

Import the PowerFlex Unit Faceplate Routine


1. From the Controller Organizer, right-click on the program where you would like to add the PowerFlex unit faceplate routine, and choose Import Routine.




2. Navigate to the ME PowerFlex Faceplate Files folder, select the routine for the drive you are using, and click Import.




The Import Configuration dialog box opens.




- Enter the name for your routine in the Final Name field.



- In the Import Content organizer, select tags.
The Configure Tag References dialog box opens.
- Replace `_DeviceName` in the Final Name with the name of your device.




For the 'Motor_1' example, the Final Names are renamed to the following:




6. In the Import Content organizer, select Other Components.

The communication path can be set for all messages by selecting the device from the I/O configuration drop-down in the Component References.




7. Click OK.

The new Routine appears in the Controller Organizer within the selected program.




8. Open the routine and enter the value for the Inp_Scaled_Speed_At_XXXX input on the AOI on rung 1.

The AOI scales the drive input and output speed values based on the value entered.




9. Add a JSR to your main routine, or other desired location, to execute the new routine.



Set Other PowerFlex Drive Parameters

PowerFlex drive parameter settings are very specific to your application and need to be reviewed carefully before running your drive application. If you modify the datalink configuration for any PowerFlex drive, follow these steps to re-configure tag data types in the PowerFlex AOI.


1. In your RSLogix5000 Controller Organizer, expand the Add-On Instructions folder.
2. Select the AOI for your PowerFlex drive and double click on 'Parameters and Local Tags'.
3. Select the Edit Tags tab and locate the 'Inp_PowerFlex_*' AOI tag.
4. Change the Data Type to match the PowerFlex Module Input Data Type that applies to your application.



5. Repeat the previous steps for the 'Out_PowerFlex_*' AOI tag by using the Module Output Data Type.

IMPORTANT Any time you modify your PowerFlex module definitions after you have created your PowerFlex AOI, it is necessary for you to reassign your PowerFlex AOI Input and Output Tag Data Types. If multiple changes to your PowerFlex module definitions were made and saved, there are multiple Data Types listed for a particular DataLink configuration. Be careful to match the Data Type you select within the AOI to the Data Type of the intended PowerFlex module definition.


6. Select the 'Drive' tab of the PowerFlex Module Properties.




7. Open the Parameter List and modify as your application requires.

In addition to application required parameters, the following parameter settings must be applied for general Ethernet/IP network communication for the PowerFlex drive faceplates to operate correctly.

- a. For the PowerFlex 70, 70EC, 700, 700VC, and 700H drives, set parameter 90 to DPI Port 5 (22).




- b. For the PowerFlex 700S drives, set parameter 16 to Spd Ref DPI (6) and parameter 691 to Int DPI Comm (5).



- c. For the PowerFlex 700S 2P drives, set parameter 27 to DPI Port 5 (16).



- d. For the PowerFlex 753 drives, verify that parameter 545 Spd Ref A Sel is set to Port 0: Port 6 Reference and the value is set to 876.




8. Close the Parameter List window.
 9. Download your parameters to the PowerFlex drive by choosing the download icon from the toolbar.
- Follow prompts to complete the download process.




Correlate the Online Drive


1. On the Drive tab, click Connect to Drive.



2. Select which drive to connect to and click OK.



3. In the Differences Found dialog box, click Download.




4. When the drive download successfully completes, the drive status indicates 'Connected', highlighted in green.




Import Program Control Rungs

Example logic is provided for configuring program commands. To import this configuration, follow these steps.

1. Choose a routine for importing the new rungs.
2. On a new rung, right click and select 'Import Rungs'
3. From the Basic PowerFlex Control folder, select 'PowerFlex_Control_Rungs.L5X' and click Import.
4. Click Tags in the Import Content organizer.
5. Replace '_DriveName' in the Final Name field with the name of your PowerFlex module and click OK.




6. Select Add-On Instructions in the Import Content organizer.
7. Discard the import of the PFlex_70_AOI (this AOI was used to create the rung import file, but is needed, because the existing AOI for your PowerFlex drive is used).



Important Program and Operator Control Transfer Considerations

The first three rungs of each AOI handle the transfer of control from the Logix program (Program Control) to the faceplate (Operator Control). The two Operator Control rungs are shown below. It is important to understand how these rungs operate so your desired program to operator and operator to program control transfers are achieved.



For example, these rungs enable the Operator Control of the intended PowerFlex drive. Command requests (Cmd) can be initiated from either the Logix Programs (ProgOperReq) or RSViewME/SE PowerFlex Faceplate (OperOperReq).

The following is a specific drive example:

EXAMPLE To enable Operator Control for a drive associated with 'Motor_1' AOI instance, a rung can be added to the Logix MainRoutine with specific input conditions driving an output instruction with the tag name 'Motor_1.Cmd_ProgOperReq'. Also, a pushbutton in an RSView ME/SE faceplate can be added with a value tag name of '#1.Cmd_OperOperReq' with the #1 parameter for that faceplate display associated with 'Motor_1' tag.

A 'Motor_1.Cmd_ProgToOperPermissive' must also be included in the Logix Program to control whether Program to Operator Control transfer requests are allowed or acted upon. A tag value of 1 permits the associated control transfer requests. A value of 0 prevents the associated control transfer requests.



ATTENTION: If an `Xxxx.Cmd_ProgToOperPermissive` tag is set to 1, the associated AOI is programmed to allow a transfer from Program Control to Operator Control regardless of the current direction, speed, or active status of the PowerFlex drive. In addition, the AOI is programmed to transfer the current Program Speed value '`Xxxx.Set_SpeedProg`' to the associated Operator Speed tag, '`Xxxx.Set_SpeedOper`', creating a 'bumpless' transfer when a transfer from Program Control to Operator Control is executed. Therefore, if the PowerFlex drive is running at the time of a Program to Operator Control transition, the PowerFlex drive continues to run at the most recent commanded Program Speed. If a different Program to Operator Control transition is desired, then the status of the PowerFlex drive and the Operator command requests must be monitored and the appropriate Program commands must be issued before the `Xxxx.Cmd_ProgToOperPermissive` is allowed. Therefore, it is very important that the status of the PowerFlex drive is monitored and appropriate Program commands, for the specific application, are issued before the `Xxxx.Cmd_ProgToOperPermissive` tag is set, to insure a safe Program to Operator Control transfer.



ATTENTION: If an `Xxxx.Cmd_OperToProgramPermissive` tag is set to 1, the associated AOI is programmed to allow a transfer from Operator Control to Program Control regardless of the current direction, speed, or active status of the PowerFlex Drive. In addition, there is no logic within the AOI that sets the '`Set_SpeedProg`' upon transfer to Program mode, so the PowerFlex drive assumes the last commanded '`Set_SpeedProg`' speed value unless logic is programmed outside of the AOI to set it to a different value. Therefore, it is very important that the status of the PowerFlex Drive is monitored and appropriate Program commands, for the specific application, are issued before the `Xxxx.Cmd_OperToProgramPermissive` tag is set, to insure a safe Operator to Program Control transfer.



ATTENTION: If The PowerFlex drive is started in Operator Mode and the RSView ME PowerFlex faceplate is closed while the PowerFlex drive is running, the PowerFlex drive continues running at the current `Set_SpeedOper` tag value. Therefore, it is very important to understand how this operation affects the specific application and appropriate actions and safeguards are implemented.




ATTENTION: There is no logic in the AOI that controls the minimum or maximum PowerFlex Commanded Speed values sent to the specific drive. Therefore, it is very important to understand the limitations of the motor connected to the specific drive and set the appropriate PowerFlex drive parameters and add additional Program logic if necessary.

Configure FactoryTalk View ME for the PowerFlex Drive Unit Faceplate


Follow these procedures to configure the faceplate.

Add PowerFlex Drive Faceplate to ME Application

1. Launch FactoryTalk View Studio software and create or open an existing application file.
2. In the Graphics folder, right-click on Displays and choose 'Add Component Into Application'.




3. Navigate to the ME PowerFlex Faceplate Files folder, select the applicable PowerFlex faceplate, and click Open.



Add a Parameter File

1. Right-click on Parameters, and choose 'Add Component Into Application'.



2. Navigate to the ME PowerFlex Faceplate Files folder, select the ME_PowerFlex_Parameter.par file, and click Open.

Configure a Parameter File

1. From the explorer window in FactoryTalk View Studio, in the Parameters folder, right-click the ME_PowerFlex_Parameter.par file, and choose Rename.
2. Rename the parameter file with the name of the corresponding device in your RSLogix5000 application.
For example, Motor_1.
3. Double-click the parameter file to open it.

The parameter file contains configuration for two parameters. Parameter #1 represents the tag name for the specific Faceplate AOI in your RSLogix 5000 project. Parameter #2 represents the tag name for the Base Energy Object tag (UDT_BE0) in your RSLogix5000 project. This second parameter only applies when the energy monitoring option is being used. Each tag contains a controller shortcut name in brackets. This must match the shortcut name created in your RSLinx Enterprise communication setup.

```

===== Parameter File Created 2010/07/21 =====
! Parameter files are used with graphic displays to specify the tags a display
! uses at run time. You assign parameter files in certain application components
! and object properties dialog boxes. Please see the Help for details.
! Syntax:
!   #replacement=tagname
! Example:
!   #1:::[CLX]DriveName_FP
! #1 in any expression is replaced by the tag ::[CLX]DriveName_FP
!
! For Example:
! ::[CLX] --> Represents the 'Device Shortcut' name of Logix controller you configured in
! RSLinx Enterprise Communication Setup.
!
! DriveName_FP --> Represents the AOI name for the device configured in your Logix application file.
! DriveName_BE0 --> Represents the tagname for the Base Energy Object tag (UDT_BE0) configured in your Logix application file.
! This only applies when using the faceplate with the energy tab.
=====


#1=[CLX]DriveName_FP

! #2 only applies If using the faceplate with the energy tab
#2=[CLX]DriveName_BE0

```

4. Replace the shortcut name (CLX) and DriveName in parameters 1 and 2(if applicable) to match the tags configured in your RSLogix5000 project.

For the Motor_1 example, the configuration looks like the following:




5. Save your parameter file.
6. To add parameter files for additional drives:
 - a. Right-click on the parameter file that you just created and choose Duplicate.
 - b. Rename the file with the new device name.
 - c. Open the parameter file and configure the tag to match the associated device.


Create a Display Navigation Button

A display navigation button must be created to launch the PowerFlex faceplate at runtime. This can be drawn over an existing graphic object that represents the device you intend to monitor/control or it can be configured to use a bitmap image as the display.

1. From the display where you want to launch the faceplate (can be a new or an existing display), choose **Objects > Display Navigation > Goto**.




2. Draw the Goto button rectangle.
3. Double-click the new Goto rectangle to configure the button properties.
 - a. Modify the appearance as desired for your application (for example, choose Transparent as the Back style if you are drawing the Goto button over an existing object on your display).
 - b. Click the ellipse next to the Display field and assign the PowerFlex Faceplate display.
 - c. Click the ellipse next to the Parameter file field and assign the PowerFlex parameter file you created earlier for this intended device.



4. Follow these steps to use a bitmap image with the button.
 - a. Click the Label Tab and click the ellipse button next to the Image field.
 - b. Click Add from File and select the PowerFlex Bitmap Image located in the ME_PowerFlex_GotoButtons folder.

IMPORTANT You only need to add the image from File the first time you use the image. Once added, the image can be selected from the image list.

- c. Click Open to add the image then OK to close the Image Browser window.
- d. Add text in the Caption field if desired.



- e. Click OK to close the Goto button properties window.

This is an example of a final goto button on your display.




To support additional PowerFlex devices, create a new Goto display navigation button, assign the PowerFlex faceplate display, and assign a unique parameter file associated with the additional device.


Configure ME E3PLUS Faceplates

The ME E3PLUS Faceplate files provide a pre-configured display and associated logic for the E3 Plus Solid State Overload Relay using FactoryTalk View Machine Edition and RSLogix 5000. The faceplate includes status, control, diagnostic, and energy views controlled by its own toolbar buttons.


The E3 Plus faceplate is compatible only with the E3 Plus Overload Relays communicating with the 193-DNENCAT.




Shows status and provides operator control of the Trip Reset and Outputs A and B.



Shows the last fault.



Lets you rename the device for display at the top of the faceplate.



Shows basic energy data.

DeviceNet to EtherNet/IP Network Setup

In order for the faceplate add-on instruction to function properly in your RSLogix5000 application, you need to configure the following parameters for your E3 Plus module:

- Param 59, Output Assembly = 105
- Param 60, Input Assembly = 100
- Param 61, Assy Word 0 Param = 21 (supplies status of Inputs and Outputs)
- Param 62, Assy Word 1 Param = 4 (supplies Avg current)
- Param 63, Assy Word 2 Param = 14 (supplies Trip Status)
- Param 64, Assy Word 3 Param = 15 (supplies Warning Status)

The Communication Auxiliary module can be configured by using an internal web page.

1. Type the IP Address of your 193-DNENCATR module into the URL window in an internet browser.



2. Select Scan List Configuration to configure the scan list to allow for E3 Plus communication.
3. When prompted, use 'Administrator' as the User name, leave the password blank, and click OK.



4. Select the E3 Plus for your application and click Save.




5. Select E3 Plus > Parameters > DNET Setup and edit these parameters:

IMPORTANT You must set these parameters or the AOI does not function properly in your RSlogix5000 application.

- Param 59, Output Assembly = 105
- Param 60, Input Assembly = 100
- Param 61, Assy Word 0 Param = 21 (supplies status of Inputs and Outputs)
- Param 62, Assy Word 1 Param = 4 (supplies Avg current)
- Param 63, Assy Word 2 Param = 14 (supplies Trip Status)
- Param 64, Assy Word 3 Param = 15 (supplies Warning Status)

When your edit is complete, be sure to Save the changes.



6. Configure additional parameters for the E3 Plus.

Refer to the E3 and E3 Plus Solid-State Overload Relay User Manual, publication [193-um002](#). Determine which trips, warnings, and corresponding parameter limits are to be enabled. The E3 Plus Overload Relay faceplate is configured to support all the Trip and Warning Status as defined in the user manual.

Trip Status	Warning Status
Overload Phase Loss	Overload
Ground Fault	Ground Fault
Stall Jam	Jam
Underload	Underload
PTC	PTC
Current Imbal	Current Imbal
Comm Fault	Comm Fault
Comm Idle	Comm Idle
Remote Trip (only in major revision 3 of E3 Plus)	

In this example, the Overload, Phase Loss, and Comm Fault trips are enabled.



Configure RSLogix5000 for the E3 Plus Faceplate

Follow these procedures to configure the faceplate.

Add the 193-DNENCATR(R) Communication Module to your Ethernet Network


1. Create a new or open an existing RSLogix 5000 file.
2. Under I/O Configuration, right-click the network communication module to be used for the intended E3 Plus module.

IMPORTANT This step assumes you have already added and configured an Ethernet module to your I/O tree.


3. Select 'New Module'.

- Expand the Communications folder and select the '193-DNENCAT' (or 193-DNENCATR) module and click OK.

IMPORTANT If this module is not available in the list, you can update the Add-on Profile for your device. Refer to Appendix E for more information on updating the Add-on Profiles.




- Enter a distinct module name and the IP Address of your DNENCAT module.
(For example, we use 'Motor_1' for the module name throughout this document.)



The default setting for Data Mapping is Generic.

- If Data Mapping is not set to Generic, click 'Change' under the Module Definition and set Data Mapping to Generic.




IMPORTANT The E3 Plus faceplate AOI has been configured to work with the Generic data mapping. If you change the data mapping to a specific type of E3 the AOI does not function properly.

- Click OK to close the Module Properties window.

Import the E3 Plus Module Faceplate Routine


- From the Controller Organizer, right-click on the program where you would like to add the E3 Plus module faceplate routine, and choose Import Routine.




2. Navigate to the ME E3 PLUS Faceplate Files folder, select the RXX_E3Plus_Faceplate_Energy.L5X file, and click Import.



The Import Configuration dialog box opens.




3. Enter the name for your routine in the Final Name field.




4. In the Import Content organizer, select tags.

The Configure Tag References dialog box opens.

5. Replace `_DeviceName` in the Final Name with the name of your device.




For the 'Motor_1' example, the Final Names are renamed to the following:




6. In the Import Content organizer, select Other Components.

The communication path can be set for all messages by selecting the device from the I/O configuration drop-down in the Component References.




7. Click OK.

The new Routine appears in the Controller Organizer within the selected program.



8. Add a JSR to your main routine, or other desired location, to execute the new routine.




9. Open the new routine that you just created.

The communication path for the message instruction in rung 1 needs to be configured with the port number for the DeviceNet scanner and the node address for the E3 Plus.

- a. Click on the ellipse in the E3Plus_CommsAux_Rev6_AOI instruction next to the Ref_MSG1 input.
- b. Click the Communication tab.
- c. Add the 193-DNENCAT port number and your E3 Plus node address to your path configuration in the following format: _DeviceName, 3, #.

TIP DeviceName - the name of the EtherNet/IP Communications Auxiliary Module
 3 - the port number of the DeviceNet Scanner of the EtherNet/IP Communications Auxiliary.
 5 - the node address of the E3 Plus Overload Relay.




The communication path for the message instruction in rung 6 also needs to be configured with the port number for the DeviceNet scanner and the node address for the E3 Plus.

- d. Click on the ellipse in the MSG instruction in rung 6.

- e. Click the Communication tab.
- f. Add the 193-DNENCAT port number and your E3 Plus node address to your path configuration in the following format: Motor1, 3, #.


TIP Motor_1 - the name of the EtherNet/IP Communications Auxiliary
 3 - the port number of the DeviceNet Scanner of the EtherNet/IP Communications Auxiliary.
 5 - the node address of the E3 Plus Overload Relay.



Import Program Control Rungs


Example logic is provided for configuring program commands. Follow these steps to import this configuration.

1. Choose a routine for importing the new rungs.
2. On a new rung, right click and select 'Import Rungs...'
3. From the ME E3 Plus Faceplate Files folder, select "E3Plus_Control_Rungs.L5X." Click Import.
4. Click Tags within the Import Content organizer.
5. Replace "_DeviceName" in the Final Name field with the name of your E3 Plus device. Click OK.



Important Program and Operator Control Transfer Considerations

The first two rungs of the E3Plus_CommsAux AOI handle the transfer of control from the Logix program (Program Control) to the faceplate (Operator Control). These are the two Operator Control rungs. It is important to understand how these rungs operate so your desired program to operator and operator to program control transfers are achieved.



For example, these rungs enable the Program or Operator Control of the intended E3 Plus Overload Relay. Command requests (Cmd) can be initiated from either the Logix Programs (ProgOperReq) or the FactoryTalk View ME E3 Plus Faceplate (OperOperReq).

EXAMPLE

To enable Operator Control for a device associated with 'Motor_1' AOI instance, a rung is added to the Logix MainRoutine with specific input conditions driving an output instruction with the tag name 'Motor_1.Cmd_ProgOperReq'. Likewise, a pushbutton in an RSView ME/SE Faceplate is added with a value tag name of '#1.Cmd_OperOperReq' with the #1 parameter for that faceplate display associated with 'Motor_1' tag.


A 'Motor_1.Cmd_ProgToOperPermissive' must also be included in the Logix Program to control whether Program to Operator Control transfer requests are allowed or acted upon. A tag value of 1 permits the associated control transfer requests. A value of 0 prevents the associated control transfer requests.

Configure FactoryTalk View ME for the E3 Plus Module Faceplate


Follow these procedures to configure the faceplate.

Add E3 Plus Module Faceplate to ME Application

1. Launch FactoryTalk View Studio software and create or open an existing application file.
2. In the Graphics folder, right-click on Displays and choose 'Add Component Into Application'.




3. Navigate to the ME E3 Plus Faceplate Files folder, select the E3Plus_Faceplate_Energy.gfx file, and click Open.



Add a Parameter File

1. Right-click on Parameters, and choose 'Add Component Into Application'.



2. Navigate to the ME E3PLUS Faceplate Files folder, select the E3Plus_Parameter.par file, and click Open.

Configure a Parameter File

1. From the explorer window in FactoryTalk View Studio, in the Parameters folder, right-click the E3Plus_Parameter file, and choose Rename.
2. Rename the parameter file with the name of the corresponding device in your RSLogix5000 application.

For example, Motor_1.

3. Double-click the parameter file to open it.

The parameter file contains configuration for two parameters. Parameter #1 represents the tag name for the specific Faceplate AOI in your RSLogix 5000 project. Parameter #2 represents the tag name for the Base Energy Object tag (UDT_BEO) in your RSLogix5000 project. This second parameter only applies when the energy monitoring option is being used. Each tag contains a controller shortcut name in brackets. This must match the shortcut name created in your RSLinx Enterprise communication setup.

```

===== Parameter File Created 2013/05/13 =====
! Parameter files are used with graphic displays to specify the tags a display
! uses at run time. You assign parameter files in certain application components
! and object properties dialog boxes. Please see the Help for details.
! Syntax:
!   #replacement=tagname
! Example:
!   #1=::[CLX]DeviceName_FP
! #1 in any expression is replaced by the tag ::[CLX]DeviceName_FP
!
! For Example:
! ::[CLX] --> Represents the 'Device Shortcut' name of Logix controller you configured in
! RSLinx Enterprise Communication Setup.
!
! DeviceName_FP --> Represents the AOI name for the device configured in your Logix application.
! DeviceName_BEO --> Represents the tagname for the Base Energy Object tag (UDT_BEO)
!                   configured in your Logix application file.
!                   This only applies when using the faceplate with the energy tab.
=====

#1=[CLX]DeviceName_FP

! #2 only applies If using the faceplate with the energy tab
#2=[CLX]DeviceName_BEO

```

4. Replace the shortcut name (CLX) and DriveName in parameters 1 and 2(if applicable) to match the tags configured in your RSLogix5000 project.

For the Motor_1 example, the configuration looks like the following:

```

===== Parameter File Created 2013/05/13 =====
! Parameter files are used with graphic displays to specify the tags a display
! uses at run time. You assign parameter files in certain application components
! and object properties dialog boxes. Please see the Help for details.
! Syntax:
!   #replacement=tagname
! Example:
!   #1=::[CLX]DeviceName_FP
! #1 in any expression is replaced by the tag ::[CLX]DeviceName_FP
!
! For Example:
! ::[CLX] --> Represents the 'Device Shortcut' name of Logix controller you configured in
! RSLinx Enterprise Communication Setup.
!
! DeviceName_FP --> Represents the AOI name for the device configured in your Logix application.
! DeviceName_BEO --> Represents the tagname for the Base Energy Object tag (UDT_BEO)
!                   configured in your Logix application file.
!                   This only applies when using the faceplate with the energy tab.
=====

#1=[CLX]Motor_1_FP

! #2 only applies If using the faceplate with the energy tab
#2=[CLX]Motor_1_BEO

```


5. Save your parameter file.

6. To add parameter files for additional E3 Plus modules:
 - a. Right-click on the parameter file that you just created and choose Duplicate.
 - b. Rename the file with the new device name.
 - c. Open the parameter file and configure the tag to match the associated device.


Create a Display Navigation Button

A display navigation button must be created to launch the E3 Plus faceplate at runtime. This can be drawn over an existing graphic object that represents the device you intend to monitor/control or it can be configured to use a bitmap image as the display.

1. From the display where you want to launch the faceplate (can be a new or an existing display), choose Objects > Display Navigation > Goto.




2. Draw the Goto button rectangle.
3. Double-click the new Goto rectangle to configure the button properties.
 - a. Modify the appearance as desired for your application (for example, choose Transparent as the Back style if you are drawing the Goto button over an existing object on your display).
 - b. Click the ellipse next to the Display field and assign the E3PLUS_Faceplate_Energy display.
 - c. Click the ellipse next to the Parameter file field and assign the E3PLUS parameter file you created earlier for this intended device.



4. Follow these steps to use a bitmap image with the button.
 - a. Click the Label Tab and click the ellipse button next to the Image field.
 - b. Click Add from File and select the E3 Plus Bitmap Image located in the ME E3 Plus Files folder.

IMPORTANT You only need to add the image from File the first time you use the image. Once added, the image can be selected from the image list.

- c. Click Open to add the image then OK to close the Image Browser window.
- d. Add text in the Caption field if desired.



- e. Click OK to close the Goto button properties window.
- This is an example of a final goto button on your display.




To support additional E3 Plus modules, create a new Goto display navigation button, assign the E3 Plus faceplate display, and assign a unique parameter file associated with the additional device.


Configure ME E300 Faceplate

The ME E300 Faceplate files provide a preconfigured display and associated logic for the E300 Electronic Overload Relay using FactoryTalk View Machine Edition and RSLogix5000 software. The faceplate includes status, control, diagnostic, and energy views controlled by its own toolbar buttons.


The E300 module faceplate is compatible only with E300 Relay modules communicating over the EtherNet/IP network.




Shows status and provides operator control of the Trip Reset and Outputs.




Shows the last fault.



Lets you configure the min and max EU values to be displayed on the trend display and rename the device for display at the top of the faceplate



The energy data displayed is dependent on the module definition configured in the controller. If you do not have a voltage-sensing module configured, only the current is displayed on the energy tab.



Shows a trend of the current or %TCU.

Configure RSLogix5000 for the E300 Module Faceplate

Follow these procedures to configure the faceplate.


Add the E300 Module to Your Ethernet Network

1. Create a new or open an existing RSLogix 5000 file.
2. Under I/O Configuration, right-click the network communication module to be used for the intended E300 module.

IMPORTANT This step assumes you have already added and configured an Ethernet module to your I/O tree.

3. Select 'New Module'.
 4. Select the E300 Electronic Overload Relay Communication module (193-ECM-ETR) and click OK.
-

IMPORTANT If this module is not available in the list, you can update the Add-on Profile for your device. Refer to Appendix E for more information on updating the Add-on Profiles.



5. Enter a distinct module name and the IP Address of your E300 module.

(For example, we use 'MyE300' for the module name throughout this document.)

New Module

General

Type: 193-ECM-ETR E300 Electronic Overload Relay, 2-Port
 Vendor: Allen-Bradley
 Parent: Ethernet
 Name: MyE300
 Description:

Ethernet Address
☒ Private Network: 192.168.1.3
☐ IP Address:
☐ Host Name:

Module Definition
 Series: A
 Revision: 1.1
 Electronic Keying: Compatible Module
 Connection: Data
 Sensing Module: XXX-ESM-IG-30A
 Control Module: 193-EIO-43-120
 Control Strategy: Overload

The E300 Control Strategy may override control of module outputs from the controller.

Status: Creating

OK Cancel Help

6. Click Change to launch the Module Definition window.
7. Select the specific E300 Electronic Overload Relay Sensing and Control Modules and their respective Option Match actions.

Module Definition

MyE300


Series: A
 Revision: 1
 Electronic Keying: Compatible Module
 Connection: Data

Sensing Module
 Module: XXX-ESM-IG-30A
 Description: 0.5A-30A, Current & Ground Fault
 Mismatch Action: Trip


Control Module
 Module: 193-EIO-43-120
 Description: 4 Point 110V-120V AC Input, 3 Point Relay Output
 Mismatch Action: Trip

OK Cancel Help

8. Right click on the Expansion Bus to add the specific Expansion Bus accessories for the E300 Electronic Overload Relay system and select their specific Option Match action.
9. When finished, click OK.




10. Configure the Operating Mode and associated relay output assignments for the E300 Electronic Overload Relay.




The E300 module lets you configure up to 8 Datalinks.

11. Select the parameters for the additional data to be included with the input tags.

12. Click OK to complete the module definition.



13. Select Protection and set the overload configuration parameters for your specific application and click OK.




14. To configure the other protection configuration parameters, follow these steps.
- In Controller Tags, browse to the configuration tags of the newly added E300 module.
 - Modify the configuration tags directly to enable and adjust the other current-based and control-based protection functions of the E300 module.


Name	Value	Forc
MyE 300: C.GroundFaultType	1	
MyE 300: C.GroundFaultInhibitTime	10	
MyE 300: C.GroundFaultTripDelay	5	
MyE 300: C.GroundFaultWarnDelay	0	
MyE 300: C.GroundFaultTripLimit	250	
MyE 300: C.GroundFaultWarnLimit	200	
MyE 300: C.PhaseLossInhibitTime	0	
MyE 300: C.PhaseLossTripDelay	10	
MyE 300: C.StallEnabledTime	10	
MyE 300: C.StallTripLimit	600	
MyE 300: C.JamInhibitTime	10	
MyE 300: C.JamTripDelay	50	
MyE 300: C.JamTripLimit	250	
MyE 300: C.JamWarnLimit	150	
MyE 300: C.UnderloadInhibitTime	10	
MyE 300: C.UnderloadTripDelay	50	
MyE 300: C.UnderloadTripLimit	50	
MyE 300: C.UnderloadWarnLimit	70	
MyE 300: C.CurrentImbalanceInhibitTime	10	
MyE 300: C.CurrentImbalanceTripDelay	50	
MyE 300: C.CurrentImbalanceTripLimit	35	
MyE 300: C.CurrentImbalanceWarnLimit	20	

Import the E300 Module Faceplate Routine


1. From the Controller Organizer, right-click on the program where you would like to add the E300 module faceplate routine, and choose Import Routine.




2. Navigate to the ME E300 Faceplate Files folder and select the ME_E300_Faceplate with Energy.L5X file, and click Import.



The Import Configuration dialog box opens.




3. Enter the name for your routine in the Final Name field.




4. In the Import Content organizer, select tags.

The Configure Tag References dialog box opens.

5. Replace _DeviceName in the Final Name with the name of your device.




For the 'MyE300' example, the Final Names are renamed to the following:




6. In the Import Content organizer, select Other Components.

The communication path can be set for all messages by selecting the device from the I/O configuration drop-down in the Component References.



7. Click OK.

The new Routine appears in the Controller Organizer within the selected program.



8. Add a JSR to your main routine, or other desired location, to execute the new routine.




Configure FactoryTalk View ME for the E3 Plus Module Faceplate


Follow these procedures to configure the faceplate.

Add E300 Module Faceplate to ME Application

1. Launch FactoryTalk View Studio software and create or open an existing application file.
2. In the Graphics folder, right-click on Displays and choose 'Add Component Into Application'.




3. Navigate to the ME E300 Faceplate Files folder, select the ME_E300_Faceplate_Energy.gfx, and click Open.



Add a Parameter File

1. Right-click on Parameters, and choose 'Add Component Into Application'.



2. Browse to the ME E300 Faceplate Files folder, select the ME_E300_Parameter.par file, and click Open.

Configure a Parameter File

1. From the explorer window in FactoryTalk View Studio, in the Parameters folder, right-click the ME_E300_Parameter.par file, and choose Rename.
2. Rename the parameter file with the name of the corresponding device in your RSLogix5000 application.
For example, MyE300.
3. Double-click the parameter file to open it.

Parameter #1 represents the tag name for the specific faceplate tag within your RSLogix 5000 project. Each tag contains a controller shortcut name in brackets. This should match the shortcut name created in your RSLinx Enterprise communication setup.

```
ME_E300_Parameter - /DMAT/ (Parameters)
!===== Parameter File Created 2013/05/06 =====
! Parameter files are used with graphic displays to specify the tags a display
! uses at run time. You assign parameter files in certain application components
! and object properties dialog boxes. Please see the Help for details.
! Syntax:
! #replacement=tagname
! Example:
! #1=:[CLX]DeviceName_FP
! #1 in any expression is replaced by the tag ::[CLX]DeviceName_FP
!
! For Example:
! ::[CLX] --> Represents the 'Device Shortcut' name of Logix controller you configured in
! RSLinx Enterprise Communication Setup.
!
! DeviceName_FP --> Represents the AOI name for the device configured in your Logix application file.
! DeviceName_EEO --> Represents the tagname for the Electrical Energy Object tag (UDT_EEO)
!                    configured in your Logix application file.
!                    This only applies when using the faceplate with the energy tab.
!=====
#1=[CLX]DeviceName_FP
```

4. Replace the shortcut name (CLX) and DriveName in parameters 1 to match the tags configured in your RSLogix5000 project.

For the MyE300 example, the configuration looks like the following:

```
! DeviceName_FP --> Represents the AOI name for the device configured in your Logix application file.
! DeviceName_EEO --> Represents the tagname for the Electrical Energy Object tag (UDT_EEO)
!                    configured in your Logix application file.
!                    This only applies when using the faceplate with the energy tab.
!=====
#1=[MyCLX]MyE300_FP
! #2 only applies If using the faceplate with the energy tab
#2=[MyCLX]MyE300_EEO
```

5. For parameter #2, change the shortcut name [CLX] to match your communication setup and DeviceName to match the tag configured in your RSLogix5000 project.

For the MyE300 example, the configuration would look like the following:

```
! DeviceName_FP --> Represents the AOI name for the device configured in your Logix application file.
! DeviceName_EEO --> Represents the tagname for the Electrical Energy Object tag (UDT_EEO)
!                    configured in your Logix application file.
!                    This only applies when using the faceplate with the energy tab.
!=====
#1=[MyCLX]MyE300_FP
! #2 only applies If using the faceplate with the energy tab
#2=[MyCLX]MyE300_EEO
```


6. Save your parameter file.

7. To add parameter files for additional E300 modules:
 - a. Right-click on the parameter file that you just created and choose Duplicate.
 - b. Rename the file with the new device name.
 - c. Open the parameter file and configure the tag to match the associated device.


Create a Display Navigation Button

A display navigation button must be created to launch the E300 faceplate at runtime. This can be drawn over an existing graphic object that represents the device you intend to monitor/control or it can be configured to use a bitmap image as the display.

1. From the display where you want to launch the faceplate (can be a new or an existing display), choose Objects > Display Navigation > Goto.




2. Draw the Goto button rectangle.
3. Double-click the new Goto rectangle to configure the button properties.
 - a. Modify the appearance as desired for your application (for example, choose Transparent as the Back style if you are drawing the Goto button over an existing object on your display).
 - b. Click the ellipse next to the Display field and assign the ME_E300_Faceplate display.
 - c. Click the ellipse next to the Parameter file field and assign the E300 parameter file you created earlier for this intended device.



4. Follow these steps to use a bitmap image with the button.
 - a. Click the Label Tab and click the ellipse button next to the Image field.
 - b. Click Add from File and select the E300 Bitmap Image located in the ME E300 Faceplate Files folder.

IMPORTANT You only need to add the image from File the first time you use the image. Once added, the image can be selected from the image list.

- c. Click Open to add the image then OK to close the Image Browser window.
- d. Add text in the Caption field if desired.



- e. Click OK to close the Goto button properties window.
- This is an example of a final goto button on your display.




To support additional E300 modules, create a new Goto display navigation button, assign the E300 faceplate display, and assign a unique parameter file associated with the additional device.

Configure ME SMC-50 Controller Faceplates

The ME SMC-50 controller faceplate files provide a pre-configured display and associated logic for the SMC-50 Solid State Soft Starter using FactoryTalk View Machine Edition and RSLogix 5000 software. The faceplate includes status, control, diagnostic and energy views controlled by its own toolbar buttons.

These instructions are for the SMC_50 communicating over the EtherNet/IP network only.

Home Display




Shows status and provides operator control of the soft starter

Fault Display




Shows the last fault.

Configuration Display



Lets you set the communication fault timer and the slow speed percentage and rename the device for display at the top of the faceplate.

Energy Display



Shows basic energy data.

Configure RSLogix5000 for the SMC-50 Controller Faceplate


Follow these procedures to configure the faceplate.

Add the SMC_50 Controller to Your Ethernet Network

1. Create a new or open an existing RSLogix5000 file.
2. Under I/O Configuration, right-click the network communication module to be used for the intended SMC-50 controller.


IMPORTANT This step assumes you have already added and configured an Ethernet module to your I/O tree.

3. Select 'New Module'.
4. Expand the Drives folder and select the appropriate SMC-50-E controller and click OK.



5. Enter a distinct module name and the IP Address of your module.
(For example, we use 'Motor_1' for the module name throughout this document.)

IMPORTANT The IP address must match with that of your 20-COMM-E module. This step assumes you already assigned an IP address to your 20-COMM-E module. Refer to the PowerFlex 20-COMM-E EtherNet/IP Adapter User Manual, publication [20COMM-UM010](#), for information on how to assign it an IP address.



6. Click Change to launch the Module Definition window.

7. Select the firmware of the device you are using.

IMPORTANT If the firmware revision of your drive is not listed, refer to the lower left corner of the Module Definition window for instructions on how to create a database.

Module Definition

Revision: 2 1

Electronic Keying: Compatible Module

Drive Rating: Standard

Connection: Parameters via Datalinks

Data Format: Parameters

☒ Sort Input/Output selection lists by Parameter Name

Datalink

Datalink	Input Data	Output Data
	LogicStatus	LogicCommand
	PhaseACurrent	NotUsed
		<input type="checkbox"/> Use Network Reference
<input checked="" type="checkbox"/> A	MtrThermUsage - 18	SlowSpeed - 72
	Fault1 - 138	Undefined_A2
<input checked="" type="checkbox"/> B	VoltsPhaseA_B - 2	Undefined_B1
	StopMode - 65	Undefined_B2
<input type="checkbox"/> C		
<input type="checkbox"/> D		

WARNING DANGER: Unexpected, hazardous motion of machinery may occur when improperly using software to configure a drive.

If the revision of your drive is not listed:
 - click Create Database... button below if drive is online.
 - click Web Update... to download the database from the web if drive is offline.

To match revision and upload the configuration of an online drive:
 - click Match Drive.

Parameter names selected for the Input and Output Data appear as member names in the drive Module-Defined Data Types and defines necessary Datalink parameters in the RSLogix 5000 project. Actual data transfer between controller and drive is determined by Datalink parameters.

You must download configuration to the drive to ensure that the controller, drive and communication module configurations are consistent with each other.

Create Database... Web Update...


Match Drive OK Cancel Help

8. Enter the DataLink Module Definitions exactly as shown.

IMPORTANT The datalinks listed must be configured exactly as shown for successful faceplate AOI import and operation. If additional datalinks are required for your application, modifications to the corresponding AOIs may be required. Refer to step 4 of the Set Other SMC-50 Parameters section, for more information on how to modify the AOI.


Datalink	Input Data	Output Data
	LogicStatus	LogicCommand
	PhaseACurrent	NotUsed
		<input type="checkbox"/> Use Network Reference
<input checked="" type="checkbox"/> A	MtrThermUsage - 18	SlowSpeed - 72
	Fault1 - 138	Undefined_A2
<input checked="" type="checkbox"/> B	VoltsPhaseA_B - 2	Undefined_B1
	StopMode - 65	Undefined_B2
<input type="checkbox"/> C		
<input type="checkbox"/> D		

9. Click OK to accept the changes.
10. Click OK again to close the dialog box.
11. In the Data Types folder, verify these module-defined data types have been created.




Import the SMC-50 Controller Faceplate Routine


1. From the Controller Organizer, right-click on the program where you would like to add the SMC-50 controller faceplate routine, and choose Import Routine.




2. Browse to the ME SMC 50 Faceplate Files folder, select the SMC50_Faceplate_Energy.L5X file, and click Import.




The Import Configuration dialog box opens.




3. Enter the name for your routine in the Final Name field.



4. In the Import Content organizer, select tags.
The Configure Tag References dialog box opens.
5. Replace _DeviceName in the Final Name with the name of your device.




For the 'Motor_1' example, the Final Names are renamed to the following:




6. In the Import Content organizer, select Other Components.

The communication path can be set for all messages by selecting the device from the I/O configuration drop-down in the Component References.




7. Click OK.

The new Routine appears in the Controller Organizer within the selected program.



8. Add a JSR to your main routine, or other desired location, to execute the new routine.




Set Other SMC-50 Controller Parameters

SMC-50 controller parameter settings are very specific to your application and need to be reviewed carefully before running your application.


1. Double click on the 'SMC-50 Motor_1' in the I/O Configuration tree.
2. On the General tab, click Change to configure any additional datalink parameters, other than those configured in [step 8](#) on [page 294](#), that are required for your application.

In this example, input parameter 17 and output parameter 189 were added.



3. Click OK and Apply to accept any changes.


4. If you modify the datalink configuration, you must also re-configure tag data types in the SMC 50 AOI.
 - a. In your RSLogix5000 Controller Organizer, expand the Add-On Instructions folder.
 - b. Select the SMC_50 AOI and double-click on 'Parameters and Local Tags'.
 - c. Click the Edit Tags tab and find the 'Inp_SMC_50' AOI tag
 - d. Change the Data Type to match the SMC_50 Module Input Data Type that applies to your application.



- e. Repeat the previous steps for the "Out_SMC_50" AOI tag, using the Module Output Data Type.

IMPORTANT Any time you modify your SMC_50 Module definitions after you have created your SMC_50 AOI, you have to reassign your SMC_50 AOI Input and Output Tag Data Types. If multiple changes to your SMC_50 Module definitions were made and saved, there are multiple Data Types listed for a particular DataLink configuration. Be careful to match the Data Type you select within the AOI to the Data Type of the intended SMC_50 Module definition.

5. Select the 'Drive' tab of the SMC_50 Module Properties.



6. Open the Parameter List and modify as your application requires.

7. This faceplate requires bit 4 of parameter 148 to be set to 1 to enable start and maneuver commands via the internal comm module.

Parameter List - SMC-50 - Motor_1

Parameter Group: All Parameters

ID	Name	Value	Units	Internal Value	Min	Max
148	Logic Mask	000000000010000		16	0000000000000000	0111111111111111
149	Logic Mask Act	0000000000000000		0	0000000000000000	1111111111111111
150	Write Mask Cfg	0111111111111111		32767	0000000000000000	0111111111111111
151	Write Mask Act	0000000000000000		0	0000000000000000	1111111111111111

8. Close the Parameter List window.
9. Download your parameters to the SMC-50 controller by choosing the download icon from the toolbar.
Follow prompts to complete the download process.



Import Program Control Rungs

Example logic is provided for configuring program commands. To import this configuration, follow these steps.

1. Choose a routine for importing the new rungs.
2. On a new rung, right click and select 'Import Rungs'
3. From the ME SMC 50 Faceplate Files folder, select 'SMC_50_Control_Rungs.L5X' and click Import.
4. Click Tags in the Import Content organizer.

Import Content:

MainTask
MainProgram
MainRoutine (Rungs)
References
Tags
Add-On Instructions
Errors/Warnings

Configure Tag References

	Import Name	Operation	Final Name	Data Type
	Cmd_SMCName_OperCntrl	Use Existing	Cmd_SMCName_OperCntrl	BOOL
	Cmd_SMCName_Reset	Use Existing	Cmd_SMCName_Reset	BOOL
	Cmd_SMCName_Start	Use Existing	Cmd_SMCName_Start	BOOL
	Cmd_SMCName_Stop	Use Existing	Cmd_SMCName_Stop	BOOL
	SMCName_FP	Use Existing	SMCName_FP	SMC_50_AOI

5. Replace SMCName in the Final Name field with the name of your SMC50 device and click OK.

Import Content:


MainTask
MainProgram
MainRoutine (Rungs)
References
Tags
Add-On Instructions
Errors/Warnings

Configure Tag References

	Import Name	Operation	Final Name	Data Type
	Cmd_SMCName_OperCntrl	Create	Cmd_Motor_1_OperCntrl	BOOL
	Cmd_SMCName_Reset	Create	Cmd_Motor_1_Reset	BOOL
	Cmd_SMCName_Start	Create	Cmd_Motor_1_Start	BOOL
	Cmd_SMCName_Stop	Create	Cmd_Motor_1_Stop	BOOL
	SMCName_FP	Use Existing	Motor_1_FP	SMC_50_AOI

Important Program and Operator Control Transfer Considerations

The first rung of the SMC_50_AOI handles the transfer of control from the Logix program (Program Control) to the faceplate (Operator Control). The Operator Control rung is shown below. It is important to understand how this rung operates so your desired program to operator and operator to program control transfers are achieved.



For example, these rungs enable the Operator Control of the intended SMC-50 controller. Command requests (Cmd) can be initiated from either the Logix Programs (ProgOperReq) or RSViewME/SE SMC_50 Faceplate (OperOperReq).

The following is a specific drive example:

EXAMPLE

To enable Operator Control for an SMC associated with 'Motor_1' AOI instance, a rung can be added to the Logix MainRoutine with specific input conditions driving an output instruction with the tag name 'Motor_1.Cmd_ProgOperReq'. Also, a pushbutton in an RSView ME/SE faceplate can be added with a value tag name of '#1.Cmd_OperOperReq' with the #1 parameter for that faceplate display associated with 'Motor_1' tag.

A 'Motor_1.Cmd_ProgToOperPermissive' must also be included in the Logix Program to control whether Program to Operator Control transfer requests are allowed or acted upon. A tag value of 1 permits the associated control transfer requests. A value of 0 prevents the associated control transfer requests.



ATTENTION: If an Xxxx.Cmd_ProgToOperPermissive tag is set to 1, the associated AOI is programmed to allow a transfer from Program Control to Operator Control regardless of the current direction, speed, or active status of the SMC_50. Therefore, if the SMC_50 is running at the time of a Program to Operator Control transition, the SMC_50 continues to run. If a different Program to Operator Control transition is desired, then the status of the SMC_50 and the Operator command requests must be monitored and the appropriate Program commands must be issued before the Xxxx.Cmd_ProgToOperPermissive is allowed. Therefore, it is very important that the status of the SMC_50 is monitored and appropriate Program commands, for the specific application, are issued before the Xxxx.Cmd_ProgToOperPermissive tag is set, to insure a safe Program to Operator Control transfer.




ATTENTION: If the SMC_50 is started in Operator Mode and the RSView ME SMC_50 Faceplate is closed while the SMC_50 is running, the SMC_50 continues running. Therefore, it is very important to understand how this operation affects the specific application and appropriate actions and safeguards are implemented.

Configure FactoryTalk View ME for the SMC-50 Controller Faceplate


Follow these procedures to configure the faceplate.

Add SMC-50 Controller Faceplate to ME Application

1. Launch FactoryTalk View Studio software and create or open an existing application file.
2. In the Graphics folder, right-click on Displays and choose 'Add Component Into Application'.




3. Navigate to the ME SMC 50 Faceplate Files folder, select the SMC_50_Faceplate_Energy.gfx file, and click Open.



Add a Parameter File

1. Right-click on Parameters, and choose 'Add Component Into Application'.



2. Navigate to the ME SMC 50 Faceplate Files folder, select the SMC50_Parameter.par file, and click Open.

Configure a Parameter File

1. From the explorer window in FactoryTalk View Studio, in the Parameters folder, right-click the SMC50_Parameter file, and choose Rename.
2. Rename the parameter file with the name of the corresponding device in your RSLogix5000 application.

For example, Motor_1.

3. Double-click the parameter file to open it.

The parameter file contains configuration for two parameters. Parameter #1 represents the tag name for the specific Faceplate AOI in your RSLogix 5000 project. Parameter #2 represents the tag name for the Base Energy Object tag (UDT_BEO) in your RSLogix5000 project. Each tag contains a controller shortcut name in brackets. This matches the shortcut name created in your RSLinx Enterprise communication setup.

```

===== Parameter File Created 2013/05/13 =====
! Parameter files are used with graphic displays to specify the tags a display
! uses at run time. You assign parameter files in certain application components
! and object properties dialog boxes. Please see the Help for details.
! Syntax:
!   #replacement=tagname
! Example:
!   #1=::[CLX]DeviceName_FP
! #1 in any expression is replaced by the tag ::[CLX]DeviceName_FP
!
! For Example:
! ::[CLX] --> Represents the 'Device Shortcut' name of Logix controller you configured in
! RSLinx Enterprise Communication Setup.
!
! DeviceName_FP --> Represents the AOI name for the device configured in your Logix application.
! DeviceName_BEO --> Represents the tagname for the Base Energy Object tag (UDT_BEO)
!                    configured in your Logix application file.
!                    This only applies when using the faceplate with the energy tab.
!=====

#1=[CLX]DeviceName_FP

! #2 only applies If using the faceplate with the energy tab
#2=[CLX]DeviceName_BEO

```

4. Replace the shortcut name (CLX) and DriveName in parameters 1 and 2(if applicable) to match the tags configured in your RSLogix5000 project.

For the Motor_1 example, the configuration looks like the following:

```

===== Parameter File Created 2013/05/13 =====
! Parameter files are used with graphic displays to specify the tags a display
! uses at run time. You assign parameter files in certain application components
! and object properties dialog boxes. Please see the Help for details.
! Syntax:
! #replacement=tagname
! Example:
! #1=:[CLX]DeviceName_FP
! #1 in any expression is replaced by the tag ::[CLX]DeviceName_FP
!
! For Example:
! ::[CLX] --> Represents the 'Device Shortcut' name of Logix controller you configured in
! RSLinx Enterprise Communication Setup.
!
! DeviceName_FP --> Represents the AOI name for the device configured in your Logix application.
! DeviceName_BEO --> Represents the tagname for the Base Energy Object tag (UDT_BEO)
! configured in your Logix application file.
!
! This only applies when using the faceplate with the energy tab.
=====

#1=[CLX]Motor_1_FP

! #2 only applies If using the faceplate with the energy tab
#2=[CLX]Motor_1_BEO


```

5. Save your parameter file.
6. To add parameter files for additional SMC-50 controllers:
 - a. Right-click on the parameter file that you just created and choose Duplicate.
 - b. Rename the file with the new device name.
 - c. Open the parameter file and configure the tag to match the associated device.

Create a Display Navigation Button


A display navigation button must be created to launch the SMC_50 faceplate at runtime. This can be drawn over an existing graphic object that represents the device you intend to monitor/control or it can be configured to use a bitmap image as the display.

1. From the display where you want to launch the faceplate (can be a new or an existing display), choose Objects > Display Navigation > Goto.



2. Draw the Goto button rectangle.


3. Double-click the new Goto rectangle to configure the button properties.
 - a. Modify the appearance as desired for your application (for example, choose Transparent as the Back style if you are drawing the Goto button over an existing object on your display).
 - b. Click the ellipse next to the Display field and assign the SMC_50_Faceplate_Energy display.
 - c. Click the ellipse next to the Parameter file field and assign the SMC_50 parameter file you created earlier for this intended device.



4. Follow these steps to use a bitmap image with the button.
 - a. Click the Label Tab and click the ellipse button next to the Image field.
 - b. Click Add from File and select the SMC50 Bitmap Image located in the ME SMC 50 folder.

IMPORTANT You only need to add the image from File the first time you use the image. Once added, the image can be selected from the image list.

- c. Click Open to add the image then OK to close the Image Browser window.
- d. Add text in the Caption field if desired.



- e. Click OK to close the Goto button properties window.
- This is an example of a final goto button on your display.




To support additional SMC-50 controllers, create a new Goto display navigation button, assign the SMC-50 faceplate display, and assign a unique parameter file associated with the additional device.

Configure ME CIP Motion Drive Faceplates

The 'ME CIP Motion Energy Faceplate' files let you quickly load, configure, and use a preconfigured status display or 'faceplate' for the CIP Motion Servo Drives by using FactoryTalk View Machine Edition software.

IMPORTANT This faceplate covers Kinetix® K6500, K5500, and K350 drives. The instructions show the Kinetix K5500 drive as an example. These instructions are similar for the other drives.



System Compatibility

The faceplate and routine import files are compatible with the following software:

- Studio 5000 Logix Designer application, version 21.00 or later
- FactoryTalk View Machine Edition software, version 7.0 or later

The faceplate files are also compatible with the following faceplates:

- Equipment Status Faceplate Rev 1.0
- Alarm History Faceplate Rev 1.0

IMPORTANT These instructions are for CIP Motion Servo Drives (Kinetix 350, 5500, and 6500) communicating over an EtherNet/IP network.

General Setup

After downloading your faceplate zip file, the following folders are created:

- ME_CIPMotion_Energy_Faceplate_Files - contains the CIP Motion Energy faceplate, parameter file, and controller logic
- ME_CIPMotion_Goto Buttons - contains the image used in creating a Goto button for your HMI display

Configure Studio 5000 Logix Designer Application for the Kinetix Drive Faceplate


Follow these procedures to configure the faceplate.

Add the Kinetix Drive to Your Ethernet Network


1. Create a new or open an existing Logix Designer application file.
2. Under I/O Configuration, right click the network communication module to be used for the intended drive.

IMPORTANT This step assumes you have already added and configured an Ethernet module to your I/O tree.

3. Select 'New Module.'
4. Select the applicable Kinetix drive and click Create.




5. Enter a distinct module name and the IP Address of your drive.
(For example, we use My5500 for the module name throughout this document.)




Import the CIP Motion Energy Faceplate Routine


1. From the Controller Organizer, right-click on the program where you want to add the CIP Motion Energy faceplate routine, and choose Import Routine.




2. Navigate to the ME CIP Motion Energy Faceplate Files folder and select the CIPMotion_EnergyOnly_Faceplate routine and click Import.




The Import Configuration dialog box opens.




3. Enter the name for your routine in the Final Name field.



4. Click Tags in the Import Content organizer.
The Configure Tag References dialog box opens.
5. Replace _DriveName in the Final Name with the name of your device.




For the My5500 example, the Final Names would be renamed to the following:




- Click Other Components in the Import Content organizer and choose your drive from the I/O configuration drop-down in the Final Name column.

This configures the communication path to your device in the message instructions.




- Click OK.

The new Routine appears in the Controller Organizer in the selected program.



- Add a JSR to your main routine, or other desired location, to execute the new routine.




Configure FactoryTalk View ME for the CIP Motion Energy Faceplate


Follow these procedures to configure the faceplate.

Add CIP Motion Energy Faceplate to ME Application

1. Launch FactoryTalk View Studio (Machine Edition) and create or open an existing application file.
2. Right-click on Displays in the Graphics folder and select 'Add Component Into Application.'




3. Navigate to the ME CIP Motion Energy Faceplate Files folder, select the CIPMotion_Faceplate_EnergyOnly.gfx file, and click Open.



Add Parameter File


1. Right-click on Parameters, and choose 'Add Component Into Application.'



2. Browse to the ME CIP Motion Energy Faceplate Files folder, select the CIPMotion_Parameter.par file, and click Open.

Configure Parameter File

1. In the FactoryTalk View Explorer window, in the Parameters folder, right-click the CIPMotion_Parameter file and choose Rename.



2. Rename the parameter file with the name of the corresponding device in your Logix Designer application.
For example, My5500_Parameter.
3. Double-click the parameter file to open it.

Parameter #1 represents the tag name of the faceplate tag in your Studio 5000 project. Parameter #2 represents the base energy object tag in your Studio 5000 project. Each tag contains a controller shortcut name in brackets. This matches the shortcut name created in your RSLinx Enterprise communication setup.

```
My5500_Parameter - /DMAT/ (Parameters)
===== Parameter File Created 2013/05/13 =====
! Parameter files are used with graphic displays to specify the tags a display
! uses at run time. You assign parameter files in certain application components
! and object properties dialog boxes. Please see the Help for details.
! Syntax:
!   #replacement=tagname
! Example:
!   #1=::[CLX]_DeviceName_FP
! #1 in any expression is replaced by the tag ::[CLX]_DeviceName_FP
!
! For Example:
! ::[CLX] --> Represents the 'Device Shortcut' name of Logix controller you configured in
! RSLinx Enterprise Communication Setup.
!
! _DeviceName_FP --> Represents the AOI name for the device configured in your Logix application.
! =====
#1=[CLX]_DriveName_FP
#2=[CLX]_DriveName_BEO
```

4. For parameter #1 and #2, change the shortcut name [CLX] to match your communication setup and _DriveName to match the tag configured in your Studio 5000 project.

For the My5500 example, the configuration looks like the following:


```
===== RSLinx Enterprise Communication Setup. =====
!
! _DeviceName_FP --> Represents the AOI name for the device configured in your Logix application.
! =====
#1=[CLX]My5500_FP
#2=[CLX]My5500_BEO
```

5. Save your parameter file.
6. To add parameter files for additional CIP Motion Servo Drives:
 - a. Right-click on the parameter file that you just created and choose Duplicate.
 - b. Rename the file with the new device name.
 - c. Open the parameter file and configure the tags to match the associated device.


Create Display Navigation Button

A display navigation button must be created to launch the CIP Motion Energy Faceplate at runtime. This can be drawn over an existing graphic object that represents the device you intend to monitor/control or it can be configured to use a bitmap image as the display.


1. From the display where you want to launch the faceplate (can be a new or an existing display), choose Objects > Display Navigation > Goto.



2. Draw the Goto button rectangle.
3. Double-click the Goto button to configure its properties
 - a. Modify the appearance as desired for your application (choose Transparent as the Back style if you are drawing the goto button over an existing object on your display).
 - b. Click the ellipse next to the Display field and assign the CIPMotion_Faceplate_EnergyOnly display.
 - c. Click the ellipse next to the Parameter file field and assign the CIPMotion parameter file you created earlier for this intended device.



4. Follow these steps to use a bitmap image with the button.
 - a. Click the Label Tab and click the ellipse next to the Image field.
Images are available for the Kinetix Servo drives in the ME_CIPMotion_GotoButtons folder.
 - b. Click Add from File, navigate to the gotobuttons folder, and select the desired image.
 - c. Click Open to add the image then OK to close the Image Browser window.
 - d. Add text in the Caption field if desired.



- e. Click OK to close the Goto button properties window.

This is an example of a final goto button on your display.



5. To support additional Kinetix Servo Drives, create a new Goto display navigation button, assign the CIPMotion_Faceplate_EnergyOnly display, and assign a unique parameter file associated with the additional device.

CIP Motion Energy Faceplate Overview





Table 1 - Faceplate Status/Control Buttons

Button	Icons	Description
Configuration		The Configuration button lets you edit the faceplate/device name to be displayed at the top of the faceplate.
Help		The Help button provides information for the current view.
Base Energy Object Values		Resource Type – Indicates the type of energy resource being monitored Capabilities - Indicates how the energy values are generated <ul style="list-style-type: none">Measured indicates the values are directly measured by the deviceDerived indicates the values are derived from fixed nominal power values or some other combination of values


Configuration View


1. Click Configuration on the toolbar to launch the Configuration view.
2. Click the string entry box to launch the QWERTY keyboard popup.
3. Type the desired text and press Enter.

The text you enter is displayed at the top of the faceplate.



Help View

Click Help  on the toolbar to access the online help information.



Configure Device Logic for Equipment Status and Alarm History Faceplates


Some logic is required in the CompactLogix controller for PowerMonitor 1000 and 3000 devices to support the Equipment Status and Alarm History Faceplates.

- TIP** The faceplate logic required for the CompactLogix energy inputs is included in the Energy Add-On Instructions that were configured in [Configure CompactLogix Energy Inputs](#) on [page 86](#).
- TIP** The equipment status faceplate logic required for the PowerMonitor 500, PowerMonitor 5000, PowerFlex Drives, E3 Plus, E300, SMC-50, and CIP Motion Drives is included in the faceplate routines that were configured in the previous sections.

Configure PowerMonitor 1000 and 3000 Communication

Follow these steps to add the PowerMonitor 1000 and 3000 devices to your Ethernet network in the CompactLogix I/O Configuration.

1. Browse to the CompactLogix Ethernet network in the I/O Configuration.
2. Right-click Ethernet and choose New Module.
3. Choose Communication.
4. Scroll through the modules and choose the ETHERNET-MODULE (Generic Ethernet Module).
5. Click OK.



- Enter a module name for the first PowerMonitor device.

For this example, you will configure the first PowerMonitor device named Electric_Main_PM3000.

- Choose Input Data-REAL from the Comm Format list.
- Enter Connection Parameters.

Table 2 - PowerMonitor 1000/3000 Connection Parameters

	Assembly Instance	Size
Input	1	16
Output	2	
Configuration	3	0

- Enter the IP address of the PowerMonitor device.


For this example, the Electric_Main_PM3000 IP address is 10.10.10.0.

- Click OK.
- Repeat steps 1...9 to configure each PowerMonitor 1000 and 3000 device in your project.

For the [Efficient Industries Plant 1](#), enter the names and IP addresses of the PowerMonitor devices in the table. The rest of the parameters in the New Module dialog box are the same.

When done, the I/O configuration should look like this.

PowerMonitor Device Name	IP Address
Electric_Main_PM3000	10.10.10.0
Boiler_House_PM1000	10.10.10.1
Power_House_PM1000	10.10.10.2
Production1_PM1000	10.10.10.3
Production2_PM1000	10.10.10.4
Shipping_Receiving_DC_PM1000	10.10.10.5
MCC2_PM1000	10.10.10.6



Import PowerMonitor and Status Input Faceplate AOl's


You will now learn how to import faceplate Add-On Instructions for PowerMonitor devices and PowerMonitor status inputs. These Add-On Instructions support the Equipment Status and Alarm History faceplates for FactoryTalk View Machine Edition or Site Edition applications.

Faceplate Add-on Instruction types required for the [Efficient Industries Plant 1](#) example are listed in the table.


Energy Meter	Meter Type	Add-on Instruction Required
Electric Main	PowerMonitor 3000	PM_3000
Boiler House	PowerMonitor 1000	PM_1000
Power House		
Production 1		
Production 2		
Shipping/Receiving/DC		
Gas Main	PowerMonitor Status Input	Energy_Gas_PM_Status
Air Flow		Energy_Air_PM_Status
Water Main		Energy_Water_PM_Status

Follow these steps to import the required Add-on Instructions.

1. Open your RSLogix 5000 project.
2. Right-click the Add-On Instructions folder and choose Import Add_On Instruction.




3. Browse to the Faceplate Files folder on your Energy Management Accelerator Toolkit CD image and select the PowerMonitor Faceplate Logic Files folder.



4. Select the required Add-On Instruction file then click Import.

For this example, PM_3000.L5X is imported for the Electric Main meter connected to the PowerMonitor 3000 device.


5. Click OK on the Import Configuration dialog box to continue the import.



6. Verify the imported instruction is listed under the Add-On Instructions folder.

For this example, you should see the PM_3000 Add-On Instruction.

7. Repeat steps 1...7 to import each PowerMonitor and PowerMonitor Status Input Add-On Instruction required for your project.




Configure PowerMonitor 1000 and 3000 Faceplate AOIs

You will now configure the faceplate Add-On Instructions for each PowerMonitor 1000 or 3000 device in your system.

1. Open your program routine and create a new rung.
2. Click the Add-On tab, then click the desired PowerMonitor Add-On Instruction to add to the rung.


For this example, the PM_3000 Add-On Instruction was added.



3. Click in the PowerMonitor tag name field and enter a tag name.

For this example, Electric_Main is entered.

4. Right-click the PowerMonitor tag name and choose the New 'tag_name' just entered.



- Click OK to accept the default setup for the new PowerMonitor tag.

The PowerMonitor Add-On Instructions use explicit messaging to retrieve data from PowerMonitor devices. You must configure an explicit message for each PowerMonitor data address. Four messages will be configured to display PowerMonitor device values on the Equipment Status and Alarm History faceplates. The table lists the data and corresponding Add-On Instruction parameters, tags, and addresses to be configured for each device.




Table 3 - PowerMonitor Add-On Instruction Tag References

PowerMonitor Data	Add-On Instruction Parameter Tags	Message Tag	PLCS Address		Message Destination Tag
			PowerMonitor 1000	PowerMonitor 3000	
Real Power	Ref_Total_Real_Power Val_Total_Real_Power	xxx ⁽¹⁾ _MsgTotalRealPower	F22:7	F17:3	xxx<Footnote>(1)_TotalRealPower
Average L-L Volts	Ref_Avg_L_L_Volts Val_Avg_L_L_Volts	xxx<Footnote>(1)_MsgAvgLLVolts	F21:11	F15:11	xxx<Footnote>(1)_AvgLLVolts
Average Current	Ref_Avg_Current Val_Avg_Current	xxx<Footnote>(1)_MsgAvgCurrent	F21:3	F15:3	xxx<Footnote>(1)_AvgCurrent
True Power Factor	Ref_True_Power_Factor Val_True_Power_Factor	xxx<Footnote>(1)_MsgTruePowerFactor	F22:3	F19:3	xxx<Footnote>(1)_TruePowerFactor


(1) xxx is the PowerMonitor device name. For example, the prefix Electric_Main in Electric_Main_MsgTotalRealPower is the message tag for the PM 3000 Electric_Main device.

- Select the message tag name field next to the Ref_Total_Real_Power parameter and type a tag name in the format xxx_MsgTotalRealPower.


For this example Electric_Main_MsgTotalRealPower is entered.

- Right-click the message tag name just entered and choose New 'xxx_MsgTotalRealPower'.

For this example, New 'Electric_Main_MsgTotalRealPower' is selected.



8. Click OK to accept the default setup for the new message tag.



9. Click the Browse icon next to the `xxx_MsgTotalRealPower` tag to open the Message Configuration dialog box.


10. Choose PLC5 Typed Read for Message Type.

11. Enter the associated PM1000 or PM3000 PLC5 address as the Source Element.

For this example, F17:3 is entered for the PM 3000 Real Power PLC5 address.

Refer to [PowerMonitor Add-On Instruction Tag References](#) table on [page 321](#) for the PLC5 address.

12. Set the Number of Elements to 1.
13. Click New Tag to create a controller-scoped tag for the Destination Element.
 - a. Enter a name for the associated controller-scoped tag.




Use the Message Destination Tag, `xxx_TotalRealPower`, defined in the [PowerMonitor Add-On Instruction Tag References](#) table on [page 321](#).

For this example, enter `Electric_Main_TotalRealPower`.

- b. Choose REAL as the Data Type.
- c. Choose a controller from the Scope list.
For this example, L2x is selected.
- d. Choose Float for Style.
- e. Click OK.

14. Click the Communication tab on the Message Configuration dialog.

- Click the Browse icon.
- Select the path to the PowerMonitor device.




For this example, select ETHERNET-MODULE Electric_Main_PM3000.

- Click OK.
- Verify the path is okay.
- Verify CIP is the Communication Method.
- Click OK to close the Message Configuration dialog box.

15. Assign the Val_Total_Real_Power parameter to the associated controller-scoped tag.

- Double-click the tag name field next to Val_Total_Real_Power.
- Click the pull-down menu icon then double-click the associated controller-scoped tag to select it.

For this example, the tag is Electric_Main_TotalRealPower.




16. Repeat steps 6...15 to configure the remaining three PowerMonitor data messages and tags.


Refer to the [PowerMonitor Add-On Instruction Tag References](#) table on [page 321](#) for associated parameters, tags, and addresses.

For this example, the completed PM_3000 Add-On Instruction instance for the Electric_Main meter looks like this.

17. Repeat steps 1...16 for each PowerMonitor 1000 or 3000 device in your system.



For the Efficient Industries Plant 1 example, the completed PowerMonitor faceplate logic would look similar to this.




Configure PowerMonitor Status Input Faceplate AOl's

Logic is required to display energy meter data on Equipment Status and Alarm History faceplates from PowerMonitor status inputs.

1. Open your program routine and create a new rung.
2. Click the Add-On tab, then click the required PowerMonitor status input Add-On Instruction to add to the rung.


For this example, the Energy_Gas_PM_Status instruction is selected to support the Gas Main meter connected to the MCC 2 PowerMonitor status input.



3. Click in the PowerMonitor status input tag name field and enter a tag name.

For this example, Gas_Main is entered.

4. Right-click the tag name just entered and choose New 'tag_name' from the list.



5. Click OK to accept the default setup for the new PowerMonitor status input tag.

The PowerMonitor status input Add-on Instructions also use explicit messaging to retrieve data from the PowerMonitor devices. You must configure an explicit message for each PowerMonitor status input. The table lists the data and corresponding Add-On Instruction parameters, tags, and addresses to be configured for each status input.




Table 4 - PowerMonitor Status Input Add-on Instruction Tag References

PowerMonitor Data	Add-On Instruction Parameter Tags	Message Tag	PLC5 Address			Message Destination Tag
			PowerMonitor 1000	PowerMonitor 3000	PowerMonitor 5000	
Status 1 Count x 1	Ref_Status_Input Val_Status_Input	xxx ⁽¹⁾ _MsgStatusInput1	F11:12	N9:4	F55:1	xxx<Footnote>(1)_Status1Count
Status 2 Count x 1	Ref_Status_Input Val_Status_Input	xxx<Footnote>(1)_MsgStatusInput2	F11:13	N9:5	F55:3	xxx<Footnote>(1)_Status2Count
Status 3 Count x 1	Ref_Status_Input Val_Status_Input	xxx<Footnote>(1)_MsgStatusInput3			F55:5	xxx<Footnote>(1)_Status3Count
Status 4 Count x 1	Ref_Status_Input Val_Status_Input	xxx<Footnote>(1)_MsgStatusInput4			F55:7	xxx<Footnote>(1)_Status4Count

(1) xxx is the PowerMonitor device name associated with the Add-on Instruction message tag and message destination tag. For example, the prefix MCC2 in MCC2_MsgStatusInput1 and MCC2_Status1Count are the message tags for the MCC2 PM1000 Gas_Main device.



6. Select the message tag name field next to the Ref_Status_Input parameter and type a tag name in the format xxx_MsgStatusInput1.

For this example, MCC_2_MsgStatusInput1 is entered for the Gas Main meter.

7. Right-click the message tag name just entered and choose New 'xxx_MsgStatusInput1'.

In this example, 'MCC_2_MsgStatusInput1' is selected.

8. Click OK to accept the default setup for the new message tag.




9. Click the Browse icon next to the `xxx_MsgStatusInput1` tag to open the Message Configuration dialog box.
10. Choose PLC5 Typed Read for Message Type.
11. Enter the associated PM1000, PM3000, or PM5000 PLC5 address as the Source Element.

Refer to [PowerMonitor Status Input Add-on Instruction Tag References](#) table on [page 326](#) for the correct PLC5 address.

For this example, F11:12 is entered as the Status 1 Count x 1 PLC5 address for the PM 1000 MCC 2.

12. Set the Number of Elements to 1.
13. Click New Tag to create a controller-scoped tag for the Destination Element.
 - a. Enter a name for the associated controller-scoped tag.




Use the Message Destination Tag defined in the [PowerMonitor Status Input Add-on Instruction Tag References](#) table on [page 326](#).

For this example, MCC_2_Status1Count is entered.

- b. Choose REAL as the Data Type for PowerMonitor 1000 messages; choose INT for PowerMonitor 3000 messages.
- c. Choose a controller from the Scope list.
For this example, L2x is chosen.
- d. Choose Float as the style for PowerMonitor 1000 and PowerMonitor 5000 messages.
Choose Decimal for PowerMonitor 3000 messages.
- e. Click OK.


14. Click the Communication tab on the Message Configuration dialog box.
 - a. Click the Browse icon.
 - b. Select the path to the PowerMonitor device.



For this example, select ETHERNET-MODULE MCC2_PM1000.

- c. Click OK, then verify the path is correct.
 - d. Verify CIP is the Communication Method.
 - e. Click OK to close the Message Configuration dialog box.
15. Assign the Val_Status_Input parameter to the associated controller-scoped tag.
 - a. Double-click the tag name field next to Val_Status_Input parameter.
 - b. Click the pull-down menu icon then double-click the associated controller-scoped tag to select it.

For this example, the tag is MCC_2_Status1 Count.



16. Assign energy input calculation and alarm setpoints based on the Energy Add-On Instruction Factor table definitions on [page 329](#).

One table provides factor definitions for electric inputs and one for all other energy inputs.

This example shows values that need to be set for the Energy_Gas_PM_Status Add-On Instruction.

Energy_Gas_PM_Status	
Energy_Gas_PM_Status	Gas_Main
Ref_Status_Input	MCC2_MsgStatusInput1
Val_Status_Input	MCC2_Status1 Count
Set_Calc_Interval	0.0
	1
Set_Critical_Flow	1500
Set_High_Flow	1000
Val_Total_Gas	0.0
Val_Gas_Per_Calc_Interval	0.0

Table 5 - Energy Add-On Instruction Factors for Electric Inputs

Energy Factor Tag	Description
Set_Demand_Interval	The value, in minutes, used to calculate the End of Demand Interval (EOI). This value is used only if the Val_End_of_Demand_Type is 2.
Set_Demand_Delay	The time value used to reset the end of interval after the Set_Demand_Interval value has been exceeded without a utility contact or master end of demand contact closure. The value must be between 0...90 seconds.
Set_End_of_Demand_Interval_Type	The value that defines how the End of Demand Interval (EOI) is triggered. 1 = A local digital input connected to an electric utility meter EOI contact (Inp_End_of_Demand_Utility_Contact). 2 = An internal PLC timer (Demand_Interval_PLC_Timer) that is typically used when an electric utility meter EOI contact is not available. 3 = A master command input (CMD_Master_End_Of_Demand_Interval) typically from a central controller that is used to synchronize multiple electric meter EOIs.
Set_High_Demand	When the demand (kW) value exceeds the Set_High_Demand, the High Demand Fault is set.
Set_Critical_Demand	When the demand (kW) value exceeds the Set_Critical_Demand, the High Critical Fault is set.

Table 6 - Energy Add-On Instruction Factors for Gas, Propane, Fuel Oil, Steam, Air and Water Inputs

Energy Factor Tag	Definitions										
Set_Calc_Interval	The time interval, in minutes, used to calculate the average energy flow. For example, an interval value of 5 will calculate the average energy flow every 5 minutes.										
Set_High_Flow	When the flow rate value exceeds the Set_High_Flow value, the High Flow Fault is set. <table border="1"> <thead> <tr> <th>Energy Add-On Instruction</th><th>Default Flow Rate Unit</th></tr> </thead> <tbody> <tr> <td>Air</td><td>cfm (cubic feet per minute)</td></tr> <tr> <td>Fuel Oil, Propane, Water</td><td>gpm (gallons per minute)</td></tr> <tr> <td>Gas</td><td>therms/hr</td></tr> <tr> <td>Steam</td><td>lbs/hr</td></tr> </tbody> </table> <p>Example: A value of 1000 will set the High Flow Fault in the Energy_Gas_PM_Status Add-On Instruction when the gas flow rate exceeds 1000 therms/hr.</p>	Energy Add-On Instruction	Default Flow Rate Unit	Air	cfm (cubic feet per minute)	Fuel Oil, Propane, Water	gpm (gallons per minute)	Gas	therms/hr	Steam	lbs/hr
Energy Add-On Instruction	Default Flow Rate Unit										
Air	cfm (cubic feet per minute)										
Fuel Oil, Propane, Water	gpm (gallons per minute)										
Gas	therms/hr										
Steam	lbs/hr										
Set_Critical_Flow	When the flow rate value exceeds the Set_Critical_Flow value, the Critical Flow Fault is set. <table border="1"> <thead> <tr> <th>Energy Add-On Instruction</th><th>Default Flow Rate Unit</th></tr> </thead> <tbody> <tr> <td>Air</td><td>cfm (cubic feet per minute)</td></tr> <tr> <td>Fuel Oil, Propane, Water</td><td>gpm (gallons per minute)</td></tr> <tr> <td>Gas</td><td>therms/hr</td></tr> <tr> <td>Steam</td><td>lbs/hr</td></tr> </tbody> </table> <p>Example: A value of 1500 will set the Critical Flow Fault in the Energy_Gas_PM_Status Add-On Instruction when the gas flow rate exceeds 1500 therms/hr.</p>	Energy Add-On Instruction	Default Flow Rate Unit	Air	cfm (cubic feet per minute)	Fuel Oil, Propane, Water	gpm (gallons per minute)	Gas	therms/hr	Steam	lbs/hr
Energy Add-On Instruction	Default Flow Rate Unit										
Air	cfm (cubic feet per minute)										
Fuel Oil, Propane, Water	gpm (gallons per minute)										
Gas	therms/hr										
Steam	lbs/hr										


TIP The meter pulse factor, consumption value of each input pulse, is set within the PowerMonitor configuration. Refer to [Configure CompactLogix Energy Inputs](#), on [page 80](#).

TIP For additional information on how these energy factors affect calculations, refer to Appendix C, [Energy Electric Add-On Instructions](#) and Appendix D, [Digital and Analog Energy Add-On Instructions](#)

17. Repeat steps 1...16 for each PowerMonitor 1000 or 3000 status input in your system.

For the [Efficient Industries Plant 1](#) example, the completed PowerMonitor status input Add-On Instruction logic would look similar to this.

3



Modify Faceplate or Energy AOI for Equipment Status Faceplate

TIP The procedure in this section is optional and necessary only if you intend to use the Equipment Status Faceplate.

The Equipment Status Faceplate displays a status summary of energy meter data on PanelView Plus terminals. The Equipment Status Faceplate works in conjunction with energy and faceplate Add-On Instructions.

You can display up to nine energy meters on a single Equipment Status Faceplate. In addition, you can configure the Equipment Status Faceplate to launch your faceplates by using preconfigured Goto Display buttons.

This example shows the Boiler House energy meters for the Efficient Industries Plant 1. The faceplate is configured for five rows or five energy meters and provides overall status with up to four additional status values for each meter.

Efficient Plant 1_ Boiler House					
Device	State	Value 1	Value 2	Value 3	Value 4
Gas Main	ACTIVE	9565.000 therms	503.000 therms/hr	0.000	0.000
Boiler House Gas	ACTIVE	7654.000 therms	385.000 therms/hr	0.000	0.000
Propane	HIGH FLOW	43225.000 gal	4.300 gpm	0.000	0.000
Fuel Oil	CRITICAL FLOW	21653.000 gal	5.900 gpm	0.000	0.000
Boiler House Electric	Comms Fault	0.000 KW	0.000 Volts	0.000 Amps	0.000 PF


Follow these steps to modify the faceplate or energy Add-On Instruction to set the number of rows for the Equipment Status Faceplate.

1. Determine how many of the nine available rows you will use on the Equipment Status Faceplate and which energy meter you will assign to each row.

For the [Efficient Industries Plant 1](#) example, you will use five rows to display data from five meters.

Row Number	Energy Meter	Faceplate or Energy Add-On Instruction
1	Gas Main	Gas_Main
2	Boiler House Gas	Boiler_House_Gas
3	Propane	Propane
4	Fuel Oil	Fuel_Oil
5	Boiler House (Electric)	Boiler_House

2. In your RSLogix 5000 project, set the Inp_NumRowsVis tag of the energy meter Add-On Instruction that is assigned to row 1.
 - a. Select Controller Tags under the Controller folder for your project then click Show to open the Define Tag Filter dialog box.
 - b. Check the Add-On-Defined filter and click OK.




- c. Choose the Faceplate or Energy Add-On Instruction associated with the energy meter you want to assign to row 1.

For this example, Gas_Main is selected.

- d. Click the Monitor Tags tab.

- e. Click in the `xxx.Inp_NumRowsVis` Value field and type the number of rows to display on the Equipment Status Faceplate.

For this example, 5 is entered.



Add Input Fault Logic for Equipment Status and Alarm History Faceplate

TIP The procedure in this section is optional and necessary only if you intend to use the Equipment Status or Alarm History Faceplate.


The energy Add-On Instructions include logic to update the Equipment Status Faceplate Status field and the Alarm History Faceplate alarm triggers with the analog or digital input faults.

An additional rung is required to transfer the local I/O fault data to the energy *MeterName.Sts_xxx_Input_Fault* tag.

Follow these steps to add the fault logic to your RSLogix 5000 project.

1. Open your RSLogix 5000 project and add a new rung.
2. Add a MOV instruction and assign the local fault tag of your analog or digital energy input to the Source field.

For this example, the Local:1:I.Fault tag is selected for the Boiler_House_Gas digital input.





- Choose the corresponding energy tag, *MeterName.Sts_xxx_Input_Fault*, for the Dest tag.

For this example,

Boiler_House_Gas.Sts_Digital_Input_Fault tag is chosen.

- Repeat steps 2 and 3 for each of your CompactLogix energy digital and analog inputs that were configured on [page 80](#).

For the Efficient Industries Plant 1 example, the fault logic would look similar to this.



Configure Alarm Logic for Alarm History Faceplate

TIP The procedure in this section is optional and necessary only if you intend to use the Alarm History Faceplate.


The Alarm History Faceplate can display date and time-stamped alarm, and fault information for each energy meter on a PanelView Plus terminal. The Alarm History Faceplate works in conjunction with energy and faceplate Add-On Instructions.

In this example, the Alarm History Faceplate shows alarms from three energy meters.




Follow these steps to add required logic for each energy meter you want to include in the Alarm History Faceplate.


1. Open your RSLogix 5000 program routine and select the end rung or an existing rung that you want the alarm logic to follow.
2. Right-click the rung and choose Import Rungs.




3. Browse to the Faceplate Files folder on your Energy Management Toolkit CD image and select the ME Alarm History Faceplate Files folder.



4. Select Energy_AlarmHistory_Logix.L5x then click Import.




5. Select Tags under Import Content to display the Tag References view.
6. Scroll to and select the MeterName tag in the Final Name column.



7. Click the pull-down menu icon and double-click the energy, PowerMonitor, or PowerMonitor status input Add-On Instruction tag that you want to include in the Alarm History Faceplate.


For this example, the Gas_Main PowerMonitor status input tag is selected.




8. Replace *MeterName* in *MeterName_AlarmName* with the corresponding Add-On Instruction tag name selected in the previous step.

For this example, Gas_Main is entered.


9. Click OK to complete the alarm logic import.
- Two alarm logic rungs should appear without errors.



For this example, two alarm logic rungs will move the alarm trigger values and names for the Gas_Main meter to the Alarm History Faceplate tags.




10. Enter the string value for the *MeterName_AlarmName* tag just imported.
 - a. Navigate to and double-click Controller Tags in the Controller folder.
 - b. Click the Monitor Tags tab.
 - c. Browse to the *MeterName_AlarmName* tag and select the Value Column field.
For this example, Gas_Main_AlarmName is selected.
 - d. Click the ... ellipse icon in the Value field.
 - e. In the String Browser dialog box, enter the meter name that you want to display in the Alarm History Faceplate for the corresponding alarm.
For this example, Gas Main is entered.
 - f. Click OK.



The completed string entry appears in the Value field.

g. Close the Controller Tags dialog box.



11. Repeat steps 1...10 for each energy meter that you want to include in the Alarm History faceplate.

Configure Equipment Status Faceplate

The Equipment Status Faceplate is a display that provides device status and meter data from data collector devices in your energy management application. The faceplate works in conjunction with energy and faceplate Add-On Instructions.

You can display up to nine energy meters on a single Equipment Status Faceplate. In addition, you can configure the Equipment Status Faceplate to launch your faceplates by using preconfigured Goto Display buttons.

This example shows the Boiler House energy meters for the Efficient Industries Plant 1. The faceplate is configured for five rows or five energy meters and provides overall status with up to four additional status values for each meter.

Efficient Plant 1_ Boiler House					
Device	State	Value 1	Value 2	Value 3	Value 4
Gas Main	ACTIVE	9565.000 therms	503.000 therms/hr	0.000	0.000
Boiler House Gas	ACTIVE	7654.000 therms	385.000 therms/hr	0.000	0.000
Propane	HIGH FLOW	43225.000 gal	4.300 gpm	0.000	0.000
Fuel Oil	CRITICAL FLOW	21653.000 gal	5.900 gpm	0.000	0.000
Boiler House Electric	Comms Fault	0.000 KW	0.000 Volts	0.000 Amps	0.000 PF


Add Equipment Status Faceplate Display

Follow these steps to add the Equipment Status Faceplate display to your FactoryTalk View ME application. The procedure uses the [Efficient Industries Plant 1](#) example to demonstrate the configuration steps.


1. Open the FactoryTalk View ME application to which you want to add the Equipment Status Faceplate display.

TIP The default display size for the Equipment Status Faceplate is 640 x 480 and is compatible with PanelView Plus 700 or larger terminals.


2. Right-click Displays and choose Add Component into Application.



3. Browse to the Faceplate Files folder on your Energy Management Toolkit CD image and select the ME Equipment Status Faceplate Files folder.



4. Select the Equipment_Status_Faceplate.gfx file and click Open.



5. Verify the Equipment_Status_Faceplate display appears under Displays.



ME Equipment Status Summary Faceplate

The CIP Motion energy faceplate routine is compatible with an equipment status faceplate, which is available on the Rockwell Automation sample code library. Search for 'ME Equipment Status' from the Sample Code Home search page.


http://search.rockwellautomation.com/search?site=sample_code&client=samplecode&output=xml_no_dtd&proxystylesheet=samplecode

Follow the user instructions provided with the equipment status faceplate.

Add ME Equipment Parameter File

Follow these steps to add and configure the ME_Equipment_Parameter file.

1. Right-click Parameters and choose Add Component into application.
2. Browse to the ME Equipment Status Faceplate Files folder on your Energy Management Toolkit CD image and select the ME_Equipment_Parameter file.
3. Click Open.
4. Verify the ME_Equipment_Parameter file appears under Parameters.



5. Open the ME_Equipment_Parameter file.

The file has nine parameters, #1...#9, that correspond to each of the nine rows on the Equipment Status Faceplate.

For the Efficient Industries Plant 1 example, the first five default parameters will be replaced with these Add-On Instruction tag assignments:

```
#1=:[L2X]Gas_Main
#2=:[L2X]Boiler_House_Gas
#3=:[L2X]Propane
#4=:[L2X]Fuel_Oil
#5=:[L2X]Boiler_House
```

```
General Parameter Syntax:
#replacement=tagname
Example:
#1=:[CLX-L63]Device_1 (This will represent the device monitored in row 1 of the Equipment Faceplate)
#2=:[CLX-L63]Device_2_EEO (This will represent the device monitored in row 2 of the Equipment Faceplate)
#3=:[CLX-L63]Device_3_EEO (This will represent the device monitored in row 3 of the Equipment Faceplate)
#4=:[CLX-L63]Device_4 (This will represent the device monitored in row 4 of the Equipment Faceplate)
#5=:[CLX-L63]Device_4 (This will represent the device monitored in row 5 of the Equipment Faceplate)
#9=:[CLX-L63]Device_4 (This will represent the device monitored in row 9 of the Equipment Faceplate)

**NOTE: YOU MUST CONFIGURE ALL 9 Parameter numbers representing each of the 9 rows, respectively
for the Equipment Status Faceplate. If you are not planning on using 9 devices for the Equipment Status
Faceplate, fill in the remaining parameters with the last device used, ie. In the example above, only
4 devices are configured for the Equipment Faceplate, therefore the remaining rows 5-9 are configured the
same as the last device in row 4.

**NOTE: Configure parameter #1 with the name of the AOI that has the "Inp_NumRowsVis" configured
in the AOI to represent the actual number of rows to appear on the Equipment Status Faceplate.

Assign the energy tagname of the device you intend to monitor.

The tagname includes the "Device Shortcut" of your system's Logix Controller. This is the name of the Logix controller
you configured in RSLogix Enterprise Communication Setup that is connected to the intended device you want to monitor.
Ex: [CLX-63]

The tagname also includes the energy tag of the device that was configured in your Logix application file.
For PowerMonitor 1000/3000 and PowerMonitor Status Inputs, energy tagnames are of the format "DeviceName". Ex: My_PM1000
For PowerMonitor 500, 5000, and E300 devices, energy tagnames are of the format "DeviceName_EEO". Ex: My_PM500_EEO
For PowerFlex, SMC 50, and E3 Plus devices, energy tags are of the format "DeviceName_BEO". Ex: My_SMC50_BEO
(EEO/BEO in the tagnames represents the CIP standard Electrical Energy Object/Base Energy Object)

=====
#1=:[CLX-L63]Motor_1
#2=:[CLX-L63]Motor_2
#3=:[CLX-L63]Motor_3
#4=:[CLX-L63]Motor_4
#5=:[CLX-L63]Motor_5
#6=:[CLX-L63]Motor_6
#7=:[CLX-L63]Motor_7
```


TIP Unused parameters can be replaced with any of the previous valid tag assignments. Unused parameters must be assigned to a valid Add-On Instruction for the Equipment Status Faceplate to operate without errors.

6. Assign an energy or faceplate Add-On Instruction tag name to each of the nine parameters.

- a. Enter the device shortcut name of the controller associated with the tag assignment.

For this example, [L2x] is the shortcut name of the controller associated with the Gas_Main Add-On Instruction.


Shortcut names are defined in the RSLogix Enterprise Communication Setup.



```
#1=:[L2x]Motor_1
#2=:[CLX-L63]Motor_2
#3=:[CLX-L63]Motor_3
#4=:[CLX-L63]Motor_4
#5=:[CLX-L63]Motor_5
#6=:[CLX-L63]Motor_6
#7=:[CLX-L63]Motor_7
#8=:[CLX-L63]Motor_8
#9=:[CLX-L63]Motor_9
```

- b. Enter the energy or faceplate Add-On Instruction name to display in the corresponding row of the faceplate.

For this example, Gas_Main is entered to display data from the Gas_Main Add-On Instruction on the first row of the faceplate.



```
#1=:[L2x]Gas_Main
#2=:[CLX-L63]Motor_2
#3=:[CLX-L63]Motor_3
#4=:[CLX-L63]Motor_4
#5=:[CLX-L63]Motor_5
#6=:[CLX-L63]Motor_6
#7=:[CLX-L63]Motor_7
#8=:[CLX-L63]Motor_8
#9=:[CLX-L63]Motor_9
```


TIP The first parameter, #1, must be assigned to a preconfigured energy or faceplate Add-On Instruction that includes the Inp_NumRowsVis assignment configured on [page 330](#).

TIP For PowerMonitor 1000/3000 and PM Status Inputs, energy tags are of the format 'DeviceName', for example, My_PM1000
 For PowerMonitor 500, 5000, and E300 devices, energy tags are of the format 'DeviceName_EEO', for example, My_PM500_EEO.
 For PowerFlex, SMC 50, and E3 Plus devices, energy tags are of the format 'DeviceName_BEO', for example, My_SMC50_BEO.

When done, the parameter file will look similar to this.

TIP To add devices that do not have preconfigured Add-On Instructions or faceplates, refer to the ME Equipment Status Summary Faceplate at <http://samplecode.rockwellautomation.com>.

Unused
parameters



7. Close and save the file.

Configure Energy Meter Goto Buttons

The Goto Display buttons within the Equipment Status Faceplate are used to identify the energy meters displayed in each row and can also be used to launch the PowerMonitor faceplates.

For the Efficient Industries Plant 1 example, the first four Goto Display buttons are configured for meter identification only. The Boiler House Electric Goto Display button is configured to identify the meter and also launch the corresponding PowerMonitor 1000 faceplate.

Goto Display buttons identify meters only.


Goto Display button identifies meter and launches faceplate

Efficient Plant 1_ Boiler House					
Device	State	Value 1	Value 2	Value 3	Value 4
Gas Main	ACTIVE	9565.000 therms	503.000 therms/hr	0.000	0.000
Boiler House Gas	ACTIVE	7654.000 therms	385.000 therms/hr	0.000	0.000
Propane	HIGH FLOW	43225.000 gal	4.300 gpm	0.000	0.000
Fuel Oil	CRITICAL FLOW	21653.000 gal	5.900 gpm	0.000	0.000
Boiler House Electric	Comms Fault	0.000 KW	0.000 Volts	0.000 Amps	0.000 PF


Follow these steps to configure the energy meter Goto Display buttons for each row of the Equipment Status Faceplate.

1. Double-click the Equipment Status Faceplate display in the Graphics folder.

The display opens.




2. Right-click in the display and choose Object Explorer.




3. Browse to Row_Group_x and double-click the GotoDisplayButton_x that you want to configure.

For this example, GotoDisplayButton_5 is selected to configure the Boiler_House meter button in row 5 of the faceplate.



4. Click the Label tab and type the text you want to display on the corresponding Goto Display button.


For this example, Boiler House Electric is entered.



TIP Complete steps 5 and 6 only if you are configuring the button to also launch a faceplate. Otherwise, skip to step 7.

- Click the General tab, then choose the faceplate display to be launched when the GotoDisplay button is pressed, then click OK.


For this example, the PM1K_FP is selected.



- Select the Parameter file that corresponds to the faceplate previously configured in the Configure Faceplate sections above, then click OK.

For this example, PM1K-172-144 is selected.


- Click OK to complete the configuration.
- Repeat steps 3...7 to configure a GotoDisplay button for each faceplate row.



Configure Additional Device Value Columns

Not all device faceplates used with the Equipment Status Faceplate are configured to display four value fields. If additional value fields are needed, then you must add logic to the existing faceplate routine or Add-On Instruction to move the additional tag values to the corresponding Sts_Valuexx tags.


In this example, preconfigured logic in the Energy_Gas_AOI writes values to Sts_Value1 and Sts_Value2. Two additional MOV instructions were added to this rung to display high flow and critical flow values on the Equipment Status Faceplate.



You can do the same for units displayed with additional value fields. Write logic to move a string value to the SetValueUnits tag in the Add-On Instruction, or set the default string for this tag by:

- opening the Controller Tags browser,
- changing the scope to your Add-On Instruction,
- editing the Set_ValueUnits default field.


In this example, High Flow and Critical Flow are added to Set_Value3Unit and Set_Value4Unit tags.




Create a Goto Button to Launch Faceplate

Follow these steps to add a Goto Display button to launch the Equipment Status Faceplate from a display in your FactoryTalk View ME application.

1. Add a Goto Display button to one of your existing ME application displays.
2. Double-click the button to open its Properties.




3. Under Display Settings, set the Display to Equipment_Status_Faceplate and the Parameter file to ME_Equipment_Parameter.



- Click the Label tab and type the text you want displayed on the button.

For this example, Boiler House is entered.

- Click OK.
- Save and test your application by creating a runtime application.



Configure Alarm History Faceplate

The Alarm History Faceplate leverages the alarm functionality in FactoryTalk View Machine Edition and provides time and date-stamped alarm, and fault information for energy data collector devices. This faceplate works in conjunction with energy and faceplate Add-On Instructions.

In this example, the Alarm History Faceplate shows alarms from three energy meters.




Add Alarm History Faceplate Display

Follow these steps to add the Alarm History Faceplate display to your FactoryTalk View ME application. The procedure uses the [Efficient Industries Plant 1](#) example to demonstrate the configuration steps.


1. Open the FactoryTalk View ME application to which you want to add the Alarm History Faceplate.

TIP The default display size for the Alarm History Faceplate is 640 x 480 and is compatible with PanelView Plus 700 or larger terminals.


2. Right-click Displays and choose Add Component Into Application.




3. Browse to the Faceplate Files folder on your Energy Management Toolkit CD image and select the ME Alarm History Faceplate Files folder.



4. Select the Alarm History.gfx file and click Open.




5. Verify Alarm History appears under Displays.



Import Alarm Configuration File

Follow these steps to import the alarm configuration file with energy alarm trigger tags and alarm messages into your FactoryTalk View application.

1. Right-click Alarm Setup in the Alarms folder and choose Import and Export.




2. Select Import alarm configuration into application then click Next.



IMPORTANT When importing the alarm configuration, your existing alarm configuration is lost. When prompted to back up the existing alarm configuration, you can choose to save it as a .xml file.

3. Choose Yes or No when prompted to back up application, then click Next.




4. Browse to the ME Alarm History Faceplate Files folder on your Energy Management Toolkit CD image, then select Alarms.xml and click Open.



5. Choose Finish to complete the import.

- Double-click Alarm Setup in the Alarms folder to open the new configuration.

You will see the EnergyAlarmTrigger tag and other Rockwell Automation device triggers.




You can remove device triggers not needed by selecting the triggers and clicking Remove. Corresponding messages not needed can be deleted from the Messages tab.

Configure Alarm Trigger Tags

Although the alarm triggers were imported, you must configure the alarm trigger tags.

Follow these steps to configure the alarm trigger tags.

- Access the Machine Edition HMI tag database by double-clicking Tags under the HMI Tags folder.



2. Create two FactoryTalk View device tags used by the preconfigured alarm triggers.
 - EnergyAlarmTrigger - Analog tag set to a maximum of 200
 - EnergyAlarmName- String tag
3. Assign the data source of each tag to the EnergyAlarmTrigger and EnergyAlarmName controller tags that you configured in RSLogix 5000 software.

The first screenshot shows the configuration for the 'EnergyAlarmTrigger' tag. It is an Analog tag with a maximum value of 200. The data source is set to 'Device' with the address '[L2x]EnergyAlarmTrigger'.

The second screenshot shows the configuration for the 'EnergyAlarmName' tag. It is a String tag with a length of 82. The data source is set to 'Device' with the address '[L2x]EnergyAlarmTrigger'.

Alarm History Faceplate/AOI

If you choose to display the kW High Limit alarm and Communication alarm, you need to create two FactoryTalk View device tags and customize two alarm messages:

- 'ModuleAlarmTrigger' – Analog tag (Set max to 200 for each)
 - 'ModuleAlarmName' - String tag
1. Assign each tag to the associated controller tag that was created when you imported the CIP Motion Energy faceplate routine.


The screenshot shows the configuration for the 'ModuleAlarmTrigger' tag. It is an Analog tag with a maximum value of 200. The data source is set to 'Device' with the address '[CLX]ModuleAlarmTrigger'.

Below the configuration window is a table listing the tags:

Search For:	Tag Name	Type	Description
	1 E300AlarmName	String	
	2 E300AlarmTrigger	Analog	
	3 ModuleAlarmName	String	
	4 ModuleAlarmTrigger	Analog	

2. Customize two alarm messages.

- Expand Alarms and double-click on Alarm Setup.
- Go to the Messages tab.
- Filter on ModuleAlarmTrigger.
- Replace 'User Alarm' in alarm message 18 with 'Communication Fault'.
- Replace 'User Alarm' in alarm message 19 with 'kW High Limit'.





- Configure the kW High Limit alarm threshold in the controller by modifying the value for the tag, `_DriveName_BEO.Set_High_Limit`; where '`_DriveName`' is the device name particular to your application.

<input type="checkbox"/> _DriveName_BEO	{ ... }
<input type="checkbox"/> +_DriveName_BEO.Control1	{ ... }
<input type="checkbox"/> +_DriveName_BEO.Inp_NumRowsVis	0
<input type="checkbox"/> +_DriveName_BEO.Set_DeviceNameOper	'MyPM5500'
<input type="checkbox"/> +_DriveName_BEO.Set_EquipFaceplateAnimation	2
<input type="checkbox"/> +_DriveName_BEO.Set_EquipmentDisplayName	' '
<input checked="" type="checkbox"/> _DriveName_BEO.Set_High_Limit	100000000.0
<input type="checkbox"/> _DriveName_BEO.Set_kWhMaxRate	0.0
<input type="checkbox"/> _DriveName_BEO.Set_kWhSamplingRate	0.05

Create a Goto Button to Launch Faceplate

Follow these steps to add a Goto Display button to launch the Alarm History Faceplate from a display in your FactoryTalk View ME application.


1. Add a Goto Display button to one of your existing ME application displays.
2. Double-click the button to open its Properties.
3. Under Display Settings, set the Display to Alarm History.



- Click the Label tab and type the text you want displayed on the button.

For this example, Alarm History is entered.


- Click OK.
- Save and test your application by creating a runtime application.



Create a Runtime Application File

Before you can download your application to a PanelView Plus terminal, you must first create a runtime version of your FactoryTalk View application.


- Choose Create Runtime Application from the Application menu.



- Specify the target directory and file name for the runtime application.


You can accept the default application name.

- In the Save as type box, select the terminal firmware version on which the .mer application will run.
- Click Save and wait for the progress bar to complete.



TIP Older versions of Factory Talk View ME Station cannot run newer versions of ME runtime applications. Check the version of ME Station on your PanelView Plus by selecting System Information under Terminal Settings.


A Validation message appears when the runtime application has been created. Any errors or warnings are displayed.



Transfer Runtime File to PanelView Plus Terminal

Follows these steps to download the runtime file just created to the PanelView Plus terminal.

1. Choose Transfer Utility from the Tools menu.
2. Click the Download tab.
3. Click the ... icon to locate the source runtime file.
4. Choose Internal Storage box, from the Destination storage type list.
5. Optionally, check Run application at start-up to start the application when the download finishes.
6. Browse through the RSLinx Enterprise communication tree to select the destination PanelView Plus terminal for the download.
7. Click Download.
8. Click OK when the download completes successfully.
9. Click Exit to close the File Transfer Utility.
10. Choose Exit from the File menu to close the FactoryTalk View Studio software.



Run Application on PanelView Plus Terminal


The (.mer) runtime file is now stored in the PanelView Plus terminal so you are ready to run the application on the terminal.

1. Apply power to the PanelView Plus terminal.

The FactoryTalk View ME Station window opens.


2. Press F1, Load Application.

You can skip this step if you checked Run application at start-up when creating the runtime application.




The Load Application window opens.

3. Press the up and down arrows to scroll through the list and select the application you want to load and run.
4. Press Load [F2] to load the application.




5. Press Yes [F7].

If you press No, the communication settings from the previously run project will be used.



6. Wait for the application to load and verify the application name appears under Current application.
7. Press Run [F2] to run the application.
8. Verify the functionality of the application.



Demand Control

Introduction

ControlLogix and CompactLogix controllers, with preconfigured demand logic, can be used as demand controllers to control a maximum of 16 loads, with the objective of maintaining total plant electrical real power demand below a threshold, defined by the user, during peak demand periods. The power monitor calculates the predicted end-of-interval demand according to its demand configuration. It also provides real time clock, end of demand interval, and demand period time remaining data to the controller. The controller converts predicted demand in excess of the setpoint into kWh to shed based on the time remaining in the demand interval, and then sheds loads based on their priority and availability until the predicted demand is under the setpoint. Loads are restored when the predicted demand is less than the demand setpoint by a hysteresis value.

Alarms are raised if the total sheddable kWh is less than the kWh to shed to satisfy the setpoint, when there is only one sheddable load remaining, or when a shed command fails to shed the load based on its status input. Alarms are also used to prompt an operator to remove load override status.

Before You Begin

- Complete an energy assessment and review monitoring methods in [Chapter 1](#).
- Complete other Energy Monitoring and Analysis chapters as applicable, [Chapter 2](#) through [9](#).

What You Need

- Energy Management Accelerator Toolkit, publication IASIMP-SP014 or visit the Integrated Architecture Tools and Resources website at <http://www.ab.com/go/iatools>
- RSLogix 5000 software, version 18.0 or later or Studio 5000 Logix Designer application, version 21.00 or later
- FactoryTalk View Machine Edition Software, version 5.1 or later
- Logix controller and supporting hardware
- PowerMonitor 1000 or 5000 unit

Follow These Steps

The following steps are based on a CompactLogix 1769-L23E-QBFC1 packaged controller, but the general steps may be applied to other Logix controller configurations and are similar. Follow these steps to implement your Demand Control application.

- Control Hardware Selection and Wiring
- Logic Integration
- HMI Integration
- System Commissioning

Control Hardware Selection and Wiring

Follow these steps to determine the hardware required for your application.

List Load Outputs and Inputs

1. Determine which loads in your application will be controlled by the Demand controller (maximum of 16 loads).
2. Number each load from 1...16.
3. List the outputs and inputs associated with each load.

As a minimum each load must accept a command to stop from the Demand Controller. The Demand Controller also accepts a load status input that is used for indication and alarming, however this is not required.

In the Efficient Industries Plant 1 example, the monitoring and analysis revealed some significant energy savings if Demand control was used to control the loads identified below.

Load	Description	Output I/O Location	Input I/O Location
1	Air Compressor 1	Local:2:0.Data.0	Local:1:I.Data.0
2	Air Compressor 2	Local:2:0.Data.1	Local:1:I.Data.1
3	AHU 1 Production	Local:2:0.Data.2	Local:1:I.Data.2
4	AHU 2 Production	Local:2:0.Data.3	Local:1:I.Data.3
5	AHU 3 Shipping	Local:2:0.Data.4	Local:1:I.Data.4
6	AHU 4 Office	Local:2:0.Data.5	Local:1:I.Data.5
7	Exhaust Fan 1	Local:2:0.Data.6	N/A
8	Exhaust Fan 2	Local:2:0.Data.7	N/A
9	Exhaust Fan 3	Local:2:0.Data.8	N/A
10	Exhaust Fan 4	Local:2:0.Data.9	N/A
11	Lighting Production	Local:2:0.Data.10	Local:1:I.Data.6
12	Lighting Production	Local:2:0.Data.11	Local:1:I.Data.7
13	Lighting Shipping	Local:2:0.Data.12	Local:1:I.Data.8
14	Lighting Office	Local:2:0.Data.13	Local:1:I.Data.9

Create Control Panel Layout and Wiring


The toolkit provides panel layout and wiring drawings in DWG, DXF, and PDF file formats to help you plan the layout of your system. If you do not have CAD software, use the pdf files to build your system drawings.

Use CAD Drawings from Toolkit

1. Browse to the System Layout and Wiring folder on the Energy Management Accelerator Toolkit CD image.
2. Double Click the CompactLogix folder.
3. Navigate to the desired files based on your file format (DXF, DWG, or PDF).
4. Add the required files to your project or copy them to your project folder.


Panel Layout Drawings

The AutoCAD Electrical project includes a panel-layout drawing for the CompactLogix controller, shown below. Add or remove components as needed.



Power and Control Wiring Drawings

The AutoCAD electrical project also includes power and control wiring drawings for the CompactLogix L23E controller. Several digital output examples are shown below.



Access Other RA CAD Drawings

Follow these steps to download other Allen-Bradley product CAD drawings.

1. Open your browser and go to <http://www.rockwellautomation.com/en/e-tools/>.
2. The Configuration and Selection Tools webpage opens.
3. If you don't know the complete catalog number, click product directory to browse the configured Rockwell Automation products.
4. Click Rockwell Automation and follow the prompts.

Logic Integration

You will need to configure the controller, import the Demand program, configure the load inputs and outputs, and configure messages.

Configure Controller, Network, and I/O

These next sections will show you how to configure the controller, network, and I/O.




Create or Open a Project in RSLogix 5000 Software

Follow these steps to create or open a project in RSLogix 5000 software.

1. Open RSLogix 5000 software by clicking Start > Programs > Rockwell Software > RSLogix 5000 Enterprise Series > RSLogix 5000.

The Quick Start window displays in the RSLogix workspace.




2. Click Open Project to open an existing project, or click New Project.
3. If you are creating a new project, configure the controller.
 - a. Choose your controller and revision number.
 - b. Enter a unique controller name.
 - c. Click OK.



Configure the PowerMonitor Unit

Follow these steps to configure a PowerMonitor unit.

1. Right-click the Ethernet Port and choose New Module.
2. Select ETHERNET-MODULE (Generic Ethernet Module) as the module type and click OK.
3. Configure the PowerMonitor's IP address and Connection Parameters and then click OK.



PowerMonitor 1000/3000 Connection Parameters

	Assembly Instance	Size
Input	1	16
Output	2	
Configuration	3	0

PowerMonitor 5000 Connection Parameters

	Assembly Instance	Size
Input	100	60
Output	101	1
Configuration	102	160

Configure the I/O


Configure the I/O specific to your application, as identified in the control Hardware Selection and Wiring section above.

The 1769-L23E packaged controller included embedded I/O for 16 DC inputs, 16 DC outputs, 4 differential or single-ended analog inputs, 2 single-ended analog outputs, 6 HSC inputs, and 4 HSC outputs.

1. To configure the properties for any of the embedded I/O modules, right-click on the module and select Properties.

If required, up to two 1769 CompactLogix modules may be added to the 1769-L23E-QBFC1B packaged controller.


2. To add an expansion module to the I/O configuration tree, right-click the Expansion I/O folder and select New Module.



For detailed information about configuring your embedded I/O, see Chapter 3 of the 1769 CompactLogix Packaged Controllers Quick Start and User Manual, publication [IASIMP-QS010](#), Embedded I/O (page 191).

Save the Project File


Click to save your RSLogix 5000 application file.




Import and Configure Demand Control Program

Follow these steps to import and configure your Demand Control program.

1. If not already opened, open your RSLogix 5000 software project.




- Expand the Tasks folder in your Controller Organizer, right click the Main Task folder, and select Import Program.
- Browse to and open the Demand Control Logic folder on the Energy Management Accelerator Toolkit CD image.




C:\Program Files\RA_Simplification\EMAT\File\Demand Control Logic.


- Select the DemandControl.L5x file and click Import.
The Import Configuration dialog will appear.



- Leave the program properties at the default; click OK to create the Demand Control program.



- The new DemandControl program should appear in the Controller Organizer within the Main Task folder.




Configure Load Inputs and Outputs

Follow these steps to load inputs and outputs.

1. Expand the DemandControl program and double-click the SR00_IO_Mapping Routine.
2. Rungs 1 through 32 have been configured for I/O mapping.

The I/O mapping routine will not be executed unless the Enable_IO bit is set. Refer to [page 379, step 10](#).



For each load, there are two rungs to configure. The first is for mapping the command output.

3. Double-click the NOP instruction on rung 1 and type OTE.



4. Click Enter.
5. Double click on the question mark above the OTE and type the name of the tag that should be mapped to the output command for Load Number 1.

Use an XIC/XIO or an OTE/OTU instruction as required to fit your application.

In the Efficient Industries example, the output for Load 1 is hard-wired to Local:2:O.Data.0.



6. Click Enter.

In rung 2, the input status has been configured to follow the commanded state. If the input status is not available for the load, this rung can be left alone. In the Efficient Industries example, the input status for Load number 1 is available and is hard-wired to Local:1:I.Data.0.

7. Double click the tag above the XIC instruction and enter the tag for the input status.

Use an XIO or an XIC instruction as required to fit your application.



8. Click Enter.
9. Use the same procedure to configure the I/O mapping for the remaining loads in rungs 3...32.


If you are not utilizing all 16 loads in your application, you can delete the unused I/O mapping rungs, or leave them as is.

Configure PowerMonitor Messages

Follow these steps to configure PowerMonitor unit messages.

IMPORTANT The demand control program is configured to use a PowerMonitor 1000 by default.


1. If you are using a PowerMonitor 1000, skip to step 2.
If you are using a PowerMonitor 5000, you must edit the main routine.
 - a. Expand the DemandControl program and double-click the MainRoutine.
 - b. In rung 5, modify the JSR instruction to call the SR01_ProcessPM5000 routine.




2. Expand the DemandControl program and double-click the SR01_ProcessPM1000 or SR01_ProcessPM5000 routine as required per your application.

Rung 1 includes several message instructions.

3. For each message, click the View Configuration Dialog button to launch the configuration window.




4. Select the Communication tab and set the path to your PowerMonitor unit.




Configure Password

A password is required for configuring the demand control from the faceplate. To set the password, locate the controller tag, FP.Cfg_Password in the controller. Configure the string value to your desired password.



Save the Project File

Click save to save your RSLogix 5000 application file.



HMI Integration


These next sections show you how to integrate the HMI into your system.

Add Demand Faceplate to FactoryTalk View ME Application

1. Launch FactoryTalk View Studio for Machine Edition.
2. Create a new or open an existing application to which you want to add the Demand Control faceplate.
3. Expand the graphics folder in the explorer window, right-click on the displays folder and choose Add Component into Application.
4. Browse to and open the ME Demand Control Faceplate Files folder on the Energy Management Accelerator Toolkit CD image.

C:\Program Files\RA_Simplification\EMAT\Files\Faceplate Files\ME
Demand Control Faceplate Files

5. Choose the ME_Demand_Faceplate.gfx file and click Open.




Create a Display Navigation Button

Follow these steps to create a Goto Display navigation button to launch the faceplate display.

1. Create a new or open an existing display from which you want to launch the Demand Control faceplate.

If you do not have any additional displays in your application, use the default MAIN display.

2. Choose Goto from the Objects > Display Navigation menu.
3. Draw the Goto Display push button on the display.
4. Double-click the Goto Display push button to configure its properties.




5. Click the ellipse icon next to Display:, select the ME_Demand_Faceplate, and then click OK.
6. Click on the Label tab and enter a caption, such as 'Demand Controller'.
7. Click OK to close the Goto Display push button Properties dialog box.

If you do not already have a Shutdown or Goto Configure Mode button configured in your application, you should add one to the main page as well.



This will provide a means of shutting down your application.

8. From the Objects > Advanced menu select Goto Configure Mode or Shutdown.
9. Draw the button on your display and configure its properties.
10. Save your display.



Configure Alarms

1. Expand the Alarms folder in the system tree.
2. Right-click Alarm Setup and choose Import and Export.
3. Select Import alarm configuration into application.
4. Click Next.



5. Choose Yes or No when prompted to backup your existing alarm configuration, and then click Next.




IMPORTANT When importing the alarm configuration, the existing alarm configuration is lost. When prompted to backup the existing alarm configuration, you can choose to save it as an XML file.

6. Browse to and open the ME Demand Control Faceplate Files folder on the Energy Management Accelerator Toolkit CD image to import the Alarms.xml file to your project.

C:\Program Files\RA_Simplification\EMAT\Files\Faceplate Files\ME Demand Control Faceplate Files

7. Click Open.

8. Click Finish.




Configure Communication

Follow these steps to configure communication.


1. Double-click Communication Setup under RSLinx Enterprise in the Explorer window.

You will see this dialog box if a communication setup does not exist.



2. Select Create a new configuration and click Finish.




3. Click Add under Device Shortcuts to create a new shortcut, then rename the shortcut DMD.
4. Click the Design Local tab.
5. Expand the Ethernet network and select the controller containing the DMD program.
6. Verify that the shortcut name is highlighted, then click Apply.
7. Click Yes to apply the changes when prompted.



8. Click Copy from Design to Runtime to copy changes to the runtime communication setup.
9. Click Yes when prompted to continue with the copy operation.



10. Click OK at the bottom of the RSLinx Enterprise dialog box to save the communication setup changes.



System Commissioning

To commission the system, you need to install the system hardware and download the projects.

Install System Hardware


Refer to the documentation listed below for information on installing the CompactLogix and PanelView Plus Hardware.

Document Name	Publication Number	Document Contents
CompactLogix Packaged Controller Installation Instructions	1769-IN082	<ul style="list-style-type: none"> • Installation Checklist • Controller Dimensions • How to Install the Battery • How to Connect Expansion Modules • Minimum Spacing Requirements • How to Panel Mount • How to DIN Rail Mount • Grounding Considerations • Wiring Power to the System • Wire the I/O Removable Terminal Blocks • Expansion Module Wiring • Selecting Operating Mode • Status Indicators
PanelView Plus Installation Manual	2711P-IN002	<ul style="list-style-type: none"> • Environmental Information • Mounting Clearances • Cutout Dimensions • Panel Mounting Instructions • Product Dimensions • Removing and Installing the Power Terminal Block • DC Power Connections • AC Power Connections • Troubleshooting • Battery Removal • System Specifications • Certifications


Download RSLogix5000 Project

Follow these steps to download your RSLogix 5000 project file to the Logix controller.


1. Open your RSLogix 5000 project file.
2. From the Communications menu, choose Who Active.
The Who Active dialog box opens.




3. Browse to and select your Logix controller.
4. Verify the key switch on your controller module is in the REM (remote) position.



5. Click Download.
The Download dialog box opens. Click Download.






6. From the Communications menu, choose Run mode to switch the controller to Run mode.



Configure and Download FactoryTalk Project to PanelView Plus Terminal

Before you can download your application to a PanelView Plus terminal, you must first create a runtime version of your FactoryTalk View application.

1. Start FactoryTalk View Studio for Machine Edition and open your application which contains the Demand Control faceplate.
2. Choose Create Runtime Application from the Application menu.
3. Specify the target directory and the file name for the runtime application.
4. In the Save as type box, select the terminal firmware version on which the .mer application will run.
5. Click Save and wait for the progress bar to complete.




Download the PanelView Plus terminal Runtime File

Follow these steps to download the runtime file just created to the PanelView Plus terminal.

1. Choose Transfer Utility from the Tools menu.
2. Click the Download tab.
3. Click the ... icon to locate the source runtime file.
4. Choose Internal Storage box, from the Destination storage type list.

Optionally, check Run application at start-up to start the application when the download finishes.


5. Browse through the RSlinx Enterprise communication tree to select the destination PanelView Plus terminal for the download.



6. Click Download.
7. Click OK when the download completes successfully.
8. Click Exit to close the File Transfer Utility.

Run Application on PanelView Plus Terminal

The (.mer) runtime file is now stored in the PanelView Plus terminal so you are ready to run the application on the terminal.




1. Press F1, Load Application.

You can skip this step if you checked Run application at start-up when creating the runtime application.

The Load Application window opens.



2. Press the up and down arrows to scroll through the list and select the application you want to load and run.
3. Press Load [F2] to load the application.



4. Press Yes [F7].

If you press No, the communication settings from the previously run project will be used.



5. After the application loads, press Run [F2] to run the application.



Demand Control Configuration

Prior to configuring the loads in the controller, you must assign priority levels and interlock times to the loads in your application. The configuration for the Efficient Industries Plant 1 Example is shown below:

Load	Description	Rated KW	Priority	On Delay (s)	Off Delay (s)	Max Off Time (s)
1	Air Compressor 1	21	1	60	60	900
2	Air Compressor 2	21	1	60	60	900
3	AHU 1 Production	15	4	120	120	1800
4	AHU 2 Production	15	4	120	120	1800
5	AHU 3 Shipping	12	5	120	120	1800
6	AHU 4 Office	10	7	120	120	1800
7	Exhaust Fan 1	2	2	30	30	2700
8	Exhaust Fan 2	2	2	30	30	2700
9	Exhaust Fan 3	2	10	30	30	2700
10	Exhaust Fan 4	2	10	30	30	2700
11	Lighting Production	6	3	15	15	1200
12	Lighting Production	6	6	15	15	1200
13	Lighting Shipping	6	8	15	15	3600
14	Lighting Office	6	9	15	15	3600

Priority Levels


- There are up to 16 priority levels available.
- Loads with the largest priority number are shed first (priority level 1 is shed last).
- More than one load may be assigned to a given priority level. If loads share the same priority level, they will be shed based on the time since the load was last shed. (In other words, when a shed is required, the running load with the largest priority level number and the longest minutes since shed will be the next load to shed.)

Interlocks


- On Delay interlock is the minimum time the load must be off, in seconds, before it can be restarted.
- Off Delay interlock is the minimum time the load must be on, in seconds, before it can be shed.
- Max Off Time interlock is the maximum amount of time, in seconds, that the load is allowed to be shed per hour.

Configure the individual loads and the demand control schedule.

1. Click the configuration button on the toolbar.




2. Enter your configured password.




3. Configure the demand control schedule, kW setpoint, and billing end date.

For the Efficient Industries example, the demand control is on from 8:00 to 18:00, Monday through Friday.




4. Click on the load config button to configure the individual loads.

For the efficient industries example, loads are configured as follows:




Load	Description	Priority	Rated KW	On Delay SEC	Off Delay SEC	Max Off Time SEC
1	Air Compressor 1	1	21	60	60	900
2	Air Compressor 2	1	21	60	60	900
3	AHU 1 Production	4	15	120	120	1800
4	AHU 2 Production	4	15	120	120	1800
5	AHU 3 Shipping	5	12	120	120	1800
6	AHU 4 Office	7	10	120	120	1800
7	Exhaust Fan 1	2	2	30	30	2700
8	Exhaust Fan 2	2	2	30	30	2700
9	Exhaust Fan 3	10	2	30	30	2700
10	Exhaust Fan 4	10	2	30	30	2700
11	Lighting Production	3	6	15	15	1200
12	Lighting Production	6	6	15	15	1200
13	Lighting Shipping	8	6	15	15	3600
14	Lighting Office	9	6	15	15	3600

5. Click on the load number to launch the numeric keypad.




6. Enter the load number you wish to configure, and then click Return.
7. Configure the load priority, rated kW, description, on delay, off delay, and max off times for the load.

Place the load in Normal Demand Control mode
(Remove OVR if OVR is applied).



8. To change the mode, click on the mode indicator to toggle between modes.
9. Repeat the above step for each load in your application.

10. Once the demand controller has been configured, enable the IO mapping routine.



Go online with your RSLogix project and monitor the Enable_IO tag. Set the tag value to '1' if it is not already set.


Scope: DemandControl Show: All Tags		
Name	Value	
Alm_InsufficientLoad	1	
Alm_OneLoadAvail	0	
CalcPresentBillingDemand	1	
Demand_Hysteresis_Pct	5.0	
Demand_SP_90_Pct	90	
Enable_IO	1	
EOL_Delay_Timer	{...}	
KWH to Shed	1	

System Application Guide




This section guides you through the pre-configured FactoryTalk View Machine Edition faceplate providing you with an understanding of the status, control, and diagnostic operation of the faceplate display.

Faceplate Operation Overview

The Demand Control Faceplate opens with the Demand Control Status displayed.




Button	Icons	Description
Alarm		The alarm button indicates an alarm condition and activates alarm diagnostic views. A grey bell indicates normal status, with no alarms. A red flashing bell indicates an alarm condition.
Configuration		The Configuration button displays the main demand control configuration screen (upon entering the correct password).
Load 1...8		The Load 1-8 button lets you view the load status and descriptive name for loads 1...8
Load 9...16		The Load 9-16 button lets you view the load status and descriptive name for loads 9...16
Help		The Help button provides information for the existing view.
Close		Click the Close button to close the faceplate.
Status Indicators		Grey = Off/Normal Control Green = On/Normal Control D-Grey = Off/Demand Control OVR-Grey = Off/Override Set OVR-Green = On/Override Set OVR-Red = On/Override Set/Operator Action Required Red Flashing = Load is not in OVR, controller telling to turn off, but load is still on. INT-Green = Interlocked On INT-Grey = Interlocked Off
Interlocks Bypassed		Indicates that the interlocks have been bypassed for the load.
Predicted KW Demand		The predicted KW demand is read from the PowerMonitor with the following color code <ul style="list-style-type: none"> Red = Operator Action Required to stay within Demand kW Setpoint Yellow = Shedding Loads to stay within Demand kW Setpoint Green = Predicted Demand within Demand kW Setpoint - Shedding not required

Button	Icons	Description
Present billing KW Demand		The present kW Billing Demand is the max of interval demands during the on-peak time-of-use periods in the current month. <ul style="list-style-type: none">• Red= Present Billing Demand is greater than or equal to the Demand kW SP• Yellow=Present Billing Demand is within 10% of the Demand kW SP• Green=Present Billing Demand is 10% Below the Demand kW SP
Demand KW Setpoint		The demand kW setpoint is entered by the user from the main demand configuration screen
Demand Control Status		Indicates whether demand control is currently on or off (on-peak or off-peak).

Main Demand Configuration View


Click on the wrench button from the toolbar to display the load configuration view.



Button	Icons	Description
Alarm		The alarm button indicates an alarm condition and activates alarm diagnostic views. A grey bell indicates normal status, with no alarms. A red flashing bell indicates an alarm condition.
Load Configuration		The Load Configuration button displays the load configuration screen. (The load configuration screen can also be displayed by clicking a load number from any of the status screens and entering the correct password.)
Home		The Home button lets you view the status of all 16 loads.
Help		The Help button provides information for the existing view.
Close		Click the Close button to close the faceplate.
Days of the Week		Click on a day of the week to toggle demand control on/off for that day.
Demand Control Schedule		Click on the Start Time or Stop Time Hour or Minute to launch the keypad input object and enter a time.
Predicted KW Demand		The predicted kW demand is read from the PowerMonitor device and displayed here for status only. (The color indication is the same as described for the demand control status screen.)
Present Billing KW Demand		The present billing kW demand is equal to the max of interval demands during the on-peak time-of-use periods in the current billing month. (The color indication is the same as described for the demand control status screen.)
Demand KW Setpoint		Click on the demand setpoint to launch the numeric keypad and enter the demand kW setpoint.
Billing End Date		Click on the billing end date to launch the numeric keypad and enter the monthly billing end date. (This date is used to calculate the present billing kW demand for the current billing month.)
Time and Date		The current time and date are displayed in the lower right corner of the faceplate.

Load Configuration View


Click on the wrench button from the toolbar to display the load configuration view.



Button	Icons	Description
Alarm		The alarm button indicates an alarm condition and activates alarm diagnostic views. A grey bell indicates normal status, with no alarms. A red flashing bell indicates an alarm condition.
Configuration		The Configuration button displays the main demand control configuration screen.
Home		The Home button lets you view the status of all 16 loads.
Help		The Help button provides information for the existing view.
Close		Click the Close button to close the faceplate.
Load Number		The load currently being displayed/configured. To select a new load for configuration, click on the load number to launch the numeric keypad input object. Enter a load number from 1...16, and then click Enter.
Load Priority		The priority number for the load currently being displayed/configured. To change the priority, click on the priority number to launch the numeric keypad input object. Valid priority numbers are from 1...16. The loads with the highest priority numbers are shed first. Loads can share the same PRI values.
Load Rated KW		The rated kW for the load currently being displayed/configured. To change the rated kW, click on the number to launch the numeric keypad input object.
Load Description		Click on the load description to launch the keypad input object and enter a description for the load.
Demand Control Mode		Click on the Apply Override button to place the load in override mode. In override mode, the demand controller will not attempt to shed the load. When the load is in override mode, the button text will change to Remove OVR with a yellow background. Click on the Remove Override button to place the load back in demand control mode.
Interlock Bypass		Click on the Bypass Interlocks button to ignore the interlocks for the load. When the interlocks are bypassed, the button text will change to 'Remove Intlk Bypass' with a yellow background. Click the Remove Intlk Bypass button to re-activate the interlocks.
Interlocks		On Delay (0...3600 s) = minimum time off before restarting Off Delay (0...3600 s) = minimum time on before shedding Max Off Time (0...3600 s) = Max time per hour shed If an interlock is active, the interlock time remaining will appear to the right of the associated interlock.
Time and Date		The current time and date are displayed in the lower right corner of the faceplate.

Load Status View


Click the Loads 1-8 or Loads 9-16 button on the toolbar to display the Load Status view. The Load 1-8 and Load 9-16 Status views display the load status, just like the Home View, as well as the load's rated kW, priority and description.



Button	Icons	Description
Alarm		The alarm button indicates an alarm condition and activates alarm diagnostic views. A grey bell indicates normal status, with no alarms. A red flashing bell indicates an alarm condition.
Home		The Home button lets you view the status of all 16 loads.
Configuration		The Configuration button displays the main demand control configuration screen (upon entering the correct password).
Help		The Help button provides information for the existing view.
Close		Click the Close button to close the faceplate.
Status Indicators		Grey - Off/Normal Control Green - On/Normal Control D-Grey - Off/Demand Control OVR-Grey - Override Set OVR-Green - On/Override Set OVR-Red - On/Override Set/Operator Action Required Red Flashing - Load is not in OVR, controller telling to turn off, but load is still on INT-Green - Interlocked On INT-Grey - Interlocked Off
Interlocks Bypassed		Indicates that the interlocks have been bypassed for the load.
Load Number		The load number. To change the configuration for a load, click on the load number to launch the load configuration screen.
Load Priority		The priority currently assigned to the load.
Load Rated KW		The rated kW currently assigned to the load.
Load Description		The description currently assigned to the load.

Alarm View


Click on the alarm bell button to display the Alarm Status view.







Button	Icons	Description
Alarm		The alarm button indicates an alarm condition and activates alarm diagnostic views. A grey bell indicates normal status, with no alarms. A red flashing bell indicates an alarm condition.
Configuration		The Configuration button displays the main demand control configuration screen (upon entering the correct password).
Home		The Home button lets you view the status of all 16 loads.
Load 1...8		The Load 1-8 button lets you view the load status, rated kW, priority and descriptive name for loads 1...8.
Load 9...16		The Load 9-16 button lets you view the load status, rated kW, priority and descriptive name for loads 9...16.
Help		Press the Help button to access a more detailed alarm description and recommended actions.
Close		Click the Close button to close the faceplate.
Current Alarm		Indicates the highest priority active alarm in the demand controller.

Help View


Press the Help button on any view to access the online help information.



Button	Icons	Description
Alarm		The alarm button indicates an alarm condition and activates alarm diagnostic views. A grey bell indicates normal status, with no alarms. A red flashing bell indicates an alarm condition.
Configuration		The Configuration button displays the main demand control configuration screen (upon entering the correct password).
Home		The Home button lets you view the status of all 16 loads.
Next Page		The next button will appear if there is more than one help screen for the help topic. Click the next button to scroll through the screens.

Program Overview


The Demand Control program is organized into eight routines, as shown below.



Routine Name	Description
MainRoutine	Performs the demand control calculations and processes the commands from the faceplate. It also dispatches all of the subroutines.
SR00_IO_Mapping	Used to map the demand control inputs (Load[#].Inp_Status) and outputs (Load[#].Out_Shed) to the corresponding hardwired I/O point or device level control tag for each load. This routine will need to be customized for each application, as described on the next page.
SR01_ProcessPM1000	Reads the PowerMonitor 1000 device data and writes the data to the PM tag (UDT).
SR01_ProcessPM5000	Reads the PowerMonitor 5000 device data and writes the data to the PM tag (UDT).
SR02_ProcessLoads	Calculates the KWH_Sheddable, processes the timers, determines the interlock state, output state, and load status for the load.
SR03_EvaluateLoads	Determines which loads are sheddable and copies the data for the sheddable loads into an array for sorting. This routine is executed after each shed or restore event and periodically every 10 seconds.
SR04_Sort	Sorts the sheddable loads first by priority and then by minutes since shed ascending and stores them in the Sheddable_Load LIFO array. This array presents the next load to shed as the last element in the array.
SR05_Shed	Sets the shed status equal to 'Shed' for the next load to shed. Adds the load to the Shed_Load FIFO array. This array presents the next load to restore as the first element in the array.
SR06_Restore	Sets the shed status equal to 'Normal' for the next load to restore (the first element in the Shed_Load array).
SR07_ProcessAlarms	Sets the alarm status bit for the following alarms: <ul style="list-style-type: none"> • Power monitor communication loss • Invalid Power monitor Demand Configuration • Insufficient Sheddable Load • [Load Name] Load Shed Failed alarm • Only 1 Sheddable Load Available

I/O Mapping

The only modifications to the controller code that will be required for your application will be to map the demand controller inputs and outputs to the loads in your application. The shed command from the demand controller, `Load[##].Out_Shed`, will need to be mapped to the stop command or enable bit for the load. This could be a hardwired output or a tag in your controller that ties into your device level control. The load status (on/off) will need to be mapped to the Demand Controller tag, `Load[##].Inp_Status` (if it is available). The `SR00_IO_Mapping` routine has been provided to easily configure your I/O mapping. This routine contains 2 rungs for each of the 16 loads available in the demand controller:



To map the shed output, replace the NOP instruction with an OTE or OTU instruction as required per your application. In the example below, the shed output for Load number 1 is mapped to the first output on the local I/O card in slot 2.



The input status has been configured to follow the shed command by default. If the load's actual input status is not available, this rung can be left as is. If the load's input status is available, map the input status to the appropriate status bit. In the example below, the input status for Load number 1 is mapped to the first input on the local I/O card in slot 1.



Demand Controller Tags

When the DemandControl program is imported, three User Defined Data Types will be added to the controller; DemandFaceplate, Load, and PM.

The DemandFaceplate UDT is used for the HMI interface.

Name	Data Type	Description
Set_FaceplateAnimation	INT	Controls the visibility on the faceplate
Set_LoadNum	DINT	Load number currently being configured
Set_Password	STRING	Password entered from the HMI
Cfg_Load	Load	Configured Load Buffer
Cfg_Password	STRING	Configured Password
Cfg_StartHour	DINT	Configured Demand Control Start Hour
Cfg_StartMin	DINT	Configured Demand Control Start Minute
Cfg_StopHour	DINT	Configured Demand Control Stop Hour
Cfg_StopMin	DINT	Configured Demand Control Stop Minute
Cfg_PeakDays	BOOL[32]	Configured Peak Days of the week
Cmd_PasswordEntered	DINT	Set when a password is entered from the faceplate (Bit 0 is set when a password is entered for demand control configuration, bits 1...16 are set when a password is entered for configuring a specific load)
Cmd_SetPriority	BOOL	Set when a new priority is entered from the load configuration screen
Cmd_SetKWRated	BOOL	Set when a new KW rating is entered from the load configuration screen
Cmd_SetDesc	BOOL	Set when a new load description is entered from the load configuration screen
Cmd_SetOnDelay	BOOL	Set when a new on delay time is entered from the load configuration screen
Cmd_SetOffDelay	BOOL	Set when a new off delay time is entered from the load configuration screen
Cmd_SetMaxOffTime	BOOL	Set when a new maximum off time is entered from the load configuration screen
Sts_PasswordAccepted	BOOL	Set when the correct password is entered from the faceplate, allowing visibility of the configuration screen
Sts_BillingKW	DINT	Used for color animation of the present billing kW
Sts_PredKW	DINT	Used for color animation of the predicted kW demand
Val_ActiveAlarm	DINT	Used for displaying the highest priority alarm on the faceplate
Val_AlmLabel	STRING	Used for displaying the load name on the faceplate when the load shed failed alarm is active

The Load UDT is used to store the main load attributes for each load.

Name	Data Type	Description
Name	STRING	Load Description
Number	DINT	Load Number
Priority	DINT	Load Priority 1...16 (Priority 16 loads are shed first)
kW_Rated	DINT	User Input (0...65535)
kWh_Sheddable	DINT	$kW_Rated * PM.Period_Remaining_Sec / 3600$
Inp_Status	BOOL	Status of load from discrete input 0=Off 1=On
Avail	BOOL	0=Override, 1=Normal
Shed_State	BOOL	Shed (on) Normal (off)
Out_Shed	BOOL	1=Shed Load
Intlk_State	BOOL	1=Interlocked (Load not available to shed)
Intlk_Bypass	BOOL	User command to bypass all interlocks
Alm_FailToShed	BOOL	Load Shed Failed Alarm
Val_Status	DINT	Status Value used to drive status indicators on the faceplate
Off_Delay_Sec	DINT	Min time on before shedding User Input (0...3600 s)
On_Delay_Sec	DINT	Min time off before restarting User Input (0...3600 s)
Max_Off_Time_Sec	DINT	Max time per hour shed User input (0...3600 s)
Alm_DelayTimer	TIMER	Failed to Shed Alarm Delay Timer
Off_Delay_Timer	TIMER	Min time on before shedding timer
On_Delay_Timer	TIMER	Min time off before restarting timer
OneHourTimer	TIMER	Rolling One Hour Timer to limit the amount of time per hour the load is shed
Max_Off_Timer	TIMER	Maximum Off (Shed) timer
Min_Since_Shed_Timer	TIMER	One minute timer used to count the minutes since shed
Minutes_Since_Shed	COUNTER	Incremented each time the minutes since shed timer is done
storagebits	BOOL[32]	Miscellaneous storage bits used for programming

The PM UDT is used to store the main load attributes for each load.

Name	Data Type	Description
MeteringIteration	REAL	Read from PowerMonitor Demand Results element
Predicted_Demand_KW	REAL	Read from PowerMonitor Demand Results element
Present_Billing_Demand_KW	REAL	Set to the max of interval demands during the on-peak time-of-use periods in the current billing month
Real_Power_Demand	REAL	Read from PowerMonitor Demand Results element
Period_Remaining_Sec	REAL	Seconds remaining in the current interval
Interval_Elapsed_Time	REAL	Read from PowerMonitor Demand Results element
Real_Time_Clock	DINT[7]	Read from PowerMonitor Date and Time Configuration element
Demand_Period_Min	DINT	Read from PowerMonitor Advanced Configuration element
Number_of_Demand_Periods	DINT	Read from PowerMonitor Advanced Configuration element
Billing_End_Date	DINT	Monthly billing date
End_Of_Interval	BOOL	Set for one scan at the end of each 15-minute interval
Alm_Comm	BOOL	Loss of Communication Alarm
Alm_Cfg	BOOL	Invalid Demand Configuration Alarm
Interval_Timer	TIMER	15 minute interval timer, synchronized with the interval elapsed time in the PM once per interval
Billing_Start_Init	TIMER	Present Billing Demand Initialize Timer
Comm_Timer	TIMER	Communication Alarm Timer

Most of the demand controller tags will be added as program scope tags. However, there are a few tags that will be added as controller scope, shown in the figure below. The power monitor message tags are required by the Message instruction to be controller scope. The FP_DMD tag has been configured as controller scope to minimize the length of the tagnames used in the HMI.

Scope:	Demand_Control	Show:	All Tags
	Name	Data Type	
	FP_DMD	DemandFaceplate	
	PM_DemandPeriod	REAL[2]	
	PM_DemandResults	REAL[9]	
	PM_MSG_AdvCtg	MESSAGE	
	PM_MSG_DemandResults	MESSAGE	
	PM_MSG_TimeDate	MESSAGE	
	PM_RealTimeClock	DINT[7]	

Notes:

Time of Day Control

Introduction

ControlLogix and CompactLogix controllers, with preconfigured Time of Day logic, can be used as Time of Day controllers to control up to sixteen loads. Six configurable on/off settings are provided for each day of the week for each load. A calendar allows for configuring in holidays. Each load can be configured to follow a holiday schedule or ignore the holiday calendar and follow the normal daily schedule.

In this chapter you will configure hardware, import preconfigured logic and edit it specifically for your application. The toolkit provides preconfigured logic and an operator interface faceplate that can run on a PC or a PanelView Plus terminal.

Before You Begin

- Complete an energy assessment and review monitoring methods in [Chapter 1](#).
- Complete other Energy Monitoring and Analysis chapters as applicable, [Chapter 2](#) through [9](#).

What You Need

- Energy Management Accelerator Toolkit, publication IASIMP-SP014 or visit the Integrated Architecture Tools and Resources website at <http://www.ab.com/go/iatools>
- RSLogix 5000 software, version 18.0 or later or Studio 5000 Logix Designer application, version 21.00 or later
- FactoryTalk View Machine Edition Software, version 5.1 or later
- Logix controller and supporting hardware

Follow These Steps

The following steps are based on a CompactLogix 1769-L23E-QBFC1 packaged controller, but the general steps may be applied to other Logix controller configurations and are similar. Follow these steps to implement your Time of Day Control application:

- Control Hardware Selection and Wiring
- Logic Integration
- HMI Integration
- System Commissioning

Control Hardware Selection and Wiring

You need to determine what your system will contain.

List Load Outputs and Inputs

1. Determine which loads in your application will be controlled by the Time of Day controller (maximum of 16 loads).
2. Number each load from 1...16.
3. List the outputs and inputs associated with each load.

As a minimum each load must accept a command to run from the Time of Day Controller. The Time of Day Controller will also accept a load status input that can be used for indication and alarming, however this is not required.

In the Efficient Industries Plant 1 example, the monitoring and analysis revealed some significant energy savings if TOD control was used to control the loads identified below:

Load Number	Loads	Output Description	Output I/O Location	Input Description	Input I/O Location
1	Boiler 1	Command On	Local:2:0.Data.0	Status Feedback	Local:1:I.Data.0
2	Boiler 2	Command On	Local:2:0.Data.1	Status Feedback	Local:1:I.Data.1
3	Air Compressor 1	Command On	Local:2:0.Data.2	Status Feedback	Local:1:I.Data.2
4	Air Compressor 2	Command On	Local:2:0.Data.3	Status Feedback	Local:1:I.Data.3
5	Air Compressor 3	Command On	Local:2:0.Data.4	Status Feedback	Local:1:I.Data.4
6	Lighting Production Area 1	Command On	Local:2:0.Data.5	Status Feedback	Local:1:I.Data.5
7	Lighting Production Area 2	Command On	Local:2:0.Data.6	Status Feedback	Local:1:I.Data.6
8	Lighting Shipping/Receiving	Command On	Local:2:0.Data.7	Status Feedback	Local:1:I.Data.7
9	Lighting Office	Command On	Local:2:0.Data.8	N/A	N/A

Create Control Panel Layout and Wiring


The toolkit provides panel layout and wiring drawings in DWG, DXF, and PDF file formats to help you plan the layout of your system. If you do not have CAD software, use the pdf files to build your system drawings.

Use CAD Drawings from Toolkit

1. Browse to the System Layout and Wiring folder on the Energy Management Accelerator Toolkit CD image.
2. Double Click the CompactLogix folder.
3. Navigate to the desired files based on your file format (DXF, DWG, or PDF).
4. Add the required files to your project or copy them to your project folder.


Panel Layout Drawings

The AutoCAD Electrical project includes a panel-layout drawing for the CompactLogix controller, shown below. Add or remove components as needed.



Power and Control Wiring Drawings

The AutoCAD electrical project also includes power and control wiring drawings for the CompactLogix L23E controller. Several digital output examples are shown below.



Access Other RA CAD Drawings

Follow these steps to download other Allen-Bradley product CAD drawings.

1. Open your browser and go to <http://www.rockwellautomation.com/en/e-tools/>.
2. The Configuration and Selection Tools webpage opens.
3. If you don't know the complete catalog number, click product directory to browse the configured Rockwell Automation products.
4. Click Rockwell Automation and follow the prompts.

Logic Integration

You will need to configure the controller, import the Time of Day program, configure the load inputs and outputs, and configure alarms.

Configure Controller, Network, and I/O

These next sections will show you how to configure the controller, network, and I/O.



Create or Open a Project in RSLogix 5000 Software

Follow these steps to create or open a project in RSLogix 5000 software.

1. Open RSLogix 5000 software by clicking Start > Programs > Rockwell Software > RSLogix 5000 Enterprise Series > RSLogix 5000.

The Quick Start window displays in the RSLogix workspace.

2. Click Open Project to open an existing project, or click New Project.
3. If you are creating a new project, configure the controller.
 - a. Choose your controller and revision number.
 - b. Enter a unique controller name.
 - c. Click OK.





Configure the Network

Follow these steps to configure the network.

1. Right-click the Ethernet Port and choose Properties.
2. Enter the controller's IP address and click OK.

For detailed information about assigning an IP address to your controller, see Chapter 2 of the 1769 CompactLogix Packaged Controllers Quick Start and User Manual; Assign an IP Address to the Packaged Controller, (page 42).



Configure the I/O


Configure the I/O specific to your application, as identified in the [Control Hardware Selection and Wiring](#) section.

The 1769-L23E packaged controller included embedded I/O for 16 DC inputs, 16 DC outputs, 4 differential or single-ended analog inputs, 2 single-ended analog outputs, 6 HSC inputs, and 4 HSC outputs.

1. To configure the properties for any of the embedded I/O modules, right-click on the module and select Properties.

If required, up to two 1769 CompactLogix modules may be added to the 1769-L23E-QBFC1B packaged controller.


2. To add an expansion module to the I/O configuration tree, right-click the Expansion I/O folder and select New Module.



For detailed information about configuring your embedded I/O, see Chapter 3 of the 1769 CompactLogix Packaged Controllers Quick Start and User Manual, publication [IASIMP-QS010](#), Embedded I/O (page 191).

Save the Project File


Click to save your RSLogix 5000 application file.




Import and Configure Time of Day Program

Follow these steps to import and configure the Time-of-Day program.

1. If not already opened, open your RSLogix 5000 software project.



- Expand the Tasks folder in your Controller Organizer, right click the Main Task folder, and select Import Program.




- Browse to and open the TOD Control Logic folder on the Energy Management Accelerator Toolkit CD image.


C:\Program Files\RA_Simplification\EMAT\Files\TOD Control Logic

- Select the TOD_Program.L5x file, and click Import.

The Import Configuration dialog appears.



- Leave the program properties at the default; click OK to create the TOD_program.




- The new TOD_program should appear in the Controller Organizer within the Main Task folder.


Configure Load Inputs and Outputs

Follow these steps to configure the load inputs and outputs.

- Expand the TOD_Program and double-click MainRoutine. Rungs 3 through 34 have been configured for I/O mapping.



The I/O mapping rungs will not be executed unless the Enable_IO bit in rung 2 is set.



For each load, there are two rungs to configure. The first is for mapping the command output.

2. Double-click the NOP instruction on rung 3 and type OTE.



3. Click Enter.
4. Double click on the question mark above the OTE and type the name of the tag that should be mapped to the output command for Load Number 1.

In the Efficient Industries example, the output for Load 1 is mapped to Local:2:O.Data.0.



5. Click Enter.

In rung 4, the input status has been configured to follow the commanded state. If the input status is not available for the load, this rung can be left alone. In the Efficient Industries example, the input status for Load number 1 is available and is wired to Local:1:I.Data.0.

6. Double click the tag above the XIC instruction and enter the I/O tag for the input status.



7. Click Enter.
8. Use the same procedure to configure the I/O mapping for the remaining loads in rungs 5...34.

If you are not utilizing all 16 loads in your application, you can delete the unused I/O mapping rungs, or leave them as is.




Configure Alarms

Each load is configured to generate a feedback alarm if the load input status does not match the commanded state. If the load input status is not available, the feedback alarm can be disabled. Perform the following steps to disable the alarm.

1. Expand the TOD_Program folder and double-click Program Tags.
2. Expand the Loads tag.
3. Select the Monitor Tags tab and expand the load instance (Loads[#] where # equals the load number) for the alarm that is being disabled.


In the Efficient Industries example, load number 9 does not have an input status, so we would want to disable the feedback alarm for that load.

4. Set the Loads[#].Cfg_AlarmDisable tag to 1.
5. Repeat for any loads that do not have a feedback status.



Save the Project File

Click save to save your RSLogix 5000 application file.



HMI Integration

These next sections show you how to integrate the HMI into your system.


Add TOD Faceplate to FactoryTalk View ME Application

Follow these steps to add a Time of Day (TOD) faceplate to a FactoryTalk View ME application.

1. Launch FactoryTalk View Studio for Machine Edition.
2. Create a new or open an existing application to which you want to add the Time of Day Control faceplate.
3. Expand the graphics folder in the explorer window, right-click on the displays folder, and choose Add Component into Application.
4. Browse to and open the ME TOD Control Faceplate Files folder on the Energy Management Accelerator Toolkit CD image.

C:\Program Files\RA_Simplification\EMAT\Files\Faceplate Files\ME TOD Control Faceplate Files


5. Choose the ME_TOD_Faceplate.gfx file and click Open.



Configure Alarms

Follow these steps to configure alarms.

1. Expand the Alarms folder in the system tree.
2. Right-click Alarm Setup and choose Import and Export.
3. Select Import alarm configuration into application.
4. Click Next.



5. Choose Yes or No when prompted to backup your existing alarm configuration, and then click Next.




IMPORTANT When importing the alarm configuration, the existing alarm configuration is lost. When prompted to backup the existing alarm configuration, you can choose to save it as an XML file.

6. Browse to and open the ME TOD Control Faceplate Files folder on the Energy Management Accelerator Toolkit CD image to import the Alarms.xml file to your project.

C:\Program Files\RA_Simplification\EMAT\Files\Faceplate Files\ME TOD Control Faceplate Files

7. Click Open.

8. Click Finish.





Configure Communication

Follow these steps to configure communication.


1. Double-click Communication Setup under RSLinx Enterprise in the Explorer window.

You will see this dialog box if a communication setup does not exist.


2. Select Create a new configuration and click Finish.




3. Click Add under Device Shortcuts to create a new shortcut, then rename the shortcut TOD.
4. Click the Design Local tab.
5. Expand the Ethernet network and select the controller containing the TOD program.




6. Verify that the shortcut name is highlighted, then click Apply.
7. Click Yes to apply the changes when prompted.



8. Click Copy from Design to Runtime to copy changes to the runtime communication setup.
9. Click Yes when prompted to continue with the copy operation.



10. Click OK at the bottom of the RSLinx Enterprise dialog box to save the communication setup changes.



System Commissioning

To commission the system, you need to install the system hardware and download the projects.

Install System Hardware

Refer to the documentation listed below for information on installing the CompactLogix and PanelView Plus Hardware.


Document Name	Publication Number	Document Contents
CompactLogix Packaged Controller Installation Instructions	1769-IN082	<ul style="list-style-type: none"> • Installation Checklist • Controller Dimensions • How to Install the Battery • How to Connect Expansion Modules • Minimum Spacing Requirements • How to Panel Mount • How to DIN Rail Mount • Grounding Considerations • Wiring Power to the System • Wire the I/O Removable Terminal Blocks • Expansion Module Wiring • Selecting Operating Mode • Status Indicators
PanelView Plus Installation Manual	2711P-IN002	<ul style="list-style-type: none"> • Environmental Information • Mounting Clearances • Cutout Dimensions • Panel Mounting Instructions • Product Dimensions • Removing and Installing the Power Terminal Block • DC Power Connections • AC Power Connections • Troubleshooting • Battery Removal • System Specifications • Certifications

Download RSLogix5000 Project File


Follow these steps to download your RSLogix 5000 project file to the Logix controller.

1. Open your RSLogix 5000 project file.
2. From the Communications menu, choose Who Active.

The Who Active dialog box opens.




3. Browse to and select your Logix controller.
4. Verify the key switch on your controller module is in the REM (remote) position.




5. Click Download.

The Download dialog box opens. Click Download.






6. From the Communications menu, choose Run mode to switch the controller to Run mode.



Configure and Download FactoryTalk Project to PanelView Plus Terminal

Before you can download your application to a PanelView Plus terminal, you must first create a runtime version of your FactoryTalk View application.

1. Start FactoryTalk View Studio for Machine Edition and open your application which contains the Time of Day control faceplate.
2. Choose Create Runtime Application from the Application menu.
3. Specify the target directory and the file name for the runtime application.
4. In the Save as type box, select the terminal firmware version on which the .mer application will run.
5. Click Save and wait for the progress bar to complete.




Download the PanelView Plus terminal Runtime File

Follow these steps to download the runtime file just created to the PanelView Plus terminal.

1. Choose Transfer Utility from the Tools menu.
2. Click the Download tab.
3. Click the ... icon to locate the source runtime file.
4. Choose Internal Storage box, from the Destination storage type list.

Optionally, check Run application at start-up to start the application when the download finishes.

5. Browse through the RSlinx Enterprise communication tree to select the destination PanelView Plus terminal for the download.



6. Click Download.
7. Click OK when the download completes successfully.
8. Click Exit to close the File Transfer Utility.

Run Application on PanelView Plus Terminal

The (.mer) runtime file is now stored in the PanelView Plus terminal so you are ready to run the application on the terminal.

1. Apply power to the PanelView Plus terminal.



The FactoryTalk View ME Station window opens.

2. Press F1, Load Application.

You can skip this step if you checked Run application at start-up when creating the runtime application.

The Load Application window opens.


3. Press the up and down arrows to scroll through the list and select the application you want to load and run.
4. Press Load [F2] to load the application.



5. Press Yes [F7].

If you press No, the communication settings from the previously run project will be used.

6. After the application loads, press Run [F2] to run the application.




System Startup and Test

Configure the individual loads and the time of day schedule.

Setup


1. Verify the TOD controller is in Run mode.
2. Verify the HMI application is running on the PanelView Plus Terminal.
3. Verify the IO Mapping rungs in the controller are enabled.
 - a. Go online with your RSLogix project and monitor the Enable_IO tag.
 - b. Set the tag value to '1' if it is not already set.



Name	Value	Force
Calendar	{...}	
Clock	{...}	
Enable_IO	1	
Holidays	{...}	
Index_CalendarDate	30	

Configure Time and Date

1. From the TOD faceplate, click the configuration button on the toolbar.
2. Verify the current date and time.
If the current date and time are correct, no action is required. If the current date and time are not correct, click the time and date configuration button on the toolbar.
3. Enter the current time and date.
4. Choose an option for Daylight Savings Time.
5. Click on the box to toggle between Yes (apply) and No (do not apply).
6. Click Update PLC Clock.



Time Of Day Control Status

Load	State	Load	State
1	OVR	9	OVR
2	OVR	10	OVR
3	OVR	11	OVR
4	OVR	12	OVR
5	OVR	13	OVR
6	OVR	14	OVR
7	OVR	15	OVR
8	OVR	16	OVR

10:06:14
5/4/2011

Load Configuration

Load	Load Description	Start Time	Stop Time
15	Load 15	99 99	99 99

TOD Control: Override Off

Copy Day Paste Day

Save Day Changes Undo Day Changes Reset Day to Default

Sun Mon Tue Wed Thu Fri Sat Hol

Holidays Enabled

10:08:33
5/4/2011

Time and Date Configuration

Hour: 9 Minute: 43 Second: 0

Month: 5 Day: 4 Year: 2011

Update PLC Clock

Apply Daylight Savings Time



PLC Clock Calibration Alarm Delay (in days): 10

*The PLC Clock is the Default Clock Source.

10:11:03
5/4/2011


Configure Holidays

1. Click on the Calendar Configuration button on the toolbar.
2. Configure holidays by clicking the date on the calendar.
Days configured as holidays are highlighted in purple. In this example, May 30, 2011 (Memorial Day) has been configured as a holiday.
3. Select the left and right arrows next to the name of the displayed month to scroll through the months and configure holidays.
4. To return to the current month, click Go to Current Month.





Override Mode Testing

1. Verify that all loads wired to your TOD controller are currently off.
Initially, all loads will be in Override Off mode by default. Prior to configuring the load schedules and running the Time of Day control, the loads should be tested using the override modes.
2. To set the override for each load, click the load configuration button on the toolbar.





3. Select a load by clicking on the load number to launch the numeric keypad.
4. Enter a load number, and then click Enter.



- Click on the TOD Control mode indicator until the Override On mode is displayed.

Each click will toggle between TOD Control, Override On, and Override Off modes.

- Click Save Day Changes to confirm the mode selection.
- Verify that the load turns on and the input status (where applicable) is on.
- Click on the TOD Control mode indicator until the Override Off mode is displayed and click Save Day Changes to confirm the mode selection.
- Verify that the load turns off and the input status (where applicable) is off.
- Repeat the above steps for each load in your application.




TOD Control Mode Testing

Once the loads have been override tested, configure the TOD schedules for each load and enable TOD control.


- Click the load configuration button on the toolbar.

For the Efficient Industries example, the load schedule has been defined as shown in the table below.




Load Number	Loads	Sunday	Monday	Tuesday	Wednesday	Thursday	Friday	Saturday	Holiday
1	Boiler 1	Off	6:30 on	On all day	On all day	On all day	On all day	11:30 off	Off
2	Boiler 2	Off	6:30-23:00	6:30-23:00	6:30-23:00	6:30-23:00	6:30-23:00	6:30-11:30	Off
3	Air Compressor 1	Off	7:00 on	On all day	On all day	On all day	On all day	7:00-11:00	Off
4	Air Compressor 2	Off	7:00-11:30 12:00-7:00 7:30-11:00	7:00-11:30 12:00-7:00 7:30-11:00	7:00-11:30 12:00-7:00 7:30-11:00	7:00-11:30 12:00-7:00 7:30-11:00	7:00-11:30 12:00-7:00 7:30-11:00	7:00-12:00	Off
5	Air Compressor 3	Off	3:00-11:00	3:00-11:00	3:00-11:00	3:00-11:00	3:00-11:00	Off	Off
6	Lighting Production Area 1	Off	6:45-23:15	6:45-23:15	6:45-23:15	6:45-23:15	6:45-23:15	6:45-11:15	Off
7	Lighting Production Area 2	Off	6:45-11:30 12:00-7:00 7:30-11:00	6:45-11:30 12:00-7:00 7:30-11:00	6:45-11:30 12:00-7:00 7:30-11:00	6:45-11:30 12:00-7:00 7:30-11:00	6:45-11:30 12:00-7:00 7:30-11:00	6:45-11:30	Off
8	Lighting Shipping/ Receiving	Off	7:00-23:00	7:00-23:00	7:00-23:00	7:00-23:00	7:00-23:00	7:00-12:00	Off
9	Lighting Office	Off	8:00-17:00	8:00-17:00	8:00-17:00	8:00-17:00	8:00-17:00	Off	Off


- Click on the load number to launch the numeric keypad.



- Select a load to configure by entering the load number, then clicking Enter.




- Click on the load description.



- Enter a description for the load and then click Enter.


The Save Day Changes button will turn yellow indicating changes have been made that have not been saved.



- Click the Save Day Changes button.

- To configure the schedule for the load, click on each day of the week and enter the desired schedule.

Be sure to click the Save Day Changes button after entering the schedule for each day. If a new day is selected prior to saving the schedule for the displayed day, the changes will be lost.



In the Efficient Industries example, the configuration for Boiler 1 (Load 1) would look like the following:

•Sunday

•Monday

•Tuesday

•Wednesday

•Thursday

•Friday

•Saturday

8. If the load will not follow a holiday schedule, click the Holidays Enabled/Disabled button so that Holidays Disabled is displayed.
9. If the load will follow a different schedule on holidays, click the Holidays Enabled/Disabled button so that Holidays Enabled is displayed.

10. Click the holiday button and enter the desired holiday schedule.


11. Place the load in TOD Control mode.

To change the mode, click on the mode indicator to toggle between TOD Control, Override On, and Override Off.

12. Click Save Day Changes to confirm your mode selection.

13. Verify that the load turns on and off per the configured schedule.

14. Repeat the above steps for each load in your application.




System Application Guide

This section guides you through the pre-configured FactoryTalk View Machine Edition faceplate providing you with an understanding of the status, control, and diagnostic operation of the faceplate display.

Faceplate Operation Overview


The Time of Day Control Faceplate opens with the Home View displayed.










Button	Icons	Description
Alarm		The alarm button indicates an alarm condition and activates alarm diagnostic views. A grey bell indicates normal status, with no alarms. A red flashing bell indicates an alarm condition.
Configuration		The Configuration button lets you edit the Time of Day control settings, such as load schedules, overrides, time and date configuration, and calendar configuration.
Load 1...8		The Load 1-8 button lets you view the load status and descriptive name for loads 1...8
Load 9...16		The Load 9-16 button lets you view the load status and descriptive name for loads 9...16
Help		The Help button provides information for the existing view.
Close		Click the Close button to close the faceplate.
Status Indicators		Grey = Off/Auto TOD Control H Grey = Off/Auto TOD control - Holiday Green = On/Auto TOD Control H Green = On/Auto TOD Control - Holiday OVR-Grey = Off/Override Set/Load is off. OVR Grey/Red Flashing = Override Off is set, but load is still on. OVR-Green = On/Override Set/Load is on OVR Green/Red Flashing = Override On is set, but load is still off. Red/Grey Flashing = Load is not in OVR, controller telling to turn off, but load is still on. Red/Green Flashing = Load is not in OVR, controller telling to turn on, but load is still off.

Load Configuration View

Click on the wrench button from the toolbar to display the load configuration view.




Button	Icons	Description
Alarm		The alarm button indicates an alarm condition and activates alarm diagnostic views. A grey bell indicates normal status, with no alarms. A red flashing bell indicates an alarm condition.
Home		The Home button lets you view the status of all 16 loads.
Clock		The Clock button displays the Time and Date Configuration View, which lets you update the PLC clock.
Calendar		The Calendar button displays the Calendar Configuration View, which lets you assign holidays.
Help		The Help button provides information for the existing view.
Close		Click the Close button to close the faceplate.
Load Number		The load currently being displayed/configured. To select a new load for configuration, click on the load number to launch the numeric keypad input object. Enter a load number from 1...16, then click Enter.
Load Description		Click on the load description to launch the keypad input object and enter a description for the load. When a description change is made, the Save Day Changes button background will turn yellow, indicating that a change has been made, but has not been saved. The description change will not take effect until it is saved. Click on the Save Day Changes button to save the change.
TOD Control Mode		Click on the Mode Selection button to toggle between TOD Control, Override On, and Override Off modes. When a mode change is made, the Save Day Changes button will turn yellow, indicating a save is required. The mode change will not take effect until saved.
Copy/Paste Commands		To copy the schedule from the displayed day to another day, click Copy Day. Select a new day, and then click Paste Day. Click Save Day Changes to download the changes to the controller.
Save Command		Click Save Day Changes anytime a change is made to the load configuration. You must save your changes prior to selecting a new day or a new load to configure. If you select a new day or new load prior to saving your changes, the changes will be lost.
Undo Command		To revert to the previously saved schedule for the day, click Undo Day Changes. You can only undo changes if they have not been saved. Once saved, you cannot revert to the previous schedule.

Button	Icons	Description
Reset Command		To reset all schedule entries for the day to the default, click Reset Day to Default. The default value is 99:99. When a value of 99:99 is entered, the setting is ignored by the TOD program.
Days of the Week		Click on a day of the week to configure the schedule for that day. The TOD schedule for the day highlighted in green is displayed in the configuration view.
Holiday Enable/Disable		When holidays are enabled, the load will follow its holiday schedule whenever a holiday is configured on the calendar. To modify the holiday schedule, click on the 'HOL' day of the week button. When holidays are disabled, the holiday schedule for the load is ignored. Click on the Holidays Enabled/Disabled button to toggle between holidays enabled or disabled.
Time of Day Schedule		<p>By default, all schedule entries are set to 99:99. If a value of 99:99 is entered, the setting is ignored by the TOD program.</p> <p>Click on the Start Time or Stop Time Hour or Minute to launch the keypad input object and enter a time. Enter start and stop times in military time, 00:00 through 23:59.</p> <p>Once the desired schedule for the day is entered, Click Save Day Changes to download the schedule to the controller.</p> <p>Tip: To run the load overnight, configure a start time, but leave the stop time at 99:99. On the next day, configure a start time of 00:00. For example the load configured below would start at 20:00 on Monday and stop at 6:00 on Tuesday.</p> <div style="display: flex; justify-content: space-around;">   </div>
Time and Date		The current time and date are displayed in the lower right corner of the faceplate.

Time and Date Configuration View


Click on the clock button from the toolbar to display the Time and Date configuration view.



Button	Icons	Description
Alarm		The alarm button indicates an alarm condition and activates alarm diagnostic views. A grey bell indicates normal status, with no alarms. A red flashing bell indicates an alarm condition.
Configuration		The Configuration button lets you edit the Time of Day control settings, such as load schedules, overrides, time and date configuration, and calendar configuration.
Home		The Home button lets you view the status of all 16 loads.
Calendar		The Calendar button displays the Calendar View, which lets you assign holidays.
Help		The Help button provides information for the existing view.
Close		Click the Close button to close the faceplate.
Time and Date Configuration	<div> <div>HourMinuteSecond</div> <div>8570</div> <div>MonthDayYear</div> <div>2162011</div> </div>	Click on each button to launch the numeric entry keypad input object and enter the current values for the time and date. Enter the hour in military time. When the desired date and time have been entered, click the Update PLC Clock button to download the new date and time to the controller.
Clock Update Button		Click the Update PLC Clock button to download the configured date and time to the controller.
Daylight Savings Time Selection	<div>NO Apply Daylight Savings Time</div>	Click the button to turn Daylight Savings Time on and off. When Daylight Savings time is applied, one hour is added to the current hour.
Alarm Delay	<div>PLC Clock Calibration</div> <div>Alarm Delay (in days): 10</div>	The PLC clock will drift over time and will need to be recalibrated every so often, depending on the accuracy of your PLC clock. Enter an alarm delay here (in days) to notify the operator when the PLC clock should be checked for accuracy.

Calendar Configuration View

Click on the calendar button on the toolbar to display the Calendar Configuration view.



Button	Icons	Description
Alarm		The alarm button indicates an alarm condition and activates alarm diagnostic views. A grey bell indicates normal status, with no alarms. A red flashing bell indicates an alarm condition.
Configuration		The Configuration button lets you edit the Time of Day control settings, such as load schedules, overrides, time and date configuration, and calendar configuration.
Home		The Home button lets you view the status of all 16 loads.
Clock		The Clock button displays the Time and Date Configuration View, which lets you update the PLC clock.
Help		The Help button provides information for the existing view.
Close		Click the Close button to close the faceplate.
Display previous month		Click to move to the previous month.
Display next month		Click to move to the next month.
Display current month		Click to return to the current month.
Monthly Calendar Display		Click on a date to toggle between a holiday and a non-holiday. Days configured as holidays are highlighted in purple. If the current day is configured as a holiday, the load will follow the holiday schedule, unless holidays are disabled for that load.


Load Status View

Click the Loads 1-8 or Loads 9-16 button on the toolbar to display the Load Status view. The Load 1-8 and Load 9-16 Status views display the load status, just like the Home View, as well as the load description.



Fault View


Click on the alarm bell button to display the Fault Status view.



Button	Icons	Description
Alarm		The alarm button indicates an alarm condition and activates alarm diagnostic views. A grey bell indicates normal status, with no alarms. A red flashing bell indicates an alarm condition.
Configuration		The Configuration button lets you edit the Time of Day control settings, such as load schedules, overrides, time and date configuration, and calendar configuration.
Home		The Home button lets you view the status of all 16 loads.
Load 1...8		The Load 1-8 button lets you view the load status and descriptive name for loads 1...8
Load 9...16		The Load 9-16 button lets you view the load status and descriptive name for loads 9...16
Help		Press the Help button to access a more detailed alarm description and recommended actions.
Close		Click the Close button to close the faceplate.
Last Fault		Indicates the error being reported by the TOD control program; a load mismatch, a PLC clock recalibration alert, or both.
Clear Faults		Click the clear faults button to clear the alert from the fault view. The alert will only clear if the condition causing the alert is no longer active.

Help View

Press the Help button on any view to access the online help information.



Button	Icons	Description
Alarm		The alarm button indicates an alarm condition and activates alarm diagnostic views. A grey bell indicates normal status, with no alarms. A red flashing bell indicates an alarm condition.
Configuration		The Configuration button lets you edit the Time of Day control settings, such as load schedules, overrides, time and date configuration, and calendar configuration.
Home		The Home button lets you view the status of all 16 loads.
Next Page		The next button will appear if there is more than one help screen for the help topic. Click the next button to scroll through the screens. The Help Screen Title will indicate the total number of help screens and the current screen being displayed.

Notes:

Custom Meter Types


This appendix shows how to create custom meter types. The [Efficient Industries Plant 1](#) example has two custom meter types under the Fuels group: Fuel Oil and Propane.

Follow these steps to create custom meter types.

1. Launch SQL Server Manager Studio from the Start menu or Programs.
2. Enter your SQL Server name and click Connect.



3. Navigate to Databases>EMMA and select Tables.
4. Right-click MeterTypes and choose Open Table.



5. Select the last row and enter a MeterTypeId and Name.

For this example, Fuel Oil and Propane were added.

6. Click X to close dialog box, the close SQL Server Management Studio.

Table - dbo.MeterTypes		Summary
	MeterTypeId	Name
	1	Manual
	2	Water
	3	Air
	4	Gas
	5	Electric
	6	Steam
	7	Environmental
→	8	Fuel Oil
→	9	Propane
*	NULL	NULL

Custom Units and Value Types


This appendix shows how to configure custom base units, units, and value types used by meter tags for logging energy data. The FactoryTalk EnergyMetrix software collection of base units are those most commonly used in energy management applications. A base unit consists of a unit and a scaling factor. For example, VA (voltampere) is a base unit, and kVA (kilovoltampere) is a unit, with a scaling factor of 0.001.

Value types are used by reporting and billing functions to aggregate values of a specific type in one or more meters or groups. The FactoryTalk EnergyMetrix software value types represent the most commonly used electrical energy management parameters. Value types are set up as consumption or demand. Consumption types are treated as accumulated values of energy or process output, for example, real energy net. Demand types are treated as rate values such as real power demand.

If FactoryTalk EnergyMetrix software does not contain the base units, units, and value types required, you'll need to create them.

Verify Base Units

1. Select Unit Setup on the System tab.
2. Click the Base Units tab.
3. Click the Base unit pull-down menu to show the available units.
4. Verify that all base units required are available in the list.




You'll need to create those base units that don't appear in the FactoryTalk EnergyMetrix list. For the [Efficient Industries Plant 1](#) example, create these base units:

- gallons (gal) for fuel oil, propane, and water
- therms (thm) for natural gas
- pounds (lbs) for steam
- cubic feet (cf) for air

TIP For advanced users, an SQL query named Accel Tk Units Value Units.sql is available that will automatically populate the database with value types and units. This query is in the System Layout and Wiring folder of the Energy Management Accelerator Toolkit CD image.

Create Base Units


1. Click Add on the Base Units tab.



2. Enter the base unit text.


For this example, enter Gal for fuel oil, propane, and water.

3. Click Save.



4. Repeat steps 1...3 to add therms (thm), cubic feet (cf), and pounds (lbs).

When done, you should see cf, thm, and lb in the Base unit list.



Verify Units

1. Click the Units tab.
2. Click the Units pull-down menu to show the available units.
3. Verify that all units required are available in the list.

You'll need to create those units that don't appear in the FactoryTalk EnergyMetrix list. For the [Efficient Industries Plant 1](#) example, you'll need to create these units:

- gallon (gal) for fuel oil, propane, and water
- therms (thm) for natural gas
- pounds (lbs) for steam
- cubic feet (cf) for air

Create Units

1. Click the Add button on the Units tab.

2. Choose the base unit just created from the pull-down menu.
3. Enter the Base units scale and text.
For this example, enter 1 and Gal to be used by the fuel oil, propane, and water meter tags.
4. Click Save.

5. Repeat steps 1...4 to create other units.

For this example, create:

- therms (thm) for natural gas
- pounds (lbs) for steam
- cubic feet (cf) for air

Enter the settings from the table for each unit.


Base Unit	Base Unit Scale	Text	Display Decimals
thm	1	thm	2
cf	1	cf	2
lbs	1	lbs	2

6. Verify that each unit appears in the Units pull-down menu.

The screenshot shows the 'Unit Setup' dialog box with the 'Units' tab selected. The 'Units' pull-down menu is open, displaying a list of units including 'cf', 'Deg C', 'Deg F', 'Gal', 'Hz', 'kA', 'kAh', 'lbs', 'kPa', 'kV', and 'kVA'. The 'cf' unit is currently selected. To the right of the menu, there are input fields for 'Base' (set to '0.01'), 'Text' (set to 'cf'), and 'Display Decimals' (set to '2'). At the top of the dialog, there are buttons for 'Edit', 'Add', and 'Delete'.

Verify Value Types

1. Click the Value Types tab.
2. Click the Values types pull-down menu to show the available value types.




3. Verify that all value types required appear in the list.

You'll need to create the value types that don't appear in the FactoryTalk EnergyMetrix list. For the [Efficient Industries Plant 1](#) example, you'll need to create these value types:

- Fuel Oil Usage
- Propane Usage
- Water Usage
- Natural Gas Usage
- Steam Usage
- Air Usage

Create Value Types

1. Click Add on the Value Types tab.



2. Enter a name for the value type.

In this example, enter Fuel Oil Usage. This value type is used for the Fuel Oil Meter.

3. Choose a Unit.

For this example, select Gal.

4. Check Consumption and/or Demand.

For this example, only Consumption will be logged for the Fuel Oil, Propane, Water, Natural Gas, Steam, and Air meters.

Demand is typically associated only with electric meters.

5. Click Save.

6. Repeat steps 1...4 to add value types for:

- Propane Usage
- Water Usage
- Natural Gas Usage
- Steam Usage
- Air Usage

Enter the settings from the table for each value type.

Value Type Name	Unit	Consumption	Demand
Propane Usage	Gal	Check	Uncheck
Water Usage	Gal	Check	Uncheck
Natural Gas Usage	thm	Check	Uncheck
Steam Usage	lbs	Check	Uncheck
Air Usage	cf	Check	Uncheck

When done, the new value types should appear in the list.

Energy Electric Add-On Instructions

This appendix describes the behavior of the Energy_Electric_Digital, Energy_Electric_Analog, and Energy_Electric_PM_Status Add-On Instructions. It is provided to help you understand the output values and calculations methods. It also provides information you need to adjust consumption rollover values, and interval timer presets. Tag names for end of demand intervals from a utility meter or central controller are also included.

The Add-On Instructions perform four functions.


- Calculate the total electric consumption, kWh, for the metered input. This value is stored in the Add-On Instruction output, Val_Total_kWh.
- Calculate the demand for the metered input over a user-defined interval.
- Provide the Equipment Status Faceplate, total Val_Total_kWh, Val_Demand_Electric, and Demand_Interval_PLC_Timer.ACC values with the predefined device status information.
- Provide the Alarm History Faceplate information needed to display predefined alarm messages based on the device status.

CompactLogix Digital Input Logic

The following logic is included in the Energy_Electric_Digital Add-On Instructions to calculate the total kWh electric consumption from a CompactLogix digital input.

The Inp_Pulse tag initiates a total kWh computation. Every time a pulse is triggered, the logic adds the value of the Set_Meter_Pulse_Factor tag to the Val_Total_kWh (total consumption) tag. The Inp_Pulse tag is assigned to a CompactLogix digital input and the Set_Meter_Pulse_Factor is entered when the Add-On Instruction is added to your program.


When the total kWh value reaches 10 million, the rollover rung resets the Val_Total_kWh value.



PowerMonitor Digital Status Input Logic

The following logic is included in the Energy_Elecric_PM_Status Add-On Instruction to read the kWh value from a PowerMonitor status input.

An explicit message reads the status inputs from the PowerMonitor 1000, 3000, or 5000 device. A PLC-5 Typed Read message is configured to read one of the status inputs when adding the Add-On Instruction to your logic. Refer to [page 326](#) for details on configuring the message instruction. The destination tag of the message must be input back into the instruction through the Inp_Status_Input tag. The PowerMonitor status inputs are counters that total the number of incoming digital pulses. Additional logic is not required to calculate total consumption as the digital pulse is scaled in the advanced device parameters of the PowerMonitor. The Inp_Status_Input value is moved to the Val_Total_kWh tag.




CompactLogix Analog Input Logic

The following logic is included in the Energy_Electric_Analog Add-On Instructions to calculate the total kWh electric consumption from a CompactLogix analog input.

The Inp_Meter_Analog_Value tag is the instantaneous electric value from the CompactLogix analog input. To calculate total kWh, the instantaneous electric value is calculated every 250 ms and stored as Buffered_Flow. This value is then included in the Val_Total_kWh, total consumption. For very small instantaneous values, a comparison between the new Val_Total_kWh and the previous Val_Total_kWh (Temp_Buffer) is performed by using the NEQ instruction. If the two values are not equal the Buffer_Flow is cleared.

When the total value equals 10 million, the rollover rung resets the Val_Total_kWh value.




Demand Calculation Logic


The following logic is included in the Energy_Electric_Digital, Energy_Electric_Analog, and Energy_Electric_PM_Status Add-On Instructions for calculating electric demand, Val_Demand_Electric.

The end-of-demand interval is based on the Set_End_of_Demand_Interval_Type that is set when configuring the Add-On Instruction.

- The first rung sets and runs the internal PLC timer based on the Set_Demand_Interval tag minute setting.
- The second rung sets and runs the Demand_Interval_Exceeded timer in case the end-of-demand utility contact or master end-of-demand command is not seen by the controller.




To calculate the electric demand, a MUL instruction converts the Set_Demand_Interval minutes to milliseconds for the preset used by the Demand_Interval_PLC_Timer and Demand Interval_Exceeded Timer. Once the Cmd_End of_Demand_Interval is set, the Val_Total_kWh is compared to the previous interval's Val_Total_kWh, and the Val_Demand_Electric is calculated.



Equipment Status Faceplate Logic


The following logic is included in the Energy_Electric_Digital, Energy_Electric_Analog, and Energy_Electric_PM_Status Add-On Instructions to provide the Equipment Status Faceplate with electric consumption, demand, and device states.

This rung moves the Val_Total_xxx and Val_Avg_Flow_xxx values to predefined tags in the Equipment Status Faceplate, Sts_Value1 and Sts_Value2.



The next four rungs monitor and send device status information to the Equipment Status Faceplate including Active, Fault, High Flow, and Critical Flow.


The Sts_DeviceState tag is a predefined tag mapped to a multistate indicator in the Equipment Status Faceplate. Each device status state is triggered by a unique integer value preconfigured in the multistate indicator.




Alarm History Faceplate Logic

The following logic is included in the Energy_Electric_Digital, Energy_Electric_Analog, and Energy_Electric_PM_Status Add-On Instructions to initiate an alarm trigger and send corresponding device state to the alarm trigger value.

The following two rungs monitor the Fault, High Flow, and Critical Flow bits, and send predefined integer values to the Sts_Energy_AlarmTrigger tags already configured in the Alarm History setup file. The Alarm History Faceplate uses these values to trigger the appropriate messages to show on the Alarm Display.



Additional rungs must be added to the main routine to reset the alarm trigger tags and the alarm messages. Refer to [page 332](#) and [page 333](#) for more details on the alarm history.



Digital and Analog Energy Add-On Instructions

This appendix describes the behavior of all Digital and Analog Energy Add-On Instructions with the exception of the Energy_Electric_Analog or Energy_Electric Digital Add-On Instructions, described in Appendix C.

The Digital and Analog Energy Add-On Instructions perform four functions.

- A total consumption calculation for the metered input. This value is stored in the output, Val_Total_xxx.
- A consumption rate calculation for the metered input over a predefined interval set by the user. This value, also known as Average Flow rate, is stored in the output, Val_xxx_Per_Calc_Interval.
- Equipment Status Faceplate update of the energy total Val_Total_xxx, the flow rate (Val_xxx_Per_Min or Val_xxx_Per_Hr), and energy device status information.
- Alarm History Faceplate update of information needed to display predefined alarm messages based on the energy device status.


CompactLogix Digital Input Logic

Logic is provided in all Energy_xxx_Digital Add-On Instructions to calculate energy consumption from CompactLogix digital inputs. The Inp_Pulse tag initiates an energy computation, where 1 pulse = 1 (unit).

Energy Add-On Instruction	Unit
Air_Flow	cf
Fuel_Oil	gallons
Propane	gallons
Steam_Flow	lbs
Water_Flow	gallons

Every time a pulse is triggered, the logic adds the value of the Set_Meter_Pulse_Factor tag to the Val_Total_xxx (total consumption) tag. The Set_Meter_Pulse_Factor, is set by default to 1, but can be user-defined for scaling purposes.


When the total pulses equal 10 million, the rollover rung resets the total energy value, VAL_Total_xxx.



PowerMonitor Digital Status Input Logic

The following logic is included in all Energy_xxx_PM_Status Add-On Instructions to read the energy values from a PowerMonitor status input.

An explicit message reads the status inputs from the PowerMonitor 1000, 3000, or 5000 device. A PLC-5 Typed Read message is configured to read one of the status inputs when adding the Add-On Instruction to your logic. Refer to [page 326](#) for details on configuring the message instruction. The destination tag of the message must be input back into the instruction through the Inp_Status_Input tag. The PowerMonitor status inputs are counters that total the number of incoming digital pulses. No additional logic is required to calculate total consumption as the digital pulse is scaled in the advanced parameters of the PowerMonitor. The Inp_Status_Input value is simply moved to the Val_Total_xxx tag (Total Consumption).




CompactLogix Analog Input Logic


The following Logic is provided in all the Energy_xxx_Analog Add-On Instructions to calculate energy consumption from corresponding CompactLogix analog inputs. The Inp_Meter_Analog_Value tag is the instantaneous energy flow value from the CompactLogix analog input.

To calculate total flow, an instantaneous flow value is calculated every 250 ms and is stored as Buffered_Flow. This value is then included in the Val_Total_xxx, total consumption. For very small instantaneous flows, a comparison between the new Val_Total_xxx and the previous Val_Total (Temp_Buffer) is performed by using the NEQ instruction. If the two values are not equal the Buffer_Flow is cleared.


When the total value equals 10 million, the rollover rung resets the total energy value, Val_Total_xxx.



To calculate the average flow rate, Val_xxx_Per_Calc_Interval, the logic uses the Set_Calc_Interval, in minutes, to configure the sample interval. A MUL instruction converts the sample interval in minutes to milliseconds for the Avg_Flow_Interval_PLC_Timer preset. At the end of interval, Val_Total_xxx is compared to the previous interval's Val_Total_xxx and the flow rate, Val_xxx_Per_Min or Val_xxx_Per_Hr, is calculated.




The average flow rate, Val_xxx_Per_Calc_Interval, is calculated by dividing the flow rate (in minutes) by the Set_Calc_Interval, which you previously entered.



Equipment Status Faceplate Logic


The following logic is included all digital and analog energy Add-On Instructions to provide the Equipment Status Faceplate with energy consumption, flow, and device states.

The following rung moves the Val_Total_xxx and Val_xxx_Per_Min or Val_xxx_Per_Hr values to the predefined tags in the Equipment Status Faceplate, Sts_Value1 and Sts_Value2.




The next four rungs monitor and send device status information to the Equipment Status Faceplate including Active, Fault, High Flow, and Critical Flow.

The Sts_DeviceState tag is a predefined tag mapped to a multistate indicator in the Equipment Status Faceplate. Each device status state is triggered by a unique integer value preconfigured in the multistate indicator.




The additional input fault logic added on [page 332](#) is used to move the Local:x:I.Fault data to the Sts_xxx_Input_Fault tag of the Add-On Instruction.




Alarm History Faceplate Logic

The following logic is included all digital and analog energy Add-On Instructions to initiate an alarm trigger and send the corresponding device state to the alarm trigger value.

The following two rungs monitor the Fault, High Flow, and Critical Flow bits and send predefined integer values to the Sts_EnergyAlarmTrigger tags configured in the Alarm History setup file. The Alarm History Faceplate uses these values to trigger the appropriate messages to show on the Alarm Display.



Additional rungs must be added to the main routine to reset the alarm trigger tags and the alarm messages. Refer to [page 332](#) and [page 333](#) for more details on the alarm history.



Notes:

Update Add-on Profiles

Update the E3PLUS Add-On Profiles

The E3 Plus Add-On Profiles are independent of RSLogix 5000 software releases. Update your E3 Plus Add-On Profiles to make sure your application runs correctly. Add-On Profiles are available for download at the RSLogix 5000 Add-On Profiles website:

<https://download.rockwellautomation.com/esd/download.aspx?downloadid=add-onprofiles>

- Select the AOP for RA E3 Plus 193-DNENCAT(R) profile.
- Click the Download Now button and follow instructions.




<input type="checkbox"/>	5XRF_IN MultiSight RFID Interface	1.02.05	2012/08/20		6.48 MB	15.00.00 - Minimum RSLogix 5000 Software Revision
<input type="checkbox"/>	842E Ethernet/IP Encoders	2.01.26	2012/08/20		28.73 MB	18.00.00 - Minimum RSLogix 5000 Software Revision
<input type="checkbox"/>	RA E1 Plus	1.01.00	2012/08/20		27.86 MB	15.00.00 - Minimum RSLogix 5000 Software Revision
<input type="checkbox"/>	RA E3 Plus via 2100-ENET	1.01.02	2012/08/20		70.71 MB	17.00.00 - Minimum RSLogix 5000 Software Revision
<input checked="" type="checkbox"/>	RA E3 Plus 193-DNENCAT(R)	1.01.04	2012/08/20		27.85 MB	17.00.00 - Minimum RSLogix 5000 Software Revision
<input type="checkbox"/>	1756-IB, LS, OB Apex I/O	2.03.12	2012/08/21		65.1 MB	20.00.00 - Minimum RSLogix 5000 Software Revision. AOP for 1756-IB16IF, 1756-LSC8XIB8I, 1756-OB16IEF
<input type="checkbox"/>	Drives - PowerFlex / SCANport	4.04.01	2012/09/05		247 MB	16.00.00 - Minimum RSLogix 5000 Software Revision

Update the SMC-50 Add-On Profiles

The SMC-50 Add-On Profiles are independent of RSLogix 5000 software releases. Update your SMC-50 Add-On Profiles to make sure your application runs correctly. Add-On Profiles are available for download at the RSLogix 5000 Add-On Profiles website:

<https://download.rockwellautomation.com/esd/download.aspx?downloadid=addonprofiles>

- Select the AOP for Drives-PowerFlex/SCANport profile which includes SMC profiles.
- Click the Download Now button and follow instructions.

<input type="checkbox"/>	AOP for 280E, 281E, 284E ArmorStart ENet	1.04.03	2012/08/20		78.69 MB	17.00.00 - Minimum RSLogix 5000 Software Revision
<input type="checkbox"/>	AOP for 290E, 291E, 294E ArmorStart LT	2.01.02	2012/08/20		82.11 MB	17.00.00 - Minimum RSLogix 5000 Software Revision
<input type="checkbox"/>	AOP for 48MS MultiSight ENet Vision Sens	1.01.19	2012/08/20		6.48 MB	15.00.00 - Minimum RSLogix 5000 Software Revision
<input type="checkbox"/>	AOP for 5XRF_IN MultiSight RFID Interfac	1.02.05	2012/08/20		6.48 MB	15.00.00 - Minimum RSLogix 5000 Software Revision
<input type="checkbox"/>	AOP for 842 Ethernet/IP Encoders	2.01.26	2012/08/20		28.73 MB	18.00.00 - Minimum RSLogix 5000 Software Revision
<input type="checkbox"/>	AOP for Drives-PowerFlex 755/CIP Motion	8.01.00	2012/08/20		62.92 MB	19.00.00 - Minimum RSLogix 5000 Software Revision
<input type="checkbox"/>	AOP for RA E1 Plus	1.01.00	2012/08/20		27.86 MB	15.00.00 - Minimum RSLogix 5000 Software Revision
<input type="checkbox"/>	AOP for RA E3 Plus via 2100-ENET	1.01.02	2012/08/20		70.77 MB	17.00.00 - Minimum RSLogix 5000 Software Revision
<input type="checkbox"/>	AOP for E3 Plus 193-DNETCAT(R)	1.01.04	2012/08/20		27.85 MB	17.00.00 - Minimum RSLogix 5000 Software Revision
<input checked="" type="checkbox"/>	AOP for Drives-PowerFlex/SCANport	4.04.01	2012/09/05		247 MB	16.00.00 - Minimum RSLogix 5000 Software Revision
<input type="checkbox"/>	AOP for RA1769Analog	8.04.00	2012/09/12		73.42 MB	13.04.00 - Minimum RSLogix 5000 Software Revision
<input type="checkbox"/>	AOP for 1788-CN2FFR	1.01.16	2012/10/25		78.86 MB	15.00.00 - Minimum RSLogix 5000 Software Revision
<input type="checkbox"/>	AOP for 1788-EN2FFR	1.01.16	2012/10/25		78.81 MB	15.00.00 - Minimum RSLogix 5000 Software Revision
<input type="checkbox"/>	AOP for 1788-CN2PAR	2.01.01	2012/10/25		76.8 MB	16.00.00 - Minimum RSLogix 5000 Software Revision
<input type="checkbox"/>	AOP for 1788-EN2PAR	2.01.01	2012/10/25		76.8 MB	16.00.00 - Minimum RSLogix 5000 Software Revision

Update the PowerFlex Add-On Profiles

The PowerFlex Add-On Profiles are independent of RSLogix 5000 software releases. Update your PowerFlex Add-On Profiles to make sure your application runs correctly. Add-On Profiles are available for download at the RSLogix 5000 Add-On Profiles website:

<https://download.rockwellautomation.com/esd/download.aspx?downloadid=addonprofiles>

- Select the AOP for Drives-PowerFlex / SCANport profile.
- Click the Download Now button and follow instructions.

<input type="checkbox"/>	AOP for 280E,281E,284E ArmorStart ENet	1.04.03	2012/08/20		78.69 MB	17.00.00 - Minimum RSLogix 5000 Software Revision
<input type="checkbox"/>	AOP for 290E, 291E, 294E ArmorStart LT	2.01.02	2012/08/20		82.11 MB	17.00.00 - Minimum RSLogix 5000 Software Revision
<input type="checkbox"/>	AOP for 48MS MultiSight ENet Vision Sens	1.01.19	2012/08/20		6.48 MB	15.00.00 - Minimum RSLogix 5000 Software Revision
<input type="checkbox"/>	AOP for 5XRF_IN MultiSight RFID Interfac	1.02.05	2012/08/20		6.48 MB	15.00.00 - Minimum RSLogix 5000 Software Revision
<input type="checkbox"/>	AOP for 842 Ethernet/IP Encoders	2.01.26	2012/08/20		28.73 MB	18.00.00 - Minimum RSLogix 5000 Software Revision
<input type="checkbox"/>	AOP for Drives-PowerFlex 755/CIP Motion	8.01.00	2012/08/20		62.92 MB	19.00.00 - Minimum RSLogix 5000 Software Revision
<input type="checkbox"/>	AOP for RA E1 Plus	1.01.00	2012/08/20		27.86 MB	15.00.00 - Minimum RSLogix 5000 Software Revision
<input type="checkbox"/>	AOP for RA E3 Plus via 2100-ENET	1.01.02	2012/08/20		70.77 MB	17.00.00 - Minimum RSLogix 5000 Software Revision
<input type="checkbox"/>	AOP for E3 Plus 193-DNETCAT(R)	1.01.04	2012/08/20		27.85 MB	17.00.00 - Minimum RSLogix 5000 Software Revision
<input checked="" type="checkbox"/>	AOP for Drives-PowerFlex/SCANport	4.04.01	2012/09/05		247 MB	16.00.00 - Minimum RSLogix 5000 Software Revision
<input type="checkbox"/>	AOP for RA1769Analog	8.04.00	2012/09/12		73.42 MB	13.04.00 - Minimum RSLogix 5000 Software Revision
<input type="checkbox"/>	AOP for 1788-CN2FFR	1.01.16	2012/10/25		78.86 MB	15.00.00 - Minimum RSLogix 5000 Software Revision
<input type="checkbox"/>	AOP for 1788-EN2FFR	1.01.16	2012/10/25		78.81 MB	15.00.00 - Minimum RSLogix 5000 Software Revision
<input type="checkbox"/>	AOP for 1788-CN2PAR	2.01.01	2012/10/25		76.8 MB	16.00.00 - Minimum RSLogix 5000 Software Revision
<input type="checkbox"/>	AOP for 1788-EN2PAR	2.01.01	2012/10/25		76.8 MB	16.00.00 - Minimum RSLogix 5000 Software Revision

Update the E300 Add-On Profiles

An Add-On Profile is available for the E300 Overload Relay EtherNet/IP Communication Module. The profile can be downloaded from:

<https://download.rockwellautomation.com/esd/download.aspx?downloadid=addonprofiles>.

- Select the AOP for 193-ECM-ETR E300 Ethernet Overload Relay profile.
- Click the Download Now button and follow instructions.

<input type="checkbox"/>	Stratix 5700/8000/8300 Switches 6.07.001		6.07.01	2014/06/12		79.85 MB	Added Power over Ethernet. 16.00.00 Minimum RSLogix 5000 Software Revision.
<input type="checkbox"/>	PowerFlex 525 & PowerFlex 523		1.04.00	2014/06/20		480 MB	17.00.00 - Minimum RSLogix 5000 Software Revision
<input checked="" type="checkbox"/>	193-ECM-ETR E300 Ethernet Overload Relay		2.00.11	2014/07/17		77.2 MB	17.00.00 Minimum RSLogix 5000 Software Revision. Minimum Module/ Firmware Revision is 1.0
<input type="checkbox"/>	PSSCENA - Parker Isysnet™ Ethernet Adapt		3.03.01	2014/07/18		33 MB	17.00.00 - Minimum RSLogix 5000 Software Revision
<input type="checkbox"/>	1440 DYN02-01R.I XM Module		2.02.04	2012/02/01		34.72 MB	16.00.00 - Minimum RSLogix

Rockwell Automation Support

Rockwell Automation provides technical information on the Web to assist you in using its products.

At <http://www.rockwellautomation.com/support> you can find technical and application notes, sample code, and links to software service packs. You can also visit our Support Center at <https://rockwellautomation.custhelp.com/> for software updates, support chats and forums, technical information, FAQs, and to sign up for product notification updates.

In addition, we offer multiple support programs for installation, configuration, and troubleshooting. For more information, contact your local distributor or Rockwell Automation representative, or visit <http://www.rockwellautomation.com/services/online-phone>.

Installation Assistance

If you experience a problem within the first 24 hours of installation, review the information that is contained in this manual. You can contact Customer Support for initial help in getting your product up and running.

United States or Canada	1.440.646.3434
Outside United States or Canada	Use the Worldwide Locator at http://www.rockwellautomation.com/rockwellautomation/support/overview.page , or contact your local Rockwell Automation representative.

New Product Satisfaction Return

Rockwell Automation tests all of its products to help ensure that they are fully operational when shipped from the manufacturing facility. However, if your product is not functioning and needs to be returned, follow these procedures.

United States	Contact your distributor. You must provide a Customer Support case number (call the phone number above to obtain one) to your distributor to complete the return process.
Outside United States	Please contact your local Rockwell Automation representative for the return procedure.

Documentation Feedback

Your comments will help us serve your documentation needs better. If you have any suggestions on how to improve this document, complete this form, publication [RA-DU002](#), available at <http://www.rockwellautomation.com/literature/>.

Rockwell Automation maintains current product environmental information on its website at <http://www.rockwellautomation.com/rockwellautomation/about-us/sustainability-ethics/product-environmental-compliance.page>.

Rockwell Otomasyon Ticaret A.Ş., Kar Plaza İş Merkezi E Blok Kat:6 34752 İçerenköy, İstanbul, Tel: +90 (216) 5698400

www.rockwellautomation.com

Power, Control and Information Solutions Headquarters

Americas: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444
Europe/Middle East/Africa: Rockwell Automation NV, Pegasus Park, De Kleetlaan 12a, 1831 Diegem, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640
Asia Pacific: Rockwell Automation, Level 14, Core F, Cyberport 3, 100 Cyberport Road, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846

Rockwell Automation Publication IASIMP-QS016C-EN-P - October 2014

Supersedes Publication IASIMP-QS016B-EN-P - August 2012

Copyright © 2014 Rockwell Automation, Inc. All rights reserved. Printed in the U.S.A.