



# ArmorBlock 16-channel I/O-Link Hub

Catalog Numbers 1732IL-IB16M12, 1732IL-10X6M12,  
1732IL-16CFGM12M12L



**Allen-Bradley**

by ROCKWELL AUTOMATION

User Manual

Original Instructions

## Important User Information

Read this document and the documents listed in the additional resources section about installation, configuration, and operation of this equipment before you install, configure, operate, or maintain this product. Users are required to familiarize themselves with installation and wiring instructions in addition to requirements of all applicable codes, laws, and standards.

Activities including installation, adjustments, putting into service, use, assembly, disassembly, and maintenance are required to be carried out by suitably trained personnel in accordance with applicable code of practice.

If this equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.

In no event will Rockwell Automation, Inc. be responsible or liable for indirect or consequential damages resulting from the use or application of this equipment.

The examples and diagrams in this manual are included solely for illustrative purposes. Because of the many variables and requirements associated with any particular installation, Rockwell Automation, Inc. cannot assume responsibility or liability for actual use based on the examples and diagrams.

No patent liability is assumed by Rockwell Automation, Inc. with respect to use of information, circuits, equipment, or software described in this manual.

Reproduction of the contents of this manual, in whole or in part, without written permission of Rockwell Automation, Inc., is prohibited.

Throughout this manual, when necessary, we use notes to make you aware of safety considerations.



**WARNING:** Identifies information about practices or circumstances that can cause an explosion in a hazardous environment, which may lead to personal injury or death, property damage, or economic loss.

---



**ATTENTION:** Identifies information about practices or circumstances that can lead to personal injury or death, property damage, or economic loss. Attentions help you identify a hazard, avoid a hazard, and recognize the consequence.

---

**IMPORTANT** Identifies information that is critical for successful application and understanding of the product.

---

These labels may also be on or inside the equipment to provide specific precautions.



**SHOCK HAZARD:** Labels may be on or inside the equipment, for example, a drive or motor, to alert people that dangerous voltage may be present.

---



**BURN HAZARD:** Labels may be on or inside the equipment, for example, a drive or motor, to alert people that surfaces may reach dangerous temperatures.

---



**ARC FLASH HAZARD:** Labels may be on or inside the equipment, for example, a motor control center, to alert people to potential Arc Flash. Arc Flash will cause severe injury or death. Wear proper Personal Protective Equipment (PPE). Follow ALL Regulatory requirements for safe work practices and for Personal Protective Equipment (PPE).

---

The following icon may appear in the text of this document.



Identifies information that is useful and can help to make a process easier to do or easier to understand.

	About This Publication .....	5
	Summary of Changes.....	5
	Who Should Use This Manual .....	5
	Purpose of This Manual.....	5
	Additional Resources.....	6
	<b>Chapter 1</b>	
<b>ArmorBlock 16-channel IO-Link Hub</b>	ArmorBlock 16-Channel IO-Link Hubs .....	7
	IO-Link System .....	7
	Before You Begin .....	8
	Module Overview .....	8
	<b>Chapter 2</b>	
<b>Connect and Operate with IO-Link Masters</b>	Operation with IO-Link Masters.....	11
	<b>Chapter 3</b>	
<b>Configure Parameters</b>	Activate or Deactivate Block Communication .....	13
	Restore the IO-Link Hub to Factory Default Settings .....	13
	Configure IO-Link Device Parameters Using Message Instructions ..	13
	About the IO-Link Device Parameter Object .....	13
	Parameters and Identification Information .....	14
	View IO-Link Hub Identity Details .....	14
	Change Identification Information.....	15
	Description of Parameter Data .....	17
	Parameters for Operation Configuration .....	18
	Parameters for Input Filter .....	18
	Parameters for Input Latching.....	19
	Parameters for Input Logic Settings.....	20
	Parameters for Output Fault Values .....	21
	Parameters for Output Fault Delay .....	21
	<b>Chapter 4</b>	
<b>Diagnostic Properties</b>	Device Status .....	23
	Parameters for Device Config.....	24
	Parameters for General Diagnostic Settings.....	24
	Device Status in Detail .....	25
	<b>Chapter 5</b>	
<b>Download and Install IO-Link Device Descriptions</b>	Download the IO-Link Device Description.....	29
	Register an IODD.....	29
	<b>Appendix A</b>	
<b>Configure IO-Link Hub as a Generic IO-Link Device</b>	Input and Output Process Data for 1732IL-IB16M12.....	31
	Input Data .....	31
	Output Data.....	31

	Input and Output Process Data for 1732IL-10X6M12 .....	32
	Input Data .....	32
	Output Data .....	32
	Input and Output Process Data for 1732IL-16CFGM12M12L .....	32
	Input Data .....	32
	Output Data .....	33
	Description of Process Data Terms .....	33
	Configure IO-Link Devices .....	33
	Tag Name Conventions .....	34
	<b>Appendix B</b>	
<b>Interpret Status Indicators</b>	Status Indicator Overview .....	37
	Status Indicator Descriptions .....	38
	<b>Appendix C</b>	
<b>Wire your IO-Link System</b>	Recommended Wiring Configurations .....	39
	<b>Appendix D</b>	
<b>History of Changes</b>		
	<b>Index</b> .....	45

## About This Publication

This manual describes how to use the ArmorBlock® 16-Channel IO-Link hubs.

Make sure that you are familiar with the following:

- Use of a controller in a Logix 5000® control system
- Studio 5000 Logix Designer® environment

---

**IMPORTANT** You must use Studio 5000 Logix Designer, version 20 or later, to configure the ArmorBlock IO-Link hubs.

---

Rockwell Automation recognizes that some of the terms that are currently used in our industry and in this publication are not in alignment with the movement toward inclusive language in technology. We are proactively collaborating with industry peers to find alternatives to such terms and making changes to our products and content. Please excuse the use of such terms in our content while we implement these changes.

## Summary of Changes

This publication contains the following new or updated information. This list includes substantive updates only and is not intended to reflect all changes. Translated versions are not always available for each revision.

Topic	Page
Updated template	throughout
Added inclusive language acknowledgment	5
Improved description of 1732IL-16CFGM12M12L power consumption	8
Added Appendix D - History of Changes	43
Added Index	45

## Who Should Use This Manual

This manual is intended for trained and qualified personnel who are responsible for installing, configuring, and troubleshooting the ArmorBlock 16-Channel IO-Link hubs.

## Purpose of This Manual

This manual provides information and describes the procedures that are used to configure, operate, and troubleshoot the ArmorBlock 16-Channel IO-Link hubs.

## Additional Resources

These documents contain additional information concerning related products from Rockwell Automation.

Resource	Description
ArmorBlock 16-Channel IO-Link Hubs Installation Instructions, publication <a href="#">1732IL-IN001</a>	Describes how to install and wire the ArmorBlock IO-Link hubs.
ArmorBlock I/O Module Selection Guide, publication <a href="#">1732-SG001</a>	Provides specifications, wiring diagrams, and module block diagrams for ArmorBlock I/O blocks, and IO-Link master and hubs.
ArmorBlock I/O 8 Channel IO-Link Master Module User Manual, publication <a href="#">1732E-UM007</a>	Describes how to use the ArmorBlock I/O 8-channel IO-Link Master Module.
POINT I/O 4 Channel IO-Link Master Module User Manual, publication <a href="#">1734-UM020</a>	Describes how to use the POINT I/O™ 4-Channel IO-Link Master Module.
EtherNet/IP Network Devices User Manual, publication <a href="#">ENET-UM006</a>	Describes how to configure and use EtherNet/IP™ devices to communicate on the EtherNet/IP network.
Ethernet Reference Manual, publication <a href="#">ENET-RM002</a>	Describes basic Ethernet concepts, infrastructure components, and infrastructure features.
System Security Design Guidelines Reference Manual, publication <a href="#">SECURE-RM001</a>	Provides guidance on how to conduct security assessments, implement Rockwell Automation products in a secure system, harden the control system, manage user access, and dispose of equipment.
Industrial Components Preventive Maintenance, Enclosures, and Contact Ratings Specifications, publication <a href="#">IC-TD002</a>	Provides a quick reference tool for Allen-Bradley® industrial automation controls and assemblies.
Safety Guidelines for the Application, Installation, and Maintenance of Solid-State Control, publication <a href="#">SGI-1.1</a>	Designed to harmonize with NEMA Standards Publication No. ICS 1.1-1987 and provides general guidelines for the application, installation, and maintenance of solid-state control in the form of individual devices or packaged assemblies incorporating solid-state components.
Industrial Automation Wiring and Grounding Guidelines, publication <a href="#">1770-4.1</a>	Provides general guidelines for installing a Rockwell Automation industrial system.
Product Certifications website <a href="http://rok.auto/certifications">rok.auto/certifications</a> .	Provides declarations of conformity, certificates, and other certification details.

You can view or download publications at [rok.auto/literature](http://rok.auto/literature).



## ArmorBlock 16-channel IO-Link Hub

Topic	Page
ArmorBlock 16-Channel IO-Link Hubs	7
IO-Link System	7
Before You Begin	8
Module Overview	8

### ArmorBlock 16-Channel IO-Link Hubs

The ArmorBlock 16-Channel IO-Link hubs are used with an IO-Link master to add additional I/O into the system. They are suitable for use in machines and installations with moderate I/O concentration.

The ArmorBlock 16-Channel IO-Link hubs are compact and well built for direct field service in tough industrial environments. The fully sealed housing is made of die-cast zinc to help protect electronic components from environmental factors.

There are three IO-Link hubs with different channel configurations available – 16 digital inputs; 10 digital inputs and 6 digital outputs; and 16 configurable digital inputs/outputs.

IO-Link hubs with digital outputs or configured with outputs feature an Output Fault Value function. This function enables you to configure the behavior of each output channel if there are interruptions or loss of communications.

For electrical connection, the widely adopted M12 connector system is used with M12 A-coded connectors for I/O signals and an IO-Link interface.


### IO-Link System

IO-Link technology is a worldwide open-standard protocol that integrates sensors into our Connected Enterprise® by connecting the IO-Link enabled device into an IO-Link master module. You can deliver data from the sensor directly into a control system efficiently. The flexibility of IO-Link capable sensors allows machines to operate more effectively by providing the controller with diagnostics. In addition to product detection, sensors provide detailed and accurate machine health status to improve uptime.

The IO-Link system is a configuration of IO-Link masters, IO-Link hubs, and IO-Link enabled devices, such as sensors, actuators, and valves. The IO-Link master provides a network interface to the controller and controls the communication to the IO-Link enabled devices. The connection between masters, hubs, and devices can be achieved with a standard unshielded connection cable.

You can connect the IO-Link devices directly to the ports of the IO-Link master.

Figure 1 - The IO-Link System Configuration Example



## Before You Begin

Before you use ArmorBlock 16-Channel IO-Link hubs, connect the IO-Link hub to the IO-Link master.

For more information on the installation and connection of the IO-Link hub to the IO-Link master, see the ArmorBlock 16-Channel IO-Link Hubs Installation Instructions, publication [1732IL-IN001](#).

## Module Overview

The ArmorBlock 16-Channel IO-Link hubs receive binary signals from the devices and transfer them to the controller through the IO-Link master.

- 1732IL-IB16M12 has 16 digital inputs.
- 1732IL-10X6M12 has 10 digital inputs and 6 digital outputs.
- 1732IL-16CFGM12M12L has 16 channels that can be configured as either digital inputs or digital outputs.


The ArmorBlock 16-Channel IO-Link hubs draw power from the following power connectors on the respective hubs.

- 1732IL-IB16M12 draws module and sensor power from (L+/-).
- 1732IL-10X6M12 draws module and sensor power from (L+/-), and output power from (2L+/-).
- 1732IL-16CFGM12M12L draws module power from IO-Link connector (L+/-), sensor ( $U_S$ ) and output power ( $U_I$ ) from M12 L-code connector.

See ArmorBlock 16-Channel IO-Link Hubs Installation Instructions, publication [1732IL-IN001](#) for the specific pin out.



Figure 2 - ArmorBlock 16-Channel IO-Link Hubs



<sup>(1)</sup> Functional earth is provided for the grounding of field devices and is internally connected to each Pin 5 of the M12 style A-coded I/O ports.

**Notes:**

## Connect and Operate with IO-Link Masters

Topic	Page
Operation with IO-Link Masters	11

### Operation with IO-Link Masters

The ArmorBlock 16-Channel IO-Link hubs operate with IO-Link masters via the IO-Link connector. The IO-Link hubs feature 8 x M12 connectors that can support up to 16 digital channels.

Each IO-Link hub takes one IO-Link channel from the IO-Link master. For more information on how to use the IO-Link master, see the respective IO-Link master user manual.

If you are using an ArmorBlock IO-Link master, see the ArmorBlock I/O 8 Channel IO-Link Master Module User Manual, publication [1732E-UM007](#).

If you are using a POINT I/O IO-Link Master module, see the POINT I/O 4 Channel IO-Link Master Module User Manual, publication [1734-UM020](#).

**Notes:**

## Configure Parameters

Topic	Page
Activate or Deactivate Block Communication	13
Restore the IO-Link Hub to Factory Default Settings	13
Parameters and Identification Information	14
Description of Parameter Data	17

### Activate or Deactivate Block Communication

IO-Link enables you to transfer all parameter data from the controller as a block. Activate block communication by using the command “ParamDownloadStart”, index 0x02, subindex 0, 3. To deactivate block communication, use the command “ParamDownloadEnd”, index 0x02, subindex 0, 4. For information on how to use a message instruction to get index information, see the ArmorBlock I/O 8 Channel IO-Link Master Module user manual, publication [1732E-UM007](#).

### Restore the IO-Link Hub to Factory Default Settings

You can restore your ArmorBlock IO-Link hub to factory default settings by performing one of the following:

- Activate the IO-Link specified system command “Restore factory settings.” The command requires that 0x0082 is written to index 0x02, subindex 0.
- Set output bit “ConfigRST” to “1”. You can also access the bit under index 0x0040, subindex 3, bit 2.
- From the Diagnostics tab in the IO-Link master Add-on Profile (AOP), click “Restore Factory Settings”.

### Configure IO-Link Device Parameters Using Message Instructions

Use message instructions to the IO-Link Device Parameter Object to read or change configuration parameters for IO-Link devices with IO-Link Device Description (IODD) Basic or Generic integration.

For more information on how to create a message instruction, see the ArmorBlock I/O 8 Channel IO-Link Master Module user manual, publication [1732E-UM007](#).

### About the IO-Link Device Parameter Object

IO-Link device configuration parameters include multiple sets of index/subindex pairs, a length, and a data value that is sent to the IO-Link master through instances of the IO-Link Device Parameter Object. The IO-Link Device Parameter Object provides a mechanism for a CIP™ client to access parameters within an IO-Link device. Within this class, the instance number maps to an IO-Link index value.

The details of each index and subindex depend entirely on the IO-Link device and are described in the IODD XML file for that device.

## Parameters and Identification Information

The following tables show direct parameters, identification information, and device access locks for the ArmorBlock IO-Link hubs. These configuration settings are only available in 1732 (AOP) version 3.1.xx or later, and 1734 AOP version 2.1.xx or later.



Not all indexes can be configured in the AOP. However, you can use CIP message instructions to configure all available indexes.

### View IO-Link Hub Identity Details

In the Studio 5000 Logix Designer application, you can view the identity details of your ArmorBlock IO-Link hub from the **IO-Link > Common** tab.

Figure 3 - Example of Common Tab in Studio 5000 Logix Designer




Table 1 - Direct Parameter 1

Index	Subindex	Parameter	Access	Data Length (Byte)	Data Type	Default Value
0x0000	8	Vendor ID1 (MSB)	RO	1	UINT8	0x0002  0x00012A = 1732IL-1B16M12, 0x00012B = 1732IL-10X6M12, 0x00012C = 1732IL-16CFGM12M12L
	9	Vendor ID2 (LSB)				
	10	Device ID1 (MSB)				
	11	Device ID2				
	12	Device ID3 (LSB)				




Table 2 - Device Access Locks

Index	Subindex	Parameter	Access	Data Length (Byte)	Data Type	Default Value
0x00C	1	Parameters (write) Access (opt.)	RW	1 bit	Boolean	0
	2	Data storage lock				Lock parameter upload 0 = Unlocked (default) 1 = Locked
	3	Local parameterization (opt.)				0
	4	Local user interface (opt.)				

## Change Identification Information

You can change the application-specific tag and view the rest of the identity details for your ArmorBlock IO-Link hub from the **IO-Link > Identification** tab.

Figure 4 - Example of Identification Tab in Studio 5000 Logix Designer



**Table 3 - Identification - 1732IL-IB16M12**

Index	Subindex	Parameter	Access	Data Length (Byte)	Data Type	Default Value
0x0010	0	Vendor Name	R0	64	String	Allen-Bradley
0x0011		Vendor Text				<a href="http://www.ab.com/sensors">www.ab.com/sensors</a> <sup>(1)</sup>
0x0012		Product Name				1732IL-IB16M12
0x0013		Product ID				1732IL-IB16M12 Series A
0x0014		Product Text				IO-Link Hub, 16 Point Digital Input
0x0015		Serial Number	16	SV*****		
0x0016		Hardware Version	64	1.0		
0x0017		Firmware revision		1.011		
0x0018		Application Specific Tag	RW	32		***
0x0019		Electrical Node ID		32		***
0x001A	Location Tag	32		***		

(1) Search for "Sensors" on the IO-Link Smart Devices with IO-Link Technology product page.

**Table 4 - Identification - 1732IL-10X6M12**

Index	Subindex	Parameter	Access	Data Length (Byte)	Data Type	Default Value
0x0010	0	Vendor Name	R0	64	String	Allen-Bradley
0x0011		Vendor Text				<a href="http://www.ab.com/sensors">www.ab.com/sensors</a> <sup>(1)</sup>
0x0012		Product Name				1732IL-10X6M12
0x0013		Product ID				1732IL-10X6M12 Series A
0x0014		Product Text				IO-Link Hub, 10 Point Digital Input, 6 Point Digital Output
0x0015		Serial Number	16	SV*****		
0x0016		Hardware Version	64	1.0		
0x0017		Firmware revision		1.011		
0x0018		Application Specific Tag	RW	32		***
0x0019		Electrical Node ID		32		***
0x001A	Location Tag	32		***		

(1) Search for "Sensors" on the IO-Link Smart Devices with IO-Link Technology product page.


Table 5 - Identification - 1732IL-16CFGM12M12L

Index	Subindex	Parameter	Access	Data Length (Byte)	Data Type	Default Value
0x0010	0	Vendor Name	RO	64	String	Allen-Bradley
0x0011		Vendor Text				<a href="http://www.ab.com/sensors">www.ab.com/sensors</a> <sup>(1)</sup>
0x0012		Product Name				1732IL-16CFGM12M12L
0x0013		Product ID				1732IL-16CFGM12M12L Series A
0x0014		Product Text				IO-Link Hub, 16 Configurable Digital input/output
0x0015		Serial Number				SV*****
0x0016		Hardware Version	64	1.0		
0x0017		Firmware revision	64	1.011		
0x0018		Application Specific Tag	RW	32		***
0x0019		Electrical Node ID		32		***
0x001A	Location Tag	32		***		

(1) Search for "Sensors" on the IO-Link Smart Devices with IO-Link Technology product page.

**Description of Parameter Data** You can view and configure the parameter tags for your ArmorBlock IO-Link hub from the **IO-Link > Parameter** tab.

Figure 5 - Example of Parameter Tab in Studio 5000 Logix Designer



**Table 6 - Device Parameters (Individual)**

Index	Subindex	Parameter	Access	Data Length (Byte)	Data Type	Default Value
0x0040	1..16	Device Config	RW	1	Boolean	0
0x0041		General Diagnostic Settings		1	Boolean	0
0x0043	1..16	Input Filter		16	UINT8	3 ms
0x0044		Input Latching		16	UINT8	Off
0x0045		Input Logic Settings		16	UINT8	Normal
0x0046 <sup>(1)</sup>		Output Fault Value		16	UINT8	Low
0x0047 <sup>(1)</sup>		Output Fault Delay		16	UINT8	80 ms
0x0048	1..16	User Serial Number		16	String	0
0x0060	1	Module Identification ID		1		0

(1) This index does not apply to 1732IL-IB16.

### Parameters for Operation Configuration

These parameters are used to enter information that helps you to identify your module.

Name	R/W	Value	Unit
[ - ] Operation Configuration			
User Serial Number	rw		
Electrical Node ID tag	rw		
Module Identification ID	rw	0	

**Table 7 - Description of Operation Configuration Parameters**

Index	Subindex	Bit Number	Parameter
0x0048	1..16	16 x 0..7	User serial number The value entered here is displayed in index 0x0015 (Serial Number). If there is no value entered here, the production serial number is displayed in 0x0015.
0x0049	1..16	16 x 0..7	Electrical Node ID Tag, ASCII text (Default: 16 x 0x00) Enter descriptions and tags for your device.
0x0060	1	0..6	Module Identification ID Assign numerical values to identify which modules are used or connected. This parameter is outside the data storage range.

### Parameters for Input Filter

This parameter (FilterTime.Chxx) specifies the filter time for the module inputs. Each input can be configured individually.

Name	R/W	Value	Unit
[ - ] Input Filter			
FilterTime.Ch0	rw	3ms	▼
FilterTime.Ch1	rw	3ms	▼
FilterTime.Ch2	rw	3ms	▼
FilterTime.Ch3	rw	3ms	▼
FilterTime.Ch4	rw	3ms	▼
FilterTime.Ch5	rw	3ms	▼
FilterTime.Ch6	rw	3ms	▼

You can configure the filter times for each input channel from the device index 0x0043.

**Table 8 - Description of Index 0x0043**

Index	Subindex	Bit Number	Channel	IO Number	Parameter Value
0x0043	1	0...3	Ch0	I0, C0	0 = Off 1 = 0.5 ms 2 = 1 ms 3 = 2 ms 4 = 3 ms (default)
	2		Ch1	I1, C1	
	3		Ch2	I2, C2	
	4		Ch3	I3, C3	
	5		Ch4	I4, C4	
	6		Ch5	I5, C5	
	7		Ch6	I6, C6	
	8		Ch7	I7, C7	
	9		Ch8	I8, C8	
	10		Ch9	I9, C9	
	11		Ch10	I10, C10	
	12		Ch11	I11, C11	
	13		Ch12	I12, C12	
	14		Ch13	I13, C13	
	15		Ch14	I14, C14	
	16		Ch15	I15, C15	

## Parameters for Input Latching

This parameter (LatchTime.Chxx) specifies the minimum time that the input stays in one value before switching to another. The minimum time is used when for both Input Logic-1 and Input Logic-0 status.

Name	R/W	Value	Unit
[ - ] Input Latching			
LatchTime.Ch0	rw	off	
LatchTime.Ch1	rw	off	
LatchTime.Ch2	rw	off	
LatchTime.Ch3	rw	off	
LatchTime.Ch4	rw	off	
LatchTime.Ch5	rw	off	
LatchTime.Ch6	rw	off	

You can configure the latch time for each input channel from the device index 0x0044.

Table 9 - Description of Index 0x0044

Index	Subindex	Bit Number	Channel	IO Number	Parameter Value
0x0044	1	0...3	Ch0	I0, C0	0 = Off (default) 1 = 0.5 ms 2 = 1 ms 3 = 2 ms 4 = 3 ms
	2		Ch1	I1, C1	
	3		Ch2	I2, C2	
	4		Ch3	I3, C3	
	5		Ch4	I4, C4	
	6		Ch5	I5, C5	
	7		Ch6	I6, C6	
	8		Ch7	I7, C7	
	9		Ch8	I8, C8	
	10		Ch9	I9, C9	
	11		Ch10	I10, C10	
	12		Ch11	I11, C11	
	13		Ch12	I12, C12	
	14		Ch13	I13, C13	
	15		Ch14	I14, C14	
	16		Ch15	I15, C15	

### Parameters for Input Logic Settings

This parameter (Input Logic Settings.Chxx) determines whether the switched input is displayed as NO (normally open) or NC (normally closed).

Name	R/W	Value	Unit
[ - ] Input Logic Settings			
Input Logic Settings.Ch0	rw	NO	
Input Logic Settings.Ch1	rw	NO	
Input Logic Settings.Ch2	rw	NO	
Input Logic Settings.Ch3	rw	NO	
Input Logic Settings.Ch4	rw	NO	
Input Logic Settings.Ch5	rw	NO	
Input Logic Settings.Ch6	rw	NO	

You can configure the logic for each input channel from the device index 0x0045.

Table 10 - Description of Index 0x0045

Index	Subindex	Bit Number	Channel	IO Number	Parameter Value
0x0045	1	0	Ch0	I0, C0	0 = NO (Normally open) (default) 1 = NC (Normally closed)
	2		Ch1	I1, C1	
	3		Ch2	I2, C2	
	4		Ch3	I3, C3	
	5		Ch4	I4, C4	
	6		Ch5	I5, C5	
	7		Ch6	I6, C6	
	8		Ch7	I7, C7	
	9		Ch8	I8, C8	
	10		Ch9	I9, C9	
	11		Ch10	I10, C10	
	12		Ch11	I11, C11	
	13		Ch12	I12, C12	
	14		Ch13	I13, C13	
	15		Ch14	I14, C14	
	16		Ch15	I15, C15	



## Parameters for Output Fault Values

This parameter (Fault Value.Ch $xxx$ ) determines the behavior of the digital outputs in there is a loss of communications. Each channel can be configured individually.

**IMPORTANT** The Fault Value function is available only for 1732IL-10X6M12 and 1732IL-16CFGM12M12L.

Name	R/W	Value	Unit
[ - ] Output Fault Value			
Fault Value.Ch0	rw	Off	
Fault Value.Ch1	rw	Off	
Fault Value.Ch2	rw	Off	
Fault Value.Ch3	rw	Off	
Fault Value.Ch4	rw	Off	
Fault Value.Ch5	rw	Off	
Fault Value.Ch6	rw	Off	

You can configure the value for each output channel from the device index 0x0046.

**Table 11 - Description of Index 0x0046**

Index	Subindex	Bit Number	Channel	IO Number	Parameter Value
0x0046	1	0...1	Ch0	C0	0 = Off (default) 1 = On
	2		Ch1	C1	
	3		Ch2	C2	
	4		Ch3	C3	
	5		Ch4	C4	
	6		Ch5	C5	
	7		Ch6	C6	
	8		Ch7	C7	
	9		Ch8	C8	
	10		Ch9	C9	
	11		Ch10	00, C10	
	12		Ch11	01, C11	
	13		Ch12	02, C12	
	14		Ch13	03, C13	
	15		Ch14	04, C14	
	16		Ch15	05, C15	

## Parameters for Output Fault Delay

This parameter (Fault Delay.Ch $xxx$ ) sets the delay time before an output channel is monitored for possible fault conditions. The delay time starts after a change to the output channel status, and monitoring of the output starts only after the delay time expires. Any fault conditions that occur after this delay are reported as diagnostics. Each channel can be configured individually.

**IMPORTANT** The Fault Delay function is available only for 1732IL-10X6M12 and 1732IL-16CFGM12M12L.

Name	R/W	Value	Unit
[-] Output Fault Delay			
Fault Delay.Ch0	rw	80	ms
Fault Delay.Ch1	rw	80	ms
Fault Delay.Ch2	rw	80	ms
Fault Delay.Ch3	rw	80	ms
Fault Delay.Ch4	rw	80	ms
Fault Delay.Ch5	rw	80	ms
Fault Delay.Ch6	rw	80	ms

You can configure the value for each output channel from the device index 0x0047.

**Table 12 - Description of Index 0x0047**

Index	Subindex	Bit Number	Channel	IO Number	Parameter Value
0x0047	1	0...15	Ch0	C0	0...255 ms (default is 80 ms)
	2		Ch1	C1	
	3		Ch2	C2	
	4		Ch3	C3	
	5		Ch4	C4	
	6		Ch5	C5	
	7		Ch6	C6	
	8		Ch7	C7	
	9		Ch8	C8	
	10		Ch9	C9	
	11		Ch10	00, C10	
	12		Ch11	01, C11	
	13		Ch12	02, C12	
	14		Ch13	03, C13	
	15		Ch14	04, C14	
	16		Ch15	05, C15	

## Diagnostic Properties

Topic	Page
Device Status	23
Device Status in Detail	25

The ArmorBlock IO-Link hubs provide diagnostic messages to identify the status of the device.




Not all indexes can be configured in the AOP. However, you can use CIP message instructions to configure all available indexes.

## Device Status

You can view and configure the diagnostic tags for your ArmorBlock IO-Link hub from the **IO-Link > Diagnosis** tab.

Figure 6 - Example of Diagnosis Tab in Studio 5000 Logix Designer



To restore your ArmorBlock IO-Link hub to factory default settings, click Restore Factory Settings.

Table 13 - Description of Index 0x0024

Index	Subindex	Length	Parameter <sup>(1)</sup>	
			Value	Definition
0x0024	0	Octet	0	Device is operating properly
			1	Maintenance required
			2	Out of specification

Table 13 - Description of Index 0x0024 (Continued)

Index	Subindex	Length	Parameter <sup>(1)</sup>	
			Value	Definition
0x0024	0	Octet	3	Functional check
			4	Failure
			5...255	Reserved

(1) Read-only: Contains the status of the device.

### Parameters for Device Config

You cannot access individual subindexes.

Name	R/W	Value	Unit
[-] Device Config			
Device Config.Digital Output Error Restart Mode	rw	Enable Auto Restart	
Device Config.Factory Reset	rw	Enable Factory Reset	

Table 14 - Description of Index 0x0040

Index	Subindex	Bit Number	Parameter
0x0040	1	0	Reserved: Do not use
	2	1	Digital Output Error Restart Mode <sup>(1)</sup> 0 = Disable, 1 = Enable (default)
	3	2	Factory Reset 0 = Disable, 1 = Enable (default)
	4	3	Reserved: Do not use
	5	4	
	6	5	
	7	6	
	8	7	

(1) This parameter does not apply to 1732IL-1B16M12.

### Parameters for General Diagnostic Settings

You cannot access individual subindexes.

**IMPORTANT** The diagnostic function is available only for 1732IL-10X6M12 and 1732IL-16CFGM12M12L.

Name	R/W	Value	Unit
[-] General Diagnostic Settings			
General Diagnostic Settings.Device Diagnosis	rw	Enable Diagnosis	
General Diagnostic Settings.DO Actuator Supply Voltage Fault	rw	Enable Fault	
General Diagnostic Settings.Actuator Supply Voltage Fault	rw	Enable Fault	

Table 15 - Description of Index 0x0041

Index	Subindex	Bit Number	Diagnostic Parameter
0x0041	1	0	Device Diagnosis (for outputs) 0 = Disable, 1 = Enable (default) Diagnostics for inputs are always enabled.
	2	1	DO Actuator Supply Voltage Fault 0 = Disable, 1 = Enable (default)
	3	2	Actuator Supply Voltage Fault 0 = Disable, 1 = Enable (default)

Table 15 - Description of Index 0x0041 (Continued)

Index	Subindex	Bit Number	Diagnostic Parameter
0x0041	4	3	Reserved: Do not use
	5	4	
	6	5	
	7	6	
	8	7	

Table 16 - Diagnosis Based on 0x0041 Parameter Settings

Actuator Supply Voltage NOK = Supply <5V OK = Supply >18V	DO Actuator Supply Voltage Fault Parameter Value	Actuator Supply Voltage Fault Parameter Value	DO Actuator Supply Voltage Fault Diagnosis	Actuator Supply Voltage Fault Diagnosis
NOK	0	0	Yes <sup>(1)</sup>	Yes
NOK	0	1	Yes <sup>(1)</sup>	No
NOK	1	0	No <sup>(1)</sup>	Yes
NOK	1	1	No <sup>(1)</sup>	No
OK	0	0	Yes <sup>(2)</sup>	Yes
OK	0	1	Yes <sup>(2)</sup>	No
OK	1	0	No <sup>(2)</sup>	Yes
OK	1	1	No <sup>(2)</sup>	No

(1) There must be at least one output set logically.

(2) There must be at least one output set logically, and an overload or short-circuit is detected.

## Device Status in Detail

Table 17 describes the status of the device in detail. These indexes cannot be configured in the AOP, but you can configure them by using CIP message instructions.

Table 17 - Description of Index 0x0025

Index	Subindex	Length	Parameter <sup>(1)</sup>				
			Subindex	Object Name	Data Type	Comment	
0x0025	1...24	Array T	1	Error_Warning_1	3 octets	All octets 0x00: no error/warning Octet 1: Event qualifier <sup>(2)</sup> Octet 2, 3: Event code <sup>(3)</sup>	
			2	Error_Warning_2	3 octets		
			3	Error_Warning_3	3 octets		
			4	Error_Warning_4	3 octets		
			:	:	:		:
			n	Error_Warning_n	3 octets		

(1) Read-only: Contains the detailed status of the device.

(2) See Table 18 for more information about event qualifiers.

(3) See Table 19 for more information about event codes for peripheral errors.

Table 18 - Event Qualifier

Bits	Description	Parameters	
		Value	Definition
b7...b6	Mode	0	Reserved
		1	Event single shot
		2	Event disappears
		3	Event appears

Table 18 - Event Qualifier (Continued)

Bits	Description	Parameters	
		Value	Definition
b5...b4	Type	0	Reserved
		1	Notification
		2	Warning
		3	Error
b3	Source	0	Device (remote)
		1	Master (local)
b2...b0	Instance	0	Unknown
		1...3	Reserved
		4	Application
		5...7	Reserved

Table 19 - Event Codes for Peripheral Errors

Event Code	Type	Device Status	Description <sup>(1)</sup>
0x5111	Warning	2	Low voltage sensor (U <sub>S</sub> )
0x5112 <sup>(2)</sup>	Warning	2	Low voltage actuator (U <sub>AUX</sub> )
0x7710	Error	4	Sensor error (short-circuit)
0x8CA0 <sup>(1)(3)</sup>	Error	4	Sensor error (short-circuit)
0x8CA1 <sup>(1)(2)</sup>	Error	4	Sensor error (short-circuit)
0x8CA2 <sup>(1)(2)</sup>	Error	4	Sensor error (short-circuit)
0x8CA3 <sup>(1)(2)</sup>	Error	4	Sensor error (short-circuit)
0x8CA4 <sup>(1)(2)</sup>	Error	4	Sensor error (short-circuit)
0x8CA5 <sup>(1)(2)</sup>	Error	4	Sensor error (short-circuit)
0x8CA6 <sup>(1)(2)</sup>	Error	4	Sensor error (short-circuit)
0x8CA7 <sup>(1)(2)</sup>	Error	4	Sensor error (short-circuit)
0x8CB0 <sup>(1)(2)</sup>	Error	4	Output error C0
0x8CB1 <sup>(1)(2)</sup>	Error	4	Output error C1
0x8CB2 <sup>(1)(2)</sup>	Error	4	Output error C2
0x8CB3 <sup>(1)(2)</sup>	Error	4	Output error C3
0x8CB4 <sup>(1)(2)</sup>	Error	4	Output error C4
0x8CB5 <sup>(1)(2)</sup>	Error	4	Output error C5
0x8CB6 <sup>(1)(2)</sup>	Error	4	Output error C6
0x8CB7 <sup>(1)(2)</sup>	Error	4	Output error C7
0x8CB8 <sup>(1)(2)</sup>	Error	4	Output error C8
0x8CB9 <sup>(1)(2)</sup>	Error	4	Output error C9
0x8CBA <sup>(1)</sup>	Error	4	Output error C10/00
0x8CBB <sup>(1)</sup>	Error	4	Output error C11/01
0x8CBC <sup>(1)</sup>	Error	4	Output error C12/02
0x8CBD <sup>(1)</sup>	Error	4	Output error C13/03
0x8CBE <sup>(1)</sup>	Error	4	Output error C14/04
0x8CBF <sup>(1)</sup>	Error	4	Output error C15/05

(1) For output errors, Cxx and Oxx indicate the channel/output number.

(2) These event codes do not apply to 1732IL-IB16M12.

(3) These event codes do not apply to 1732IL-10X6M12.



**Table 20 - Error Codes for Access Management**

<b>Error Codes for Access Management</b>	<b>Description</b>
0x8011	Index is not available
0x8012	Subindex is not available
0x8023	Access denied
0x8033	Parameter length overrun
0x8034	Parameter length underrun
0x8035	Function not available

**Notes:**

## Download and Install IO-Link Device Descriptions

Topic	Page
Download the IO-Link Device Description	29

An IO-Link Device Description (IODD) file is a set of multiple files including a file in XML format, which describes all parameters that are associated with the device. The IODD set also includes graphic image files of the device and the vendor logo.

### Download the IO-Link Device Description

You can find the matching device description file for every ArmorBlock IO-Link module from the following locations:

- Product Compatibility and Download Center (PCDC): [rok.auto/pcdc](http://rok.auto/pcdc).
- IO-Link community download area: <https://ioddfinder.io-link.com/>.



**ATTENTION:** We recommend that you download and install the most up-to-date version of the relevant IODD from the PCDC or the community download area.

For more information about the registration and the addition of IODD to the IO-Link channel, see the respective IO-Link Master user manual.

### Register an IODD


Before you proceed with this task, take note that:

- Only IODD files that are based on IO-Link specification v1.0.1 or v1.1 can be registered.
- You need administrator rights for the machine where the AOP is installed to be able to register an IODD file.

To register an IODD file:


1. From the IO-Link tab, in the Channel tree, right-click on the IO-Link channel.
2. Select Register IODD.

The following dialog box appears.



3. Click Register IODD.

The following dialog box appears.



4. Locate the IODD XML file, and then click Open.

The previous dialog box displays with the tree list view of registered IODD files.

5. Click Exit.

## Configure IO-Link Hub as a Generic IO-Link Device

Topic	Page
Input and Output Process Data for 1732IL-IB16M12	31
Input and Output Process Data for 1732IL-IOX6M12	32
Input and Output Process Data for 1732IL-16CFGM12M12L	32
Configure IO-Link Devices	33
Tag Name Conventions	34
Description of Process Data Terms	33

This appendix describes how to assign process data from the controller to the I/O channels of your IO-Link hub. It also shows the process data length and the structure of the data.

You do not need to configure the IO-Link hub as a generic IO-Link device if you register the IODD and use a specific IO-Link hub catalog number. To register the IODD files, see [Register an IODD on page 29](#).



You are not allowed to change the process data length.

### Input and Output Process Data for 1732IL-IB16M12

#### Input Data

The 1732IL-IB16M12 hub provides up to 4 bytes of input data. The input process image is mapped in the first 2 bytes (bytes 0 and 1) as shown in the following table.

**Table 21 - Input Process Data - 1732IL-IB16M12**

	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Byte 0	I14	I12	I10	I8	I6	I4	I2	I0
Byte 1	I15	I13	I11	I9	I7	I5	I3	I1
Byte 2	PortError				ModuleOutputError <sup>(1)</sup>	ModuleInputError	ModuleActuatorPwrLow <sup>(1)</sup>	ModuleSensorPwrLow
Byte 3	UserConfig	Module_ID						

(1) These parameters do not apply to 1732IL-IB16M12.

#### Output Data

The 1732IL-IB16M12 hub also provides up to 4 bytes of output data.

**Table 22 - Output Process Data - 1732IL-IB16M12**

	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Byte 0	—							
Byte 1	—							
Byte 2	—							
Byte 3	ConfigRST	—						

## Input and Output Process Data for 1732IL-10X6M12

### Input Data

The 1732IL-10X6M12 hub provides up to 4 bytes of input data. The input process image is mapped in the first 2 bytes (bytes 0 and 1) as shown in the following table.

**Table 23 - Input Process Data - 1732IL-10X6M12**

	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Byte 0	—			18	16	14	12	10
Byte 1	—			19	17	15	13	11
Byte 2	PortError				ModuleOutputError	ModuleInputError	ModuleActuatorPwrLow	ModuleSensorPwrLow
Byte 3	UserConfig	Module_ID						

### Output Data

The 1732IL-10X6M12 hub also provides up to 4 bytes of output data. The output process image is mapped in the first 2 bytes (bytes 0 and 1) as shown in the following table.

**Table 24 - Output Process Data - 1732IL-10X6M12**

	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Byte 0	04	02	00	—				
Byte 1	05	03	01	—				
Byte 2	—							
Byte 3	ConfigRST	—						

## Input and Output Process Data for 1732IL-16CFGM12M12L

### Input Data

The 1732IL-16CFGM12M12L hub provides up to 4 bytes of input data. The input process image is mapped in the first 2 bytes (bytes 0 and 1) as shown in the following table.

**Table 25 - Input Process Data - 1732IL-16CFGM12M12L**

	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Byte 0	C14	C12	C10	C8	C6	C4	C2	C0
Byte 1	C15	C13	C11	C9	C7	C5	C3	C1
Byte 2	PortError				ModuleOutputError	ModuleInputError	ModuleActuatorPwrLow	ModuleSensorPwrLow
Byte 3	UserConfig	Module_ID						



## Output Data

The 1732IL-16CFGM12M12L hub also provides up to 4 bytes of output data. The output process image is mapped in the first 2 bytes (bytes 0 and 1) as shown in the following table.

**Table 26 - Output Process Data - 1732IL-16CFGM12M12L**

	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Byte 0	C14	C12	C10	C8	C6	C4	C2	C0
Byte 1	C15	C13	C11	C9	C7	C5	C3	C1
Byte 2	—							
Byte 3	ConfigRST	—						

## Description of Process Data Terms

Table 27 lists the definition for terms that are used in the input process data and output process data tables for the ArmorBlock IO-Link hubs.

**Table 27 - Description of Terms in Process Data Tables**


Process Data	Definition
IO...I15	Refers to the status of the input channel.
OO...O4	Refers to the status of the output channel.
CO...C15	Refers to the status of the configurable channel.
ModuleSensorPwrLow	System/sensor power supply voltage is < 18V
ModuleActuatorPwrLow <sup>(1)</sup>	Output power supply voltage is < 18V
ModuleInputError	Sensor error (short-circuit or overload)
ModuleOutputError <sup>(1)</sup>	Output error (short-circuit or overload)
PortError	When ModuleSensorPwrLow is true, the value of PortError is 1 (Byte 2, bits 4...7). Individual port error is not available.
Module_ID	ID byte for identification of a module change. 0 = not used, Module_ID = 1...127
	<b>Possible values</b>
UserConfig	1 Parameters are configured with non-default values.
	0 Parameters are using default values.
ConfigRST	Reset to factory settings for configuration 50 ms after detection of the signal "I".

(1) This parameter does not apply to 1732IL-IB16M12.

## Configure IO-Link Devices


You can configure a generic IO-Link device using Studio 5000 Logix Designer. The following example shows how to configure the 1732IL-IB16M12 as a generic IO-Link device.

- In the channel tree, right-click on the IO-Link channel, and then select Change. Alternatively, click Change on the working pane. The Change Channel Configuration dialog box displays.




- Click the button in the Change Device column for the IO-Link channel.

The Select IO-Link Device dialog box displays.



3. Select Generic Device from the tree and click Create.
4. From the Edit Generic Device Properties dialog box, type the following values in the correct text boxes, and click OK.  
 Vendor ID: 2  
 Device ID: 298  
 Input Length: 4  
 Output Length: 4



## Tag Name Conventions

The module tag names use defined naming conventions. The conventions are as follows:

Tag name examples = IOL:I.Ch3.ModuleSensorPwrLow and IOL:I.Ch3Ch8

- IOL = name of the IO-Link master in your system
- I = tag type

The possible tag types are I (input) and O (output).

- Ch3 = channel number of the IO-Link master
- ModuleSensorPwrLow = tag function
- Ch8 = channel number of the IO-Link hub

In this case, ModuleSensorPwrLow signifies that the sensor power supply voltage is less than 18V. For a list of tag functions available for the IO-Link hub, see [Description of Terms in Process Data Tables on page 33](#).

**Notes:**


## Interpret Status Indicators

Topic	Page
Status Indicator Overview	37
Status Indicator Descriptions	38

### Status Indicator Overview

See [Table 7](#) to identify the location of the status indicators.

Figure 7 - Status Indicators



## Status Indicator Descriptions

[Table 28](#) describes the meaning of colors and flashes produced by the status indicators.

**Table 28 - Status Indicators and Descriptions**

Status Indicator	Color	Description
IO-Link status	Off	Power off.
	Flashing green	IO-Link communication is running.
	Green	Port is starting up (pre-operate).
	Red	Hardware fault.
Sensor power/Module supply status	Off	Power supply is off.
	Green	Power supply is operating normally.
	Red	Power supply is < 18V ±1V.
Output power supply status <sup>(1)</sup>	Off	Power supply is off.
	Green	Power supply is operating normally.
	Red	Power supply is < 18V ±1V.
I/O status (1 status indicator per channel)	Off	The input or output is in the off state.
	Yellow for even channels; White for odd channels	The input or output is in the on state.
	Red	Hardware fault.
Diagnostic status <sup>(1)</sup>	Off	No error message exists.
	Red	Module diagnosis available.

(1) These indicators do not apply to 1732IL-1B16M12.


## Wire the IO-Link System

Topic	Page
Recommended Wiring Configurations	39

### Recommended Wiring Configurations

Figure 8, Figure 9, and Figure 10 show how to connect your IO-Link master to ArmorBlock IO-Link hubs. For more information on the types of cables and receptacles available, see the ArmorBlock I/O Module Selection Guide, publication [1732-SG001](#).

Figure 8 - Example of Wiring from ArmorBlock IO-Link Master to ArmorBlock IO-Link Hub



Pin	Value	Description
1	+24V DC (L+)	Supply voltage from IO-Link master
2	+24V DC (2L+)	Additional supply voltage
3	GND (L-)	Reference potential to L+
4	C/Q (IO-Link)	IO-Link data channel
5	GND (2L-)	Reference potential for additional supply voltage

Pin	Description
1 <sup>(2)</sup>	Sensor source voltage
2	IO-Link, input/output B
3	Return
4	IO-Link, input/output A
5	PE

(1) x represents the length of cable in meters (1, 2, 5, 10).

(2) SSV (Pin 1) of the IO-Link master supports a maximum of 500 mA per channel/1 A per port.

Figure 9 - Example of Wiring from ArmorBlock IO-Link Master to ArmorBlock IO-Link Hub with Additional Power Supply







Figure 10 - Example of Wiring from POINT I/O IO-Link Master to ArmorBlock IO-Link Hub

POINT I/O  
IO-Link master




1734-4IOL

0	CH 0	1	CH 1
2	CH 2	3	CH 3
4	C	5	C
6	V	7	V



Channel	Common	Voltage
0	4	6
1	5	7
2	4	6
3	5	7

ArmorBlock  
IO-Link hub



1732IL-10X6M12

View into connector



Pin	Value	Description
1	+24V DC (L+)	Supply voltage from IO-Link master
2	+24V DC (2L+)	Additional supply voltage
3	GND (L-)	Reference potential to L+
4	C/Q (IO-Link)	IO-Link data channel
5	GND (2L-)	Reference potential for additional supply voltage

**Notes:**

## History of Changes

This appendix contains the new or updated information for each revision of this publication. These lists include substantive updates only and are not intended to reflect all changes. Translated versions are not always available for each revision.

### 1732IL-UM001C-EN-P, September 2019

---

#### Change

Corrected Figure 2 callout for M12 style L-coded power connector.

Added reference to message instructions in publication 1732E-UM007.

Corrected parameter description for Data storage lock in Table 2.

Corrected descriptions in Table 19 - Event Codes for Peripheral Errors.

Correct Status Indicator Overview callouts.

---

### 1732IL-UM001B-EN-P, April 2019

---

#### Change

Added description of features of new IO-Link hubs.

Updated Module Overview with features of new IO-Link hubs.

Updated description of Operation with IO-Link masters.

Added method to restore IO-Link hub to factory settings.

Added section about configuring indexes using CIP messaging.

Updated Parameters and Identification topic with new tables for 1732IL-10X6M12 and 1732IL-16CFGM12M12L.

Grouped indexes 0x0048, 0x0049, and 0x0060 together based on new AOP version.

Updated section Parameters for Input Filter.

Updated section Parameters for Input Latching.

Updated section Parameters for Input Logic Settings.

Added section Parameters for Output Fault Values.

Added section Parameters for Output Fault Delay.

Updated section Device Status.

Moved section Parameters for Device Config and added section Parameters for General Diagnostic Settings to Chapter 4.

Updated table Event Codes for Peripheral Errors.

Updated Appendix A with new topics for 1732IL-10X6M12 and 1732IL-16CFGM12M12L.

Updated tables in Description of Parameter Data Terms with information for 1732IL-10X6M12 and 1732IL-16CFGM12M12L.

Added topic Tag Name Conventions.

Updated table Status Indicators and Description with new information for 1732IL-10X6M12 and 1732IL-16CFGM12M12L.

Added Appendix C, Wire your IO-Link System.

---

**Notes:**

## Numerics

### 1732IL-10X6M12

power 8

### 1732IL-16CFG12M12L

power 8

### 1732IL-IB16M12

power 8

## A

### access

parameters 13

### access lock

device 15

### access management

error code 27

### A-coded

M12 connector 7

### activate

IO-Link system command 13

### actuator

low voltage 26

### additional I/O

add 7

### AOP

Add-on Profile 14

### application event 26

### application specific

tag 15

### assign

process data 31

## B

### basic integration 13

### behavior

configure 7

### block communication 13

## C

### cable

type 39

### cables

types 39

### change

identification information 15, 15 - 17

### channel

configurations 7

### CIP

message instructions 25

### colors

status indicators 38

### communication

block 13

### configuration

diagram 39

parameters 13

### configuration settings 14

### configurations

channel 7

### configure

generic IO-Link device 33

### configure as generic IO-Link device 31 - 33

### configure behavior 7

### configure diagnostic tags 23

### configure parameter tags 17

### connect

IO-Link master 39

### connect directly

IO-Link devices 7

### connect IO-Link hub 39

### Connected Enterprise

sensors 7

### connector

female 39

IO-Link 8

M12 A-coded 9

M12 L-coded 8

M12 L-coded 9

male 39

power 8

### connectors

M12 7

M12 A-coded 7

## D

### deactivate

block communication 13

### description

parameter data 17 - 22

### details

identity 14, 15

### device

access lock 15

description file 29

### device status 23, 25

### devices

IO-Link enabled 7

### diagnosis

parameter settings 25

### diagnostic

tags 23

### diagnostic status indicator 37

### diagnostic tags

configure 23

### die-cast zinc

housing 7

### direct parameter 14

### direct parameters 14

## E

### earth

functional 9

**error**

- output 26
- sensor 26

**error codes**

- access management
  - Access denied 27
  - Function not available 27
  - Index not available 27
  - Parameter length overrun 27
  - Parameter length underrun 27
  - Subindex not available 27

**error event 26****event qualifiers**

- application 26
- error 26
- local master 26
- notification 26
- remote device 26
- reserved 26
- unknown event 26
- warning 26

**F****factory default settings**

- Restore Factory Settings 23

**female**

- connector 39

**fully sealed housing 7****functional earth 9****G****generic integration 13****generic IO-link 31****grounding**

- field devices 9

**H****housing**

- die-cast zinc 7
- fully sealed 7

**hub**

- IO-Link 7, 39

**I****I/O concentration**

- moderate 7

**I/O signals 7****identification**

- 1732IL-10X6M12 16
- 1732IL-16CFGM12M12L 17
- 1732IL-1B16M12 16
- information 14

**identification information 15 - 17**

- change 15, 15 - 17

**identify**

- device status 23

**identity**

- details 15

**index**

- details 14

**index value**

- map 13

**indexes 25****information**

- identification 14

**input process image 31****instance**

- number 13

**instruction**

- message 13

**integration**

- basic 13
- generic 13

**interface**

- IO-Link 7

**IO 7****IODD**

- basic 13
- generic 13
- integration 13
- IO-Link Device Description 13, 29
- register 29
- XML file 14

**IODD file 30****IO-Link**

- channel 11
- connector 8, 11
- device 33
- devices 7
- hub 7, 15, 17, 39
  - catalog number 31
  - identity details 14
  - restore 13
- hubs 7, 8, 11
- index 14
- interface 7
- master 7, 8, 11, 39
- master module 7
- module 29
- open-standard 7
- subindex 14
- system 7
- system command 13
- system configuration 8
- technology 7

**IO-Link channel 11****IO-Link connector 11****IO-Link device**

- parameter object 13

**IO-Link Device Description**

- IODD 13, 29

**IO-Link enabled devices 7****IO-Link hub 11**

- digital outputs 7
- output features
  - configured 7
- restore 13

**IO-Link master 11****IO-Link status indicator 37****L****low voltage**

- actuator 26
- sensor 26

## M

### M12

- A-coded 7, 9
- connector 9
- L-code 8
- L-coded 9

### M12 A-coded connector 7

### M12 connector 7

### M12 L-code

- connector 8

### male

- connector 39

### map

- IO-Link index value 13

### master

- IO-Link 8, 39

### master event 26

### message

- instruction 13

### module location

- remote I/O modules 7, 13, 17, 23, 25

### module tag names 34

### modules

- 1732IL-10X6M12 8
- 1732IL-16CFGM12M12L 8
- 1732IL-1B16M12 8

## N

### names

- module tag 34

### notification event 26

### number

- instance 13

## O

### output error 26

### overrun

- parameter length 27

## P

### parameter

- direct 14

### parameter data

- description 17 - 22
- transfer 13

### parameter length overrun 27

### parameter length underrun 27

### Parameter Object

- IO-Link device 13

### parameter settings diagnosis 25

### Parameter tab

- Studio 5000 Logix Designer 17

### parameter tags

- configure 17
- view 17

### parameters

- access 13
- device config 24
- device configuraton 13
- direct 14
- general diagnostic settings 24
- input filter 18
- input latching 19
- input logic settings 20
- operation cofiguration 18
- output fault delay 21
- output fault values 21
- parameter object 13

### Patchcord 39

### patchcord

- configuration 39

### power

- connector 8

### power supply status indicator 37

### process data

- assign 31
- input 33
- output 33

### process image

- input 31

### Product Compatibility and Download Center

- PCDC 29

## R

### receptacle

- type 39

### receptacles

- types 39

### recommended wiring 39

### register

- I0DD 29 - 30

### register I0DD 29

### remote device event 26

### remote I/O modules 7, 13, 17, 23, 25

### reserved event 26

### restore

- IO-Link hub 13

## S

### sensor

- low voltage 26

### sensor error 26

### sensors

- Connected Enterprise 7

### settings

- configuration 14
- general diagnostic 24

### status

- device 25

### status indicator

- diagnostic 37
- IO-Link 37
- power supply 37

### status indicator colors 38

### status indicators

- identify 37
- interpret 38

**subindex** 24  
    details 14

**system**  
    IO-Link 7

**system command**  
    activate 13

**system configuration**  
    IO-Link 8

## T

**tag**  
    application 15

**terms**  
    input process data 33  
    output process data 33

**transfer**  
    parameter data 13

**type**  
    cable 39  
    receptacle 39

**types of cables** 39

**types of receptacles** 39

## U

**underrun**  
    parameter length 27

**unknown event** 26

## V

**view parameter tags** 17

## W

**warning event** 26

**wire**  
    ArmorBlock IO-Link master 40  
    POINT I/O IO-Link master 41

**wire ArmorBlock IO-Link** 39

**wiring**  
    configurations 39  
    recommended 39

## X

**XML file**  
    IODD 14





# Rockwell Automation Support

Use these resources to access support information.

<b>Technical Support Center</b>	Find help with how-to videos, FAQs, chat, user forums, and product notification updates.	<a href="http://rok.auto/support">rok.auto/support</a>
<b>Knowledgebase</b>	Access Knowledgebase articles.	<a href="http://rok.auto/knowledgebase">rok.auto/knowledgebase</a>
<b>Local Technical Support Phone Numbers</b>	Locate the telephone number for your country.	<a href="http://rok.auto/phonesupport">rok.auto/phonesupport</a>
<b>Literature Library</b>	Find installation instructions, manuals, brochures, and technical data publications.	<a href="http://rok.auto/literature">rok.auto/literature</a>
<b>Product Compatibility and Download Center (PCDC)</b>	Download firmware, associated files (such as AOP, EDS, and DTM), and access product release notes.	<a href="http://rok.auto/pcdc">rok.auto/pcdc</a>

## Documentation Feedback

Your comments help us serve your documentation needs better. If you have any suggestions on how to improve our content, complete the form at [rok.auto/docfeedback](http://rok.auto/docfeedback).

## Waste Electrical and Electronic Equipment (WEEE)



At the end of life, this equipment should be collected separately from any unsorted municipal waste.





Rockwell Automation maintains current product environmental compliance information on its website at [rok.auto/pec](http://rok.auto/pec).

Allen-Bradley, ArmorBlock, Connected Enterprise, ControlLogix, expanding human possibility, FactoryTalk, Logix 5000, POINT I/O, Rockwell Automation, Stratix, Studio 5000 Logix Designer, and TechConnect are trademarks of Rockwell Automation, Inc.

CIP and EtherNet/IP are trademarks of ODVA, Inc.

Trademarks not belonging to Rockwell Automation are property of their respective companies.

Rockwell Otomasyon Ticaret A.Ş. Kar Plaza İş Merkezi E Blok Kat:6 34752, İçerenköy, İstanbul, Tel: +90 (216) 5698400 EEE Yönetmeliğine Uygundur

Connect with us.    

**rockwellautomation.com** — expanding **human possibility**<sup>®</sup>

AMERICAS: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444

EUROPE/MIDDLE EAST/AFRICA: Rockwell Automation NV, Pegasus Park, De Kleetlaan 12a, 1831 Diegem, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640

ASIA PACIFIC: Rockwell Automation, Level 14, Core F, Cyberport 3, 100 Cyberport Road, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846

Publication 1732IL-UM001D-EN-P - June 2022

Supersedes Publication 1732IL-UM001C-EN-P - September 2019

Copyright © 2022 Rockwell Automation, Inc. All rights reserved.