




Program Keypad Module or Ready/Fault Panel




(Cat 160-P1 or 160-B1)



ATTENTION: To prevent electrical shock, disconnect from power source before installing or servicing.

Removal



Installation

