


Common DC Input Power Connection Instructions

This PowerFlex 750-Series, Frame 5, 600V Common DC Input drive requires a snubber connection on the +DC Power Terminal in addition to the positive input power wire.

The illustrations below show how to correctly stack the customer supplied power wire and the factory installed snubber wire.



ATTENTION: Risk of equipment damage exists if the snubber wire and the input power wire are not installed in the sequence shown. Be sure the snubber wire is positioned on top of the input wire lug to avoid overheating the connection.



www.rockwellautomation.com

Power, Control and Information Solutions Headquarters

Americas: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444

Europe/Middle East/Africa: Rockwell Automation, Vorstlaan/Boulevard du Souverain 36, 1170 Brussels, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640

Asia Pacific: Rockwell Automation, Level 14, Core F, Cyberport 3, 100 Cyberport Road, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846