






**Installation Instructions**  
**Installationsanleitung**  
**Installation**  
**Installazione**  
**Instalación**  
**Instructies**  
**Instalação**


**PowerFlex 70 Input RFI Filters**  
**PowerFlex 70 HF-EingangsfILTER**  
**PowerFlex 70 Filtres d'entrée RFI**  
**PowerFlex 70 Filtro di Ingresso controle radiofrequenze**  
**PowerFlex 70 Filtros de entrada RFI**  
**PowerFlex 70 Input RFI Filters**  
**PowerFlex 70 Filtros RFI de Entrada**



4



⚠ 3.16 – 3.62 N·m  
(28 – 32 lb.-in.)  
M5 x 0.8 x 12 mm LG



Not Supplied  
Nicht geliefert  
Non fourni  
Non fornito  
No Suministrado  
Niet meegeleverd  
Não fornecido

[www.abpowerflex.com](http://www.abpowerflex.com)



[www.rockwellautomation.com](http://www.rockwellautomation.com)

**Power, Control and Information Solutions Headquarters**

Americas: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444  
Europe/Middle East/Africa: Rockwell Automation, Vorstlaan/Boulevard du Souverain 36, 1170 Brussels, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640  
Asia Pacific: Rockwell Automation, Level 14, Core F, Cyberport 3, 100 Cyberport Road, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846

Publication 20A-IN002C-MU-P – February 2002

