

# SLC 5/03, SLC 5/04, and SLC 5/05 Processors Operating System Series C, FRN 10

## **Purpose of This Document**

Read this document before using SLC 5/03 (OS302), SLC 5/04 (OS401), and SLC 5/05 (OS501) Series C, FRN 10 operating system firmware. Keep this document with your SLC 500 Instruction Set Reference Manual, publication 1747-RM001.

This document directs you to information on the series C, FRN 10 features.

## **New Features**

For information on the following features, refer to the SLC 500 Instruction Set Reference Manual, publication 1747-RM001. To view and download a pdf, go to Literature Library at http://www.literature.rockwellautomation.com. To order a printed copy, contact you local Allen-Bradley Distributor or Rockwell Automation sales office.

The new features include:

- SLC 5/05 DHCP capability
- SLC 5/05 EtherNet/IP Explicit Message (EEM) instruction
- DeviceNet Explicit Message (DEM) instruction
- ControlNet Explicit Message (CEM) instruction
- Read Program Checksum (RPC) instruction
- Secure processor via RSAssetSecurity

RSLogix 500 programming software, version 7.10 or higher, is required to configure and program these new features.

# **Rockwell Automation Support**

Rockwell Automation provides technical information on the web to assist you in using its products. At http://support.rockwellautomation.com, you can find technical manuals, a knowledge base of FAQs, technical and application notes, sample code and links to software service packs, and a MySupport feature that you can customize to make the best use of these tools.

For an additional level of technical phone support for installation, configuration and troubleshooting, we offer TechConnect Support programs. For more information, contact your local distributor or Rockwell Automation representative, or visit <a href="http://support.rockwellautomation.com">http://support.rockwellautomation.com</a>.

#### Installation Assistance

If you experience a problem with a hardware module within the first 24 hours of installation, please review the information that's contained in this manual. You can also contact a special Customer Support number for initial help in getting your module up and running:

United States	1.440.646.3223 Monday — Friday, 8am — 5pm EST
Outside United States	Please contact your local Rockwell Automation representative for any technical support issues.

### **New Product Satisfaction Return**

Rockwell tests all of its products to ensure that they are fully operational when shipped from the manufacturing facility. However, if your product is not functioning and needs to be returned:

United States	Contact your distributor. You must provide a Customer Support case number (see phone number above to obtain one) to your distributor in order to complete the return process.
Outside United States	Please contact your local Rockwell Automation representative for return procedure.

Allen-Bradley, RSLogix 500, RSAssetSecurity, SLC, and SLC 500 are trademarks of Rockwell Automation, Inc. Trademarks not belonging to Rockwell Automation are property of their respective companies.

#### www.rockwellautomation.com

#### Power, Control and Information Solutions Headquarters

Americas Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414,382,2000, Fax: (1) 414,382,4444
Europe/Middle East/Africa: Rockwell Automation, Vorstlaan/Boulevard du Souverain 36, 1170 Brussels, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640
Asia Pacific Rockwell Automation, Level 14, Core F, Cyberport 3, 100 cyberport Road, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846